## ETSI TS 138 413 V15.8.0 (2020-07)



5G; NG-RAN; NG Application Protocol (NGAP) (3GPP TS 38.413 version 15.8.0 Release 15)



# Reference RTS/TSGR-0338413vf80 Keywords 5G

#### **ETSI**

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° 7803/88

#### Important notice

The present document can be downloaded from: <u>http://www.etsi.org/standards-search</u>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at <a href="https://www.etsi.org/deliver">www.etsi.org/deliver</a>.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<a href="https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx">https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx</a>

If you find errors in the present document, please send your comment to one of the following services: https://portal.etsi.org/People/CommitteeSupportStaff.aspx

#### **Copyright Notification**

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2020.

All rights reserved.

**DECT™**, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

oneM2M<sup>™</sup> logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners.

GSM® and the GSM logo are trademarks registered and owned by the GSM Association.

## Intellectual Property Rights

#### **Essential patents**

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (https://ipr.etsi.org/).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

#### **Trademarks**

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

## **Legal Notice**

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under http://webapp.etsi.org/key/queryform.asp.

## Modal verbs terminology

In the present document "shall", "shall not", "should", "should not", "may", "need not", "will", "will not", "can" and "cannot" are to be interpreted as described in clause 3.2 of the <u>ETSI Drafting Rules</u> (Verbal forms for the expression of provisions).

"must" and "must not" are NOT allowed in ETSI deliverables except when used in direct citation.

## Contents

Intell	lectual Property Rights	2
Legal	l Notice	2
Moda	al verbs terminology	2
Forev	word	13
1	Scope	14
2	References	14
3	Definitions and abbreviations.	15
3.1	Definitions	
3.2	Abbreviations	16
4	General	
4.1	Procedure Specification Principles	
4.2	Forwards and Backwards Compatibility	
4.3	Specification Notations	
5	NGAP Services	17
6	Services Expected from Signalling Transport	17
7	Functions of NGAP	18
8	NGAP Procedures	
8.1	List of NGAP Elementary Procedures	18
8.2	PDU Session Management Procedures	
8.2.1	PDU Session Resource Setup	
8.2.1.1		
8.2.1.2	1	
8.2.1.3		
8.2.1.4		
8.2.2		
8.2.2.1		
8.2.2.2	1	
8.2.2.3 8.2.2.4		
8.2.3 8.2.3.1	·	
8.2.3.1		
8.2.3.3	<u>*</u>	
8.2.3.4	<u>-</u>	
8.2.4		
8.2.4.1	•	
8.2.4.2		
8.2.4.3	1	
8.2.5		
8.2.5.		
8.2.5.2	2 Successful Operation	28
8.2.5.3	3 Unsuccessful Operation	29
8.2.5.4	4 Abnormal Conditions	29
8.3	UE Context Management Procedures	
8.3.1	Initial Context Setup	
8.3.1.1		
8.3.1.2	I .	
8.3.1.3	ı	
8.3.1.4		
8.3.2	1 '	
8.3.2.	1 General	32

8.3.2.2	Successful Operation	
8.3.2.3	Abnormal Conditions	
8.3.3	UE Context Release (AMF initiated)	
8.3.3.1	General	
8.3.3.2	Successful Operation	33
8.3.3.3	Unsuccessful Operation	34
8.3.3.4	Abnormal Conditions	34
8.3.4	UE Context Modification	34
8.3.4.1	General	34
8.3.4.2	Successful Operation	34
8.3.4.3	Unsuccessful Operation	
8.3.4.4	Abnormal Conditions	
8.3.5	RRC Inactive Transition Report	
8.3.5.1	General	
8.3.5.2	Successful Operation	
8.3.5.3	Abnormal Conditions	
8.4	UE Mobility Management Procedures	
8.4.1	Handover Preparation	
8.4.1.1	General	
8.4.1.2	Successful Operation	
8.4.1.3	Unsuccessful Operation	
8.4.1.4	Abnormal Conditions	
8.4.2	Handover Resource Allocation	
8.4.2.1	General	
8.4.2.2	Successful Operation	
8.4.2.3	Unsuccessful Operation	
8.4.2.4	Abnormal Conditions	
8.4.3	Handover Notification	
8.4.3.1	General	
8.4.3.1	Successful Operation.	
8.4.3.2	Abnormal Conditions	
8.4.3.3	Path Switch Request	
8.4.4.1		
8.4.4.2	General Suppose ful Operation	
8.4.4.3	Successful Operation	
	Unsuccessful Operation	
8.4.4.4	Abnormal Conditions	
8.4.5	Handover Cancellation	
8.4.5.1	General	
8.4.5.2	Successful Operation	46
8.4.5.3	Unsuccessful Operation	
8.4.5.4	Abnormal Conditions	
8.4.6	Uplink RAN Status Transfer	
8.4.6.1	General	
8.4.6.2	Successful Operation	
8.4.6.3	Abnormal Conditions	
8.4.7	Downlink RAN Status Transfer	
8.4.7.1	General	
8.4.7.2	Successful Operation	
8.4.7.3	Abnormal Conditions	
8.5	Paging Procedures	
8.5.1	Paging	
8.5.1.1	General	
8.5.1.2	Successful Operation	
8.5.1.3	Abnormal Conditions	
8.6	Transport of NAS Messages Procedures	48
8.6.1	Initial UE Message	
8.6.1.1	General	48
8.6.1.2	Successful Operation	49
8.6.1.3	Abnormal Conditions	
8.6.2	Downlink NAS Transport	49
8.6.2.1	General	49
8.6.2.2	Successful Operation	

8.6.2.3	Abnormal Conditions	
8.6.3	Uplink NAS Transport	51
8.6.3.1	General	
8.6.3.2	Successful Operation	51
8.6.3.3	Abnormal Conditions	51
8.6.4	NAS Non Delivery Indication	51
8.6.4.1	General	51
8.6.4.2	Successful Operation	51
8.6.4.3	Abnormal Conditions	
8.6.5	Reroute NAS Request	
8.6.5.1	General	
8.6.5.2	Successful Operation	
8.6.5.3	Abnormal Conditions	
8.7	Interface Management Procedures	
8.7.1	NG Setup	
8.7.1.1	General	
8.7.1.2	Successful Operation	
8.7.1.3	Unsuccessful Operation	
8.7.1.4	Abnormal Conditions	
8.7.2	RAN Configuration Update	
8.7.2.1	General	
8.7.2.2	Successful Operation	
8.7.2.3	Unsuccessful Operation	
8.7.2.4	Abnormal Conditions	
8.7.3	AMF Configuration Update	
8.7.3.1	General	
8.7.3.2	Successful Operation	
8.7.3.3	Unsuccessful Operation	
8.7.3.4	Abnormal Conditions	
8.7.4	NG Reset	
8.7.4.1	General	
8.7.4.2	Successful Operation	
8.7.4.2.1	NG Reset initiated by the AMF	
8.7.4.2.2	NG Reset initiated by the NG-RAN node	
8.7.4.3	Unsuccessful Operation	
8.7.4.4	Abnormal Conditions	
8.7.4.4.1	Abnormal Condition at the 5GC	
8.7.4.4.2	Abnormal Condition at the NG-RAN	
8.7.4.4.3	Crossing of NG RESET Messages	
8.7.5	Error Indication	
8.7.5.1	General	
8.7.5.2	Successful Operation	
8.7.5.3	Abnormal Conditions	
8.7.5.3 8.7.6	AMF Status Indication	
8.7.6.1		
8.7.6.2	General	
8.7.6.3	Abnormal Conditions	
8.7.0.3 8.7.7		
8.7.7 8.7.7.1	Overload Start	
8.7.7.1 8.7.7.2	General Suggestion	
	Successful Operation	
8.7.7.3	Abnormal Conditions	
8.7.8	Overload Stop	
8.7.8.1	General Sycasosful Operation	
8.7.8.2	Successful Operation	
8.7.8.3	Abnormal Conditions	
8.8	Configuration Transfer Procedures	
8.8.1	Uplink RAN Configuration Transfer	
8.8.1.1	General	
8.8.1.2	Successful Operation	
8.8.1.3	Abnormal Conditions	
8.8.2	Downlink RAN Configuration Transfer	
8.8.2.1	General	63

8.8.2.2	Successful Operation	63
8.8.2.3	Abnormal Conditions	64
8.9	Warning Message Transmission Procedures	64
8.9.1	Write-Replace Warning	64
8.9.1.1	General	64
8.9.1.2	Successful Operation	64
8.9.1.3	Unsuccessful Operation	65
8.9.1.4	Abnormal Conditions	65
8.9.2	PWS Cancel	66
8.9.2.1	General	66
8.9.2.2	Successful Operation	
8.9.2.3	Unsuccessful Operation	
8.9.2.4	Abnormal Conditions	
8.9.3	PWS Restart Indication.	
8.9.3.1	General	
8.9.3.2	Successful Operation	
8.9.3.3	Abnormal Conditions	
8.9.4	PWS Failure Indication	
8.9.4.1	General	
8.9.4.2	Successful Operation	
8.9.4.3	Abnormal Conditions	
8.10	NRPPa Transport Procedures	
8.10.1	General General	
8.10.2	Successful Operations	
8.10.2.1	DOWNLINK UE ASSOCIATED NRPPA TRANSPORT	
8.10.2.1	UPLINK UE ASSOCIATED NRPPA TRANSPORTUPLINK UE ASSOCIATED NRPPA TRANSPORT	
8.10.2.2	DOWNLINK NON UE ASSOCIATED NRPPA TRANSPORT	
	UPLINK NON UE ASSOCIATED NRPPA TRANSPORT	
8.10.2.4		
8.10.3	Unsuccessful Operations	
8.10.4	Abnormal Conditions	
8.11	Trace Procedures	
8.11.1	Trace Start	
8.11.1.1	General	
8.11.1.2	Successful Operation	
8.11.1.3	Abnormal Conditions	
8.11.2	Trace Failure Indication	
8.11.2.1	General	
8.11.2.2	Successful Operation	
8.11.2.3	Abnormal Conditions	
8.11.3	Deactivate Trace	
8.11.3.1	General	
8.11.3.2	Successful Operation	
8.11.3.3	Abnormal Conditions	
8.11.4	Cell Traffic Trace	
8.11.4.1	General	
8.11.4.2	Successful Operation	
8.11.4.3	Abnormal Conditions	
8.12	Location Reporting Procedures	
8.12.1	Location Reporting Control	
8.12.1.1	General	72
8.12.1.2	Successful Operation	72
8.12.1.3	Abnormal Conditions	73
8.12.2	Location Reporting Failure Indication	73
8.12.2.1	General	73
8.12.2.2	Successful Operation	73
8.12.2.3	Abnormal Conditions	
8.12.3	Location Report	
8.12.3.1	General	
8.12.3.2	Successful Operation	
8.12.3.3	Abnormal Conditions	
8.13	UE TNLA Binding Procedures	
8.13.1	UE TNLA Binding Release	

8.13.1.1	General	74
8.13.1.2	Successful Operation	74
8.13.1.3		
8.14	UE Radio Capability Management Procedures	74
8.14.1	UE Radio Capability Info Indication	
8.14.1.1		
8.14.1.2	- I	75
8.14.1.3		
8.14.2	UE Radio Capability Check	75
8.14.2.1		
8.14.2.2		75
8.14.2.3	1	
8.14.2.4		
8.15	Data Usage Reporting Procedures	
8.15.1	Secondary RAT Data Usage Report	76
8.15.1.1		
8.15.1.2	1	
8.15.1.3	Abnormal Conditions	76
9 I	Elements for NGAP Communication	77
9.0	General	
9.1	Tabular Format Contents	
9.1.1	Presence	
9.1.2	Criticality	
9.1.3	Range	
9.1.4	Assigned Criticality	
9.2	Message Functional Definition and Content	
9.2.1	PDU Session Management Messages	
9.2.1.1	PDU SESSION RESOURCE SETUP REQUEST	
9.2.1.2	PDU SESSION RESOURCE SETUP RESPONSE	
9.2.1.3	PDU SESSION RESOURCE RELEASE COMMAND	79
9.2.1.4	PDU SESSION RESOURCE RELEASE RESPONSE	
9.2.1.5	PDU SESSION RESOURCE MODIFY REQUEST	
9.2.1.6	PDU SESSION RESOURCE MODIFY RESPONSE	
9.2.1.7	PDU SESSION RESOURCE NOTIFY	82
9.2.1.8	PDU SESSION RESOURCE MODIFY INDICATION	83
9.2.1.9	PDU SESSION RESOURCE MODIFY CONFIRM	84
9.2.2	UE Context Management Messages	84
9.2.2.1	INITIAL CONTEXT SETUP REQUEST	84
9.2.2.2	INITIAL CONTEXT SETUP RESPONSE	86
9.2.2.3	INITIAL CONTEXT SETUP FAILURE	
9.2.2.4	UE CONTEXT RELEASE REQUEST	
9.2.2.5	UE CONTEXT RELEASE COMMAND	87
9.2.2.6	UE CONTEXT RELEASE COMPLETE	
9.2.2.7	UE CONTEXT MODIFICATION REQUEST	
9.2.2.8	UE CONTEXT MODIFICATION RESPONSE	
9.2.2.9	UE CONTEXT MODIFICATION FAILURE	
9.2.2.10		
9.2.3	UE Mobility Management Messages	
9.2.3.1	HANDOVER REQUIRED	
9.2.3.2	HANDOVER COMMAND	
9.2.3.3	HANDOVER PREPARATION FAILURE	
9.2.3.4	HANDOVER REQUEST	92
9.2.3.5	HANDOVER REQUEST ACKNOWLEDGE	
9.2.3.6	HANDOVER FAILURE	
9.2.3.7	HANDOVER NOTIFY	
9.2.3.8	PATH SWITCH REQUEST	
9.2.3.9	PATH SWITCH REQUEST ACKNOWLEDGE	
9.2.3.10		
9.2.3.11		
9.2.3.12		
9.2.3.13	B UPLINK RAN STATUS TRANSFER	98

9.2.3.14	DOWNLINK RAN STATUS TRANSFER	
9.2.4	Paging Messages	98
9.2.4.1	PAGING	
9.2.5	NAS Transport Messages	99
9.2.5.1	INITIAL UE MESSAGE	
9.2.5.2	DOWNLINK NAS TRANSPORT	
9.2.5.3	UPLINK NAS TRANSPORT	
9.2.5.4	NAS NON DELIVERY INDICATION	100
9.2.5.5	REROUTE NAS REQUEST	100
9.2.6	Interface Management Messages	100
9.2.6.1	NG SETUP REQUEST	100
9.2.6.2	NG SETUP RESPONSE	101
9.2.6.3	NG SETUP FAILURE	
9.2.6.4	RAN CONFIGURATION UPDATE	102
9.2.6.5	RAN CONFIGURATION UPDATE ACKNOWLEDGE	103
9.2.6.6	RAN CONFIGURATION UPDATE FAILURE	103
9.2.6.7	AMF CONFIGURATION UPDATE	103
9.2.6.8	AMF CONFIGURATION UPDATE ACKNOWLEDGE	105
9.2.6.9	AMF CONFIGURATION UPDATE FAILURE	
9.2.6.10	AMF STATUS INDICATION	105
9.2.6.11	NG RESET	106
9.2.6.12	NG RESET ACKNOWLEDGE	106
9.2.6.13	ERROR INDICATION	106
9.2.6.14	OVERLOAD START	107
9.2.6.15	OVERLOAD STOP	107
9.2.7	Configuration Transfer Messages	107
9.2.7.1	UPLINK RAN CONFIGURATION TRANSFER	107
9.2.7.2	DOWNLINK RAN CONFIGURATION TRANSFER	108
9.2.8	Warning Message Transmission Messages	108
9.2.8.1	WRITE-REPLACE WARNING REQUEST	
9.2.8.2	WRITE-REPLACE WARNING RESPONSE	
9.2.8.3	PWS CANCEL REQUEST	109
9.2.8.4	PWS CANCEL RESPONSE	109
9.2.8.5	PWS RESTART INDICATION	109
9.2.8.6	PWS FAILURE INDICATION	110
9.2.9	NRPPa Transport Messages	111
9.2.9.1	DOWNLINK UE ASSOCIATED NRPPA TRANSPORT	
9.2.9.2	UPLINK UE ASSOCIATED NRPPA TRANSPORT	111
9.2.9.3	DOWNLINK NON UE ASSOCIATED NRPPA TRANSPORT	111
9.2.9.4	UPLINK NON UE ASSOCIATED NRPPA TRANSPORT	111
9.2.10	Trace Messages	
9.2.10.1	TRACE START	
9.2.10.2	TRACE FAILURE INDICATION	112
9.2.10.3	DEACTIVATE TRACE	
9.2.10.4	CELL TRAFFIC TRACE	112
9.2.11	Location Reporting Messages	113
9.2.11.1	LOCATION REPORTING CONTROL	113
9.2.11.2	LOCATION REPORTING FAILURE INDICATION	113
9.2.11.3	LOCATION REPORT	113
9.2.12	UE TNLA Binding Messages	114
9.2.12.1	UE TNLA BINDING RELEASE REQUEST	114
9.2.13	UE Radio Capability Management Messages	114
9.2.13.1	UE RADIO CAPABILITY INFO INDICATION	
9.2.13.2	UE RADIO CAPABILITY CHECK REQUEST	
9.2.13.3	UE RADIO CAPABILITY CHECK RESPONSE	
9.2.14	Data Usage Reporting Messages	
9.2.14.1	SECONDARY RAT DATA USAGE REPORT	
9.3	Information Element Definitions	
9.3.1	Radio Network Layer Related IEs	
9.3.1.1	Message Type	
9.3.1.2	Cause	
9.3.1.3	Criticality Diagnostics	

9.3.1.4	Bit Rate	121
9.3.1.5	Global RAN Node ID	
9.3.1.6	Global gNB ID	
9.3.1.7	NR CGI	
9.3.1.8	Global ng-eNB ID	
9.3.1.9	E-UTRA CGI	
9.3.1.10	GBR QoS Flow Information	
9.3.1.11	Void	
9.3.1.12	QoS Flow Level QoS Parameters	
9.3.1.13	QoS Flow List with Cause	
9.3.1.14	Trace Activation.	
9.3.1.15	Core Network Assistance Information for RRC INACTIVE	
9.3.1.16 9.3.1.17	User Location Information	
	Slice Support List	
9.3.1.18 9.3.1.19	Dynamic 5QI Descriptor	
9.3.1.19	Source to Target Transparent Container	
9.3.1.20	Target to Source Transparent Container	
9.3.1.21	Handover Type	
9.3.1.23	MICO Mode Indication	
9.3.1.24	S-NSSAI	
9.3.1.25	Target ID	
9.3.1.26	Emergency Fallback Indicator	
9.3.1.27	Security Indication	
9.3.1.28	Non Dynamic 5QI Descriptor	
9.3.1.29	Source NG-RAN Node to Target NG-RAN Node Transparent Container	
9.3.1.30	Target NG-RAN Node to Source NG-RAN Node Transparent Container	
9.3.1.31	Allowed NSSAI	
9.3.1.32	Relative AMF Capacity	
9.3.1.33	DL Forwarding	133
9.3.1.34	DRBs to QoS Flows Mapping List	133
9.3.1.35	Message Identifier	134
9.3.1.36	Serial Number	
9.3.1.37	Warning Area List	
9.3.1.38	Number of Broadcasts Requested	
9.3.1.39	Warning Type	
9.3.1.40	Void	
9.3.1.41	Data Coding Scheme	
9.3.1.42	Warning Message Contents	
9.3.1.43	Broadcast Completed Area List	
9.3.1.44	Broadcast Cancelled Area List	
9.3.1.45	Number of Broadcasts	
9.3.1.46	Concurrent Warning Message Indicator	
9.3.1.47	Cancel-All Warning Messages Indicator	
9.3.1.48	Emergency Area ID.	
9.3.1.49	Repetition Period	
9.3.1.50	PDU Session ID	
9.3.1.51 9.3.1.52	QoS Flow Identifier	
9.3.1.52	PDU Session Type DRB ID	
9.3.1.54	Masked IMEISV	
9.3.1.55	New Security Context Indicator	
9.3.1.56	Time to Wait	
9.3.1.57	Global N3IWF ID	
9.3.1.58	UE Aggregate Maximum Bit Rate	
9.3.1.59	Security Result	
9.3.1.60	User Plane Security Information	
9.3.1.61	Index to RAT/Frequency Selection Priority	
9.3.1.62	Data Forwarding Accepted	
9.3.1.63	Data Forwarding Not Possible	
9.3.1.64	Direct Forwarding Path Availability	
9.3.1.65	Location Reporting Request Type	

9.3.1.66	Area of Interest	
9.3.1.67	UE Presence in Area of Interest List	143
9.3.1.68	UE Radio Capability for Paging	143
9.3.1.69	Assistance Data for Paging	
9.3.1.70	Assistance Data for Recommended Cells	144
9.3.1.71	Recommended Cells for Paging	144
9.3.1.72	Paging Attempt Information	144
9.3.1.73	NG-RAN CGI	145
9.3.1.74	UE Radio Capability	
9.3.1.75	Time Stamp	
9.3.1.76	Location Reporting Reference ID	
9.3.1.77	Data Forwarding Response DRB List	
9.3.1.78	Paging Priority	
9.3.1.79	Packet Loss Rate	
9.3.1.80	Packet Delay Budget	
9.3.1.81	Packet Error Rate	
9.3.1.82	Averaging Window	
9.3.1.83	Maximum Data Burst Volume	
9.3.1.84	Priority Level	
9.3.1.85	Mobility Restriction List	
9.3.1.86	UE Security Capabilities	
9.3.1.87	Security Key	
9.3.1.88	Security Context	
9.3.1.89	IMS Voice Support Indicator	
9.3.1.90	Paging DRX	
9.3.1.90	RRC Inactive Transition Report Request	
9.3.1.91	RRC State	
9.3.1.93	Expected UE Behaviour	
9.3.1.94	Expected UE Activity Behaviour	
9.3.1.95	UE History Information	
9.3.1.96	Last Visited Cell Information	
9.3.1.97	Last Visited NG-RAN Cell Information	
9.3.1.98	Cell Type	
9.3.1.99	Associated QoS Flow List	
9.3.1.100	Information on Recommended Cells and RAN Nodes for Paging	
9.3.1.101	Recommended RAN Nodes for Paging	
9.3.1.102	PDU Session Aggregate Maximum Bit Rate	
9.3.1.103	Maximum Integrity Protected Data Rate	
9.3.1.104	Overload Response	
9.3.1.105	Overload Action	
9.3.1.106	Traffic Load Reduction Indication	
9.3.1.107	Slice Overload List	
9.3.1.108	RAN Status Transfer Transparent Container	
9.3.1.109	COUNT Value for PDCP SN Length 12	
9.3.1.110	COUNT Value for PDCP SN Length 18	
9.3.1.111	RRC Establishment Cause	
9.3.1.112	Warning Area Coordinates	160
9.3.1.113	Network Instance	
9.3.1.114	Secondary RAT Usage Information	161
9.3.1.115	Volume Timed Report List	161
9.3.1.116	Redirection for Voice EPS Fallback	162
9.3.1.117	UE Retention Information	162
9.3.1.118	UL Forwarding	162
9.3.1.119	CN Assisted RAN Parameters Tuning	162
9.3.1.120	Common Network Instance	
9.3.2	Transport Network Layer Related IEs	
9.3.2.1	QoS Flow per TNL Information List	
9.3.2.2	UP Transport Layer Information	
9.3.2.3	E-RAB ID	
9.3.2.4	Transport Layer Address	
9.3.2.5	GTP-TEID.	
9.3.2.6	CP Transport Layer Information	

9.3.2.7	TNL Association List	164
9.3.2.8	QoS Flow per TNL Information	
9.3.2.9	TNL Association Usage	
9.3.2.10	TNL Address Weight Factor	
9.3.2.11	UP Transport Layer Information Pair List	
9.3.2.12	UP Transport Layer Information List	
9.3.2.13	QoS Flow List with Data Forwarding	165
9.3.3	NAS Related IEs	
9.3.3.1	AMF UE NGAP ID	166
9.3.3.2	RAN UE NGAP ID	
9.3.3.3	GUAMI	
9.3.3.4	NAS-PDU	
9.3.3.5	PLMN Identity	
9.3.3.6	SON Configuration Transfer	
9.3.3.7	SON Information	
9.3.3.8	SON Information Reply	
9.3.3.9	Xn TNL Configuration Info	
9.3.3.10	TAC	
9.3.3.11	TAI	
9.3.3.12	AMF Set ID	
9.3.3.13	Routing ID	
9.3.3.14	NRPPa-PDU	
9.3.3.15	RAN Paging Priority	
9.3.3.16	EPS TAC	
9.3.3.17	EPS TAI	
9.3.3.18	UE Paging Identity	
9.3.3.19	AMF Pointer	
9.3.3.20	5G-S-TMSI	
9.3.3.21	AMF Name	
9.3.3.22	Paging Origin	
9.3.3.23	UE Identity Index Value	
9.3.3.24	Periodic Registration Update Timer	
9.3.3.25	UE-associated Logical NG-connection List	
9.3.3.26	NAS Security Parameters from NG-RAN	
9.3.3.27	Source to Target AMF Information Reroute	
9.3.4	SMF Related IEs.	
9.3.4.1	PDU Session Resource Setup Request Transfer	
9.3.4.2	PDU Session Resource Setup Response Transfer	
9.3.4.3	PDU Session Resource Modify Request Transfer	
9.3.4.4 9.3.4.5	· · · · · · · · · · · · · · · · · · ·	
9.3.4.5	PDU Session Resource Notify Transfer	
9.3.4.0	PDU Session Resource Modify Confirm Transfer	
9.3.4.7	Path Switch Request Transfer	
9.3.4.9	Path Switch Request Acknowledge Transfer	
9.3.4.10	Handover Command Transfer	
9.3.4.10	Handover Command Transfer  Handover Request Acknowledge Transfer	
9.3.4.11	PDU Session Resource Release Command Transfer	
9.3.4.12	PDU Session Resource Notify Released Transfer	
9.3.4.14	Handover Required Transfer	
9.3.4.15	Path Switch Request Setup Failed Transfer	
9.3.4.16	PDU Session Resource Setup Unsuccessful Transfer	
9.3.4.17	PDU Session Resource Modify Unsuccessful Transfer	
9.3.4.18	Handover Preparation Unsuccessful Transfer	
9.3.4.19	Handover Resource Allocation Unsuccessful Transfer	
9.3.4.20	Path Switch Request Unsuccessful Transfer	
9.3.4.21	PDU Session Resource Release Response Transfer	
9.3.4.22	PDU Session Resource Modify Indication Unsuccessful Transfer	
9.3.4.23	Secondary RAT Data Usage Report Transfer	
9.4	Message and Information Element Abstract Syntax (with ASN.1)	
9.4.1	General General	
9.4.2	Usage of private message mechanism for non-standard use	

9.4.3	Elementary Procedure Definitions	185
9.4.4	PDU Definitions	
9.4.5	Information Element Definitions	237
9.4.6	Common Definitions	
9.4.7	Constant Definitions	303
9.4.8	Container Definitions	309
9.5	Message Transfer Syntax	314
9.6	Timers	314
10 H	andling of Unknown, Unforeseen and Erroneous Protocol Data	315
10.1	General	
10.2	Transfer Syntax Error	315
10.3	Abstract Syntax Error	315
10.3.1	General	
10.3.2	Criticality Information	316
10.3.3	Presence Information	316
10.3.4	Not comprehended IE/IE group	317
10.3.4.1	Procedure Code	317
10.3.4.1	A Type of Message	317
10.3.4.2	IEs other than the Procedure Code and Type of Message	317
10.3.5	Missing IE or IE group	318
10.3.6	IEs or IE groups received in wrong order or with too many occurrences or erroneously present	319
10.4	Logical Error	320
10.5	Exceptions	320
10.6	Handling of AP ID	321
Annex A	A (informative): Change history	322
History		325

## **Foreword**

This Technical Specification has been produced by the 3<sup>rd</sup> Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- Y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

## 1 Scope

[19]

The present document specifies the radio network layer signalling protocol for the NG interface. The NG Application Protocol (NGAP) supports the functions of the NG interface by signalling procedures defined in this document. NGAP is developed in accordance to the general principles stated in TS 38.401 [2] and TS 38.410 [3].

## 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

[1]	3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
[2]	3GPP TS 38.401: "NG-RAN; Architecture description".
[3]	3GPP TS 38.410: "NG-RAN; NG general aspects and principles".
[4]	ITU-T Recommendation X.691 (07/2002): "Information technology – ASN.1 encoding rules: Specification of Packed Encoding Rules (PER)".
[5]	$ITU-T\ Recommendation\ X.680\ (07/2002): "Information\ technology-Abstract\ Syntax\ Notation\ One\ (ASN.1):\ Specification\ of\ basic\ notation".$
[6]	ITU-T Recommendation X.681 (07/2002): "Information technology – Abstract Syntax Notation One (ASN.1): Information object specification".
[7]	3GPP TR 25.921 (version.7.0.0): "Guidelines and principles for protocol description and error handling".
[8]	3GPP TS 38.300: "NR; NR and NG-RAN Overall Description; Stage 2".
[9]	3GPP TS 23.501: "System Architecture for the 5G System; Stage 2".
[10]	3GPP TS 23.502: "Procedures for the 5G System; Stage 2".
[11]	3GPP TS 32.422: "Trace control and configuration management".
[12]	3GPP TS 38.304: "NR; User Equipment (UE) procedures in idle mode and in RRC inactive state".
[13]	3GPP TS 33.501: "Security architecture and procedures for 5G System".
[14]	3GPP TS 38.414: "NG-RAN; NG data transport".
[15]	3GPP TS 29.281: "General Packet Radio System (GPRS); Tunnelling Protocol User Plane (GTPv1-U)".
[16]	3GPP TS 36.413: "Evolved Universal Terrestrial Radio Access Network (E-UTRAN); S1 Application Protocol (S1AP)".
[17]	3GPP TS 36.300: "Evolved Universal Terrestrial Radio Access (E-UTRA) and Evolved Universal Terrestrial Radio Access Network (E-UTRAN); Overall description; Stage 2".
[18]	3GPP TS 38.331: "NG-RAN; Radio Resource Control (RRC) Protocol Specification".
54.03	

3GPP TS 38.455: "NG-RAN; NR Positioning Protocol A (NRPPa)".

[20]	3GPP TS 23.007: "Technical Specification Group Core Network Terminals; Restoration procedures".
[21]	3GPP TS 36.331: "Evolved Universal Terrestrial Radio Access (E-UTRA) Radio Resource Control (RRC); Protocol specification".
[22]	3GPP TS 23.041: "Technical realization of Cell Broadcast Service (CBS)".
[23]	3GPP TS 23.003: "Numbering, addressing and identification".
[24]	3GPP TS 38.423: "NG-RAN; Xn Application Protocol (XnAP)".
[25]	IETF RFC 5905 (2010-06): "Network Time Protocol Version 4: Protocol and Algorithms Specification".
[26]	3GPP TS 24.501: "Non-Access-Stratum (NAS) protocol for 5G System (5GS); Stage 3".
[27]	3GPP TS 33.401: "3GPP System Architecture Evolution (SAE); Security architecture".
[28]	3GPP TS 25.413: "UTRAN Iu interface RANAP signalling".
[29]	3GPP TS 36.304: "Evolved Universal Terrestrial Radio Access (E-UTRA); User Equipment (UE) procedures in idle mode".
[30]	3GPP TS 29.531: "5G System; Network Slice Selection Services; Stage 3".

## 3 Definitions and abbreviations

#### 3.1 Definitions

For the purposes of the present document, the terms and definitions given in 3GPP TR 21.905 [1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in 3GPP TR 21.905 [1].

**Elementary Procedure:** NGAP consists of Elementary Procedures (EPs). An Elementary Procedure is a unit of interaction between the NG-RAN node and the AMF. These Elementary Procedures are defined separately and are intended to be used to build up complete sequences in a flexible manner. If the independence between some EPs is restricted, it is described under the relevant EP description. Unless otherwise stated by the restrictions, the EPs may be invoked independently of each other as standalone procedures, which can be active in parallel. The usage of several NGAP EPs together or together with EPs from other interfaces is specified in stage 2 specifications (e.g., TS 38.401 [2], TS 38.410 [3] and TS 38.300 [8]).

An EP consists of an initiating message and possibly a response message. Two kinds of EPs are used:

- Class 1: Elementary Procedures with response (success and/or failure).
- Class 2: Elementary Procedures without response.

For Class 1 EPs, the types of responses can be as follows:

#### Successful:

- A signalling message explicitly indicates that the elementary procedure successfully completed with the receipt of the response.

#### Unsuccessful:

- A signalling message explicitly indicates that the EP failed.
- On time supervision expiry (i.e., absence of expected response).

#### Successful and Unsuccessful:

- One signalling message reports both successful and unsuccessful outcome for the different included requests. The response message used is the one defined for successful outcome.

Class 2 EPs are considered always successful.

**gNB:** as defined in TS 38.300 [8].

**ng-eNB:** as defined in TS 38.300 [8].

NG-RAN node: as defined in TS 38.300 [8].

**PDU session resource:** as defined in TS 38.401 [2].

#### 3.2 Abbreviations

For the purposes of the present document, the abbreviations given in 3GPP TR 21.905 [1] and the following apply. An abbreviation defined in the present document takes precedence over the definition of the same abbreviation, if any, in 3GPP TR 21.905 [1].

5GC5G Core Network5QI5G QoS Identifier

AMF Access and Mobility Management Function

CGI Cell Global Identifier
CP Control Plane
DL Downlink

EPC Evolved Packet Core

GUAMI Globally Unique AMF Identifier

IMEISV International Mobile station Equipment Identity and Software Version number

LMF Location Management Function
N3IWF Non 3GPP InterWorking Function

NGAP NG Application Protocol
NRPPa NR Positioning Protocol Annex
NSCI New Security Context Indicator

NSSAI Network Slice Selection Assistance Information

OTDOA Observed Time Difference of Arrival

PSCell Primary SCG Cell SCG Secondary Cell Group

SCTP Stream Control Transmission Protocol SMF Session Management Function S-NG-RAN node Secondary NG-RAN node

S-NSSAI Single Network Slice Selection Assistance Information

TAC Tracking Area Code
TAI Tracking Area Identity

TNLA Transport Network Layer Association

UP User Plane

UPF User Plane Function

## 4 General

## 4.1 Procedure Specification Principles

The principle for specifying the procedure logic is to specify the functional behaviour of the terminating node exactly and completely. Any rule that specifies the behaviour of the originating node shall be possible to be verified with information that is visible within the system.

The following specification principles have been applied for the procedure text in clause 8:

- The procedure text discriminates between:

1) Functionality which "shall" be executed

The procedure text indicates that the receiving node "shall" perform a certain function Y under a certain condition. If the receiving node supports procedure X but cannot perform functionality Y requested in the REQUEST message of a Class 1 EP, the receiving node shall respond with the message used to report unsuccessful outcome for this procedure, containing an appropriate cause value.

2) Functionality which "shall, if supported" be executed

The procedure text indicates that the receiving node "shall, if supported," perform a certain function Y under a certain condition. If the receiving node supports procedure X, but does not support functionality Y, the receiving node shall proceed with the execution of the EP, possibly informing the requesting node about the not supported functionality.

- Any required inclusion of an optional IE in a response message is explicitly indicated in the procedure text. If the procedure text does not explicitly indicate that an optional IE shall be included in a response message, the optional IE shall not be included. For requirements on including *Criticality Diagnostics* IE, see clause 10.

## 4.2 Forwards and Backwards Compatibility

The forwards and backwards compatibility of the protocol is assured by mechanism where all current and future messages, and IEs or groups of related IEs, include ID and criticality fields that are coded in a standard format that will not be changed in the future. These parts can always be decoded regardless of the standard version.

## 4.3 Specification Notations

For the purposes of the present document, the following notations apply:

Procedure When referring to an elementary procedure in the specification the Procedure Name is written with

the first letters in each word in upper case characters followed by the word "procedure", e.g.,

Procedure Name procedure.

Message When referring to a message in the specification the MESSAGE NAME is written with all letters

in upper case characters followed by the word "message", e.g., MESSAGE NAME message.

IE When referring to an information element (IE) in the specification the *Information Element Name* 

is written with the first letters in each word in upper case characters and all letters in Italic font

followed by the abbreviation "IE", e.g., Information Element IE.

Value of an IE When referring to the value of an information element (IE) in the specification the "Value" is

written as it is specified in subclause 9.2 enclosed by quotation marks, e.g., "Value".

## 5 NGAP Services

NGAP provides the signalling service between the NG-RAN node and the AMF that is required to fulfil the NGAP functions described in TS 38.410 [3]. NGAP services are divided into two groups:

Non UE-associated services: They are related to the whole NG interface instance between the NG-RAN node and

AMF utilising a non UE-associated signalling connection.

UE-associated services: They are related to one UE. NGAP functions that provide these services are

associated with a UE-associated signalling connection that is maintained for the UE

in question.

## 6 Services Expected from Signalling Transport

The signalling connection shall provide in sequence delivery of NGAP messages. NGAP shall be notified if the signalling connection breaks.

## 7 Functions of NGAP

The functions of NGAP are described in TS 38.410 [3].

## 8 NGAP Procedures

## 8.1 List of NGAP Elementary Procedures

In the following tables, all EPs are divided into Class 1 and Class 2 EPs (see subclause 3.1 for explanation of the different classes):

Table 8.1-1: Class 1 procedures

Elementary	Initiating Message	Successful Outcome	Unsuccessful Outcome
Procedure		Response message	Response message
AMF	AMF CONFIGURATION	AMF CONFIGURATION	AMF CONFIGURATION
Configuration	UPDATE	UPDATE	UPDATE FAILURE
Update		ACKNOWLEDGE	
RAN	RAN CONFIGURATION	RAN CONFIGURATION	RAN CONFIGURATION
Configuration	UPDATE	UPDATE	UPDATE FAILURE
Update		ACKNOWLEDGE	
Handover	HANDOVER CANCEL	HANDOVER CANCEL	
Cancellation		ACKNOWLEDGE	
Handover	HANDOVER	HANDOVER COMMAND	HANDOVER
Preparation	REQUIRED		PREPARATION FAILURE
Handover	HANDOVER REQUEST	HANDOVER REQUEST	HANDOVER FAILURE
Resource		ACKNOWLEDGE	
Allocation			
Initial Context	INITIAL CONTEXT	INITIAL CONTEXT SETUP	INITIAL CONTEXT SETUP
Setup	SETUP REQUEST	RESPONSE	FAILURE
NG Reset	NG RESET	NG RESET	ļ
		ACKNOWLEDGE	
NG Setup	NG SETUP REQUEST	NG SETUP RESPONSE	NG SETUP FAILURE
Path Switch	PATH SWITCH	PATH SWITCH REQUEST	PATH SWITCH REQUEST
Request	REQUEST	ACKNOWLEDGE	FAILURE
PDU Session	PDU SESSION	PDU SESSION	
Resource	RESOURCE MODIFY	RESOURCE MODIFY	
Modify	REQUEST	RESPONSE	
PDU Session	PDU SESSION	PDU SESSION	
Resource	RESOURCE MODIFY	RESOURCE MODIFY	
Modify	INDICATION	CONFIRM	
Indication			
PDU Session	PDU SESSION	PDU SESSION	
Resource	RESOURCE RELEASE	RESOURCE RELEASE	
Release	COMMAND	RESPONSE	
PDU Session	PDU SESSION	PDU SESSION	
Resource Setup	RESOURCE SETUP	RESOURCE SETUP	
	REQUEST	RESPONSE	
UE Context	UE CONTEXT	UE CONTEXT	UE CONTEXT
Modification	MODIFICATION	MODIFICATION	MODIFICATION FAILURE
	REQUEST	RESPONSE	
UE Context	UE CONTEXT	UE CONTEXT RELEASE	
Release	RELEASE COMMAND	COMPLETE	
Write-Replace	WRITE-REPLACE	WRITE-REPLACE	
Warning	WARNING REQUEST	WARNING RESPONSE	
PWS Cancel	PWS CANCEL	PWS CANCEL	
	REQUEST	RESPONSE	
UE Radio	UE RADIO	UE RADIO CAPABILITY	
Capability	CAPABILITY CHECK	CHECK RESPONSE	
Check	REQUEST		

Table 8.1-2: Class 2 procedures

Elementary Procedure	Message	
Downlink RAN Configuration Transfer	DOWNLINK RAN CONFIGURATION TRANSFER	
Downlink RAN Status Transfer	DOWNLINK RAN STATUS TRANSFER	
Downlink NAS Transport	DOWNLINK NAS TRANSPORT	
Error Indication	ERROR INDICATION	
Uplink RAN Configuration Transfer	UPLINK RAN CONFIGURATION TRANSFER	
Uplink RAN Status Transfer	UPLINK RAN STATUS TRANSFER	
Handover Notification	HANDOVER NOTIFY	
Initial UE Message	INITIAL UE MESSAGE	
NAS Non Delivery Indication	NAS NON DELIVERY INDICATION	
Paging	PAGING	
PDU Session Resource Notify	PDU SESSION RESOURCE NOTIFY	
Reroute NAS Request	REROUTE NAS REQUEST	
UE Context Release Request	UE CONTEXT RELEASE REQUEST	
Uplink NAS Transport	UPLINK NAS TRANSPORT	
AMF Status Indication	AMF STATUS INDICATION	
PWS Restart Indication	PWS RESTART INDICATION	
PWS Failure Indication	PWS FAILURE INDICATION	
Downlink UE Associated NRPPa Transport	DOWNLINK UE ASSOCIATED NRPPA TRANSPORT	
Uplink UE Associated NRPPa Transport	UPLINK UE ASSOCIATED NRPPA TRANSPORT	
Downlink Non UE Associated NRPPa	DOWNLINK NON UE ASSOCIATED NRPPA	
Transport	TRANSPORT	
Uplink Non UE Associated NRPPa Transport	UPLINK NON UE ASSOCIATED NRPPA TRANSPORT	
Trace Start	TRACE START	
Trace Failure Indication	TRACE FAILURE INDICATION	
Deactivate Trace	DEACTIVATE TRACE	
Cell Traffic Trace	CELL TRAFFIC TRACE	
Location Reporting Control	LOCATION REPORTING CONTROL	
Location Reporting Failure Indication	LOCATION REPORTING FAILURE INDICATION	
Location Report	LOCATION REPORT	
UE TNLA Binding Release	UE TNLA BINDING RELEASE REQUEST	
UE Radio Capability Info Indication	UE RADIO CAPABILITY INFO INDICATION	
RRC Inactive Transition Report	RRC INACTIVE TRANSITION REPORT	
Overload Start	OVERLOAD START	
Overload Stop	OVERLOAD STOP	
Secondary RAT Data Usage Report	SECONDARY RAT DATA USAGE REPORT	

## 8.2 PDU Session Management Procedures

## 8.2.1 PDU Session Resource Setup

#### 8.2.1.1 General

The purpose of the PDU Session Resource Setup procedure is to assign resources on Uu and NG-U for one or several PDU sessions and the corresponding QoS flows, and to setup corresponding DRBs for a given UE. The procedure uses UE-associated signalling.

#### 8.2.1.2 Successful Operation




Figure 8.2.1.2-1: PDU session resource setup: successful operation

The AMF initiates the procedure by sending a PDU SESSION RESOURCE SETUP REQUEST message to the NG-RAN node.

The PDU SESSION RESOURCE SETUP REQUEST message shall contain the information required by the NG-RAN node to setup the PDU session related NG-RAN configuration consisting of at least one PDU session resource and include each PDU session resource to setup in the *PDU Session Resource Setup Request List* IE.

Upon reception of the PDU SESSION RESOURCE SETUP REQUEST message, if resources are available for the requested configuration, the NG-RAN node shall execute the requested NG-RAN configuration and allocate associated resources over NG and over Uu for each PDU session listed in the *PDU Session Resource Setup Request List* IE.

If the *RAN Paging Priority* IE is included in the PDU SESSION RESOURCE SETUP REQUEST message, the NG-RAN node may use it to determine a priority for paging the UE in RRC\_INACTIVE state.

For each requested PDU session, if resources are available for the requested configuration, the NG-RAN node shall establish at least one DRB and associate each accepted QoS flow of the PDU session to a DRB established.

For each PDU session successfully established the NG-RAN node shall pass to the UE the *PDU Session NAS-PDU* IE, if included, and the value contained in the *PDU Session ID* IE received for the PDU session. The NG-RAN node shall not send to the UE the PDU Session NAS PDUs associated to the failed PDU sessions.

If the *NAS-PDU* IE is included in the PDU SESSION RESOURCE SETUP REQUEST message, the NG-RAN node shall pass it to the UE.

For each PDU session the NG-RAN node shall store the *UL NG-U UP TNL Information* IE included in the *PDU Session Resource Setup Request Transfer* IE contained in the PDU SESSION RESOURCE SETUP REQUEST message and use it as the uplink termination point for the user plane data for this PDU session.

For each PDU session, if the *Additional UL NG-U UP TNL Information* IE is included in the *PDU Session Resource Setup Request Transfer* IE contained in the PDU SESSION RESOURCE SETUP REQUEST message, the NG-RAN node may allocate for this split PDU session resources for an additional NG-U transport bearer for some or all of the QoS flows present in the *QoS Flow Setup Request List* IE and it shall indicate these QoS flows in the *Additional DL QoS Flow per TNL Information* IE in the *PDU Session Resource Setup Response Transfer* IE. In case the *Additional DL QoS Flow per TNL Information* IE is not included the SMF shall consider the proposed additional UL NG-U UP TNL information as available again.

For each PDU session, if the *Network Instance* IE is included in the *PDU Session Resource Setup Request Transfer* IE contained in the PDU SESSION RESOURCE SETUP REQUEST message and the *Common Network Instance* IE is not present, the NG-RAN node shall, if supported, use it when selecting transport network resource as specified in TS 23.501 [9].

For each PDU session, if the *Common Network Instance* IE is included in the *PDU Session Resource Setup Request Transfer* IE contained in the PDU SESSION RESOURCE SETUP REQUEST message, the NG-RAN node shall, if supported, use it when selecting transport network resource as specified in TS 23.501 [9].

For each PDU session, if the *PDU Session Type* IE included in the *PDU Session Resource Setup Request Transfer* IE of the PDU SESSION RESOURCE SETUP REQUEST message is set to "ethernet" or "unstructured", the NG-RAN node shall not perform header compression for the concerned PDU session.

For each PDU session for which the *Security Indication* IE is included in the *PDU Session Resource Setup Request Transfer* IE of the PDU SESSION RESOURCE SETUP REQUEST message, and the *Integrity Protection Indication* IE or *Confidentiality Protection Indication* IE is set to "required", then the NG-RAN node shall perform user plane integrity protection or ciphering, respectively, for the concerned PDU session. If the NG-RAN node cannot perform the user plane integrity protection or ciphering, it shall reject the setup of the PDU session resources with an appropriate cause value.

If the NG-RAN node is an ng-eNB, it shall reject all PDU sessions for which the *Integrity Protection Indication* IE is set to "required".

For each PDU session for which the *Security Indication* IE is included in the *PDU Session Resource Setup Request Transfer* IE of the PDU SESSION RESOURCE SETUP REQUEST message, and the *Integrity Protection Indication* IE or *Confidentiality Protection Indication* IE is set to "preferred", then the NG-RAN node should, if supported, perform user plane integrity protection or ciphering, respectively, for the concerned PDU session and shall notify whether it performed the user plane integrity protection or ciphering by including the *Integrity Protection Result* IE or *Confidentiality Protection Result* IE, respectively, in the *PDU Session Resource Setup Response Transfer* IE of the PDU SESSION RESOURCE SETUP RESPONSE message.

For each PDU session for which the *Maximum Integrity Protected Data Rate Downlink* IE or the *Maximum Integrity Protected Data Rate Uplink* IE are included in the *Security Indication* IE in the *PDU Session Resource Setup Request Transfer* IE of the PDU SESSION RESOURCE SETUP REQUEST message, the NG-RAN node shall store the respective information and, if integrity protection is to be performed for the PDU session, it shall enforce the traffic limits corresponding to the received values, for the concerned PDU session and concerned UE, as specified in TS 23.501 [9].

For each PDU session for which the *Security Indication* IE is included in the *PDU Session Resource Setup Request Transfer* IE of the PDU SESSION RESOURCE SETUP REQUEST message:

- if the *Integrity Protection Indication* IE is set to "not needed", then the NG-RAN node shall not perform user plane integrity protection for the concerned PDU session;
- if the *Confidentiality Protection Indication* IE is set to "not needed", then the NG-RAN node shall not perform user plane ciphering for the concerned PDU session.

For each PDU session for which the *PDU Session Aggregate Maximum Bit Rate* IE is included in the *PDU Session Resource Setup Request Transfer* IE of the PDU SESSION RESOURCE SETUP REQUEST message, the NG-RAN node shall store the received value in the UE context and use it when enforcing traffic policing for Non-GBR QoS flows for the concerned UE as specified in TS 23.501 [9].

For each PDU session in the PDU SESSION RESOURCE SETUP REQUEST message, if the *Additional QoS Flow Information* IE is included in the *QoS Flow Level QoS Parameters* IE in the *PDU Session Resource Setup Request Transfer* IE of the PDU SESSION RESOURCE SETUP REQUEST message, the NG-RAN node may consider it for the DRB allocation process. It is up to NG-RAN node implementation to decide whether and how to use it.

For each QoS flow requested to be setup the NG-RAN node shall take into account the received *QoS Flow Level QoS Parameters* IE. For each QoS flow the NG-RAN node shall establish or modify the resources according to the values of the *Allocation and Retention Priority* IE (priority level and pre-emption indicators) and the resource situation as follows:

- The NG-RAN node shall consider the priority level of the requested QoS flow, when deciding on the resource allocation.
- The priority levels and the pre-emption indicators may (individually or in combination) be used to determine whether the QoS flow setup has to be performed unconditionally and immediately. If the requested QoS flow is marked as "may trigger pre-emption" and the resource situation requires so, the NG-RAN node may trigger the pre-emption procedure which may then cause the forced release of a lower priority QoS flow which is marked as "pre-emptable". Whilst the process and the extent of the pre-emption procedure are operator-dependent, the pre-emption indicators shall be treated as follows:
  - 1. The values of the last received *Pre-emption Vulnerability* IE and *Priority Level* IE shall prevail.
  - 2. If the *Pre-emption Capability* IE is set to "may trigger pre-emption", then this allocation request may trigger the pre-emption procedure.

- 3. If the *Pre-emption Capability* IE is set to "shall not trigger pre-emption", then this allocation request shall not trigger the pre-emption procedure.
- 4. If the *Pre-emption Vulnerability* IE is set to "pre-emptable", then this QoS flow shall be included in the pre-emption process.
- 5. If the *Pre-emption Vulnerability* IE is set to "not pre-emptable", then this QoS flow shall not be included in the pre-emption process.
- The NG-RAN node pre-emption process shall keep the following rules:
  - 1. The NG-RAN node shall only pre-empt QoS flows with lower priority, in ascending order of priority.
  - 2. The pre-emption may be done for QoS flows belonging to the same UE or to other UEs.

For each QoS flow which has been successfully established, the NG-RAN node shall store the mapped E-RAB ID if included in the *PDU Session Resource Setup Request Transfer* IE contained in the PDU SESSION RESOURCE SETUP REQUEST message and use it as specified in TS 38.300 [8].

The NG-RAN node shall report to the AMF in the PDU SESSION RESOURCE SETUP RESPONSE message the result for each PDU session resource requested to be setup:

- For each PDU session resource successfully setup, the *PDU Session Resource Setup Response Transfer* IE shall be included containing:
  - 1. The NG-U UP transport layer information to be used for the PDU session and associated list of QoS flows which have been successfully established, in the *QoS Flow per TNL Information* IE.
  - 2. The list of QoS flows which failed to be established, if any, in the *QoS Flow Failed to Setup List* IE. When the NG-RAN node reports unsuccessful establishment of a QoS flow, the cause value should be precise enough to enable the SMF to know the reason for the unsuccessful establishment.
- For each PDU session resource which failed to be setup, the *PDU Session Resource Setup Unsuccessful Transfer* IE shall be included containing a cause value that should be precise enough to enable the SMF to know the reason for the unsuccessful establishment.

Upon reception of the PDU SESSION RESOURCE SETUP RESPONSE message the AMF shall, for each PDU session indicated in the *PDU Session ID* IE, transfer transparently the *PDU Session Resource Setup Response Transfer* IE or *PDU Session Resource Setup Unsuccessful Transfer* IE to the SMF associated with the concerned PDU session.

The *UE Aggregate Maximum Bit Rate* IE should be sent to the NG-RAN node if the AMF has not sent it previously. If it is included in the PDU SESSION RESOURCE SETUP REQUEST message, the NG-RAN node shall store the UE Aggregate Maximum Bit Rate in the UE context, and use the received UE Aggregate Maximum Bit Rate for all Non-GBR QoS flows for the concerned UE as specified in TS 23.501 [9].

#### **Interactions with Handover Preparation procedure:**

If a handover becomes necessary during the PDU Session Resource Setup procedure, the NG-RAN node may interrupt the ongoing PDU Session Resource Setup procedure and initiate the Handover Preparation procedure as follows:

- The NG-RAN node shall send the PDU SESSION RESOURCE SETUP RESPONSE message in which the NG-RAN node shall indicate, if necessary, all the PDU session resources which failed to be setup with an appropriate cause value, e.g. "NG intra-system handover triggered", "NG inter-system handover triggered" or "Xn handover triggered".
- 2. The NG-RAN node shall trigger the handover procedure.

#### 8.2.1.3 Unsuccessful Operation

The unsuccessful operation is specified in the successful operation section.

#### 8.2.1.4 Abnormal Conditions

If the NG-RAN node receives a PDU SESSION RESOURCE SETUP REQUEST message containing several *PDU Session ID* IEs (in the *PDU Session Resource Setup Request List* IE) set to the same value, the NG-RAN node shall

report the establishment of the corresponding PDU sessions as failed in the PDU SESSION RESOURCE SETUP RESPONSE message with an appropriate cause value.

If the NG-RAN node receives a PDU SESSION RESOURCE SETUP REQUEST message containing a *PDU Session ID* IE (in the *PDU Session Resource Setup Request List* IE) set to a value that identifies an active PDU session (established before the PDU SESSION RESOURCE SETUP REQUEST message was received), the NG-RAN node shall report the establishment of the new PDU session as failed in the PDU SESSION RESOURCE SETUP REQUEST message with an appropriate cause value.

If the NG-RAN node receives a PDU SESSION RESOURCE SETUP REQUEST message containing a *QoS Flow Setup Request List* IE in the *PDU Session Resource Setup Request Transfer* IE including at least one Non-GBR QoS flow but the *PDU Session Aggregate Maximum Bit Rate* IE is not present, the NG-RAN node shall report the establishment of the corresponding PDU session as failed in the PDU SESSION RESOURCE SETUP REQUEST message with an appropriate cause value.

If the NG-RAN node receives a PDU SESSION RESOURCE SETUP REQUEST message containing a *QoS Flow Level QoS Parameters* IE in the *PDU Session Resource Setup Request Transfer* IE for a GBR QoS flow but the *GBR QoS Flow Information* IE is not present, the NG-RAN node shall report the establishment of the corresponding QoS flow as failed in the *PDU Session Resource Setup Response Transfer* IE of the PDU SESSION RESOURCE SETUP RESPONSE message with an appropriate cause value. If the NG-RAN node receives a PDU SESSION RESOURCE SETUP REQUEST message containing the *Delay Critical* IE in the *Dynamic 5QI Descriptor* IE of the *QoS Flow Level QoS Parameters* IE of the *PDU Session Resource Setup Request Transfer* IE set to the value "delay critical" but the *Maximum Data Burst Volume* IE is not present, the NG-RAN node shall report the establishment of the corresponding QoS flow as failed in the *PDU Session Resource Setup Response Transfer* IE of the PDU SESSION RESOURCE SETUP RESPONSE message with an appropriate cause value.

#### 8.2.2 PDU Session Resource Release

#### 8.2.2.1 General

The purpose of the PDU Session Resource Release procedure is to enable the release of already established PDU session resources for a given UE. The procedure uses UE-associated signalling.

#### 8.2.2.2 Successful Operation



Figure 8.2.2.2-1: PDU session resource release: successful operation

The AMF initiates the procedure by sending a PDU SESSION RESOURCE RELEASE COMMAND message.

The PDU SESSION RESOURCE RELEASE COMMAND message shall contain the information required by the NG-RAN node to release at least one PDU session resource, and include each PDU session resource to release in the PDU Session Resource to Release List IE.

If a *NAS-PDU* IE is contained in the PDU SESSION RESOURCE RELEASE COMMAND message, the NG-RAN node shall pass it to the UE.

Upon reception of the PDU SESSION RESOURCE RELEASE COMMAND message the NG-RAN node shall execute the release of the requested PDU sessions. For each PDU session to be released the NG-RAN node shall release the corresponding resources over Uu and over NG, if any.

If the *RAN Paging Priority* IE is included in the PDU SESSION RESOURCE RELEASE COMMAND message, the NG-RAN node may use it to determine a priority for paging the UE in RRC\_INACTIVE state.

The NG-RAN node shall, if supported, report in the PDU SESSION RESOURCE RELEASE RESPONSE message location information of the UE in the *User Location Information* IE.

After sending a PDU SESSION RESOURCE RELEASE RESPONSE message, the NG-RAN node shall be prepared to receive a PDU SESSION RESOURCE SETUP REQUEST message requesting establishment of a PDU session with a PDU Session ID corresponding to one of the PDU Session IDs that was present in the *PDU Session Resource to Release List* IE of the PDU SESSION RESOURCE RELEASE COMMAND message.

If the *User Location Information* IE is included in the PDU SESSION RESOURCE RELEASE RESPONSE message, the AMF shall handle this information as specified in TS 23.501 [9].

For each PDU session for which the *Secondary RAT Usage Information* IE is included in the *PDU Session Resource Release Response Transfer* IE, the SMF shall handle this information as specified in TS 23.502 [10].

#### 8.2.2.3 Unsuccessful Operation

The unsuccessful operation is specified in the successful operation section.

#### 8.2.2.4 Abnormal Conditions

If the NG-RAN node receives a PDU SESSION RESOURCE RELEASE COMMAND message containing multiple *PDU Session ID* IEs (in the *PDU Session Resource to Release List* IE) set to the same value, the NG-RAN node shall initiate the release of one corresponding PDU session and ignore the duplication of the instances of the selected corresponding PDU sessions.

#### 8.2.3 PDU Session Resource Modify

#### 8.2.3.1 General

The purpose of the PDU Session Resource Modify procedure is to enable configuration modifications of already established PDU session(s) for a given UE. It is also to enable the setup, modification and release of the QoS flow for already established PDU session(s). The procedure uses UE-associated signalling.

#### 8.2.3.2 Successful Operation




Figure 8.2.3.2-1: PDU session resource modify: successful operation

The AMF initiates the procedure by sending a PDU SESSION RESOURCE MODIFY REQUEST message to the NG-RAN node.

The PDU SESSION RESOURCE MODIFY REQUEST message shall contain the information required by the NG-RAN node, which may trigger the NG-RAN configuration modification for the existing PDU sessions listed in the *PDU Session Resource Modify Request List* IE.

Upon reception of the PDU SESSION RESOURCE MODIFY REQUEST message, if the NG-RAN configuration is triggered to be modified and if resources are available for the modified NG-RAN configuration, the NG-RAN node shall execute the configuration modification for the requested PDU session.

If the *RAN Paging Priority* IE is included in the PDU SESSION RESOURCE MODIFY REQUEST message, the NG-RAN node may use it to determine a priority for paging the UE in RRC\_INACTIVE state.

For each PDU session, if the *S-NSSAI* IE is included in the *PDU Session Resource Modify Request Item* IE contained in the PDU SESSION RESOURCE MODIFY REQUEST message, the NG-RAN node shall replace the previously provided S-NSSAI by the received S-NSSAI for the concerned PDU session and use it as specified in TS 23.502 [10].

For each PDU session, if the *Network Instance* IE is included in the *PDU Session Resource Modify Request Transfer* IE contained in the PDU SESSION RESOURCE MODIFY REQUEST message and the *Common Network Instance* IE is not present, the NG-RAN node shall, if supported, use it as specified in TS 23.501 [9].

For each PDU session, if the *Common Network Instance* IE is included in the *PDU Session Resource Modify Request Transfer* IE contained in the PDU SESSION RESOURCE MODIFY REQUEST message, the NG-RAN node shall, if supported, use it as specified in TS 23.501 [9].

For each PDU session included in the PDU Session Resource Modify Request List IE:

- For each QoS flow included in the *QoS Flow Add or Modify Request List* IE, based on the *QoS Flow Level QoS Parameters* IE, the NG-RAN node may establish, modify or release the DRB configuration and may change allocation of resources on NG or Uu accordingly. The NG-RAN node shall associate each QoS flow accepted to setup or modify with a DRB of the PDU session. The associated DRB for the QoS flow accepted to modify may not change.
- For each QoS flow included in the *QoS Flow Add or Modify Request List* IE, if the *QoS Flow Add or Modify Request Item* IE is included for an existing *QoS Flow Identifier* IE, the NG-RAN node shall overwrite the content of the full *QoS Flow Add or Modify Request Item* IE.
- For each QoS flow included in the *QoS Flow to Release List* IE, the NG-RAN node shall de-associate the QoS flow with the previously associated DRB.
- The NG-RAN node shall pass the *NAS-PDU* IE received for the PDU session to the UE when modifying the PDU session configuration. The NG-RAN node does not send the NAS PDUs associated to the failed PDU sessions to the UE.
- The NG-RAN node may change allocation of resources on NG according to the requested target configuration.
- If the *PDU Session Aggregate Maximum Bit Rate* IE is included in the *PDU Session Resource Modify Request Transfer* IE, the NG-RAN node shall store and use the received PDU Session Aggregate Maximum Bit Rate value when enforcing traffic policing for Non-GBR QoS flows for the concerned UE as specified in TS 23.501 [9].
- If the *UL NG-U UP TNL Modify List* IE is included in the *PDU Session Resource Modify Request Transfer* IE, the NG-RAN node shall update the transport layer information for the uplink data accordingly for the concerned transport bearers identified by the *DL NG-U UP TNL Information* IE included in the *PDU Session Resource Modify Request Transfer* IE for the concerned PDU session.
- If the Additional UL NG-U UP TNL Information IE is included in the PDU Session Resource Modify Request Transfer IE, the NG-RAN node may allocate resources for an additional NG-U transport bearer for some or all of the QoS flows present in the QoS Flow Add or Modify Request List IE and it shall indicate these QoS flows in the Additional DL QoS Flow per TNL Information IE in the PDU Session Resource Modify Response Transfer IE. In case the Additional DL QoS Flow per TNL Information IE is not included the SMF shall consider the proposed additional UL NG-U UP TNL information as available again.
- In case more than one NG-U transport bearers have been set up for the PDU session, if all the QoS flows associated to one existing NG-U transport bearer are included in the *QoS Flow to Release List* IE in the *PDU Session Resource Modify Request Transfer* IE, the NG-RAN node and 5GC shall consider that the concerned NG-U transport bearer is removed for the PDU session, and both NG-RAN node and 5GC shall therefore consider the related NG-U UP TNL information as available again.

The NG-RAN node shall report to the AMF, in the PDU SESSION RESOURCE MODIFY RESPONSE message, the result for each PDU session requested to be modified listed in the PDU SESSION RESOURCE MODIFY REQUEST message:

- For each PDU session which is successfully modified, the *PDU Session Resource Modify Response Transfer* IE shall be included containing:
  - 1. The list of QoS flows which have been successfully setup or modified, if any, in the *QoS Flow Add or Modify Response List* IE in case the PDU Session Resource Modify procedure is triggered by QoS flow setup or modification.
  - 2. The list of QoS flows which have failed to be setup or modified, if any, in the *QoS Flow Failed to Add or Modify List* IE in case the PDU Session Resource Modify procedure is triggered by QoS flow setup or modification.
- For each PDU session which failed to be modified, the *PDU Session Resource Modify Unsuccessful Transfer* IE shall be included containing the failure cause.
- For each PDU session, if the DL NG-U UP TNL Information IE is included in the PDU Session Resource Modify Response Transfer IE in the PDU SESSION RESOURCE MODIFY RESPONSE message, it shall be considered by the SMF as the new DL transport layer address for the PDU session. The NG-RAN also may indicate the mapping between each new DL transport layer address and the corresponding UL transport layer address assigned by the 5GC.
- For each PDU session, if the *Additional NG-U UP TNL Information* IE is included in the *PDU Session Resource Modify Response Transfer* IE in the PDU SESSION RESOURCE MODIFY RESPONSE message, it shall be considered by the SMF as the new DL transport layer address(es) for the PDU session. The NG-RAN also may indicate the mapping between each new DL transport layer address and the corresponding UL transport layer address assigned by the 5GC.

Upon reception of the PDU SESSION RESOURCE MODIFY RESPONSE message the AMF shall, for each PDU session indicated in the *PDU Session ID* IE, transfer transparently the *PDU Session Resource Modify Response Transfer* IE or *PDU Session Resource Modify Unsuccessful Transfer* IE to each SMF associated with the concerned PDU session.

The NG-RAN node shall, if supported, report in the PDU SESSION RESOURCE MODIFY RESPONSE message location information of the UE in the  $User\ Location\ Information\ IE$ .

For a PDU session or a QoS flow which failed to be modified, the NG-RAN node shall fall back to the configuration of the PDU session or the QoS flow as it was configured prior to the reception of the PDU SESSION RESOURCE MODIFY REQUEST message.

Upon reception of the PDU SESSION RESOURCE MODIFY REQUEST message to setup a QoS flow for IMS voice, if the NG-RAN node is not able to support IMS voice, the NG-RAN node shall initiate EPS fallback or RAT fallback for IMS voice procedure as specified in TS 23.501 [9] and report unsuccessful establishment of the QoS flow in the *PDU Session Resource Modify Response Transfer* IE or in the *PDU Session Resource Modify Unsuccessful Transfer* IE with cause value "IMS voice EPS fallback or RAT fallback triggered".

If the *User Location Information* IE is included in the PDU SESSION RESOURCE MODIFY RESPONSE message, the AMF shall handle this information as specified in TS 23.501 [9].

#### **Interactions with Handover Preparation procedure:**

If a handover becomes necessary during the PDU Session Resource Modify procedure, the NG-RAN node may interrupt the ongoing PDU Session Resource Modify procedure and initiate the Handover Preparation procedure as follows:

- 1. The NG-RAN node shall send the PDU SESSION RESOURCE MODIFY RESPONSE message in which the NG-RAN node shall indicate, if necessary, all the PDU sessions failed with an appropriate cause value, e.g. "NG intra-system handover triggered", "NG inter-system handover triggered" or "Xn handover triggered".
- 2. The NG-RAN node shall trigger the handover procedure.

#### 8.2.3.3 Unsuccessful Operation

The unsuccessful operation is specified in the successful operation section.

#### 8.2.3.4 Abnormal Conditions

If the NG-RAN node receives a PDU SESSION RESOURCE MODIFY REQUEST message containing several *PDU Session ID* IEs (in the *PDU Session Resource Modify Request List* IE) set to the same value, the NG-RAN node shall report the modification of the corresponding PDU sessions as failed in the PDU SESSION RESOURCE MODIFY RESPONSE message with an appropriate cause value.

If the NG-RAN node receives a PDU SESSION RESOURCE MODIFY REQUEST message containing some *PDU Session ID* IEs (in the *PDU Session Resource Modify Request List* IE) that the NG-RAN node does not recognize, the NG-RAN node shall report the corresponding invalid PDU sessions as failed in the PDU SESSION RESOURCE MODIFY RESPONSE message with an appropriate cause value.

If the NG-RAN node receives a PDU SESSION RESOURCE MODIFY REQUEST message containing a *QoS Flow Level QoS Parameters* IE in *the PDU Session Resource Modify Request Transfer* IE for a GBR QoS flow but the *GBR QoS Flow Information* IE is not present, the NG-RAN node shall report the addition or modification of the corresponding QoS flow as failed in the *PDU Session Resource Modify Response Transfer* IE of the PDU SESSION RESOURCE MODIFY RESPONSE message with an appropriate cause value.

If the NG-RAN node receives a PDU SESSION RESOURCE MODIFY REQUEST message containing the *Delay Critical* IE in the *Dynamic 5QI Descriptor* IE of the *QoS Flow Level QoS Parameters* IE of the *PDU Session Resource Modify Request Transfer* IE set to the value "delay critical" but the *Maximum Data Burst Volume* IE is not present, the NG-RAN node shall report the addition or modification of the corresponding QoS flow as failed in the *PDU Session Resource Modify Response Transfer* IE of the PDU SESSION RESOURCE MODIFY RESPONSE message with an appropriate cause value.

#### 8.2.4 PDU Session Resource Notify

#### 8.2.4.1 General

The purpose of the PDU Session Resource Notify procedure is to notify that the already established QoS flow(s) or PDU session(s) for a given UE are released or not fulfilled anymore or fulfilled again by the NG-RAN node for which notification control is requested. The procedure uses UE-associated signalling.

#### 8.2.4.2 Successful Operation



Figure 8.2.4.2-1: PDU session resource notify

The NG-RAN node initiates the procedure by sending a PDU SESSION RESOURCE NOTIFY message.

The PDU SESSION RESOURCE NOTIFY message shall contain the information of PDU session resources or QoS flows which are released or not fulfilled anymore or fulfilled again by the NG-RAN node.

- For each PDU session for which some QoS flows are released or not fulfilled anymore or fulfilled again by the NG-RAN node, the *PDU Session Resource Notify Transfer* IE shall be included containing:
  - 1. The list of QoS flows which are released by the NG-RAN node, if any, in the QoS flow Released List IE.

- 2. The list of GBR QoS flows which are not fulfilled anymore or fulfilled again by the NG-RAN node, if any, in the *QoS Flow Notify List* IE together with the *Notification Cause* IE.
- For each PDU session resource which is released by the NG-RAN node, the *PDU Session Resource Notify Released Transfer* IE shall be included containing the release cause in the *Cause* IE.

The NG-RAN node shall, if supported, report in the PDU SESSION RESOURCE NOTIFY message location information of the UE in the *User Location Information* IE.

Upon reception of the PDU SESSION RESOURCE NOTIFY message, the AMF shall, for each PDU session indicated in the *PDU Session ID* IE, transfer transparently the *PDU Session Resource Notify Transfer* IE or *PDU Session Resource Notify Released Transfer* IE to the SMF associated with the concerned PDU session. Upon reception of *PDU Session Resource Notify Transfer* IE, the SMF normally initiate the appropriate release or modify procedure on the core network side for the PDU session(s) or QoS flow(s) identified as not fulfilled anymore.

For each PDU session for which the *Secondary RAT Usage Information* IE is included in the *PDU Session Resource Notify Transfer* IE or the *PDU Session Resource Notify Released Transfer* IE, the SMF shall handle this information as specified in TS 23.502 [10].

If the *User Location Information* IE is included in the PDU SESSION RESOURCE NOTIFY message, the AMF shall handle this information as specified in TS 23.501 [9].

#### 8.2.4.3 Abnormal Conditions

Void.

#### 8.2.5 PDU Session Resource Modify Indication

#### 8.2.5.1 General

The purpose of the PDU Session Resource Modify Indication procedure is for the NG-RAN node to request modification of the established PDU session(s). The procedure uses UE-associated signalling.

#### 8.2.5.2 Successful Operation




Figure 8.2.5.2-1: PDU session resource modify indication: successful operation

The NG-RAN node initiates the procedure by sending a PDU SESSION RESOURCE MODIFY INDICATION message. Upon reception of the PDU SESSION RESOURCE MODIFY INDICATION message, the AMF shall, for each PDU session indicated in the *PDU Session ID* IE, transparently transfer the *PDU Session Resource Modify Indication Transfer* IE to the SMF associated with the concerned PDU session.

For each PDU session for which the *DL QoS Flow per TNL Information* IE is included in the *PDU Session Resource Modify Indication Transfer* IE in the PDU SESSION RESOURCE MODIFY INDICATION message, the SMF shall consider the included DL transport layer address as the DL transport layer address for the included associated QoS flows and it may provide the associated UL transport layer address in the *UL NG-U UP TNL Information* IE in the *PDU Session Resource Modify Confirm Transfer* IE in the PDU SESSION RESOURCE MODIFY CONFIRM message.

For each PDU session for which the *Additional DL QoS Flow per TNL Information* IE is included in the *PDU Session Resource Modify Indication Transfer* IE in the PDU SESSION RESOURCE MODIFY INDICATION message, the

SMF shall, if supported, consider for this split PDU session each included DL transport layer address(es) as the DL transport layer address(s) for the included associated QoS flows and it may provide the associated UL transport layer address(s) in the *Additional NG-U UP TNL Information* IE in the *PDU Session Resource Modify Confirm Transfer* IE in the PDU SESSION RESOURCE MODIFY CONFIRM message.

In case more than one NG-U transport bearers have been set up for the PDU session, the *DL QoS Flow per TNL Information* IE and the *Additional DL QoS Flow per TNL Information* IE in the *PDU Session Resource Modify Indication Transfer* IE in the PDU SESSION RESOURCE MODIFY INDICATION message shall be included if at least one QoS flow is associated to their respective NG-U transport bearer; if no QoS flow is associated to one existing NG-U transport bearer after the modification, the NG-RAN node and 5GC shall consider that the concerned NG-U transport bearer is removed for the PDU session, and both NG-RAN node and 5GC shall therefore consider the related NG-U UP TNL information as available again.

If the Security Result IE is included in the PDU Session Resource Modify Indication Transfer IE in the PDU SESSION RESOURCE MODIFY INDICATION message, it may be considered by the SMF as the new security status of the PDU session.

For each PDU session for which the *Secondary RAT Usage Information* IE is included in the *PDU Session Resource Modify Indication Transfer* IE, the SMF shall handle this information as specified in TS 23.502 [10].

The AMF shall report to the NG-RAN node in the PDU SESSION MODIFY RESOURCE CONFIRM message the result for each PDU session listed in PDU SESSION RESOURCE MODIFY INDICATION message:

- For each PDU session which is successfully modified, the *PDU Session Resource Modify Confirm Transfer* IE shall be included containing:
  - 1. The list of QoS flows which have been successfully modified in the QoS Flow Modify Confirm List IE.
  - 2. The list of QoS flows which have failed to be modified, if any, in the QoS flow Failed to Modify List IE.
- For each PDU session which failed to be modified, the *PDU Session Resource Modify Indication Unsuccessful Transfer* IE shall be included to report the failure cause.

Upon reception of the *PDU Session Resource Modify Confirm Transfer* IE for each PDU session listed in the PDU SESSION RESOURCE MODIFY CONFIRM message:

- If the QoS Flow Failed To Modify List IE is included, the NG-RAN node shall either
  - 1. de-associate the corresponding DRB for the concerned QoS flow, or
  - 2. keep the previous transport layer information before sending the PDU SESSION RESOURCE MODIFY INDICATION unchanged for the concerned QoS flow.

Upon reception of the *PDU Session Resource Modify Indication Unsuccessful Transfer* IE for each PDU session listed in the PDU SESSION RESOURCE MODIFY CONFIRM message, the NG-RAN node shall either:

- 1. release all corresponding NG-RAN configuration and resources for the concerned PDU session, or
- 2. keep the previous transport layer information before sending the PDU SESSION RESOURCE MODIFY INDICATION unchanged for the concerned PDU session.

#### 8.2.5.3 Unsuccessful Operation

The unsuccessful operation is specified in the successful operation section.

#### 8.2.5.4 Abnormal Conditions

Void.

### 8.3 UE Context Management Procedures

#### 8.3.1 Initial Context Setup

#### 8.3.1.1 General

The purpose of the Initial Context Setup procedure is to establish the necessary overall initial UE context at the NG-RAN node, when required, including PDU session context, the Security Key, Mobility Restriction List, UE Radio Capability and UE Security Capabilities, etc. The AMF may initiate the Initial Context Setup procedure if a UE-associated logical NG-connection exists for the UE or if the AMF has received the *RAN UE NGAP ID* IE in an INITIAL UE MESSAGE message or if the NG-RAN node has already initiated a UE-associated logical NG-connection by sending an INITIAL UE MESSAGE message via another NG interface instance. The procedure uses UE-associated signalling.

For signalling only connections and if the *UE Context Request* IE is not received in the Initial UE Message, the AMF may be configured to trigger the procedure for all NAS procedures or on a per NAS procedure basis depending on operator's configuration.

#### 8.3.1.2 Successful Operation




Figure 8.3.1.2-1: Initial context setup: successful operation

In case of the establishment of a PDU session the 5GC shall be prepared to receive user data before the INITIAL CONTEXT SETUP RESPONSE message has been received by the AMF. If no UE-associated logical NG-connection exists, the UE-associated logical NG-connection shall be established at reception of the INITIAL CONTEXT SETUP REQUEST message.

The INITIAL CONTEXT SETUP REQUEST message shall contain the *Index to RAT/Frequency Selection Priority* IE, if available in the AMF.

If the NAS-PDU IE is included in the INITIAL CONTEXT SETUP REQUEST message, the NG-RAN node shall pass it transparently towards the UE.

If the *Masked IMEISV* IE is contained in the INITIAL CONTEXT SETUP REQUEST message the target NG-RAN node shall, if supported, use it to determine the characteristics of the UE for subsequent handling.

Upon receipt of the INITIAL CONTEXT SETUP REQUEST message the NG-RAN node shall

- attempt to execute the requested PDU session configuration;
- store the received UE Aggregate Maximum Bit Rate in the UE context, and use the received UE Aggregate Maximum Bit Rate for Non-GBR QoS flows for the concerned UE as specified in TS 23.501 [9];
- store the received Mobility Restriction List in the UE context;
- store the received UE Radio Capability in the UE context;
- store the received Index to RAT/Frequency Selection Priority in the UE context and use it as defined in TS 23.501 [9];
- store the received UE Security Capabilities in the UE context;

- store the received Security Key in the UE context and, if the NG-RAN node is required to activate security for the UE, take this security key into use.

For the Initial Context Setup an initial value for the Next Hop Chaining Count is stored in the UE context.

If the *PDU Session Resource Setup Request List* IE is contained in the INITIAL CONTEXT SETUP REQUEST message, the NG-RAN node shall behave the same as defined in the PDU Session Resource Setup procedure. The NG-RAN node shall report to the AMF in the INITIAL CONTEXT SETUP RESPONSE message the result for each PDU session resource requested to be setup as defined in the PDU Session Resource Setup procedure.

Upon reception of the INITIAL CONTEXT SETUP RESPONSE message the AMF shall, for each PDU session indicated in the *PDU Session ID* IE, transfer transparently the *PDU Session Resource Setup Response Transfer* IE or *PDU Session Resource Setup Unsuccessful Transfer* IE to the SMF associated with the concerned PDU session. In case the splitting PDU session is not used by the NG-RAN node, the SMF should remove the Additional Transport Layer Information, if any.

The NG-RAN node shall use the information in the *Mobility Restriction List* IE if present in the INITIAL CONTEXT SETUP REQUEST message to

- determine a target for subsequent mobility action for which the NG-RAN node provides information about the target of the mobility action towards the UE;
- select a proper SCG during dual connectivity operation;
- assign proper RNA(s) for the UE when moving the UE to RRC\_INACTIVE state.

If the *Mobility Restriction List* IE is not contained in the INITIAL CONTEXT SETUP REQUEST message, the NG-RAN node shall consider that no roaming and no access restriction apply to the UE. The NG-RAN node shall also consider that no roaming and no access restriction apply to the UE when:

- one of the QoS flows includes a particular ARP value (TS 23.501 [9]).

If the *Trace Activation* IE is included in the INITIAL CONTEXT SETUP REQUEST message the NG-RAN node shall, if supported, initiate the requested trace function as described in TS 32.422 [11].

If the *UE Security Capabilities* IE included in the INITIAL CONTEXT SETUP REQUEST message only contains the EIA0 or NIA0 algorithm as defined in TS 33.501 [13] and if the EIA0 or NIA0 algorithm is defined in the configured list of allowed integrity protection algorithms in the NG-RAN node (TS 33.501 [13]), the NG-RAN node shall take it into use and ignore the keys received in the *Security Key* IE.

If the *Core Network Assistance Information for RRC INACTIVE* IE is included in the INITIAL CONTEXT SETUP REQUEST message, the NG-RAN node shall, if supported, store this information in the UE context and use it for e.g. the RRC\_INACTIVE state decision and RNA configuration for the UE and RAN paging if any for a UE in RRC\_INACTIVE state, as specified in TS 38.300 [8].

If the CN Assisted RAN Parameters Tuning IE is included in the INITIAL CONTEXT SETUP REQUEST message, the NG-RAN node may use it as described in TS 23.501 [9].

If the *RRC Inactive Transition Report Request* IE is included in the INITIAL CONTEXT SETUP REQUEST message, the NG-RAN node shall, if supported, store this information in the UE context.

If the *Emergency Fallback Indicator* IE is included in the INITIAL CONTEXT SETUP REQUEST message, it indicates that the UE context to be set up is subject to emergency service fallback as described in TS 23.501 [9] and the NG-RAN node may, if supported, take the appropriate mobility actions.

If the *Old AMF* IE is included in the INITIAL CONTEXT SETUP REQUEST message, the NG-RAN node shall consider that this UE-associated logical NG-connection was redirected to this AMF from another AMF identified by the *Old AMF* IE.

If the *Redirection for Voice EPS Fallback* IE is included in the INITIAL CONTEXT SETUP REQUEST message, the NG-RAN node shall, if supported, store it and use it in a subsequent decision of EPS fallback for voice as specified in TS 23.502 [10].

If the *Location Reporting Request Type* IE is included in the INITIAL CONTEXT SETUP REQUEST message, the NG-RAN node should perform the requested location reporting functionality for the UE as described in subclause 8.12.

#### **Interactions with Initial UE Message procedure:**

The NG-RAN node shall use the *AMF UE NGAP ID* IE and *RAN UE NGAP ID* IE received in the INITIAL CONTEXT SETUP REQUEST message as identification of the logical connection even if the *RAN UE NGAP ID* IE had been allocated in an INITIAL UE MESSAGE message sent over a different NG interface instance.

#### **Interactions with RRC Inactive Transition Report procedure:**

If the *RRC Inactive Transition Report Request* IE is included in the INITIAL CONTEXT SETUP REQUEST message and set to "subsequent state transition report", the NG-RAN node shall, if supported, send the RRC INACTIVE TRANSITION REPORT message to the AMF to report the RRC state of the UE when the UE enters or leaves RRC INACTIVE state.

#### 8.3.1.3 Unsuccessful Operation




Figure 8.3.1.3-1: Initial context setup: unsuccessful operation

If the NG-RAN node is not able to establish an NG UE context, it shall consider the procedure as failed and reply with the INITIAL CONTEXT SETUP FAILURE message.

If the *PDU Session Resource Setup Request List* IE is contained in the INITIAL CONTEXT SETUP REQUEST message, the NG-RAN node shall report to the AMF, in the INITIAL CONTEXT SETUP FAILURE message, the unsuccessful establishment result for each PDU session resource requested to be setup as defined in the PDU Session Resource Setup procedure.

Upon reception of the INITIAL CONTEXT SETUP FAILURE message the AMF shall, for each PDU session indicated in the *PDU Session ID* IE, transfer transparently the *PDU Session Resource Setup Unsuccessful Transfer* IE to the SMF associated with the concerned PDU session.

#### 8.3.1.4 Abnormal Conditions

If the supported algorithms for encryption defined in the *Encryption Algorithms* IE in the *UE Security Capabilities* IE, plus the mandated support of EEA0 and NEA0 in all UEs (TS 33.501 [13]), do not match any allowed algorithms defined in the configured list of allowed encryption algorithms in the NG-RAN node (TS 33.501 [13]), the NG-RAN node shall reject the procedure using the INITIAL CONTEXT SETUP FAILURE message.

If the supported algorithms for integrity defined in the *Integrity Protection Algorithms* IE in the *UE Security Capabilities* IE, plus the mandated support of the EIA0 and NIA0 algorithm in all UEs (TS 33.501 [13]), do not match any allowed algorithms defined in the configured list of allowed integrity protection algorithms in the NG-RAN node (TS 33.501 [13]), the NG-RAN node shall reject the procedure using the INITIAL CONTEXT SETUP FAILURE message.

## 8.3.2 UE Context Release Request (NG-RAN node initiated)

#### 8.3.2.1 General

The purpose of the UE Context Release Request procedure is to enable the NG-RAN node to request the AMF to release the UE-associated logical NG-connection due to NG-RAN node generated reasons. The procedure uses UE-associated signalling.

#### 8.3.2.2 Successful Operation



Figure 8.3.2.2-1: UE context release request

The NG-RAN node controlling a UE-associated logical NG-connection initiates the procedure by sending a UE CONTEXT RELEASE REQUEST message towards the affected AMF.

The UE CONTEXT RELEASE REQUEST message shall indicate the appropriate cause value, e.g., "TXn<sub>RELOCOverall</sub> Expiry", "Redirection", for the requested UE-associated logical NG-connection release.

If the *PDU Session Resource List* IE is included in the UE CONTEXT RELEASE REQUEST message, the AMF shall handle this information as specified in TS 23.502 [10].

#### **Interactions with UE Context Release procedure:**

The UE Context Release procedure should be initiated upon reception of a UE CONTEXT RELEASE REQUEST message. If the UE was configured with DC radio resources at the time UE Context Release Request procedure was triggered, and the PSCell information was available, the NG-RAN node shall store the PSCell information in the UE context.

#### 8.3.2.3 Abnormal Conditions

Void.

## 8.3.3 UE Context Release (AMF initiated)

#### 8.3.3.1 General

The purpose of the UE Context Release procedure is to enable the AMF to order the release of the UE-associated logical NG-connection due to various reasons, e.g., completion of a transaction between the UE and the 5GC, or release of the old UE-associated logical NG-connection when the UE has initiated the establishment of a new UE-associated logical NG-connection, etc. The procedure uses UE-associated signalling.

#### 8.3.3.2 Successful Operation



Figure 8.3.3.2-1: UE context release: successful operation

The AMF initiates the procedure by sending the UE CONTEXT RELEASE COMMAND message to the NG-RAN node.

The UE CONTEXT RELEASE COMMAND message shall contain both the AMF UE NGAP ID IE and the RAN UE NGAP ID IE if available, otherwise the message shall contain the AMF UE NGAP ID IE.

Upon reception of the UE CONTEXT RELEASE COMMAND message, the NG-RAN node shall release all related signalling and user data transport resources and reply with the UE CONTEXT RELEASE COMPLETE message.

If the *PDU Session Resource List* IE is included in the UE CONTEXT RELEASE COMPLETE message, the AMF shall handle this information as specified in TS 23.502 [10].

If the *User Location Information* IE is included in the UE CONTEXT RELEASE COMPLETE message, the AMF shall handle this information as specified in TS 23.502 [10].

If the *Information on Recommended Cells and RAN Nodes for Paging* IE is included in the UE CONTEXT RELEASE COMPLETE message, the AMF shall, if supported, store it and may use it for subsequent paging.

For each PDU session for which the *Secondary RAT Usage Information* IE is included in the *PDU Session Resource Release Response Transfer* IE, the SMF shall handle this information as specified in TS 23.502 [10].

#### 8.3.3.3 Unsuccessful Operation

Not applicable.

#### 8.3.3.4 Abnormal Conditions

If the UE Context Release procedure is not initiated towards the NG-RAN node before the expiry of the timer TNG<sub>RELOCOverall</sub>, the NG-RAN node shall request the AMF to release the UE context.

If the UE returns to the NG-RAN node before the reception of the UE CONTEXT RELEASE COMMAND message or the expiry of the timer  $TNG_{RELOCOverall}$ , the NG-RAN node shall stop the timer  $TNG_{RELOCOverall}$  and continue to serve the UE.

#### 8.3.4 UE Context Modification

#### 8.3.4.1 General

The purpose of the UE Context Modification procedure is to partly modify the established UE context. The procedure uses UE-associated signalling.

#### 8.3.4.2 Successful Operation



Figure 8.3.4.2-1: UE context modification: successful operation

If the *Security Key* IE is included in the UE CONTEXT MODIFICATION REQUEST message, the NG-RAN node shall store it and perform AS key re-keying according to TS 33.501 [13].

If the *UE Security Capabilities* IE is included in the UE CONTEXT MODIFICATION REQUEST message, the NG-RAN node shall store them and take them into use together with the received keys according to TS 33.501 [13].

If the *Index to RAT/Frequency Selection Priority* IE is included in the UE CONTEXT MODIFICATION REQUEST message, the NG-RAN node shall, if supported, use it as defined in TS 23.501 [9].

If the *RAN Paging Priority* IE is included in the UE CONTEXT MODIFICATION REQUEST message, the NG-RAN node may use it to determine a priority for paging the UE in RRC\_INACTIVE state.

If the *UE Aggregate Maximum Bit Rate* IE is included in the UE CONTEXT MODIFICATION REQUEST message, the NG-RAN node shall

- replace the previously provided UE Aggregate Maximum Bit Rate by the received UE Aggregate Maximum Bit Rate in the UE context;
- use the received UE Aggregate Maximum Bit Rate for all Non-GBR QoS flows for the concerned UE as specified in TS 23.501 [9].

If the *Core Network Assistance Information for RRC INACTIVE* IE is included in the UE CONTEXT MODIFICATION REQUEST message, the NG-RAN node shall, if supported, store this information in the UE context and use it for e.g. the RRC\_INACTIVE state decision and RNA configuration for the UE and RAN paging if any for a UE in RRC\_INACTIVE state, as specified in TS 38.300 [8].

If the CN Assisted RAN Parameters Tuning IE is included in the UE CONTEXT MODIFICATION REQUEST message, the NG-RAN node may use it as described in TS 23.501 [9].

If the *RRC Inactive Transition Report Request* IE is included in the UE CONTEXT MODIFICATION REQUEST message, the NG-RAN node shall, if supported, store this information in the UE context and report to the AMF the *User Location Information* IE and the *RRC State* IE in the UE CONTEXT MODIFICATION RESPONSE message.

If the *RRC Inactive Transition Report Request* IE is included in the UE CONTEXT MODIFICATION REQUEST message and set to "cancel report", the NG-RAN node shall, if supported, stop reporting to the AMF the RRC state of the UE.

The NG-RAN node shall report, in the UE CONTEXT MODIFICATION RESPONSE message to the AMF, the successful update of the UE context.

If the *Emergency Fallback Indicator* IE is included in the UE CONTEXT MODIFICATION REQUEST message, it indicates that the concerned UE context is subject to emergency service fallback as described in TS 23.501 [9] and the NG-RAN node may, if supported, take the appropriate mobility actions taking into account the *Emergency Service Target CN* IE if provided.

If the *New AMF UE NGAP ID* IE is included in the UE CONTEXT MODIFICATION REQUEST message, the NG-RAN node shall use the received value for future signalling with the AMF.

If the *New GUAMI* IE is included in the UE CONTEXT MODIFICATION REQUEST message, the NG-RAN node shall replace the previously stored GUAMI as specified in TS 23.501 [9].

#### **Interactions with RRC Inactive Transition Report procedure:**

If the *RRC Inactive Transition Report Request* IE is included in the UE CONTEXT MODIFICATION REQUEST message and set to "single RRC connected state report", the NG-RAN node shall, if supported and if the UE is in RRC\_INACTIVE state, send one subsequent RRC INACTIVE TRANSITION REPORT message to the AMF when the RRC state transitions to RRC CONNECTED state.

If the *RRC Inactive Transition Report Request* IE is included in the UE CONTEXT MODIFICATION REQUEST message and set to "subsequent state transition report", the NG-RAN node shall, if supported, send the RRC INACTIVE TRANSITION REPORT message to the AMF to report the RRC state of the UE when the UE enters or leaves RRC\_INACTIVE state.

# 8.3.4.3 Unsuccessful Operation



Figure 8.3.4.3-1: UE context modification: unsuccessful operation

In case the UE context update cannot be performed successfully, the NG-RAN node shall respond with the UE CONTEXT MODIFICATION FAILURE message to the AMF with an appropriate cause value in the *Cause* IE.

If the *New AMF UE NGAP ID* IE is included in the UE CONTEXT MODIFICATION REQUEST message, the NG-RAN node may use the received *New AMF UE NGAP ID* IE or *Old AMF UE NGAP ID* IE in the UE CONTEXT MODIFICATION FAILURE message.

#### 8.3.4.4 Abnormal Conditions

If the UE CONTEXT MODIFICATION REQUEST message including the *New AMF UE NGAP ID* IE is received after the NG-RAN node has initiated another class 1 NGAP EP, the NG-RAN node shall be prepared to receive the response message containing an AMF UE NGAP ID with the value received in the *New AMF UE NGAP ID* IE.

# 8.3.5 RRC Inactive Transition Report

#### 8.3.5.1 General

The purpose of the RRC Inactive Transition Report procedure is to notify the AMF when the UE enters or leaves RRC\_INACTIVE state. The procedure uses UE-associated signalling.

## 8.3.5.2 Successful Operation



Figure 8.3.5.2-1: RRC Inactive transition report

The NG-RAN node initiates the procedure by sending an RRC INACTIVE TRANSITION REPORT message to the AMF. Upon reception of the RRC INACTIVE TRANSITION REPORT message, the AMF shall take appropriate actions based on the information indicated by the *RRC State* IE.

#### 8.3.5.3 Abnormal Conditions

Void.

# 8.4 UE Mobility Management Procedures

# 8.4.1 Handover Preparation

#### 8.4.1.1 General

The purpose of the Handover Preparation procedure is to request the preparation of resources at the target side via the 5GC. There is only one Handover Preparation procedure ongoing at the same time for a certain UE.

## 8.4.1.2 Successful Operation



Figure 8.4.1.2-1: Handover preparation: successful operation

The source NG-RAN node initiates the handover preparation by sending the HANDOVER REQUIRED message to the serving AMF. When the source NG-RAN node sends the HANDOVER REQUIRED message, it shall start the timer TNG<sub>RELOCprep</sub>. The source NG-RAN node shall indicate the appropriate cause value for the handover in the *Cause* IE.

Upon reception of the HANDOVER REQUIRED message the AMF shall, for each PDU session indicated in the *PDU Session ID* IE, transparently transfer the *Handover Required Transfer* IE to the SMF associated with the concerned PDU session.

In case of intra-system handover, the information in the *Source to Target Transparent Container* IE shall be encoded according to the definition of the *Source NG-RAN node to Target NG-RAN node Transparent Container* IE.

If the *DL Forwarding* IE is included for a given QoS flow in the *PDU Session Resource Information Item* IE within the *Source NG-RAN node to Target NG-RAN node Transparent Container* IE of the HANDOVER REQUIRED message and it is set to "DL forwarding proposed", it indicates that the source NG-RAN node proposes forwarding of downlink data for that QoS flow.

If the *UL Forwarding* IE is included for a given QoS flow in the *PDU Session Resource Information Item* IE within the *Source NG-RAN Node to Target NG-RAN Node Transparent Container* IE of the HANDOVER REQUIRED message and it is set to "UL forwarding proposed", it indicates that the source NG-RAN node proposes forwarding of uplink data for that QoS flow.

If the *DRBs to QoS Flows Mapping List* IE is included in the *PDU Session Resource Information Item* IE within the *Source NG-RAN node to Target NG-RAN node Transparent Container* IE of the HANDOVER REQUIRED message, it implicitly indicates that the source NG-RAN node proposes forwarding of downlink data for those DRBs.

If the *QoS Flow Mapping Indication* IE for a QoS flow is included in the *Associated QoS Flow List* IE within the *DRBs to QoS Flows Mapping List* IE within the *Source NG-RAN node to Target NG-RAN node Transparent Container* IE of the HANDOVER REQUIRED message, it indicates that the source NG-RAN node has mapped only the uplink or downlink of the QoS flow to the DRB.

If the HANDOVER COMMAND message contains the *DL Forwarding UP TNL Information* IE for a given DRB within the *Handover Command Transfer* IE, the source NG-RAN node shall consider that the forwarding of downlink data for this DRB is accepted by the target NG-RAN node. If the HANDOVER COMMAND message contains the *UL Forwarding UP TNL Information* IE for a given DRB in the *Data Forwarding Response DRB List* IE within the *Handover Command Transfer* IE, it means the target NG-RAN node has requested the forwarding of uplink data for this DRB.

If the HANDOVER COMMAND message contains the *UL Forwarding UP TNL Information* IE for a given PDU session within the *Handover Command Transfer* IE, the source NG-RAN node shall consider that the forwarding of uplink data of the QoS flows is accepted by the target NG-RAN node.

In case of inter-system handover to LTE, the information in the *Source to Target Transparent Container* IE shall be encoded according to the *Source eNB to Target eNB Transparent Container* IE definition as specified in TS 36.413 [16].

If the *Direct Forwarding Path Availability* IE is included in the HANDOVER REQUIRED message the AMF shall handle it as specified in TS 23.502 [10].

If the *Direct Forwarding Path Availability* IE is included within the *Handover Required Transfer* IE of the HANDOVER REQUIRED message the SMF shall handle it as specified in TS 23.502 [10].

When the preparation, including the reservation of resources at the target side is ready, the AMF responds with the HANDOVER COMMAND message to the source NG-RAN node. In case of intra-system handover, the AMF shall include the *PDU Session Resource Handover List* IE in the HANDOVER COMMAND message.

Upon reception of the HANDOVER COMMAND message the source NG-RAN node shall stop the timer  $TNG_{RELOCprep}$  and start the timer  $TNG_{RELOCoverall}$ .

If there are any PDU Sessions that could not be admitted in the target, they shall be indicated in the *PDU Session Resources to Release List* IE.

NOTE: As an exception in case of inter-system handover to LTE, the AMF generates the *Handover Preparation Unsuccessful Transfer* IE in the *PDU Session Resources to Release List* IE.

If the HANDOVER COMMAND message contains the *QoS Flow to be Forwarded List* IE within the *Handover Command Transfer* IE for a given PDU session, then the source NG-RAN node should initiate data forwarding for the listed QoS flows over the forwarding tunnel specified in the *DL Forwarding UP TNL Information* IE as specified in TS 38.300 [8].

If the HANDOVER COMMAND message contains the *Additional DL Forwarding UP TNL Information* IE within the *Handover Command Transfer* IE, the source NG-RAN node should initiate data forwarding of the PDU session split in different tunnel and shall use the received UP transport layer information for the forwarding QoS flows associated to it.

If the HANDOVER COMMAND message contains the *Additional UL Forwarding UP TNL Information* IE within the *Handover Command Transfer* IE, the source NG-RAN node should initiate data forwarding of the PDU session split in different tunnels using the received UP transport layer information.

If the *NAS Security Parameters from NG-RAN* IE is included in the HANDOVER COMMAND message the NG-RAN node shall use it as specified in TS 33.501 [13].

If the *Target to Source Transparent Container* IE has been received by the AMF from the handover target then the transparent container shall be included in the HANDOVER COMMAND message.

In case of inter-system handover to LTE, the information in the *Target to Source Transparent Container* IE shall be encoded according to the definition of the *Target eNB to Source eNB Transparent Container* IE as specified in TS 36.413 [16].

If the *Index to RAT/Frequency Selection Priority* IE is contained in the *Source NG-RAN Node to Target NG-RAN Node Transparent Container* IE, the target NG-RAN node shall store the content of the received *Index to RAT/Frequency Selection Priority* IE in the UE context and use it as defined in TS 23.501 [9].

#### Interactions with other NGAP procedures:

If, after a HANDOVER REQUIRED message is sent and before the Handover Preparation procedure is terminated, the source NG-RAN node receives an AMF initiated PDU Session Management procedure on the same UE-associated signalling connection, the source NG-RAN node shall either:

1. Cancel the Handover Preparation procedure by executing the Handover Cancellation procedure with an appropriate cause value. After successful completion of the Handover Cancellation procedure, the source NG-RAN node shall continue the AMF initiated PDU Session Management procedure.

or

2. Terminate the AMF initiated PDU Session Management procedure by sending the appropriate response message with an appropriate cause value, e.g. "NG intra-system handover triggered" or "NG inter-system handover triggered" to the AMF and then the source NG-RAN node shall continue with the handover procedure.

# 8.4.1.3 Unsuccessful Operation




Figure 8.4.1.3-1: Handover preparation: unsuccessful operation

If the 5GC or the target side is not able to accept any of the PDU session resources or a failure occurs during the Handover Preparation, the AMF sends the HANDOVER PREPARATION FAILURE message with an appropriate cause value to the source NG-RAN node.

#### **Interaction with Handover Cancel procedure:**

If there is no response from the AMF to the HANDOVER REQUIRED message before timer TNG<sub>RELOCprep</sub> expires in the source NG-RAN node, the source NG-RAN node should cancel the Handover Preparation procedure by initiating the Handover Cancel procedure with the appropriate value for the *Cause* IE. The source NG-RAN node shall ignore any HANDOVER COMMAND message or HANDOVER PREPARATION FAILURE message received after the initiation of the Handover Cancel procedure.

#### 8.4.1.4 Abnormal Conditions

If the NG-RAN node receives at least one PDU Session ID included in the *PDU Session Resource Handover List* IE without at least one valid associated GTP tunnel address pair (in either UL or DL), then the NG-RAN node shall consider it as a logical error and act as described in subclause 10.4. A GTP tunnel address pair is considered valid if both the *GTP-TEID* IE and the *Endpoint IP Address* IE are present.

# 8.4.2 Handover Resource Allocation

## 8.4.2.1 General

The purpose of the Handover Resource Allocation procedure is to reserve resources at the target NG-RAN node for the handover of a UE.

## 8.4.2.2 Successful Operation



Figure 8.4.2.2-1: Handover resource allocation: successful operation

The AMF initiates the procedure by sending the HANDOVER REQUEST message to the target NG-RAN node.

If the *Masked IMEISV* IE is contained in the HANDOVER REQUEST message the target NG-RAN node shall, if supported, use it to determine the characteristics of the UE for subsequent handling.

Upon receipt of the HANDOVER REQUEST message the target NG-RAN node shall

- attempt to execute the requested PDU session configuration and associated security;
- store the received UE Aggregate Maximum Bit Rate in the UE context, and use the received UE Aggregate Maximum Bit Rate for all Non-GBR QoS flows for the concerned UE as specified in TS 23.501 [9];
- store the received Mobility Restriction List in the UE context;
- store the received UE Security Capabilities in the UE context;
- store the received Security Context in the UE context and take it into use as defined in TS 33.501 [13].

Upon reception of the *UE History Information* IE, which is included within the *Source to Target Transparent Container* IE of the HANDOVER REQUEST message, the target NG-RAN node shall collect the information defined as mandatory in the *UE History Information* IE and shall, if supported, collect the information defined as optional in the *UE History Information* IE, for as long as the UE stays in one of its cells, and store the collected information to be used for future handover preparations.

Upon receiving the *PDU Session Resource Setup List* IE contained in the HANDOVER REQUEST message, the target NG-RAN node shall behave the same as defined in the PDU Session Resource Setup procedure. The target NG-RAN node shall report to the AMF in the HANDOVER REQUEST ACKNOWLEDGE message the result for each PDU session resource requested to be setup. In particular, for each PDU session resource successfully setup, it shall include the *Handover Request Acknowledge Transfer* IE containing the following information:

- The list of QoS flows which have been successfully established in the QoS Flow Setup Response List IE.
- The Data Forwarding Accepted IE if the data forwarding for the QoS flow is accepted.
- The list of QoS flows which have failed to be established, if any, in the QoS Flow Failed to Setup List IE.
- The UP transport layer information to be used for the PDU session.
- The security result associated to the PDU session.

For each PDU session resource which failed to be setup, the *Handover Resource Allocation Unsuccessful Transfer* IE shall be included in the HANDOVER REQUEST ACKNOWLEDGE message containing a cause value that should be precise enough to enable the SMF to know the reason for the unsuccessful establishment.

Upon reception of the HANDOVER REQUEST ACKNOWLEDGE message the AMF shall, for each PDU session indicated in the *PDU Session ID* IE, transfer transparently the *Handover Request Acknowledge Transfer* IE or *Handover Resource Allocation Unsuccessful Transfer* IE to the SMF associated with the concerned PDU session.

If the HANDOVER REQUEST message contains the *Data Forwarding Not Possible* IE associated with a given PDU session within the *Handover Request Transfer* IE set to "data forwarding not possible", the target NG-RAN node may not include the *DL Forwarding UP TNL Information* IE and for intra-system handover the *Data Forwarding Response DRB List* IE within the *Handover Request Acknowledge Transfer* IE in the HANDOVER REQUEST ACKNOWLEDGE message for that PDU session.

In case of intra-system handover, if the target NG-RAN node accepts the downlink data forwarding for at least one QoS flow for which the *DL Forwarding* IE is set to "DL forwarding proposed", it may include the *DL Forwarding UP TNL Information* IE in the *Handover Request Acknowledge Transfer* IE as forwarding tunnel for the QoS flows listed in the *QoS Flow Setup Response List* IE of the HANDOVER REQUEST ACKNOWLEDGE message.

In case of intra-system handover, if the target NG-RAN node accepts the uplink data forwarding for at least one QoS flow for which the *UL Forwarding* IE is set to "UL forwarding proposed", it may include the *UL Forwarding UP TNL Information* IE in the *Handover Request Acknowledge Transfer* IE for the PDU session within the *PDU Session Resource Admitted List* IE of the HANDOVER REQUEST ACKNOWLEDGE message.

In case of intra-system handover, for each PDU session for which the *Additional DL UP TNL Information for HO List* IE is included in the *Handover Request Acknowledge Transfer* IE of the HANDOVER REQUEST ACKNOWLEDGE

message, the SMF shall consider the included *Additional DL NG-U UP TNL Information* IE as the downlink termination point for the associated flows indicated in the *Additional QoS Flow Setup Response List* IE for this PDU session split in different tunnels and shall consider the *Additional DL Forwarding UP TNL Information* IE, if included, as the forwarding tunnel associated to these QoS flows.

In case of intra-system handover, for each PDU session for which the *Additional UL Forwarding UP TNL Information* IE is included in the *Handover Request Acknowledge Transfer* IE of the HANDOVER REQUEST ACKNOWLEDGE message, the SMF shall consider it as the termination points for the uplink forwarding tunnels for this PDU session split in different tunnels.

In case of intra-system handover, if the target NG-RAN node accepts the data forwarding for a successfully configured DRB, the target NG-RAN node may include the *DL Forwarding UP TNL Information* IE for the DRB within the *Data Forwarding Response DRB List* IE within *Handover Request Acknowledge Transfer* IE of the HANDOVER REQUEST ACKNOWLEDGE message.

If the HANDOVER REQUEST ACKNOWLEDGE message contains the *UL Forwarding UP TNL Information* IE for a given DRB in the *Data Forwarding Response DRB List* IE within the *Handover Request Acknowledge Transfer* IE, it indicates the target NG-RAN node has requested the forwarding of uplink data for the DRB.

In case of inter-system handover from E-UTRAN, the target NG-RAN node includes the *Data Forwarding Accepted* IE for each QoS flow that the *DL Forwarding* IE is set to "DL forwarding proposed" for the corresponding E-RAB in the *Source NG-RAN Node to Target NG-RAN Node Transparent Container* IE and that the target NG-RAN node has admitted the proposed forwarding of downlink data for the QoS flow. If the target NG-RAN node accepts the downlink data forwarding for at least one QoS flow of an admitted PDU session it shall include the *DL Forwarding UP TNL Information* IE in the *PDU Session Resource Setup Response Transfer* IE for that PDU session within the *PDU Session Resource Setup Res* 

The target NG-RAN node shall use the information in the *Mobility Restriction List* IE if present in the HANDOVER REQUEST message to

- determine a target for subsequent mobility action for which the target NG-RAN node provides information about the target of the mobility action towards the UE;
- select a proper SCG during dual connectivity operation;
- assign proper RNA(s) for the UE when moving the UE to RRC\_INACTIVE state.

If the *Mobility Restriction List* IE is not contained in the HANDOVER REQUEST message, the target NG-RAN node shall consider that no roaming and no access restriction apply to the UE. The target NG-RAN node shall also consider that no roaming and no access restriction apply to the UE when:

- one of the QoS flows includes a particular ARP value (TS 23.501 [9]).

If the *Trace Activation* IE is included in the HANDOVER REQUEST message the target NG-RAN node shall, if supported, initiate the requested trace function as described in TS 32.422 [11].

If the *Location Reporting Request Type* IE is included in the HANDOVER REQUEST message, the target NG-RAN node should perform the requested location reporting functionality for the UE as described in subclause 8.12.

If the *Core Network Assistance Information for RRC INACTIVE* IE is included in the HANDOVER REQUEST message, the target NG-RAN node shall, if supported, store this information in the UE context and use it for e.g. the RRC\_INACTIVE state decision and RNA configuration for the UE and RAN paging if any for a UE in RRC\_INACTIVE state, as specified in TS 38.300 [8].

If the *CN Assisted RAN Parameters Tuning* IE is included in the HANDOVER REQUEST message, the NG-RAN node may use it as described in TS 23.501 [9].

If the *New Security Context Indicator* IE is included in the HANDOVER REQUEST message, the target NG-RAN node shall use the information as specified in TS 33.501 [13].

If the *NASC* IE is included in the HANDOVER REQUEST message, the target NG-RAN node shall use it towards the UE as specified in TS 33.501 [13].

If the *RRC Inactive Transition Report Request* IE is included in the HANDOVER REQUEST message, the NG-RAN node shall, if supported, store this information in the UE context.

If the *Redirection for Voice EPS Fallback* IE is included in the HANDOVER REQUEST message, the NG-RAN node shall, if supported, store it and use it in a subsequent decision of EPS fallback for voice as specified in TS 23.502 [10].

After all necessary resources for the admitted PDU session resources have been allocated, the target NG-RAN node shall generate the HANDOVER REQUEST ACKNOWLEDGE message.

### **Interactions with RRC Inactive Transition Report procedure:**

If the *RRC Inactive Transition Report Request* IE is included in the HANDOVER REQUEST message and set to "subsequent state transition report", the NG-RAN node shall, if supported, send the RRC INACTIVE TRANSITION REPORT message to the AMF to report the RRC state of the UE when the UE enters or leaves RRC INACTIVE state.

# 8.4.2.3 Unsuccessful Operation



Figure 8.4.2.3-1: Handover resource allocation: unsuccessful operation

If the target NG-RAN node does not admit any of the PDU session resources, or a failure occurs during the Handover Preparation, it shall send the HANDOVER FAILURE message to the AMF with an appropriate cause value.

#### 8.4.2.4 Abnormal Conditions

If the supported algorithms for encryption defined in the *Encryption Algorithms* IE in the *UE Security Capabilities* IE, plus the mandated support of EEA0 and NEA0 in all UEs (TS 33.501 [13]), do not match any allowed algorithms defined in the configured list of allowed encryption algorithms in the NG-RAN node (TS 33.501 [13]), the target NG-RAN node shall reject the procedure using the HANDOVER FAILURE message.

If the supported algorithms for integrity defined in the *Integrity Protection Algorithms* IE in the *UE Security Capabilities* IE, plus the mandated support of the EIAO and NIAO algorithm in all UEs (TS 33.501 [13]), do not match any allowed algorithms defined in the configured list of allowed integrity protection algorithms in the NG-RAN node (TS 33.501 [13]), the target NG-RAN node shall reject the procedure using the HANDOVER FAILURE message.

If the target NG-RAN node receives a HANDOVER REQUEST message which does not contain the *Mobility Restriction List* IE, and the serving PLMN cannot be determined otherwise by the NG-RAN node, the target NG-RAN node shall reject the procedure using the HANDOVER FAILURE message.

If the target NG-RAN node receives a HANDOVER REQUEST message containing the *Mobility Restriction List* IE, and the serving PLMN indicated is not supported by the target cell, the target NG-RAN node shall reject the procedure using the HANDOVER FAILURE message.

## 8.4.3 Handover Notification

#### 8.4.3.1 General

The purpose of the Handover Notification procedure is to indicate to the AMF that the UE has arrived to the target cell and the NG-based handover has been successfully completed.

# 8.4.3.2 Successful Operation



Figure 8.4.3.2-1: Handover notification

The target NG-RAN node shall send the HANDOVER NOTIFY message to the AMF when the UE has been identified in the target cell and the NG-based handover has been successfully completed.

#### 8.4.3.3 Abnormal Conditions

Void.

# 8.4.4 Path Switch Request

#### 8.4.4.1 General

The purpose of the Path Switch Request procedure is to establish a UE associated signalling connection to the 5GC and, if applicable, to request the switch of the downlink termination point of the NG-U transport bearer towards a new termination point.

## 8.4.4.2 Successful Operation



Figure 8.4.4.2-1: Path switch request: successful operation

The NG-RAN node initiates the procedure by sending the PATH SWITCH REQUEST message to the AMF. Upon reception of the PATH SWITCH REQUEST message the AMF shall, for each PDU session indicated in the *PDU Session ID* IE, transparently transfer the *Path Switch Request Transfer* IE to the SMF associated with the concerned PDU session.

After all necessary updates including the UP path switch have been successfully completed in the 5GC for at least one of the PDU session resources included in the PATH SWITCH REQUEST, the AMF shall send the PATH SWITCH REQUEST ACKNOWLEDGE message to the NG-RAN node and the procedure ends.

The list of accepted QoS flows shall be included in the PATH SWITCH REQUEST message within the *Path Switch Request Transfer* IE. The SMF shall handle this information as specified in TS 23.502 [10].

For each PDU session for which the *Additional DL QoS Flow per TNL Information* IE is included in the *Path Switch Request Transfer* IE of the PATH SWITCH REQUEST message, the SMF may use each included UP transport layer

information as the downlink termination point for the included associated QoS flows for this PDU session split in different tunnels.

The list of PDU sessions which failed to be setup, if any, shall be included in the PATH SWITCH REQUEST message within the *Path Switch Request Setup Failed Transfer* IE. The AMF shall handle this information as specified in TS 23.502 [10].

For each PDU session for which the *User Plane Security Information* IE is included in the *Path Switch Request Transfer* IE of the PATH SWITCH REQUEST message, the SMF shall behave as specified in TS 33.501 [13] and may send back the *Security Indication* IE within the *Path Switch Request Acknowledge Transfer* IE of the PATH SWITCH REQUEST ACKNOWLEDGE message.

For each PDU session for which the *DL NG-U TNL Information Reused* IE set to "true" is included in the *Path Switch Request Transfer* IE of the PATH SWITCH REQUEST message, the SMF shall, if supported, consider that the DL TNL information contained in the *DL NG-U UP TNL Information* IE has been reused.

If the *Security Indication* IE is included within the *Path Switch Request Acknowledge Transfer* IE of the PATH SWITCH REQUEST ACKNOWLEDGE message, the NG-RAN node shall behave as specified in TS 33.501 [13].

If the *UL NG-U UP TNL Information* IE is included within the *Path Switch Request Acknowledge Transfer* IE of the PATH SWITCH REQUEST ACKNOWLEDGE message, the NG-RAN node shall store this information and use it as the uplink termination point for the user plane data for this PDU session.

If the *Additional NG-U UP TNL Information* IE is included within the *Path Switch Request Acknowledge Transfer* IE of the PATH SWITCH REQUEST ACKNOWLEDGE message, the NG-RAN node shall store this information and use the included *UL NG-U UP TNL Information* IE(s) as the uplink termination point(s) of the user plane data for this PDU session split in different tunnel.

If the *Core Network Assistance Information for RRC INACTIVE* IE is included in the PATH SWITCH REQUEST ACKNOWLEDGE message, the NG-RAN node shall, if supported, store this information in the UE context and use it for e.g. the RRC\_INACTIVE state decision and RNA configuration for the UE and RAN paging if any for a UE in RRC\_INACTIVE state, as specified in TS 38.300 [8].

If the *CN Assisted RAN Parameters Tuning* IE is included in the PATH SWITCH REQUEST ACKNOWLEDGE message, the NG-RAN node may use it as described in TS 23.501 [9].

If the RRC Inactive Transition Report Request IE is included in the PATH SWITCH REQUEST ACKNOWLEDGE message, the NG-RAN node shall, if supported, store this information in the UE context.

If the *New Security Context Indicator* IE is included in the PATH SWITCH REQUEST ACKNOWLEDGE message, the NG-RAN node shall use the information as specified in TS 33.501 [13].

Upon reception of the PATH SWITCH REQUEST ACKNOWLEDGE message the NG-RAN node shall store the received *Security Context* IE in the UE context and the NG-RAN node shall use it as specified in TS 33.501 [13].

If the *UE Security Capabilities* IE is included in the PATH SWITCH REQUEST ACKNOWLEDGE message, the NG-RAN node shall handle it accordingly (TS 33.501 [13]).

If the *Redirection for Voice EPS Fallback* IE is included in the PATH SWITCH REQUEST ACKNOWLEDGE message, the NG-RAN node shall, if supported, store it and use it in a subsequent decision of EPS fallback for voice as specified in TS 23.502 [10].

If the *PDU Session Resource Released List* IE is included in the PATH SWITCH REQUEST ACKNOWLEDGE message, the NG-RAN node shall release the corresponding QoS flows and regard the PDU session(s) indicated in the *PDU Session Resource Released List* IE as being released. The appropriate cause value for each PDU session released is included in the *Path Switch Request Unsuccessful Transfer* IE contained in the PATH SWITCH REQUEST ACKNOWLEDGE message.

#### **Interactions with RRC Inactive Transition Report procedure:**

If the *RRC Inactive Transition Report Request* IE is included in the PATH SWITCH REQUEST ACKNOWLEDGE message and set to "single RRC connected state report" and the UE is in RRC\_CONNECTED state, the NG-RAN node shall, if supported, send one RRC INACTIVE TRANSITION REPORT message to the AMF to report the RRC state of the UE.

If the *RRC Inactive Transition Report Request* IE is included in the PATH SWITCH REQUEST ACKNOWLEDGE message and set to "single RRC connected state report" and the UE is in RRC\_INACTIVE state, the NG-RAN node shall, if supported, send to the AMF one RRC INACTIVE TRANSITION REPORT message plus one subsequent RRC INACTIVE TRANSITION REPORT message when the RRC state transitions to RRC\_CONNECTED state.

If the RRC Inactive Transition Report Request IE is included in the PATH SWITCH REQUEST ACKNOWLEDGE message and set to "subsequent state transition report", the NG-RAN node shall, if supported, send one RRC INACTIVE TRANSITION REPORT message to the AMF to report the RRC state of the UE and subsequent RRC INACTIVE TRANSITION REPORT messages to report the RRC state of the UE when the UE enters or leaves RRC\_INACTIVE state.

#### 8.4.4.3 Unsuccessful Operation



Figure 8.4.4.3-1: Path switch request: unsuccessful operation

If the 5GC fails to switch the downlink termination point of the NG-U transport bearer towards a new termination point for all PDU session resources, the AMF shall send the PATH SWITCH REQUEST FAILURE message to the NG-RAN node.

The NG-RAN node shall release the corresponding QoS flows and regard the PDU session(s) indicated in the *PDU* Session Resource Released List IE included in the PATH SWITCH REQUEST FAILURE message as being released.

The appropriate cause value for each PDU session released is included in the *Path Switch Request Unsuccessful Transfer* IE contained in the PATH SWITCH REQUEST FAILURE message.

#### 8.4.4.4 Abnormal Conditions

If the AMF receives a PATH SWITCH REQUEST message containing several *PDU Session ID* IEs (in the *PDU Session Resource to be Switched in Downlink List* IE) set to the same value, the AMF shall send the PATH SWITCH REQUEST FAILURE message to the NG-RAN node.

NOTE: As an exception, the AMF generates the Path Switch Request Unsuccessful Transfer IE.

## 8.4.5 Handover Cancellation

#### 8.4.5.1 General

The purpose of the Handover Cancellation procedure is to enable a source NG-RAN node to cancel an ongoing handover preparation or an already prepared handover. The procedure uses UE-associated signalling.

# 8.4.5.2 Successful Operation



Figure 8.4.5.2-1: Handover cancel: successful operation

The source NG-RAN node initiates the procedure by sending a HANDOVER CANCEL message to the AMF.

# 8.4.5.3 Unsuccessful Operation

Not applicable.

#### 8.4.5.4 Abnormal Conditions

If the source NG-RAN node becomes aware of the fact that an expected HANDOVER CANCEL ACKNOWLEDGE message is missing, the source NG-RAN node shall consider the Handover Cancellation procedure as successfully terminated.

# 8.4.6 Uplink RAN Status Transfer

# 8.4.6.1 General

The purpose of the Uplink RAN Status Transfer procedure is to enable lossless NG-based handover. The procedure uses UE-associated signalling.

## 8.4.6.2 Successful Operation



Figure 8.4.6.2-1: Uplink RAN status transfer

The source NG-RAN node initiates the procedure by stopping the assigning of PDCP-SNs to downlink SDUs and sending the UPLINK RAN STATUS TRANSFER message to the AMF at the point in time when it considers the transmitter/receiver status to be frozen.

For each DRB for which PDCP-SN and HFN status preservation applies, the source NG-RAN node shall include the *DRB ID* IE, the *UL COUNT Value* IE and the *DL COUNT Value* IE within the *DRBs Subject to Status Transfer List* IE in the *RAN Status Transfer Transparent Container* IE of the UPLINK RAN STATUS TRANSFER message.

The source NG-RAN node may also include in the UPLINK RAN STATUS TRANSFER message the missing and the received uplink SDUs in the *Receive Status of UL PDCP SDUs* IE for each DRB for which the source NG-RAN node has accepted the request from the target NG-RAN node for uplink forwarding.

#### 8.4.6.3 Abnormal Conditions

Void.

# 8.4.7 Downlink RAN Status Transfer

#### 8.4.7.1 General

The purpose of the Downlink RAN Status Transfer procedure is to is to enable lossless NG-based handover. The procedure uses UE-associated signalling.

### 8.4.7.2 Successful Operation



Figure 8.4.7.2-1: Downlink RAN status transfer

The AMF initiates the procedure by sending the DOWNLINK RAN STATUS TRANSFER message to the target NG-RAN node. The target NG-RAN node using Full Configuration for this handover as per TS 38.300 [8] shall ignore the information received in this message.

For each DRB in the *DRBs Subject to Status Transfer List* IE within the *RAN Status Transfer Transparent Container* IE, the target NG-RAN node shall not deliver any uplink packet which has a PDCP-SN lower than the value of the *UL Count Value* IE.

For each DRB in the *DRBs Subject to Status Transfer List* IE within the *RAN Status Transfer Transparent Container* IE, the target NG-RAN node shall use the value of the *DL COUNT Value* IE for the first downlink packet for which there is no PDCP-SN yet assigned.

If the *Receive Status of UL PDCP SDUs* IE is included for at least one DRB in the *RAN Status Transfer Transparent Container* IE of the DOWNLINK RAN STATUS TRANSFER message, the target NG-RAN node may use it in a Status Report message sent to the UE over the radio interface.

#### 8.4.7.3 Abnormal Conditions

If the target NG-RAN node receives this message for a UE for which no prepared handover exists at the target NG-RAN node, the target NG-RAN node shall ignore the message.

# 8.5 Paging Procedures

# 8.5.1 Paging

# 8.5.1.1 General

The purpose of the Paging procedure is to enable the AMF to page a UE in the specific NG-RAN node.

# 8.5.1.2 Successful Operation



Figure 8.5.1.2-1: Paging

The AMF initiates the Paging procedure by sending the PAGING message to the NG-RAN node.

At the reception of the PAGING message, the NG-RAN node shall perform paging of the UE in cells which belong to tracking areas as indicated in the *TAI List for Paging* IE.

If the *Paging DRX* IE is included in the PAGING message, the NG-RAN node shall use it according to TS 38.304 [12] and TS 36.304 [29].

For each cell that belongs to any of the tracking areas indicated in the *TAI List for Paging* IE, the NG-RAN node shall generate one page on the radio interface.

If the *Paging Priority* IE is included in the PAGING message, the NG-RAN node may use it according to TS 23.501 [9].

If the *UE Radio Capability for Paging* IE is included in the PAGING message, the NG-RAN node may use it to apply specific paging schemes.

If the *Assistance Data for Recommended Cells* IE is included in the *Assistance Data for Paging* IE it may be used, together with the *Paging Attempt Information* IE if also present, according to TS 38.300 [8].

If the *Next Paging Area Scope* IE is included in the *Paging Attempt Information* IE it may be used for paging the UE according to TS 38.300 [8].

If the *Paging Origin* IE is included in the PAGING message, the NG-RAN node shall transfer it to the UE according to TS 38.331 [18] and TS 36.331 [21].

#### 8.5.1.3 Abnormal Conditions

Void.

# 8.6 Transport of NAS Messages Procedures

# 8.6.1 Initial UE Message

# 8.6.1.1 General

The Initial UE Message procedure is used when the NG-RAN node has received from the radio interface the first uplink NAS message transmitted on an RRC connection to be forwarded to an AMF.

# 8.6.1.2 Successful Operation



Figure 8.6.1.2-1: Initial UE message

The NG-RAN node initiates the procedure by sending an INITIAL UE MESSAGE message to the AMF. The NG-RAN node shall allocate a unique RAN UE NGAP ID to be used for the UE and the NG-RAN node shall include this identity in the INITIAL UE MESSAGE message.

The NAS-PDU IE contains a UE – AMF message that is transferred without interpretation in the NG-RAN node.

In case of network sharing, the selected PLMN is indicated by the *PLMN Identity* IE within the *TAI* IE included in the INITIAL UE MESSAGE message.

When the NG-RAN node has received from the radio interface the 5G-S-TMSI IE, it shall include it in the INITIAL UE MESSAGE message.

If the *AMF Set ID* IE is included in the INITIAL UE MESSAGE message this indicates that the message is a rerouted message and the AMF shall, if supported, use the IE as described in TS 23.502 [10].

If the *UE Context Request* IE is included in the INITIAL UE MESSAGE message the AMF shall trigger an Initial Context Setup procedure towards the NG-RAN node.

If the *Allowed NSSAI* IE is included in the INITIAL UE MESSAGE message the AMF shall use the IE as defined in TS 23.502 [10].

If the *Source to Target AMF Information Reroute* IE is included in the INITIAL UE MESSAGE message the AMF shall use the IE as defined in TS 23.502 [10].

# 8.6.1.3 Abnormal Conditions

If the 5G-S-TMSI is not received by the AMF in the INITIAL UE MESSAGE message whereas expected, the AMF shall consider the procedure as failed.

# 8.6.2 Downlink NAS Transport

## 8.6.2.1 General

The Downlink NAS Transport procedure is used when the AMF only needs to send a NAS message transparently via the NG-RAN node to the UE, and a UE-associated logical NG-connection exists for the UE or the AMF has received the *RAN UE NGAP ID* IE in an INITIAL UE MESSAGE message or if the NG-RAN node has already initiated a UE-associated logical NG-connection by sending an INITIAL UE MESSAGE message via another NG interface instance.

# 8.6.2.2 Successful Operation



Figure 8.6.2.2-1: Downlink NAS transport

The AMF initiates the procedure by sending a DOWNLINK NAS TRANSPORT message to the NG-RAN node. If the UE-associated logical NG-connection is not established, the AMF shall allocate a unique AMF UE NGAP ID to be used for the UE and include that in the DOWNLINK NAS TRANSPORT message; by receiving the *AMF UE NGAP ID* IE in the DOWNLINK NAS TRANSPORT message, the NG-RAN node establishes the UE-associated logical NG-connection.

If the *RAN Paging Priority* IE is included in the DOWNLINK NAS TRANSPORT message, the NG-RAN node may use it to determine a priority for paging the UE in RRC\_INACTIVE state.

The NAS-PDU IE contains an AMF – UE message that is transferred without interpretation in the NG-RAN node.

If the *Mobility Restriction List* IE is contained in the DOWNLINK NAS TRANSPORT message, the NG-RAN node shall overwrite any previously stored mobility restriction information in the UE context. The NG-RAN node shall use the information in the *Mobility Restriction List* IE if present in the DOWNLINK NAS TRANSPORT message to:

- determine a target for subsequent mobility action for which the NG-RAN node provides information about the target of the mobility action towards the UE;
- select a proper SCG during dual connectivity operation;
- assign proper RNA(s) for the UE when moving the UE to RRC INACTIVE state.

If the *Mobility Restriction List* IE is not contained in the DOWNLINK NAS TRANSPORT message and there is no previously stored mobility restriction information, the NG-RAN node shall consider that no roaming and no access restriction apply to the UE.

If the *Index to RAT/Frequency Selection Priority* IE is included in the DOWNLINK NAS TRANSPORT message, the NG-RAN node shall, if supported, use it as defined in TS 23.501 [9].

The *UE Aggregate Maximum Bit Rate* IE should be sent to the NG-RAN node if the AMF has not sent it previously. If it is included in the DOWNLINK NAS TRANSPORT message, the NG-RAN node shall store the UE Aggregate Maximum Bit Rate in the UE context, and use the received UE Aggregate Maximum Bit Rate for all Non-GBR QoS flows for the concerned UE as specified in TS 23.501 [9].

If the *Old AMF* IE is included in the DOWNLINK NAS TRANSPORT message, the NG-RAN node shall consider that this UE-associated logical NG-connection was redirected to this AMF from another AMF identified by the *Old AMF* IE.

# Interactions with Initial UE Message procedure:

The NG-RAN node shall use the AMF UE NGAP ID IE and RAN UE NGAP ID IE received in the DOWNLINK NAS TRANSPORT message as identification of the logical connection even if the RAN UE NGAP ID IE had been allocated in an INITIAL UE MESSAGE message sent over a different NG interface instance.

#### 8.6.2.3 Abnormal Conditions

Void.

# 8.6.3 Uplink NAS Transport

#### 8.6.3.1 General

The Uplink NAS Transport procedure is used when the NG-RAN node has received from the radio interface a NAS message to be forwarded to the AMF to which a UE-associated logical NG-connection for the UE exists.

# 8.6.3.2 Successful Operation



Figure 8.6.3.2-1: Uplink NAS transport

The NG-RAN node initiates the procedure by sending an UPLINK NAS TRANSPORT message to the AMF.

The NAS-PDU IE contains a UE – AMF message that is transferred without interpretation in the NG-RAN node.

#### 8.6.3.3 Abnormal Conditions

Void.

# 8.6.4 NAS Non Delivery Indication

## 8.6.4.1 General

The NAS Non Delivery Indication procedure is used when the NG-RAN node decides not to start the delivery of a NAS message that has been received over a UE-associated logical NG-connection or the NG-RAN node is unable to ensure that the message has been received by the UE.

## 8.6.4.2 Successful Operation



Figure 8.6.4.2-1: NAS non delivery indication

The NG-RAN node initiates the procedure by sending a NAS NON DELIVERY INDICATION message to the AMF. The NG-RAN node shall report the non-delivery of a NAS message by including the non-delivered NAS message within the *NAS-PDU* IE and an appropriate cause value within the *Cause* IE, e.g., "NG intra system handover triggered", "NG inter system handover triggered" or "Xn handover triggered".

#### 8.6.4.3 Abnormal Conditions

Void.

# 8.6.5 Reroute NAS Request

#### 8.6.5.1 General

The purpose of the Reroute NAS Request procedure is to enable the AMF to request for a rerouting of the INITIAL UE MESSAGE message to another AMF.

# 8.6.5.2 Successful Operation



Figure 8.6.5.2-1: Reroute NAS request

The AMF initiates the procedure by sending a REROUTE NAS REQUEST message to the NG-RAN node. The NG-RAN node shall, if supported, reroute the INITIAL UE MESSAGE message to an AMF indicated by the *AMF Set ID* IE as described in TS 23.501 [9].

If the *Allowed NSSAI* IE is included in the REROUTE NAS REQUEST message, then the NG-RAN node shall propagate it in the rerouted INITIAL UE MESSAGE message as defined in TS 23.502 [10].

If the *Source to Target AMF Information Reroute* IE is included in the REROUTE NAS REQUEST message, then the NG-RAN node shall propagate it in the rerouted INITIAL UE MESSAGE message as defined in TS 23.502 [10].

#### 8.6.5.3 Abnormal Conditions

Void.

# 8.7 Interface Management Procedures

# 8.7.1 NG Setup

#### 8.7.1.1 General

The purpose of the NG Setup procedure is to exchange application level data needed for the NG-RAN node and the AMF to correctly interoperate on the NG-C interface. This procedure shall be the first NGAP procedure triggered after the TNL association has become operational. The procedure uses non-UE associated signalling.

This procedure erases any existing application level configuration data in the two nodes, replaces it by the one received and clears AMF overload state information at the NG-RAN node. If the NG-RAN node and AMF do not agree on retaining the UE contexts this procedure also re-initialises the NGAP UE-related contexts (if any) and erases all related signalling connections in the two nodes like an NG Reset procedure would do.

# 8.7.1.2 Successful Operation




Figure 8.7.1.2-1: NG setup: successful operation

The NG-RAN node initiates the procedure by sending an NG SETUP REQUEST message including the appropriate data to the AMF. The AMF responds with an NG SETUP RESPONSE message including the appropriate data.

If the *UE Retention Information* IE set to "ues-retained" is included in the NG SETUP REQUEST message, the AMF may accept the proposal to retain the existing UE related contexts and signalling connections by including the *UE Retention Information* IE set to "ues-retained" in the NG SETUP RESPONSE message.

The AMF shall include the *Backup AMF Name* IE, if available, in the *Served GUAMI List* IE in the NG SETUP RESPONSE message. The NG-RAN node shall, if supported, consider the AMF as indicated by the *Backup AMF Name* IE when performing AMF reselection, as specified in TS 23.501 [9].

# 8.7.1.3 Unsuccessful Operation




Figure 8.7.1.3-1: NG setup: unsuccessful operation

If the AMF cannot accept the setup, it should respond with an NG SETUP FAILURE message and appropriate cause value.

If the NG SETUP FAILURE message includes the *Time to Wait* IE, the NG-RAN node shall wait at least for the indicated time before reinitiating the NG Setup procedure towards the same AMF.

#### 8.7.1.4 Abnormal Conditions

If the NG-RAN node initiates the procedure by sending an NG SETUP REQUEST message including the *PLMN Identity* IEs and none of the PLMNs provided by the NG-RAN node is identified by the AMF, then the AMF shall reject the NG Setup procedure with an appropriate cause value.

# 8.7.2 RAN Configuration Update

#### 8.7.2.1 General

The purpose of the RAN Configuration Update procedure is to update application level configuration data needed for the NG-RAN node and the AMF to interoperate correctly on the NG-C interface. This procedure does not affect existing UE-related contexts, if any.

# 8.7.2.2 Successful Operation




Figure 8.7.2.2-1: RAN configuration update: successful operation

The NG-RAN node initiates the procedure by sending a RAN CONFIGURATION UPDATE message to the AMF including an appropriate set of updated configuration data that it has just taken into operational use. The AMF responds with a RAN CONFIGURATION UPDATE ACKNOWLEDGE message to acknowledge that it successfully updated the configuration data. If an information element is not included in the RAN CONFIGURATION UPDATE message, the AMF shall interpret that the corresponding configuration data is not changed and shall continue to operate the NG-C interface with the existing related configuration data.

If the *Supported TA List* IE is included in the RAN CONFIGURATION UPDATE message, the AMF shall overwrite the whole list of supported TAs and the corresponding list of supported slices for each TA, and use them for subsequent registration area management of the UE.

If the *Global RAN Node ID* IE is included in the RAN CONFIGURATION UPDATE message, the AMF shall associate the TNLA to the NG-C interface instance using the Global RAN Node ID.

If the RAN CONFIGURATION UPDATE message includes NG-RAN TNL Association to Remove List IE, and the Endpoint IP Address IE and the Port Number IE for both TNL endpoints of the TNL association(s) are included in the NG-RAN TNL Association to Remove List IE, the AMF shall, if supported, consider that the TNL association(s) indicated by both received TNL endpoints will be removed by the NG-RAN node. If the Endpoint IP Address IE, or the Endpoint IP Address IE and the Port Number IE for one or both of the TNL endpoints is included in the NG-RAN TNL Association to Remove List IE in RAN CONFIGURATION UPDATE message, the AMF shall, if supported, consider that the TNL association(s) indicated by the received endpoint IP address(es) will be removed by the NG-RAN node.

## 8.7.2.3 Unsuccessful Operation



Figure 8.7.2.3-1: RAN configuration update: unsuccessful operation

If the AMF cannot accept the update, it shall respond with a RAN CONFIGURATION UPDATE FAILURE message and appropriate cause value.

If the *Time to Wait* IE is included in the RAN CONFIGURATION UPDATE FAILURE message, the NG-RAN node shall wait at least for the indicated time before reinitiating the RAN Configuration Update procedure towards the same AMF.

#### 8.7.2.4 Abnormal Conditions

If the NG-RAN node, after initiating the RAN Configuration Update procedure, receives neither a RAN CONFIGURATION UPDATE ACKOWLEDGE nor a RAN CONFIGURATION UPDATE FAILURE message, the NG-RAN node may reinitiate a further RAN Configuration Update procedure towards the same AMF, provided that the content of the new RAN CONFIGURATION UPDATE message is identical to the content of the previously unacknowledged RAN CONFIGURATION UPDATE message.

# 8.7.3 AMF Configuration Update

#### 8.7.3.1 General

The purpose of the AMF Configuration Update procedure is to update application level configuration data needed for the NG-RAN node and AMF to interoperate correctly on the NG-C interface. This procedure does not affect existing UE-related contexts, if any.

# 8.7.3.2 Successful Operation




Figure 8.7.3.2-1: AMF configuration update: successful operation

The AMF initiates the procedure by sending an AMF CONFIGURATION UPDATE message including the appropriate updated configuration data to the NG-RAN node. The NG-RAN node responds with an AMF CONFIGURATION UPDATE ACKNOWLEDGE message to acknowledge that it successfully updated the configuration data. If an information element is not included in the AMF CONFIGURATION UPDATE message, the NG-RAN node shall interpret that the corresponding configuration data is not changed and shall continue to operate the NG-C interface with the existing related configuration data.

If the *PLMN Support List* IE is included in the AMF CONFIGURATION UPDATE message, the NG-RAN node shall overwrite the whole list of supported PLMN Identities and the corresponding list of AMF slices for each PLMN Identity and use the received values for further network slice selection and AMF selection.

If the *AMF TNL Association to Add List* IE is included in the AMF CONFIGURATION UPDATE message, the NG-RAN node shall, if supported, use it to establish the TNL association(s) with the AMF. The NG-RAN node shall report to the AMF, in the AMF CONFIGURATION UPDATE ACKNOWLEDGE message, the successful establishment of the TNL association(s) with the AMF as follows:

- A list of successfully established TNL associations shall be included in the AMF TNL Association Setup List IE;
- A list of TNL associations that failed to be established shall be included in the AMF TNL Association Failed to Setup List IE.

If the AMF CONFIGURATION UPDATE message includes AMF TNL Association to Remove List IE, and the Endpoint IP Address and the Port Number IE for both TNL endpoints of the TNL association(s) is included in the AMF TNL Association to Remove List IE, the NG-RAN node shall, if supported, initiate removal of the TNL association(s) indicated by both received TNL endpoints towards the AMF. If the Endpoint IP Address IE, or the Endpoint IP Address IE and the Port Number IE for one or both of the TNL endpoints is included in the AMF TNL Association to Remove List IE, the NG-RAN node shall, if supported, initiate removal of the TNL association(s) indicated by the received endpoint IP address(es). If the AMF Name IE is included in the AMF CONFIGURATION UPDATE message, the NG-RAN node shall overwrite the previously stored AMF name and use it to identify the AMF.

If the *Served GUAMI List* IE is included in the AMF CONFIGURATION UPDATE message, the NG-RAN node shall overwrite the whole list of GUAMIs served by the AMF by the new list and use the received values for further AMF management as defined in TS 23.501 [9].

If the *Relative AMF Capacity* IE is included in the AMF CONFIGURATION UPDATE message, the NG-RAN node may use it as defined in TS 23.501 [9].

If the AMF TNL Association to Update List IE is included in the AMF CONFIGURATION UPDATE message the NG-RAN node shall, if supported, update the TNL association(s) indicated by the received AMF Transport Layer information towards the AMF.

If the TNL Association Usage IE or the TNL Address Weight Factor IE is included in the AMF TNL Association to Add List IE or the AMF TNL Association to Update List IE, the NG-RAN node shall, if supported, consider it as defined in TS 23.502 [10].

# 8.7.3.3 Unsuccessful Operation



Figure 8.7.3.3-1: AMF configuration update: unsuccessful operation

If the NG-RAN node cannot accept the update, it shall respond with an AMF CONFIGURATION UPDATE FAILURE message and appropriate cause value.

If the *Time to Wait* IE is included in the AMF CONFIGURATION UPDATE FAILURE message, the AMF shall wait at least for the indicated time before reinitiating the AMF Configuration Update procedure towards the same NG-RAN node.

#### 8.7.3.4 Abnormal Conditions

If the AMF receives neither an AMF CONFIGURATION UPDATE ACKOWLEDGE nor an AMF CONFIGURATION UPDATE FAILURE message, the AMF may reinitiate the AMF Configuration Update procedure towards the same NG-RAN node provided that the content of the new AMF CONFIGURATION UPDATE message is identical to the content of the previously unacknowledged AMF CONFIGURATION UPDATE message.

# 8.7.4 NG Reset

## 8.7.4.1 General

The purpose of the NG Reset procedure is to initialise or re-initialise the RAN, or part of RAN NGAP UE-related contexts, in the event of a failure in the 5GC or vice versa. This procedure does not affect the application level configuration data exchanged during, e.g., the NG Setup procedure. The procedure uses non-UE associated signalling.

# 8.7.4.2 Successful Operation

# 8.7.4.2.1 NG Reset initiated by the AMF




Figure 8.7.4.2.1-1: NG reset initiated by the AMF: successful operation

In the event of a failure at the AMF which has resulted in the loss of some or all transaction reference information, an NG RESET message shall be sent to the NG-RAN node.

At reception of the NG RESET message the NG-RAN node shall release all allocated resources on NG and Uu related to the UE association(s) indicated explicitly or implicitly in the NG RESET message and remove the indicated UE contexts including NGAP ID.

After the NG-RAN node has released all assigned NG resources and the UE NGAP IDs for all indicated UE associations which can be used for new UE-associated logical NG-connections over the NG interface, the NG-RAN node shall respond with the NG RESET ACKNOWLEDGE message. The NG-RAN node does not need to wait for the release of radio resources to be completed before returning the NG RESET ACKNOWLEDGE message.

If the NG RESET message contains the UE-associated Logical NG-connection List IE, then:

- The NG-RAN node shall use the AMF UE NGAP ID IE and/or the RAN UE NGAP ID IE to explicitly identify the UE association(s) to be reset.
- The NG-RAN node shall include in the NG RESET ACKNOWLEDGE message, for each UE association to be reset, the UE-associated Logical NG-connection Item IE in the UE-associated Logical NG-connection List IE. The UE-associated Logical NG-connection Item IEs shall be in the same order as received in the NG RESET message and shall include also unknown UE-associated logical NG-connections. Empty UE-associated Logical NG-connection Item IEs, received in the NG RESET message, may be omitted in the NG RESET ACKNOWLEDGE message.
- If the *AMF UE NGAP ID* IE is included in the *UE-associated Logical NG-connection Item* IE for a UE association, the NG-RAN node shall include the *AMF UE NGAP ID* IE in the corresponding *UE-associated Logical NG-connection Item* IE in the NG RESET ACKNOWLEDGE message.
- If the *RAN UE NGAP ID* IE is included in the *UE-associated Logical NG-connection Item* IE for a UE association, the NG-RAN node shall include the *RAN UE NGAP ID* IE in the corresponding *UE-associated Logical NG-connection Item* IE in the NG RESET ACKNOWLEDGE message.

#### Interactions with other procedures:

If the NG RESET message is received, any other ongoing procedure (except for another NG Reset procedure) on the same NG interface related to a UE association, indicated explicitly or implicitly in the NG RESET message, shall be aborted.

#### 8.7.4.2.2 NG Reset initiated by the NG-RAN node




Figure 8.7.4.2.2-1: NG reset initiated by the NG-RAN node: successful operation

In the event of a failure at the NG-RAN node which has resulted in the loss of some or all transaction reference information, an NG RESET message shall be sent to the AMF.

At reception of the NG RESET message the AMF shall release all allocated resources on NG related to the UE association(s) indicated explicitly or implicitly in the NG RESET message and remove the NGAP ID for the indicated UE associations.

After the AMF has released all assigned NG resources and the UE NGAP IDs for all indicated UE associations which can be used for new UE-associated logical NG-connections over the NG interface, the AMF shall respond with the NG RESET ACKNOWLEDGE message.

If the NG RESET message contains the UE-associated Logical NG-connection List IE, then:

- The AMF shall use the AMF UE NGAP ID IE and/or the RAN UE NGAP ID IE to explicitly identify the UE association(s) to be reset.
- The AMF shall include in the NG RESET ACKNOWLEDGE message, for each UE association to be reset, the UE-associated Logical NG-connection Item IE in the UE-associated Logical NG-connection List IE. The UE-associated Logical NG-connection Item IEs shall be in the same order as received in the NG RESET message and shall include also unknown UE-associated logical NG-connections. Empty UE-associated Logical NG-connection Item IEs, received in the NG RESET message, may be omitted in the NG RESET ACKNOWLEDGE message.
- If the AMF UE NGAP ID IE is included in the UE-associated Logical NG-connection Item IE for a UE association, the AMF shall include the AMF UE NGAP ID IE in the corresponding UE-associated Logical NG-connection Item IE in the NG RESET ACKNOWLEDGE message.
- If the *RAN UE NGAP ID* IE is included in a *UE-associated Logical NG-connection Item* IE for a UE association, the AMF shall include the *RAN UE NGAP ID* IE in the corresponding *UE-associated Logical NG-connection Item* IE in the NG RESET ACKNOWLEDGE message.

#### Interactions with other procedures:

If the NG RESET message is received, any other ongoing procedure (except for another NG Reset procedure) on the same NG interface related to a UE association, indicated explicitly or implicitly in the NG RESET message, shall be aborted.

#### 8.7.4.3 Unsuccessful Operation

Not applicable.

#### 8.7.4.4 Abnormal Conditions

#### 8.7.4.4.1 Abnormal Condition at the 5GC

If the NG RESET message includes the *UE-associated Logical NG-connection List* IE, but neither the *AMF UE NGAP ID* IE nor the *RAN UE NGAP ID* IE is present for a *UE-associated Logical NG-connection Item* IE, then the AMF shall

ignore the *UE-associated Logical NG-connection Item* IE. The AMF may return the empty *UE-associated Logical NG-connection Item* IE in the *UE-associated Logical NG-connection List* IE in the NG RESET ACKNOWLEDGE message.

#### 8.7.4.4.2 Abnormal Condition at the NG-RAN

If the NG RESET message includes the *UE-associated Logical NG-connection List* IE, but neither the *AMF UE NGAP ID* IE nor the *RAN UE NGAP ID* IE is present for a *UE-associated Logical NG-connection Item* IE, then the NG-RAN node shall ignore the *UE-associated Logical NG-connection Item* IE. The NG-RAN node may return the empty *UE-associated Logical NG-connection Item* IE in the *UE-associated Logical NG-connection List* IE in the NG RESET ACKNOWLEDGE message.

# 8.7.4.4.3 Crossing of NG RESET Messages

If an NG Reset procedure is ongoing in the NG-RAN node and the NG-RAN node receives an NG RESET message from the peer entity on the same NG interface related to one or several UE associations previously requested to be reset, indicated explicitly or implicitly in the received NG RESET message, the NG-RAN node shall respond with the NG RESET ACKNOWLEDGE message as described in 8.7.4.2.1.

If an NG Reset procedure is ongoing in the AMF and the AMF receives an NG RESET message from the peer entity on the same NG interface related to one or several UE associations previously requested to be reset, indicated explicitly or implicitly in the received NG RESET message, the AMF shall respond with the NG RESET ACKNOWLEDGE message as described in 8.7.4.2.2.

## 8.7.5 Error Indication

#### 8.7.5.1 General

The Error Indication procedure is initiated by a node in order to report detected errors in one incoming message, provided they cannot be reported by an appropriate failure message.

If the error situation arises due to reception of a message utilising UE-associated signalling, then the Error Indication procedure uses UE-associated signalling. Otherwise the procedure uses non-UE associated signalling.

#### 8.7.5.2 Successful Operation



Figure 8.7.5.2-1: Error indication initiated by the AMF



Figure 8.7.5.2-2: Error indication initiated by the NG-RAN node

When the conditions defined in clause 10 are fulfilled, the Error Indication procedure is initiated by an ERROR INDICATION message sent from the receiving node.

The ERROR INDICATION message shall contain at least either the *Cause* IE or the *Criticality Diagnostics* IE. In case the Error Indication procedure is triggered by utilising UE-associated signalling the *AMF UE NGAP ID* IE and the *RAN UE NGAP ID* IE shall be included in the ERROR INDICATION message. If one or both of the *AMF UE NGAP ID* IE and the *RAN UE NGAP ID* IE are not correct, the cause shall be set to an appropriate value, e.g., "Unknown local UE NGAP ID" or "Inconsistent remote UE NGAP ID".

### 8.7.5.3 Abnormal Conditions

Void.

# 8.7.6 AMF Status Indication

#### 8.7.6.1 General

The purpose of the AMF Status Indication procedure is to support AMF management functions.

### 8.7.6.2 Successful Operation



Figure 8.7.6.2-1: AMF status indication

The AMF initiates the procedure by sending an AMF STATUS INDICATION message to the NG-RAN node.

Upon receipt of the AMF STATUS INDICATION message, the NG-RAN node shall consider the indicated GUAMI(s) will be unavailable and perform AMF reselection as defined in TS 23.501 [9].

The NG-RAN node shall, if supported, act accordingly as specified in TS 23.501 [9], based on the presence or absence of the *Timer Approach for GUAMI Removal* IE.

If the *Backup AMF Name* IE is included in the AMF STATUS INDICATION message, the NG-RAN node shall, if supported, perform AMF reselection considering the AMF as indicated by the *Backup AMF Name* IE as specified in TS 23.501 [9].

#### 8.7.6.3 Abnormal Conditions

Void.

## 8.7.7 Overload Start

#### 8.7.7.1 General

The purpose of the Overload Start procedure is to inform an NG-RAN node to reduce the signalling load towards the concerned AMF. The procedure uses non-UE associated signalling.

#### 8.7.7.2 Successful Operation



Figure 8.7.7.2-1: Overload start

The NG-RAN node receiving the OVERLOAD START message shall assume the AMF from which it receives the message as being in an overloaded state.

If the *Overload Action* IE is included the *AMF Overload Response* IE within the OVERLOAD START message, the NG-RAN node shall use it to identify the related signalling traffic. When the *Overload Action* IE is set to

- "reject RRC connection establishments for non-emergency mobile originated data transfer" (i.e., reject traffic corresponding to RRC cause "mo-data", "mo-SMS", "mo-VideoCall" and "mo-VoiceCall" in TS 38.331 [18] or "mo-data" and "mo-VoiceCall" in TS 36.331 [21]), or
- "reject RRC connection establishments for signalling" (i.e., reject traffic corresponding to RRC cause "mo-data", "mo-SMS", "mo-signalling", "mo-VideoCall" and "mo-VoiceCall" in TS 38.331 [18] or "mo-data", "mo-signalling" and "mo-VoiceCall" in TS 36.331 [21]), or
- "only permit RRC connection establishments for emergency sessions and mobile terminated services" (i.e., only permit traffic corresponding to RRC cause "emergency" and "mt-Access" in TS 38.331 [18] or in TS 36.331 [21]), or
- "only permit RRC connection establishments for high priority sessions and mobile terminated services" (i.e., only permit traffic corresponding to RRC cause "highPriorityAccess", "mps-PriorityAccess", "mcs-PriorityAccess" and "mt-Access" in TS 38.331 [18] or "highPriorityAccess" and "mt-Access" in TS 36.331 [21]),

#### the NG-RAN node shall:

- if the AMF Traffic Load Reduction Indication IE is included in the OVERLOAD START message, reduce the signalling traffic by the indicated percentage,
- otherwise ensure that only the signalling traffic not indicated as to be rejected is sent to the AMF.

If the Overload Start NSSAI List IE is included in the OVERLOAD START message, the NG-RAN node shall:

- if the *Slice Traffic Load Reduction Indication* IE is present, reduce the signalling traffic by the indicated percentage for the UE(s) whose requested NSSAI only include S-NSSAI(s) contained in the *Overload Start NSSAI List* IE, and the signalling traffic indicated as to be reduced by the *Overload Action* IE in the *Slice Overload Response* IE if the IE is present,

- otherwise ensure that only the signalling traffic from UE(s) whose requested NSSAI includes S-NSSAI(s) other than the ones contained in the *Overload Start NSSAI List* IE, or the signalling traffic not indicated as to be reduced by the *Overload Action* IE in the *Slice Overload Response* IE for the UE(s) if the requested NSSAI matched, is sent to the AMF.

If an overload control is ongoing and the NG-RAN node receives a further OVERLOAD START message, the NG-RAN node shall replace the contents of the previously received information with the new one.

#### 8.7.7.3 Abnormal Conditions

Void.

# 8.7.8 Overload Stop

## 8.7.8.1 General

The purpose of the Overload Stop procedure is to signal to an NG-RAN node the AMF is connected to that the overload situation at the AMF has ended and normal operation shall resume. The procedure uses non-UE associated signalling.

# 8.7.8.2 Successful Operation



Figure 8.7.8.2-1: Overload stop

The NG-RAN node receiving the OVERLOAD STOP message shall assume that the overload situation at the AMF from which it receives the message has ended and shall resume normal operation for the applicable traffic towards this AMF.

#### 8.7.8.3 Abnormal Conditions

Void.

# 8.8 Configuration Transfer Procedures

# 8.8.1 Uplink RAN Configuration Transfer

#### 8.8.1.1 General

The purpose of the Uplink RAN Configuration Transfer procedure is to transfer RAN configuration information from the NG-RAN node to the AMF. The AMF does not interpret the transferred RAN configuration information. This procedure uses non-UE associated signalling.

# 8.8.1.2 Successful Operation




Figure 8.8.1.2-1: Uplink RAN configuration transfer

The NG-RAN node initiates the procedure by sending the UPLINK RAN CONFIGURATION TRANSFER message to the AMF.

If the AMF receives the SON Configuration Transfer IE, it shall transparently transfer the SON Configuration Transfer IE towards the NG-RAN node indicated in the Target RAN Node ID IE which is included in the SON Configuration Transfer IE.

If the AMF receives the *EN-DC SON Configuration Transfer* IE, it shall transparently transfer the *EN-DC SON Configuration Transfer* IE towards an MME serving the eNB indicated in the *Target eNB-ID* IE which is included in the *EN-DC SON Configuration Transfer* IE.

#### 8.8.1.3 Abnormal Conditions

Void.

# 8.8.2 Downlink RAN Configuration Transfer

#### 8.8.2.1 General

The purpose of the Downlink RAN Configuration Transfer procedure is to transfer RAN configuration information from the AMF to the NG-RAN node. This procedure uses non-UE associated signalling.

## 8.8.2.2 Successful Operation




Figure 8.8.2.2-1: Downlink RAN configuration transfer

The procedure is initiated with an DOWNLINK RAN CONFIGURATION TRANSFER message sent from the AMF to the NG-RAN node.

If the NG-RAN node receives, in the SON Configuration Transfer IE or in the EN-DC SON Configuration Transfer IE, the SON Information IE containing the SON Information Request IE, it may transfer back the requested information either towards the NG-RAN node indicated in the Source RAN Node ID IE of the SON Configuration Transfer IE or towards an eNB indicated in the Source eNB-ID IE of the EN-DC SON Configuration Transfer IE by initiating the Uplink RAN Configuration Transfer procedure.

If the NG-RAN node receives, in the SON Configuration Transfer IE, the Xn TNL Configuration Info IE containing the Xn Extended Transport Layer Addresses IE, it may use it as part of its ACL functionality configuration actions, if such ACL functionality is deployed.

If the NG-RAN node receives, in the *SON Configuration Transfer* IE, the *SON Information* IE containing the *SON Information Reply* IE including the *Xn TNL Configuration Info* IE as an answer to a former request, it may use it to initiate the Xn TNL establishment.

In case the *IP-Sec Transport Layer Addresss* IE is present and the *GTP Transport Layer Addresses* IE within the *Xn Extended Transport Layer Addresses* IE is not empty, GTP traffic is conveyed within an IP-Sec tunnel terminated at the IP-Sec tunnel endpoint given in the *IP-Sec Transport Layer Address* IE.

In case the *IP-Sec Transport Layer Address* IE is not present, GTP traffic is terminated at the endpoints given by the list of addresses in the *Xn GTP Transport Layer Addresses* IE within the *Xn Extended Transport Layer Addresses* IE.

In case the Xn GTP Transport Layer Addresses IE is empty and the IP-Sec Transport Layer Address IE is present, SCTP traffic is conveyed within an IP-Sec tunnel terminated at the IP-Sec tunnel endpoint given in the IP-Sec Transport Layer Address IE, within the Xn Extended Transport Layer Addresses IE.

In case the *Xn SCTP Transport Layer Addresses* IE is present and the *IP-Sec Transport Layer Address* IE is also present, the concerned SCTP traffic is conveyed within an IP-Sec tunnel terminated at the IP-Sec tunnel endpoint given in this *IP-Sec Transport Layer Addresses* IE, within the *Xn Extended Transport Layer Addresses* IE.

If the NG-RAN node is configured to use one IPsec tunnel for all NG and Xn traffic (IPsec star topology) then the traffic to the peer NG-RAN node shall be routed through this IPsec tunnel and the *IP-Sec Transport Layer Address* IE shall be ignored.

#### 8.8.2.3 Abnormal Conditions

Void.

# 8.9 Warning Message Transmission Procedures

# 8.9.1 Write-Replace Warning

#### 8.9.1.1 General

The purpose of Write-Replace Warning procedure is to start or overwrite the broadcasting of warning messages. The procedure uses non UE-associated signalling.

# 8.9.1.2 Successful Operation



Figure 8.9.1.2-1: Write-Replace Warning procedure: successful operation

The AMF initiates the procedure by sending a WRITE-REPLACE WARNING REQUEST message to the NG-RAN node.

Upon receipt of the WRITE-REPLACE WARNING REQUEST message, the NG-RAN node shall prioritise its resources to process the warning message.

If, in a certain area, broadcast of a warning message is already ongoing and the NG-RAN node receives a WRITE-REPLACE WARNING REQUEST message with *Message Identifier* IE and/or *Serial Number* IE which are different from those in the warning message being broadcast, and if the *Concurrent Warning Message Indicator* IE is not present, the NG-RAN node shall replace the warning message being broadcast with the newly received one for that area.

If the NG-RAN node receives a WRITE-REPLACE WARNING REQUEST message with a warning message identified by the *Message Identifier* IE and *Serial Number* IE and if there are no prior warning messages being broadcast in any of the warning areas indicated in the *Warning Area List* IE, the NG-RAN node shall broadcast the received warning message for those area(s).

If, in a certain area, broadcast of one or more warning messages are already ongoing and the NG-RAN node receives a WRITE-REPLACE WARNING REQUEST message with a *Message Identifier* IE and/or *Serial Number* IE which are different from those in any of the warning messages being broadcast, and if the *Concurrent Warning Message Indictor* IE is present, the NG-RAN node shall schedule the received warning message for broadcast, for that area.

If the *Concurrent Warning Message Indicator* IE is present and if a value "0" is received in the *Number of Broadcast Requested* IE, the NG-RAN node shall broadcast the received warning message indefinitely until requested otherwise to stop broadcasting, except if the *Repetition Period* IE is set to "0".

If, in a certain area, broadcast of one or more warning messages are already ongoing and the NG-RAN node receives a WRITE-REPLACE WARNING REQUEST message with *Message Identifier* IE and *Serial Number* IE which correspond to one of the warning messages already being broadcast in that area, the NG-RAN node shall not start a new broadcast or replace an existing one but it shall still reply by sending a WRITE-REPLACE WARNING RESPONSE message which includes the *Broadcast Completed Area List* IE set according to the ongoing broadcast.

If the *Warning Area List* IE is not included in the WRITE-REPLACE WARNING REQUEST message, the NG-RAN node shall broadcast the indicated message in all of the cells within the NG-RAN node.

If the *Warning Type* IE is included in the WRITE-REPLACE WARNING REQUEST message, the NG-RAN node shall broadcast the Primary Notification irrespective of the setting of the *Repetition Period* IE and the *Number of Broadcasts Requested* IE, and process the Primary Notification according to TS 36.331 [21] and TS 38.331 [18].

If the *Data Coding Scheme* IE and the *Warning Message Contents* IE are both included in the WRITE-REPLACE WARNING REQUEST message, the NG-RAN node shall schedule a broadcast of the warning message according to the value of the *Repetition Period* IE and the *Number of Broadcasts Requested* IE and process the warning message according to TS 36.331 [21] and TS 38.331 [18].

If the *Warning Area Coordinates* IE is included in the WRITE-REPLACE WARNING REQUEST message, the NG-RAN node shall include this information together with the warning message being broadcast according to TS 36.331 [21] and TS 38.331 [18].

The NG-RAN node acknowledges the WRITE-REPLACE WARNING REQUEST message by sending a WRITE-REPLACE WARNING RESPONSE message to the AMF.

If the *Broadcast Completed Area List* IE is not included in the WRITE-REPLACE WARNING RESPONSE message, the AMF shall consider that the broadcast is unsuccessful in all the cells within the NG-RAN node.

# 8.9.1.3 Unsuccessful Operation

Not applicable.

## 8.9.1.4 Abnormal Conditions

If the *Concurrent Warning Message Indicator* IE is not present and if a value "0" is received in the *Number of Broadcast Requested* IE, the NG-RAN node shall not broadcast the received secondary notification.

If the *Concurrent Warning Message Indicator* IE is included and if a value "0" is received in the *Repetition Period* IE, the NG-RAN node shall not broadcast the received warning message except if the *Number of Broadcast Requested* IE is set to "1".

If the *Concurrent Warning Message Indicator* IE is not included and if a value "0" is received in the *Repetition Period* IE, the NG-RAN node shall not broadcast the received secondary notification except if the *Number of Broadcast Requested* IE is set to "1".

## 8.9.2 PWS Cancel

#### 8.9.2.1 General

The purpose of the PWS Cancel procedure is to cancel an already ongoing broadcast of a warning message. The procedure uses non UE-associated signalling.

# 8.9.2.2 Successful Operation




Figure 8.9.2.2-1: PWS Cancel procedure: successful operation

The AMF initiates the procedure by sending a PWS CANCEL REQUEST message to the NG-RAN node.

If the NG-RAN node receives a PWS CANCEL REQUEST message and broadcast of the warning message identified by the *Message Identifier* and *Serial Number* IE is ongoing in an area indicated within the *Warning Area List* IE, the NG-RAN node shall stop broadcasting the warning message within that area and discard the warning message for that area.

If the *Warning Area List* IE is not included in the PWS CANCEL REQUEST message, the NG-RAN node shall stop broadcasting and discard the warning message identified by the *Message Identifier* IE and the *Serial Number* IE in all of the cells in the NG-RAN node.

The NG-RAN node shall acknowledge the PWS CANCEL REQUEST message by sending the PWS CANCEL RESPONSE message, with the *Message Identifier* IE and the *Serial Number* IE copied from the PWS CANCEL REQUEST message and shall, if there is an area to report where an ongoing broadcast was stopped successfully, include the *Broadcast Cancelled Area List* IE.

If an area included in the *Warning Area List* IE in the PWS CANCEL REQUEST message does not appear in the *Broadcast Cancelled Area List* IE, the AMF shall consider that the NG-RAN node had no ongoing broadcast to stop for the same *Message Identifier* and *Serial Number* in that area.

If the *Broadcast Cancelled Area List* IE is not included in the PWS CANCEL RESPONSE message, the AMF shall consider that the NG-RAN node had no ongoing broadcast to stop for the same *Message Identifier* and *Serial Number*.

If the Cancel-All Warning Messages Indicator IE is present in the PWS CANCEL REQUEST message, then the NG-RAN node shall stop broadcasting and discard all warning messages for the area as indicated in the Warning Area List IE or in all the cells of the NG-RAN node if the Warning Area List IE is not included. The NG-RAN node shall acknowledge the PWS CANCEL REQUEST message by sending the PWS CANCEL RESPONSE message, with the Message Identifier IE and the Serial Number IE copied from the PWS CANCEL REQUEST message and shall, if there is area to report where an ongoing broadcast was stopped successfully, include the Broadcast Cancelled Area List IE with the Number of Broadcasts IE set to 0.

## 8.9.2.3 Unsuccessful Operation

Not applicable.

## 8.9.2.4 Abnormal Conditions

Void.

#### 8.9.3 PWS Restart Indication

#### 8.9.3.1 General

The purpose of the PWS Restart Indication procedure is to inform the AMF that PWS information for some or all cells of the NG-RAN node may be reloaded from the CBC if needed. The procedure uses non UE-associated signalling.

# 8.9.3.2 Successful Operation



Figure 8.9.3.2-1: PWS restart indication

The NG-RAN node initiates the procedure by sending a PWS RESTART INDICATION message to the AMF. On receipt of a PWS RESTART INDICATION message, the AMF shall act as defined in TS 23.007 [20].

If the Emergency Area ID is available, the NG-RAN node shall also include it in the *Emergency Area ID List for Restart* IE.

#### 8.9.3.3 Abnormal Conditions

Void.

## 8.9.4 PWS Failure Indication

### 8.9.4.1 General

The purpose of the PWS Failure Indication procedure is to inform the AMF that ongoing PWS operation for one or more cells of the NG-RAN node has failed. The procedure uses non UE-associated signalling.

## 8.9.4.2 Successful Operation




Figure 8.9.4.2-1: PWS failure indication

The NG-RAN node initiates the procedure by sending a PWS FAILURE INDICATION message to the AMF. On receipt of a PWS FAILURE INDICATION message, the AMF shall act as defined in TS 23.041 [22].

#### 8.9.4.3 Abnormal Conditions

Void.

# 8.10 NRPPa Transport Procedures

# 8.10.1 General

The purpose of the NRPPa Transport procedure is to carry NRPPa signalling (defined in TS 38.455 [19]) between the NG-RAN node and the LMF over the NG interface as defined in TS 38.455 [19]. The procedure may use UE-associated signalling or non-UE associated signalling. The UE-associated signalling is used to support E-CID positioning of a specific UE. The non-UE associated signalling is used to obtain assistance data from an NG-RAN node to support OTDOA positioning for any UE.

# 8.10.2 Successful Operations

#### 8.10.2.1 DOWNLINK UE ASSOCIATED NRPPA TRANSPORT




Figure 8.10.2.1-1: Downlink UE-associated NRPPa transport

The AMF initiates the procedure by sending the DOWNLINK UE ASSOCIATED NRPPA TRANSPORT message to the NG-RAN node.

# 8.10.2.2 UPLINK UE ASSOCIATED NRPPA TRANSPORT




Figure 8.10.2.2-1: Uplink UE-associated NRPPa transport

The NG-RAN node initiates the procedure by sending the UPLINK UE ASSOCIATED NRPPA TRANSPORT message to the AMF.

## 8.10.2.3 DOWNLINK NON UE ASSOCIATED NRPPA TRANSPORT



Figure 8.10.2.3-1: Downlink non UE-associated NRPPa transport

The AMF initiates the procedure by sending the DOWNLINK NON UE ASSOCIATED NRPPA TRANSPORT message to the NG-RAN node.

### 8.10.2.4 UPLINK NON UE ASSOCIATED NRPPA TRANSPORT




Figure 8.10.2.4-1: Uplink non UE-associated NRPPa transport

The NG-RAN node initiates the procedure by sending the UPLINK NON UE ASSOCIATED NRPPA TRANSPORT message to the AMF.

# 8.10.3 Unsuccessful Operations

Not applicable.

## 8.10.4 Abnormal Conditions

If an AMF receives an UPLINK UE ASSOCIATED NRPPA TRANSPORT message with an unknown Routing ID for the UE, the AMF shall ignore the message.

If an AMF receives an UPLINK NON UE ASSOCIATED NRPPA TRANSPORT message indicating an unknown or unreachable Routing ID, the AMF shall ignore the message.

# 8.11 Trace Procedures

## 8.11.1 Trace Start

# 8.11.1.1 General

The purpose of the Trace Start procedure is to allow the AMF to request the NG-RAN node to initiate a trace session for a UE. The procedure uses UE-associated signalling. If no UE-associated logical NG-connection exists, the UE-associated logical NG-connection shall be established as part of the procedure.

# 8.11.1.2 Successful Operation



Figure 8.11.1.2-1: Trace start

The AMF initiates the procedure by sending a TRACE START message. Upon reception of the TRACE START message, the NG-RAN node shall initiate the requested trace session as described in TS 32.422 [11].

#### Interactions with other procedures:

If the NG-RAN node is not able to initiate the trace session due to ongoing handover of the UE to another NG-RAN node, the NG-RAN node shall initiate a Trace Failure Indication procedure with the appropriate cause value.

#### 8.11.1.3 Abnormal Conditions

Void.

# 8.11.2 Trace Failure Indication

# 8.11.2.1 General

The purpose of the Trace Failure Indication procedure is to allow the NG-RAN node to inform the AMF that a Trace Start procedure or a Deactivate Trace procedure has failed due to an interaction with a handover procedure. The procedure uses UE-associated signalling.

## 8.11.2.2 Successful Operation




Figure 8.11.2.2-1: Trace failure indication

The NG-RAN node initiates the procedure by sending a TRACE FAILURE INDICATION message. Upon reception of the TRACE FAILURE INDICATION message, the AMF shall take appropriate actions based on the failure reason indicated by the *Cause* IE.

## 8.11.2.3 Abnormal Conditions

Void.

## 8.11.3 Deactivate Trace

#### 8.11.3.1 General

The purpose of the Deactivate Trace procedure is to allow the AMF to request the NG-RAN node to stop the trace session for the indicated trace reference. The procedure uses UE-associated signalling.

# 8.11.3.2 Successful Operation



Figure 8.11.3.2-1: Deactivate trace

The AMF initiates the procedure by sending a DEACTIVATE TRACE message to the NG-RAN node as described in TS 32.422 [11]. Upon reception of the DEACTIVATE TRACE message, the NG-RAN node shall stop the trace session for the indicated trace reference in the *NG-RAN Trace ID* IE.

#### Interactions with other procedures:

If the NG-RAN node is not able to stop the trace session due to ongoing handover of the UE to another NG-RAN node, the NG-RAN node shall initiate a Trace Failure Indication procedure with the appropriate cause value.

#### 8.11.3.3 Abnormal Conditions

Void.

## 8.11.4 Cell Traffic Trace

#### 8.11.4.1 General

The purpose of the Cell Traffic Trace procedure is to send the allocated Trace Recording Session Reference and the Trace Reference to the AMF. The procedure uses UE-associated signalling.

# 8.11.4.2 Successful Operation



Figure 8.11.4.2-1: Cell traffic trace

The NG-RAN node initiates the procedure by sending a CELL TRAFFIC TRACE message.

#### 8.11.4.3 Abnormal Conditions

Void.

# 8.12 Location Reporting Procedures

### 8.12.1 Location Reporting Control

#### 8.12.1.1 General

The purpose of the Location Reporting Control procedure is to allow the AMF to request the NG-RAN node to report the UE's current location, or the UE's last known location with time stamp, or the UE's presence in the area of interest while in CM-CONNECTED state as specified in TS 23.501 [9] and TS 23.502 [10]. The procedure uses UE-associated signalling.

#### 8.12.1.2 Successful Operation



Figure 8.12.1.2-1: Location reporting control

The AMF initiates the procedure by sending a LOCATION REPORTING CONTROL message to the NG-RAN node. On receipt of the LOCATION REPORTING CONTROL message the NG-RAN node shall perform the requested location reporting control action for the UE.

The Location Reporting Request Type IE indicates to the NG-RAN node whether:

- to report directly;
- to report upon change of serving cell;
- to report UE presence in the area of interest;
- to stop reporting at change of serving cell;
- to stop reporting UE presence in the area of interest;
- to cancel location reporting for the UE.

If the Area Of Interest List IE is included in the Location Reporting Request Type IE in the LOCATION REPORTING CONTROL message, the NG-RAN node shall store this information and use it to track the UE's presence in the area of interest as defined in TS 23.502 [10].

If the *Additional Location Information* IE is included in the LOCATION REPORTING CONTROL message and set to "Include PSCell" then, if Dual Connectivity is activated, the NG-RAN node shall include the current PSCell in the report. If a report upon change of serving cell is requested, the NG-RAN node shall provide the report also whenever the UE changes the PSCell, and when Dual Connectivity is activated.

If reporting upon change of serving cell is requested, the NG-RAN node shall send a report immediately and shall send a report whenever the UE's location changes.

#### 8.12.1.3 Abnormal Conditions

If the NG-RAN node receives a LOCATION REPORTING CONTROL message containing several *Location Reporting Reference ID* IE set to the same value, the NG-RAN node shall send the LOCATION REPORTING FAILURE INDICATION message with an appropriate cause value.

## 8.12.2 Location Reporting Failure Indication

#### 8.12.2.1 General

The purpose of the Location Reporting Failure Indication procedure is to allow the NG-RAN node to inform the AMF that the Location Reporting Control procedure has failed. The procedure uses UE-associated signalling.

#### 8.12.2.2 Successful Operation



Figure 8.12.2.2-1: Location reporting failure indication

The NG-RAN node initiates the procedure by sending a LOCATION REPORTING FAILURE INDICATION message to the AMF. Upon reception of the LOCATION REPORTING FAILURE INDICATION message the AMF shall, based on the failure reason indicated by the *Cause* IE, take appropriate action.

#### 8.12.2.3 Abnormal Conditions

Void.

# 8.12.3 Location Report

#### 8.12.3.1 General

The purpose of the Location Report procedure is to provide the UE's current location, the UE's last known location with time stamp, or the UE's presence in the area of interest to the AMF. The procedure uses UE-associated signalling.

#### 8.12.3.2 Successful Operation



Figure 8.12.3.2-1: Location report

The NG-RAN node initiates the procedure by sending a LOCATION REPORT message to the AMF. The LOCATION REPORT message may be used as a response to the LOCATION REPORTING CONTROL message.

#### 8.12.3.3 Abnormal Conditions

Void.

# 8.13 UE TNLA Binding Procedures

## 8.13.1 UE TNLA Binding Release

#### 8.13.1.1 General

The purpose of the UE TNLA Binding Release procedure is to request the NG-RAN node to release the NGAP UE TNLA binding, while requesting the NG-RAN node to maintain NG-U (user plane connectivity) and UE context information as specified in TS 23.502 [10]. The procedure uses UE-associated signalling.

#### 8.13.1.2 Successful Operation



Figure 8.13.1.2-1: UE TNLA binding release request

At reception of the UE TNLA BINDING RELEASE REQUEST message, the NG-RAN node shall release the UE TNLA binding for the UE indicated in the UE TNLA BINDING RELEASE REQUEST message. The NG-RAN node shall keep the NG-U (user plane connectivity) and UE context information for the UE.

#### **Interactions with other procedures:**

If the UE TNLA BINDING RELEASE REQUEST message is received, any other ongoing procedure (except for the NG Reset procedure or another UE TNLA Binding Release procedure) on the same NG interface related to the UE indicated in the UE TNLA BINDING RELEASE REQUEST message shall be aborted.

#### 8.13.1.3 Abnormal Conditions

Void.

# 8.14 UE Radio Capability Management Procedures

## 8.14.1 UE Radio Capability Info Indication

#### 8.14.1.1 General

The purpose of the UE Radio Capability Info Indication procedure is to enable the NG-RAN node to provide to the AMF UE radio capability-related information. The procedure uses UE-associated signalling.

#### 8.14.1.2 Successful Operation



Figure 8.14.1.2-1: UE radio capability info indication

The NG-RAN node controlling a UE-associated logical NG connection initiates the procedure by sending a UE RADIO CAPABILITY INFO INDICATION message to the AMF including the UE radio capability information.

The UE RADIO CAPABILITY INFO INDICATION message may also include paging specific UE radio capability information within the *UE Radio Capability for Paging* IE.

The UE radio capability information received by the AMF shall replace previously stored corresponding UE radio capability information in the AMF for the UE, as described in TS 23.501 [9].

#### 8.14.1.3 Abnormal Conditions

Void.

## 8.14.2 UE Radio Capability Check

#### 8.14.2.1 General

The purpose of the UE Radio Capability Check procedure is for the AMF to request the NG-RAN node to derive and provide an indication to the AMF on whether the UE radio capabilities are compatible with the network configuration for IMS voice. The procedure uses UE-associated signalling.

#### 8.14.2.2 Successful Operation




Figure 8.14.2.2-1: UE radio capability check procedure: successful operation

The AMF initiates the procedure by sending a UE RADIO CAPABILITY CHECK REQUEST message. If the UE-associated logical NG-connection is not established, the AMF shall allocate a unique AMF UE NGAP ID to be used for the UE and include the AMF UE NGAP ID IE in the UE RADIO CAPABILITY CHECK REQUEST message; by receiving the AMF UE NGAP ID IE in the UE RADIO CAPABILITY CHECK REQUEST message, the NG-RAN node establishes the UE-associated logical NG-connection.

Upon receipt of the UE RADIO CAPABILITY CHECK REQUEST message, the NG-RAN node checks whether the UE radio capabilities are compatible with the network configuration for IMS voice, and responds with a UE RADIO CAPABILITY CHECK RESPONSE message, as defined in TS 23.502 [10].

If the *UE Radio Capability* IE is contained in the UE RADIO CAPABILITY CHECK REQUEST message, the NG-RAN node shall use it to determine the value of the *IMS Voice Support Indicator* IE to be included in the UE RADIO CAPABILITY CHECK RESPONSE message.

#### 8.14.2.3 Unsuccessful Operation

Not applicable.

#### 8.14.2.4 Abnormal Conditions

Void.

# 8.15 Data Usage Reporting Procedures

### 8.15.1 Secondary RAT Data Usage Report

#### 8.15.1.1 General

The purpose of the Secondary RAT Data Usage Report procedure is to provide information on the used resources of the secondary RAT (e.g. NR resources during MR-DC operation) as specified in TS 23.501 [9].

#### 8.15.1.2 Successful Operation




Figure 8.15.1.2-1: Secondary RAT data usage report

The NG-RAN node initiates the procedure by sending the SECONDARY RAT DATA USAGE REPORT message to the AMF.

If the *Handover Flag* IE is included in the SECONDARY RAT DATA USAGE REPORT message, it indicates that for each PDU session the AMF should buffer the *Secondary RAT Data Usage Report Transfer* IE since the secondary RAT data usage report is sent due to handover as defined in TS 23.502 [10].

For each PDU session for which the *Secondary RAT Usage Information List* IE is included in the the *Secondary RAT Data Usage Transfer* IE, the SMF shall handle this information as specified in TS 23.502 [10].

The NG-RAN node shall, if supported, report in the SECONDARY RAT DATA USAGE REPORT message location information of the UE in the *User Location Information* IE.

#### 8.15.1.3 Abnormal Conditions

Void.

# 9 Elements for NGAP Communication

### 9.0 General

Subclauses 9.2 and 9.3 present the NGAP message and IE definitions in tabular format. The corresponding ASN.1 definition is presented in subclause 9.4. In case there is contradiction between the tabular format and the ASN.1 definition, the ASN.1 shall take precedence, except for the definition of conditions for the presence of conditional IEs, where the tabular format shall take precedence.

The messages have been defined in accordance to the guidelines specified in TR 25.921 [7].

When specifying IEs which are to be represented by bitstrings, if not otherwise specifically stated in the semantics description of the concerned IE or elsewhere, the following principle applies with regards to the ordering of bits:

- The first bit (leftmost bit) contains the most significant bit (MSB);
- The last bit (rightmost bit) contains the least significant bit (LSB);
- When importing bitstrings from other specifications, the first bit of the bitstring contains the first bit of the concerned information;

### 9.1 Tabular Format Contents

#### 9.1.1 Presence

All IEs are marked mandatory, optional or conditional according to table 9.1.1-1.

Table 9.1.1-1: Meaning of content within "Presence" column

Abbreviation	Meaning
M	IEs marked as Mandatory (M) shall always be included in the
	message.
0	IEs marked as Optional (O) may or may not be included in the
	message.
С	IEs marked as Conditional (C) shall be included in a message only if
	the condition is satisfied. Otherwise the IE shall not be included.

## 9.1.2 Criticality

Each IE or group of IEs may have criticality information applied to it according to table 9.1.2-1.

Table 9.1.2-1: Meaning of content within "Criticality" column

Abbreviation	Meaning
	No self-self-self-servetion is sometimal combination.
_	No criticality information is applied explicitly.
YES	Criticality information is applied. This is usable only for non- repeatable IEs
GLOBAL	The IE and all its repetitions together have one common criticality information. This is usable only for repeatable IEs.
EACH	Each repetition of the IE has its own criticality information. It is not allowed to assign different criticality values to the repetitions. This is usable only for repeatable IEs.

# 9.1.3 Range

The Range column indicates the allowed number of copies of repetitive IEs/IE groups.

## 9.1.4 Assigned Criticality

The Assigned Criticality column provides the actual criticality information as defined in subclause 10.3.2, if applicable.

# 9.2 Message Functional Definition and Content

## 9.2.1 PDU Session Management Messages

#### 9.2.1.1 PDU SESSION RESOURCE SETUP REQUEST

This message is sent by the AMF and is used to request the NG-RAN node to assign resources on Uu and NG-U for one or several PDU session resources.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
RAN Paging Priority	0		9.3.3.15		YES	ignore
NAS-PDU	0		9.3.3.4		YES	reject
PDU Session		1			YES	reject
Resource Setup Request List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource Setup		ofPDUSes				
Request Item		sions>				
>>PDU Session ID	M		9.3.1.50		-	
>>PDU Session NAS- PDU	0		NAS-PDU 9.3.3.4		-	
>>S-NSSAI	М		9.3.1.24		-	
>>PDU Session Resource Setup Request Transfer	М		OCTET STRING	Containing the PDU Session Resource Setup Request Transfer IE specified in subclause 9.3.4.1.	-	
UE Aggregate Maximum Bit Rate	0		9.3.1.58		YES	ignore

Range bound	Explanation		
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.		

### 9.2.1.2 PDU SESSION RESOURCE SETUP RESPONSE

This message is sent by the NG-RAN node as a response to the request to assign resources on Uu and NG-U for one or several PDU session resources.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1	description	YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	ignore
PDU Session	IVI	01	9.0.0.Z		YES	ignore
Resource Setup		01			120	ignore
Response List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource Setup		ofPDUSes				
Response Item		sions>				
>>PDU Session ID	M		9.3.1.50		-	
>>PDU Session	M		OCTET	Containing the	-	
Resource Setup			STRING	PDU Session		
Response Transfer				Resource Setup		
				Response		
				Transfer IE		
				specified in		
5511.6				subclause 9.3.4.2.	\/=0	
PDU Session Resource Failed to		01			YES	ignore
Setup List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>_</td><td></td></maxno<>			_	
Resource Failed to		ofPDUSes			_	
Setup Item		sions>				
>>PDU Session ID	М	0.00	9.3.1.50		-	
>>PDU Session	М		OCTET	Containing the	-	
Resource Setup			STRING	PDU Session		
Unsuccessful				Resource Setup		
Transfer				Unsuccessful		
				Transfer IE		
				specified in		
				subclause		
				9.3.4.16.		
Criticality Diagnostics	0		9.3.1.3		YES	ignore

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.

## 9.2.1.3 PDU SESSION RESOURCE RELEASE COMMAND

This message is sent by the AMF and is used to request the NG-RAN node to release already established PDU session resources for a given UE.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
RAN Paging Priority	0		9.3.3.15		YES	ignore
NAS-PDU	0		9.3.3.4		YES	ignore
PDU Session		1			YES	reject
Resource to Release						
List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource to Release		ofPDUSes				
Item		sions>				
>>PDU Session ID	M		9.3.1.50		-	
>>PDU Session	M		OCTET	Containing the	-	
Resource Release			STRING	PDU Session		
Command Transfer				Resource Release		
				Command		
				Transfer IE		
				specified in		
				subclause		
						1
		1		9.3.4.12.		1

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.

#### 9.2.1.4 PDU SESSION RESOURCE RELEASE RESPONSE

This message is sent by the NG-RAN node as a response to the request to release already established PDU session resources for a given UE.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	ignore
PDU Session		1			YES	ignore
Resource Released List						
>PDU Session Resource Released Item		1 <maxno ofPDUSes sions&gt;</maxno 			-	
>>PDU Session ID	M		9.3.1.50		-	
>>PDU Session Resource Release Response Transfer	M		OCTET STRING	Containing the PDU Session Resource Release Response Transfer IE specified in subclause 9.3.4.21.	-	
User Location Information	0		9.3.1.16		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

#### 9.2.1.5 PDU SESSION RESOURCE MODIFY REQUEST

This message is sent by the AMF and is used to request the NG-RAN node to enable modifications of already established PDU session resources for a given UE.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1	description	YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
RAN Paging Priority	0		9.3.3.15		YES	ignore
PDU Session	-	1			YES	reject
Resource Modify						1
Request List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource Modify		ofPDUSes				
Request Item		sions>				
>>PDU Session ID	M		9.3.1.50		-	
>>NAS-PDU	0		9.3.3.4		-	
>>PDU Session	M		OCTET	Containing the	-	
Resource Modify			STRING	PDU Session		
Request Transfer				Resource Modify		
				Request Transfer		
				IE specified in		
				subclause 9.3.4.3.		
>>S-NSSAI	0		9.3.1.24		YES	reject

Range bound	Explanation		
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.		

#### 9.2.1.6 PDU SESSION RESOURCE MODIFY RESPONSE

This message is sent by the NG-RAN node and is used to report the outcome of the request from the PDU SESSION RESOURCE MODIFY REQUEST message.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1	description	YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	U
PDU Session	IVI	01	9.3.3.2		YES	ignore ignore
Resource Modify		0 1			163	ignore
Response List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>_</td><td></td></maxno<>			_	
Resource Modify		ofPDUSes				
Response Item		sions>				
>>PDU Session ID	М		9.3.1.50		-	
>>PDU Session Resource Modify Response Transfer	M		OCTET STRING	Containing the PDU Session Resource Modify Response Transfer IE specified in subclause 9.3.4.4.	-	
PDU Session Resource Failed to Modify List		01			YES	ignore
>PDU Session Resource Failed to Modify Item		1 <maxno ofPDUSes sions&gt;</maxno 			-	
>>PDU Session ID	M		9.3.1.50		-	
>>PDU Session Resource Modify Unsuccessful Transfer	M		OCTET STRING	Containing the PDU Session Resource Modify Unsuccessful Transfer IE specified in subclause 9.3.4.17.	-	
User Location Information	0		9.3.1.16		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.

#### 9.2.1.7 PDU SESSION RESOURCE NOTIFY

This message is sent by the NG-RAN node to notify that the QoS requirements of already established GBR QoS flow(s) for which notification control has been requested are either not fulfilled anymore or fulfilled again by the NG-RAN node. This message can also be sent by the NG-RAN node to notify that PDU session resource(s) for a given UE are released.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
PDU Session Resource Notify List		01			YES	reject
>PDU Session		1 <maxno< td=""><td></td><td></td><td></td><td></td></maxno<>				
Resource Notify Item		ofPDUSes sions>			-	
>>PDU Session ID	M		9.3.1.50		-	
>>PDU Session Resource Notify Transfer	М		OCTET STRING	Containing the PDU Session Resource Notify Transfer IE specified in subclause 9.3.4.5.	-	
PDU Session Resource Released List		01			YES	ignore
>PDU Session Resource Released Item		1 <maxno ofPDUSes sions&gt;</maxno 			-	
>>PDU Session ID	M		9.3.1.50		-	
>>PDU Session Resource Notify Released Transfer	M		OCTET STRING	Containing the PDU Session Resource Notify Released Transfer IE specified in subclause 9.3.4.13.	-	
User Location Information	0		9.3.1.16		YES	ignore

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.

## 9.2.1.8 PDU SESSION RESOURCE MODIFY INDICATION

This message is sent by the NG-RAN node and is used to request the AMF to enable modifications of already established PDU session resources for a given UE.

Direction: NG-RAN node → AMF

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
			reference	description		Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
PDU Session		1			YES	reject
Resource Modify						
Indication List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource Modify		ofPDUSes				
Indication Item		sions>				
>>PDU Session ID	M		9.3.1.50		-	
>>PDU Session	M		OCTET	Containing the	-	
Resource Modify			STRING	PDU Session		
Indication Transfer				Resource Modify		
				Indication Transfer		
				IE specified in		
				subclause 9.3.4.6.		

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.

#### 9.2.1.9 PDU SESSION RESOURCE MODIFY CONFIRM

This message is sent by the AMF and is used to confirm the outcome of the request from the PDU SESSION RESOURCE MODIFY INDICATION message.

Direction: AMF → NG-RAN node

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
			reference	description		Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	ignore
PDU Session		01			YES	ignore
Resource Modify						
Confirm List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource Modify		ofPDUSes				
Confirm Item		sions>				
>>PDU Session ID	M		9.3.1.50		-	
>>PDU Session	M		OCTET	Containing the	-	
Resource Modify			STRING	PDU Session		
Confirm Transfer				Resource Modify		
				Confirm Transfer		
				IE specified in		
				subclause 9.3.4.7.		
PDU Session		01			YES	ignore
Resource Failed to						
Modify List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource Failed to		ofPDUSes				
Modify Item		sions>				
>>PDU Session ID	M		9.3.1.50		-	
>>PDU Session	M		OCTET	Containing the	-	
Resource Modify			STRING	PDU Session		
Indication				Resource Modify		
Unsuccessful				Indication		
Transfer				Unsuccessful		
				Transfer IE		
				specified in		
				subclause		
				9.3.4.22.		
Criticality Diagnostics	0		9.3.1.3		YES	ignore

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.

# 9.2.2 UE Context Management Messages

#### 9.2.2.1 INITIAL CONTEXT SETUP REQUEST

This message is sent by the AMF to request the setup of a UE context.

Direction: AMF → NG-RAN node

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
			reference	description		Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	М		9.3.3.2		YES	reject
Old AMF	0		AMF Name		YES	reject
			9.3.3.21			
UE Aggregate	C-		9.3.1.58		YES	reject
Maximum Bit Rate	ifPDUsess					
	ionResour					
	ceSetup				/=0	
Core Network	0		9.3.1.15		YES	ignore
Assistance Information						
for RRC INACTIVE	D 4		0.0.0.0		\/F0	
GUAMI	M	0.4	9.3.3.3		YES	reject
PDU Session		01			YES	reject
Resource Setup Request List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>_</td><td></td></maxno<>			_	
Resource Setup		ofPDUSes			-	
Request Item		sions>				
>>PDU Session ID	М	3101132	9.3.1.50		-	
>>PDU Session NAS-	0		NAS-PDU			
PDU PDU			9.3.3.4		_	
>>S-NSSAI	М		9.3.1.24		_	
>>PDU Session	M		OCTET	Containing the	_	
Resource Setup	'*'		STRING	PDU Session		
Request Transfer			01141110	Resource Setup		
1				Request Transfer		
				IE specified in		
				subclause 9.3.4.1.		
Allowed NSSAI	M		9.3.1.31	Indicates the S-	YES	reject
				NSSAIs permitted		
				by the network		
UE Security Capabilities	M		9.3.1.86		YES	reject
Security Key	M		9.3.1.87		YES	reject
Trace Activation	0		9.3.1.14		YES	ignore
Mobility Restriction List	0		9.3.1.85		YES	ignore
UE Radio Capability	0		9.3.1.74		YES	ignore
Index to	0		9.3.1.61		YES	ignore
RAT/Frequency						
Selection Priority			0.04.54		VEC	:
Masked IMEISV	0		9.3.1.54		YES	ignore
NAS-PDU	0		9.3.3.4		YES YES	ignore
Emergency Fallback Indicator			9.3.1.26		150	reject
RRC Inactive Transition	0		9.3.1.91		YES	ignoro
Report Request			3.3.1.31		153	ignore
UE Radio Capability for	0		9.3.1.68		YES	ignore
Paging	"		3.3.1.00		153	ignore
Redirection for Voice	0		9.3.1.116		YES	ignore
EPS Fallback			0.0.1.110		'23	ignore
Location Reporting	0		9.3.1.65		YES	ignore
Request Type	~		0.0.1.00		1 .20	1911010
CN Assisted RAN	0		9.3.1.119		YES	ignore
Parameters Tuning	-					.90.0

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.

Condition	Explanation
ifPDUsessionResourceSetup	This IE shall be present if the PDU Session Resource Setup List IE is
	present.

### 9.2.2.2 INITIAL CONTEXT SETUP RESPONSE

This message is sent by the NG-RAN node to confirm the setup of a UE context.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
			reference	description		Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	ignore
PDU Session		01			YES	ignore
Resource Setup						
Response List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource Setup		ofPDUSes				
Response Item		sions>				
>>PDU Session ID	M		9.3.1.50		-	
>>PDU Session	M		OCTET	Containing the	-	
Resource Setup			STRING	PDU Session		
Response Transfer				Resource Setup		
				Response		
				Transfer IE		
				specified in		
				subclause 9.3.4.2.		
PDU Session		01			YES	ignore
Resource Failed to						
Setup List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource Failed to		ofPDUSes				
Setup Item		sions>				
>>PDU Session ID	M		9.3.1.50		-	
>>PDU Session	M		OCTET	Containing the	-	
Resource Setup			STRING	PDU Session		
Unsuccessful				Resource Setup		
Transfer				Unsuccessful		
				Transfer IE		
				specified in		
				subclause		
				9.3.4.16.		
Criticality Diagnostics	0		9.3.1.3		YES	ignore

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.

## 9.2.2.3 INITIAL CONTEXT SETUP FAILURE

This message is sent by the NG-RAN node to indicate that the setup of the UE context was unsuccessful.

Direction: NG-RAN node → AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1		YES	reject
AMF UE NGAP ID	М		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	ignore
PDU Session		01			YES	ignore
Resource Failed to Setup List						
>PDU Session Resource Failed to Setup Item		1 <maxno ofPDUSes sions&gt;</maxno 			-	
>>PDU Session ID	М		9.3.1.50		-	
>>PDU Session Resource Setup Unsuccessful Transfer	M		OCTET STRING	Containing the PDU Session Resource Setup Unsuccessful Transfer IE specified in subclause 9.3.4.16.	-	
Cause	М		9.3.1.2		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

Range bound	Explanation			
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.			

#### 9.2.2.4 UE CONTEXT RELEASE REQUEST

This message is sent by the NG-RAN node to request the release of the UE-associated logical NG-connection over the NG interface.

Direction: NG-RAN node → AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
PDU Session		01			YES	reject
Resource List						-
>PDU Session Resource Item		1 <maxno ofPDUSes sions&gt;</maxno 			-	
>>PDU Session ID	M		9.3.1.50		-	
Cause	M		9.3.1.2		YES	ignore

Range bound	Explanation			
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.			

### 9.2.2.5 UE CONTEXT RELEASE COMMAND

This message is sent by the AMF to request the release of the UE-associated logical NG-connection over the NG interface.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
CHOICE UE NGAP IDs	M				YES	reject
>UE NGAP ID pair						
>>AMF UE NGAP ID	M		9.3.3.1		-	
>>RAN UE NGAP ID	M		9.3.3.2		-	
>AMF UE NGAP ID						
>>AMF UE NGAP ID	M		9.3.3.1		-	
Cause	M		9.3.1.2		YES	ignore

### 9.2.2.6 UE CONTEXT RELEASE COMPLETE

This message is sent by the NG-RAN node to confirm the release of the UE-associated logical NG-connection over the NG interface.

Direction: NG-RAN node → AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	ignore
User Location Information	0		9.3.1.16		YES	ignore
Information on Recommended Cells and RAN Nodes for Paging	0		9.3.1.100		YES	ignore
PDU Session Resource List		01			YES	reject
>PDU Session Resource Item		1 <maxno ofPDUSes sions&gt;</maxno 			-	
>>PDU Session ID	M		9.3.1.50		-	
>>PDU Session Resource Release Response Transfer	0		OCTET STRING	Containing the PDU Session Resource Release Response Transfer IE specified in subclause 9.3.4.21.	YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

Range bound	Explanation			
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.			

### 9.2.2.7 UE CONTEXT MODIFICATION REQUEST

This message is sent by the AMF to provide UE Context information changes to the NG-RAN node.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
RAN Paging Priority	0		9.3.3.15		YES	ignore
Security Key	0		9.3.1.87		YES	reject
Index to RAT/Frequency Selection Priority	0		9.3.1.61		YES	ignore
UE Aggregate Maximum Bit Rate	0		9.3.1.58		YES	ignore
UE Security Capabilities	0		9.3.1.86		YES	reject
Core Network Assistance Information for RRC INACTIVE	0		9.3.1.15		YES	ignore
Emergency Fallback Indicator	0		9.3.1.26		YES	reject
New AMF UE NGAP ID	0		AMF UE NGAP ID 9.3.3.1		YES	reject
RRC Inactive Transition Report Request	0		9.3.1.91		YES	ignore
New GUAMI	0		GUAMI 9.3.3.3		YES	reject
CN Assisted RAN Parameters Tuning	0		9.3.1.119		YES	ignore

#### 9.2.2.8 UE CONTEXT MODIFICATION RESPONSE

This message is sent by the NG-RAN node to confirm the performed UE context updates.

Direction: NG-RAN node → AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	ignore
RRC State	0		9.3.1.92		YES	ignore
User Location Information	0		9.3.1.16		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

#### 9.2.2.9 UE CONTEXT MODIFICATION FAILURE

This message is sent by the NG-RAN node in case the performed UE context update is not successful.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	ignore
Cause	M		9.3.1.2		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

#### 9.2.2.10 RRC INACTIVE TRANSITION REPORT

This message is sent by the NG-RAN node to notify the 5GC the UE enters or leaves RRC\_INACTIVE state.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
RRC State	M		9.3.1.92		YES	ignore
User Location Information	M		9.3.1.16		YES	ignore

## 9.2.3 UE Mobility Management Messages

#### 9.2.3.1 HANDOVER REQUIRED

This message is sent by the source NG-RAN node to the AMF to request the preparation of resources at the target.

Direction: NG-RAN node  $\rightarrow$  AMF.

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
			reference	description		Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	М		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
Handover Type	М		9.3.1.22		YES	reject
Cause	М		9.3.1.2		YES	ignore
Target ID	М		9.3.1.25		YES	reject
Direct Forwarding Path Availability	0		9.3.1.64		YES	ignore
PDU Session		1			YES	reject
Resource List						,
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource Item		ofPDUSes				
		sions>				
>>PDU Session ID	M		9.3.1.50		-	
>>Handover Required	M		OCTET	Containing the	-	
Transfer			STRING	Handover		
				Required Transfer		
				IE specified in		
				subclause		
				9.3.4.14.		
Source to Target Transparent Container	M		9.3.1.20		YES	reject

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.

#### 9.2.3.2 HANDOVER COMMAND

This message is sent by the AMF to inform the source NG-RAN node that resources for the handover have been prepared at the target side.

Direction: AMF→ NG-RAN node.

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
			reference	description	\/F0	Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
Handover Type	М		9.3.1.22		YES	reject
NAS Security Parameters from NG- RAN	C-iftoEPS		9.3.3.26		YES	reject
PDU Session Resource Handover List		01			YES	ignore
>PDU Session Resource Handover Item		1 <maxno ofPDUSes sions&gt;</maxno 			-	
>>PDU Session ID	М		9.3.1.50		-	
>>Handover Command Transfer	М		OCTET STRING	Containing the Handover Command Transfer IE specified in subclause 9.3.4.10.	-	
PDU Session Resource to Release List		01			YES	ignore
>PDU Session Resource to Release Item		1 <maxno ofPDUSes sions&gt;</maxno 			-	
>>PDU Session ID	M		9.3.1.50		-	
>>Handover Preparation Unsuccessful Transfer	М		OCTET STRING	Containing the Handover Preparation Unsuccessful Transfer IE specified in subclause 9.3.4.18.	-	
Target to Source Transparent Container	М		9.3.1.21		YES	reject
Criticality Diagnostics	0		9.3.1.3		YES	ignore

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.

Condition	Explanation
iftoEPS	This IE shall be present if the Handover Type IE is set to the value
	"5GStoEPS".

## 9.2.3.3 HANDOVER PREPARATION FAILURE

This message is sent by the AMF to inform the source NG-RAN node that the Handover Preparation has failed.

Direction: AMF  $\rightarrow$  NG-RAN node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	ignore
Cause	M		9.3.1.2		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

## 9.2.3.4 HANDOVER REQUEST

This message is sent by the AMF to the target NG-RAN node to request the preparation of resources.

Direction: AMF  $\rightarrow$  NG-RAN node.

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
			reference	description		Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	reject
Handover Type	M		9.3.1.22		YES	reject
Cause	M		9.3.1.2		YES	ignore
UE Aggregate	M		9.3.1.58		YES	reject
Maximum Bit Rate	0		0.04.45		VEC	:
Core Network Assistance Information	0		9.3.1.15		YES	ignore
for RRC INACTIVE						
UE Security Capabilities	M		9.3.1.86		YES	reject
Security Context	M		9.3.1.88		YES	reject
New Security Context Indicator	0		9.3.1.55		YES	reject
NASC	0		NAS-PDU 9.3.3.4	Refers to either the "Intra N1 mode NAS transparent container" or the "S1 mode to N1 mode NAS transparent container", the details of the IE definition and the encoding arespecified in TS 24.501 [26].	YES	reject
PDU Session		1			YES	reject
Resource Setup List						-
>PDU Session Resource Setup Item		1 <maxno ofPDUSes sions&gt;</maxno 			-	
>>PDU Session ID	М	0.0	9.3.1.50		_	
>>S-NSSAI	M		9.3.1.24		_	
>>Handover Request	M		OCTET	Containing the	_	
Transfer			STRING	PDU Session Resource Setup Request Transfer IE specified in subclause 9.3.4.1.		
Allowed NSSAI	M		9.3.1.31	Indicates the S- NSSAIs permitted by the network.	YES	reject
Trace Activation	0		9.3.1.14		YES	ignore
Masked IMEISV	0		9.3.1.54		YES	ignore
Source to Target Transparent Container	М		9.3.1.20		YES	reject
Mobility Restriction List	0		9.3.1.85		YES	ignore
Location Reporting	0		9.3.1.65		YES	ignore
Request Type RRC Inactive Transition Report Request	0		9.3.1.91		YES	ignore
GUAMI	М		9.3.3.3		YES	reject
Redirection for Voice EPS Fallback	O		9.3.1.116		YES	ignore
CN Assisted RAN Parameters Tuning	0		9.3.1.119		YES	ignore

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.

### 9.2.3.5 HANDOVER REQUEST ACKNOWLEDGE

This message is sent by the target NG-RAN node to inform the AMF about the prepared resources at the target.

Direction: NG-RAN node  $\rightarrow$  AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2	Allocated at the target NG-RAN node.	YES	ignore
PDU Session Resource Admitted List		1			YES	ignore
>PDU Session Resource Admitted Item		1 <maxno ofPDUSes sions&gt;</maxno 			-	
>>PDU Session ID	M		9.3.1.50		-	
>>Handover Request Acknowledge Transfer	М		OCTET STRING	Containing the Handover Request Acknowledge Transfer IE specified in subclause 9.3.4.11.	-	
PDU Session Resource Failed to Setup List		01			YES	ignore
>PDU Session Resource Failed to Setup Item		1 <maxno ofPDUSes sions&gt;</maxno 			-	
>>PDU Session ID	М		9.3.1.50		-	
>>Handover Resource Allocation Unsuccessful Transfer	M		OCTET STRING	Containing the Handover Resource Allocation Unsuccessful Transfer IE specified in subclause 9.3.4.19.	-	
Target to Source Transparent Container	М		9.3.1.21		YES	reject
Criticality Diagnostics	0		9.3.1.3		YES	ignore

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.

### 9.2.3.6 HANDOVER FAILURE

This message is sent by the target NG-RAN node to inform the AMF that the preparation of resources has failed.

Direction: NG-RAN node  $\rightarrow$  AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
Cause	M		9.3.1.2		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

#### 9.2.3.7 HANDOVER NOTIFY

This message is sent by the target NG-RAN node to inform the AMF that the UE has been identified in the target cell and the handover has been completed.

Direction: NG-RAN node  $\rightarrow$  AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
User Location Information	M		9.3.1.16		YES	ignore

### 9.2.3.8 PATH SWITCH REQUEST

This message is sent by the NG-RAN node to inform the AMF of the new serving NG-RAN node and to transfer some NG-U DL tunnel termination point(s) to the SMF via the AMF for one or multiple PDU session resources.

Direction: NG-RAN node  $\rightarrow$  AMF.

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
			reference	description		Criticality
Message Type	M		9.3.1.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
Source AMF UE NGAP	M		AMF UE NGAP		YES	reject
ID			ID			
			9.3.3.1			
User Location	M		9.3.1.16		YES	ignore
Information						
UE Security Capabilities	M		9.3.1.86		YES	ignore
PDU Session		1			YES	reject
Resource to be						
Switched in Downlink						
List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource to be		ofPDUSes				
Switched in Downlink		sions>				
Item						
>>PDU Session ID	M		9.3.1.50		-	
>>Path Switch	M		OCTET	Containing the	-	
Request Transfer			STRING	Path Switch		
				Request Transfer		
				IE specified in		
				subclause 9.3.4.8.		
PDU Session		01			YES	ignore
Resource Failed to						
Setup List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource Failed to		ofPDUSes				
Setup Item		sions>				
>>PDU Session ID	M		9.3.1.50		-	
>>Path Switch	M		OCTET	Containing the	-	
Request Setup Failed			STRING	Path Switch		
Transfer				Request Setup		
				Failed Transfer IE		
				specified in		
				subclause		
				9.3.4.15.		

Range bound	Explanation			
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.			

## 9.2.3.9 PATH SWITCH REQUEST ACKNOWLEDGE

This message is sent by the AMF to inform the NG-RAN node that the path switch has been successfully completed in the 5 GC.

Direction: AMF  $\rightarrow$  NG-RAN node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1	•	YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	ignore
UE Security Capabilities	0		9.3.1.86		YES	reject
Security Context	M		9.3.1.88		YES	reject
New Security Context	0		9.3.1.55		YES	reject
Indicator						,
PDU Session		1			YES	ignore
Resource Switched						
List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource Switched		ofPDUSes				
Item		sions>				
>>PDU Session ID	М		9.3.1.50		-	
>>Path Switch	M		OCTET	Containing the	-	
Request			STRING	Path Switch		
Acknowledge				Request		
Transfer				Acknowledge		
Transier				Transfer IE		
				specified in		
				subclause 9.3.4.9.		
PDU Session		01			YES	ignore
Resource Released					0	.9
List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>_</td><td></td></maxno<>			_	
Resource Released		ofPDUSes				
Item		sions>				
>>PDU Session ID	М		9.3.1.50		_	
>>Path Switch	M		OCTET	Containing the	_	
Request	'*'		STRING	Path Switch		
Unsuccessful			0111110	Request		
Transfer				Unsuccessful		
114110101				Transfer IE		
				specified in		
				subclause		
				9.3.4.20.		
Allowed NSSAI	М		9.3.1.31	Indicates the S-	YES	reject
7 o	'''		0.0.1.01	NSSAIs permitted	120	10,000
				by the network.		
Core Network	0		9.3.1.15	2, 110 11011101111	YES	ignore
Assistance Information	~		0.0.1.10		1.20	19.7010
for RRC INACTIVE						
RRC Inactive Transition	0		9.3.1.91		YES	ignore
Report Request	-		3.3.1.51		1	19.7010
Criticality Diagnostics	0		9.3.1.3		YES	ignore
Redirection for Voice	0		9.3.1.116		YES	ignore
EPS Fallback						-
CN Assisted RAN	0		9.3.1.119		YES	ignore
Parameters Tuning						

Range bound	Explanation				
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.				

#### 9.2.3.10 PATH SWITCH REQUEST FAILURE

This message is sent by the AMF to inform the NG-RAN node that a failure has occurred in the 5GC during the Path Switch Request procedure.

Direction: AMF  $\rightarrow$  NG-RAN node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1	description	YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	ignore
PDU Session		1			YES	ignore
Resource Released						
List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource Released		ofPDUSes				
Item		sions>				
>>PDU Session ID	M		9.3.1.50		-	
>>Path Switch	M		OCTET	Containing the	-	
Request			STRING	PDU session Path		
Unsuccessful				Switch Request		
Transfer				Unsuccessful		
				Transfer IE		
				specified in		
				subclause		
				9.3.4.20.		
Criticality Diagnostics	0		9.3.1.3		YES	ignore

Range bound	Explanation		
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.		

#### 9.2.3.11 HANDOVER CANCEL

This message is sent by the source NG-RAN node to the AMF to request the cancellation of an ongoing handover.

Direction: NG-RAN node  $\rightarrow$  AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
Cause	М		9.3.1.2		YES	ignore

#### 9.2.3.12 HANDOVER CANCEL ACKNOWLEDGE

This message is sent by the AMF to the source NG-RAN node to confirm that the ongoing handover was cancelled.

Direction: AMF  $\rightarrow$  NG-RAN node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

#### 9.2.3.13 UPLINK RAN STATUS TRANSFER

This message is sent by the source NG-RAN node to transfer the uplink PDCP-SN and HFN receiver status and the downlink PDCP SN and HFN transmitter status during intra 5GC NG-based handover.

Direction: NG-RAN node  $\rightarrow$  AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
RAN Status Transfer Transparent Container	М		9.3.1.108		YES	reject

#### 9.2.3.14 DOWNLINK RAN STATUS TRANSFER

This message is sent by the AMF to the target NG-RAN node to transfer the uplink PDCP-SN and HFN receiver status and the downlink PDCP SN and HFN transmitter status during intra 5GC NG-based handover.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
RAN Status Transfer Transparent Container	М		9.3.1.108		YES	reject

## 9.2.4 Paging Messages

#### 9.2.4.1 PAGING

This message is sent by the AMF and is used to page a UE in one or several tracking areas.

Direction: AMF  $\rightarrow$  gNB

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1		YES	ignore
UE Paging Identity	M		9.3.3.18		YES	ignore
Paging DRX	0		9.3.1.90		YES	ignore
TAI List for Paging		1			YES	ignore
>TAI List for Paging Item		1 <maxno ofTAIforPa ging&gt;</maxno 			-	
>>TAI	M		9.3.3.11		-	
Paging Priority	0		9.3.1.78		YES	ignore
UE Radio Capability for Paging	0		9.3.1.68		YES	ignore
Paging Origin	0		9.3.3.22		YES	ignore
Assistance Data for Paging	0		9.3.1.69		YES	ignore

Range bound	Explanation
maxnoofTAlforPaging	Maximum no. of TAIs for paging. Value is 16.

## 9.2.5 NAS Transport Messages

#### 9.2.5.1 INITIAL UE MESSAGE

This message is sent by the NG-RAN node to transfer the initial layer 3 message to the AMF over the NG interface.

Direction: NG-RAN node → AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	reject
NAS-PDU	M		9.3.3.4		YES	reject
User Location Information	M		9.3.1.16		YES	reject
RRC Establishment Cause	M		9.3.1.111		YES	ignore
5G-S-TMSI	0		9.3.3.20		YES	reject
AMF Set ID	0		9.3.3.12		YES	ignore
UE Context Request	0		ENUMERATED (requested,)		YES	ignore
Allowed NSSAI	0		9.3.1.31		YES	reject
Source to Target AMF Information Reroute	0		9.3.3.27		YES	ignore
Selected PLMN Identity	0		PLMN Identity 9.3.3.5	Indicates the selected PLMN id for the non-3GPP access.	YES	ignore

#### 9.2.5.2 DOWNLINK NAS TRANSPORT

This message is sent by the AMF and is used for carrying NAS information over the NG interface.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
Old AMF	0		AMF Name 9.3.3.21		YES	reject
RAN Paging Priority	0		9.3.3.15		YES	ignore
NAS-PDU	M		9.3.3.4		YES	reject
Mobility Restriction List	0		9.3.1.85		YES	ignore
Index to RAT/Frequency Selection Priority	0		9.3.1.61		YES	ignore
UE Aggregate Maximum Bit Rate	0		9.3.1.58		YES	ignore
Allowed NSSAI	0		9.3.1.31	Indicates the S- NSSAIs permitted by the network.	YES	reject

#### 9.2.5.3 UPLINK NAS TRANSPORT

This message is sent by the NG-RAN node and is used for carrying NAS information over the NG interface.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
			reference	description		Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
NAS-PDU	M		9.3.3.4		YES	reject
User Location	M		9.3.1.16		YES	ignore
Information						

#### 9.2.5.4 NAS NON DELIVERY INDICATION

This message is sent by the NG-RAN node and is used for reporting the non-delivery of a NAS PDU previously received within a DOWNLINK NAS TRANSPORT message over the NG interface.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
NAS-PDU	M		9.3.3.4		YES	ignore
Cause	M		9.3.1.2		YES	ignore

#### 9.2.5.5 REROUTE NAS REQUEST

This message is sent by the AMF in order to request for a rerouting of the INITIAL UE MESSAGE to another AMF.

Direction: AMF → NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1		YES	reject
RAN UE NGAP ID	М		9.3.3.2		YES	reject
AMF UE NGAP ID	0		9.3.3.1		YES	ignore
NGAP Message	M		OCTET STRING	Contains the INITIAL UE MESSAGE	YES	reject
AMF Set ID	М		9.3.3.12		YES	reject
Allowed NSSAI	0		9.3.1.31		YES	reject
Source to Target AMF Information Reroute	0		9.3.3.27		YES	ignore

# 9.2.6 Interface Management Messages

### 9.2.6.1 NG SETUP REQUEST

This message is sent by the NG-RAN node to transfer application layer information for an NG-C interface instance.

Direction: NG-RAN node → AMF

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
			reference	description		Criticality
Message Type	M		9.3.1.1		YES	reject
Global RAN Node ID	M		9.3.1.5		YES	reject
RAN Node Name	0		PrintableString (SIZE(1150,))		YES	ignore
Supported TA List		1		Supported TAs in the NG-RAN node.	YES	reject
>Supported TA Item		1 <maxno ofTACs&gt;</maxno 			-	
>>TAC	M		9.3.3.10	Broadcast TAC	-	
>>Broadcast PLMN List		1			-	
>>>Broadcast PLMN Item		1 <maxno ofBPLMNs &gt;</maxno 			-	
>>>>PLMN Identity	M		9.3.3.5	Broadcast PLMN	-	
>>>>TAI Slice Support List	M		Slice Support List 9.3.1.17	Supported S- NSSAIs per TA.	-	
Default Paging DRX	М		Paging DRX 9.3.1.90		YES	ignore
UE Retention Information	0		9.3.1.117		YES	ignore

Range bound	Explanation
maxnoofTACs	Maximum no. of TACs. Value is 256.
maxnoofBPLMNs	Maximum no. of Broadcast PLMNs. Value is 12.

# 9.2.6.2 NG SETUP RESPONSE

This message is sent by the AMF to transfer application layer information for an NG-C interface instance.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1		YES	reject
AMF Name	М		9.3.3.21		YES	reject
Served GUAMI List		1			YES	reject
>Served GUAMI Item		1 <maxno ofServedG UAMIs&gt;</maxno 			-	
>>GUAMI	M		9.3.3.3		-	
>>Backup AMF Name	0		AMF Name 9.3.3.21		-	
Relative AMF Capacity	M		9.3.1.32		YES	ignore
PLMN Support List		1			YES	reject
>PLMN Support Item		1 <maxno ofPLMNs&gt;</maxno 			-	
>>PLMN Identity	М		9.3.3.5		-	
>>Slice Support List	М		9.3.1.17	Supported S- NSSAIs per PLMN	-	
Criticality Diagnostics	0		9.3.1.3		YES	ignore
UE Retention Information	0		9.3.1.117		YES	ignore

Range bound	Explanation
maxnoofServedGUAMIs	Maximum no. of GUAMIs served by an AMF. Value is 256.
maxnoofPLMNs	Maximum no. of PLMNs per message. Value is 12.

### 9.2.6.3 NG SETUP FAILURE

This message is sent by the AMF to indicate NG setup failure.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
Cause	M		9.3.1.2		YES	ignore
Time to Wait	0		9.3.1.56		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

### 9.2.6.4 RAN CONFIGURATION UPDATE

This message is sent by the NG-RAN node to transfer updated application layer information for an NG-C interface instance.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
RAN Node Name	0		PrintableString (SIZE(1150,))		YES	ignore
Supported TA List		01		Supported TAs in the NG-RAN node.	YES	reject
>Supported TA Item		1 <maxno ofTACs&gt;</maxno 			-	
>>TAC	M		9.3.3.10	Broadcast TAC	-	
>>Broadcast PLMN List		1			-	
>>>Broadcast PLMN Item		1 <maxno ofBPLMNs &gt;</maxno 			-	
>>>>PLMN Identity	M		9.3.3.5	Broadcast PLMN	-	
>>>>TAI Slice Support List	M		Slice Support List 9.3.1.17	Supported S- NSSAIs per TA.	-	
Default Paging DRX	0		Paging DRX 9.3.1.90		YES	ignore
Global RAN Node ID	0		9.3.1.5		YES	ignore
NG-RAN TNL Association to Remove List		01			YES	reject
>NG-RAN TNL Association to Remove Item		1 <maxno ofTNLAss ociations&gt;</maxno 			-	
>>TNL Association Transport Layer Address	M		CP Transport Layer Information 9.3.2.6	Transport layer address of the NG-RAN node.	-	
>>TNL Association Transport Layer Address at AMF	0		CP Transport Layer Information 9.3.2.6	Transport layer address of the AMF.	-	

Range bound	Explanation
maxnoofTACs	Maximum no. of TACs. Value is 256.
maxnoofBPLMNs	Maximum no. of Broadcast PLMNs. Value is 12.
maxnoofTNLAssociations	Maximum no. of TNL Associations between the NG-RAN node and the
	AMF. Value is 32.

#### 9.2.6.5 RAN CONFIGURATION UPDATE ACKNOWLEDGE

This message is sent by the AMF to acknowledge the NG-RAN node transfer of updated information for an NG-C interface instance.

Direction: AMF → NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
Criticality Diagnostics	0		9.3.1.3		YES	ignore

#### 9.2.6.6 RAN CONFIGURATION UPDATE FAILURE

This message is sent by the AMF to indicate RAN configuration update failure.

Direction: AMF → NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
Cause	M		9.3.1.2		YES	ignore
Time to Wait	0		9.3.1.56		YES	ignore
Criticality Diagnostics	0	•	9.3.1.3		YES	ignore

#### 9.2.6.7 AMF CONFIGURATION UPDATE

This message is sent by the AMF to transfer updated information for an NG-C interface instance.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
AMF Name	0		9.3.3.21		YES	reject
Served GUAMI List		01			YES	reject
>Served GUAMI Item		1 <maxno ofServedG UAMIs&gt;</maxno 			-	
>>GUAMI	M		9.3.3.3		-	
>>Backup AMF Name	0		AMF Name 9.3.3.21		-	
Relative AMF Capacity	0		9.3.1.32		YES	ignore
PLMN Support List		01			YES	reject
>PLMN Support Item		1 <maxno ofPLMNs&gt;</maxno 			-	
>>PLMN Identity	M		9.3.3.5		-	
>>Slice Support List	М		9.3.1.17	Supported S- NSSAIs per PLMN	-	
AMF TNL Association to Add List		01			YES	ignore
>AMF TNL Association to Add Item		1 <maxno ofTNLAss ociations&gt;</maxno 			-	
>>AMF TNL Association Address	M		CP Transport Layer Information 9.3.2.6	AMF Transport Layer information used to set up the new TNL association.	-	
>>TNL Association Usage	0		9.3.2.9		-	
>>TNL Address Weight Factor	М		9.3.2.10		-	
AMF TNL Association to Remove List		01			YES	ignore
>AMF TNL Association to Remove Item		1 <maxno ofTNLAss ociations&gt;</maxno 			-	
>>AMF TNL Association Address	M		CP Transport Layer Information 9.3.2.6	Transport Layer Address of the AMF.	-	
>>TNL Association Transport Layer Address NG-RAN	0		CP Transport Layer Address 9.3.2.6	Transport Layer Address of the NG-RAN node.	YES	reject
AMF TNL Association to Update List		01			YES	ignore
>AMF TNL Association to Update Item		1 <maxno ofTNLAss ociations&gt;</maxno 			-	
>>AMF TNL Association Address	M		CP Transport Layer Information 9.3.2.6	AMF Transport Layer information used to identify the TNL association to be updated.	-	
>>TNL Association Usage	0		9.3.2.9		-	
>>TNL Address Weight Factor	0		9.3.2.10		-	

Range bound	Explanation
maxnoofServedGUAMIs	Maximum no. of GUAMIs served by an AMF. Value is 256.
maxnoofPLMNs	Maximum no. of PLMNs per message. Value is 12.
maxnoofTNLAssociations	Maximum no. of TNL Associations between the NG-RAN node and the
	AMF. Value is 32.

## 9.2.6.8 AMF CONFIGURATION UPDATE ACKNOWLEDGE

This message is sent by the NG-RAN node to acknowledge the AMF transfer of updated information for an NG-C interface instance.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1		YES	reject
AMF TNL Association		01			YES	ignore
Setup List						
>AMF TNL		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Association Setup		ofTNLAss				
Item		ociations>				
>>AMF TNL Association Address	М		CP Transport Layer	Previously received AMF	-	
			Information	Transport Layer		
			9.3.2.6	information for the		
				TNL association.		
AMF TNL Association	0		TNL		YES	ignore
Failed to Setup List			Association List			
			9.3.2.7			
Criticality Diagnostics	0		9.3.1.3		YES	ignore

Range bound	Explanation
maxnoofTNLAssociations	Maximum no. of TNL Associations between the NG-RAN node and the
	AMF. Value is 32.

#### 9.2.6.9 AMF CONFIGURATION UPDATE FAILURE

This message is sent by the NG-RAN node to indicate AMF configuration update failure.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
Cause	M		9.3.1.2		YES	ignore
Time to Wait	0		9.3.1.56		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

#### 9.2.6.10 AMF STATUS INDICATION

This message is sent by the AMF to support AMF management functions.

Direction: AMF → NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
Unavailable GUAMI List		1		Indicates the GUAMIs configured to be unavailable at the AMF	YES	reject
>Unavailable GUAMI Item		1 <maxno ofServedG UAMIs&gt;</maxno 			-	
>>GUAMI	M		9.3.3.3		-	
>>Timer Approach for GUAMI Removal	0		ENUMERATED (apply timer,)		-	
>>Backup AMF Name	0		AMF Name 9.3.3.21		-	

Range bound	Explanation
maxnoofServedGUAMIs	Maximum no. of GUAMIs served by an AMF. Value is 256.

### 9.2.6.11 NG RESET

This message is sent by both the NG-RAN node and the AMF to request that the NG interface, or parts of the NG interface, be reset.

Direction: NG-RAN node → AMF and AMF → NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
Cause	M		9.3.1.2		YES	ignore
CHOICE Reset Type	M				YES	reject
>NG interface						
>>Reset All	М		ENUMERATED (Reset all,)		-	
>Part of NG interface						
>>UE-associated Logical NG- connection List	M		9.3.3.25		-	

### 9.2.6.12 NG RESET ACKNOWLEDGE

This message is sent by both the NG-RAN node and the AMF as a response to an NG RESET message.

Direction: NG-RAN node  $\rightarrow$  AMF and AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
UE-associated Logical NG-connection List	0		9.3.3.25		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

#### 9.2.6.13 ERROR INDICATION

This message is sent by both the NG-RAN node and the AMF to indicate that some error has been detected in the node.

Direction: NG-RAN node  $\rightarrow$  AMF and AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	0		9.3.3.1		YES	ignore
RAN UE NGAP ID	0		9.3.3.2		YES	ignore
Cause	0		9.3.1.2		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

#### 9.2.6.14 OVERLOAD START

This message is sent by the AMF and is used to indicate to the NG-RAN node that the AMF is overloaded.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1		YES	ignore
AMF Overload Response	0		Overload Response 9.3.1.104		YES	reject
AMF Traffic Load Reduction Indication	0		Traffic Load Reduction Indication 9.3.1.106		YES	ignore
Overload Start NSSAI List		01			YES	ignore
>Overload Start NSSAI Item		1 <maxno ofSliceIte ms&gt;</maxno 			-	
>>Slice Overload List	M		9.3.1.107		-	
>>Slice Overload Response	0		Overload Response 9.3.1.104		-	
>>Slice Traffic Load Reduction Indication	0		Traffic Load Reduction Indication 9.3.1.106		-	

Range bound	Explanation		
maxnoofSliceItems	Maximum no. of signalled slice support items. Value is 1024.		

#### 9.2.6.15 OVERLOAD STOP

This message is sent by the AMF and is used to indicate that the AMF is no longer overloaded.

Direction: AMF → NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject

# 9.2.7 Configuration Transfer Messages

#### 9.2.7.1 UPLINK RAN CONFIGURATION TRANSFER

This message is sent by the NG-RAN node in order to transfer RAN configuration information.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
			reference	description		Criticality
Message Type	M		9.3.1.1		YES	ignore
SON Configuration	0		9.3.3.6		YES	ignore
Transfer						
EN-DC SON	0		OCTET	Contains the EN-	YES	ignore
Configuration Transfer			STRING	DC SON		
				Configuration		
				Transfer IE as		
				defined in TS		
				36.413 [16].		

### 9.2.7.2 DOWNLINK RAN CONFIGURATION TRANSFER

This message is sent by the AMF in order to transfer RAN configuration information.

Direction: AMF → NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
SON Configuration Transfer	0		9.3.3.6		YES	ignore
EN-DC SON Configuration Transfer	0		OCTET STRING	Contains the EN-DC SON Configuration Transfer IE as defined in TS 36.413 [16].	YES	ignore

# 9.2.8 Warning Message Transmission Messages

### 9.2.8.1 WRITE-REPLACE WARNING REQUEST

This message is sent by the AMF to request the start or overwrite of the broadcast of a warning message.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
Message Identifier	M		9.3.1.35		YES	reject
Serial Number	M		9.3.1.36		YES	reject
Warning Area List	0		9.3.1.37		YES	ignore
Repetition Period	M		9.3.1.49		YES	reject
Number of Broadcasts Requested	М		9.3.1.38		YES	reject
Warning Type	0		9.3.1.39		YES	ignore
Warning Security Information	0		OCTET STRING (SIZE(50))	This IE is not used in the specification. If received, the IE is ignored.	YES	ignore
Data Coding Scheme	0		9.3.1.41		YES	ignore
Warning Message Contents	0		9.3.1.42		YES	ignore
Concurrent Warning Message Indicator	0		9.3.1.46		YES	reject
Warning Area Coordinates	0		9.3.1.112		YES	ignore

#### 9.2.8.2 WRITE-REPLACE WARNING RESPONSE

This message is sent by the NG-RAN node to acknowledge the AMF on the start or overwrite request of a warning message.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
Message Identifier	M		9.3.1.35		YES	reject
Serial Number	M		9.3.1.36		YES	reject
Broadcast Completed Area List	0		9.3.1.43		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

#### 9.2.8.3 PWS CANCEL REQUEST

This message is forwarded by the AMF to the NG-RAN node to cancel an already ongoing broadcast of a warning message.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
Message Identifier	M		9.3.1.35		YES	reject
Serial Number	M		9.3.1.36		YES	reject
Warning Area List	0		9.3.1.37		YES	ignore
Cancel-All Warning Messages Indicator	0		9.3.1.47		YES	reject

#### 9.2.8.4 PWS CANCEL RESPONSE

This message is sent by the NG-RAN node to indicate the list of warning areas where cancellation of the broadcast of the identified message was successful and unsuccessful.

Direction: NG-RAN node → AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
Message Identifier	M		9.3.1.35		YES	reject
Serial Number	M		9.3.1.36		YES	reject
Broadcast Cancelled Area List	0		9.3.1.44		YES	ignore
Criticality Diagnostics	0		9.3.1.3		YES	ignore

#### 9.2.8.5 PWS RESTART INDICATION

This message is sent by the NG-RAN node to inform the AMF that PWS information for some or all cells of the NG-RAN node are available for reloading from the CBC if needed.

Direction: NG-RAN node → AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
CHOICE Cell List for Restart	М				YES	reject
>E-UTRA						
>>E-UTRA Cell List for Restart		1 <maxno ofCellsinn geNB&gt;</maxno 			-	
>>>E-UTRA CGI	M		9.3.1.9		-	
>NR						
>>NR Cell List for Restart		1 <maxno ofCellsing NB&gt;</maxno 			-	
>>>NR CGI	M		9.3.1.7		-	
Global RAN Node ID	M		9.3.1.5		YES	reject
TAI List for Restart		1 <maxno ofTAlforR estart&gt;</maxno 			YES	reject
>TAI	М		9.3.3.11		-	
Emergency Area ID List for Restart		0 <maxno ofEAlforR estart&gt;</maxno 			YES	reject
>Emergency Area ID	M		9.3.1.48		-	

Range bound	Explanation
maxnoofCellsinngeNB	Maximum no. of cells that can be served by an ng-eNB. Value is 256.
maxnoofCellsingNB	Maximum no. of cells that can be served by a gNB. Value is 16384.
maxnoofTAlforRestart	Maximum no. of TAIs subject for reloading warning message broadcast. Value is 2048.
maxnoofEAlforRestart	Maximum no. of Emergency Area IDs subject for reloading warning message broadcast. Value is 256.

## 9.2.8.6 PWS FAILURE INDICATION

This message is sent by the NG-RAN node to inform the AMF that ongoing PWS operation for one or more cells of the NG-RAN node has failed.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1		YES	ignore
CHOICE PWS Failed Cell List	M				YES	reject
>E-UTRA						
>>PWS Failed E- UTRA Cell List		1 <maxno ofCellsinn geNB&gt;</maxno 			-	
>>>E-UTRA CGI	M		9.3.1.9		-	
>NR						
>>PWS Failed NR Cell List		1 <maxno ofCellsing NB&gt;</maxno 			-	
>>>NR CGI	M		9.3.1.7		-	
Global RAN Node ID	М		9.3.1.5		YES	reject

Range bound	Explanation
maxnoofCellsinngeNB	Maximum no. of cells that can be served by an ng-eNB. Value is 256.
maxnoofCellsingNB	Maximum no. of cells that can be served by a gNB. Value is 16384.

# 9.2.9 NRPPa Transport Messages

#### 9.2.9.1 DOWNLINK UE ASSOCIATED NRPPA TRANSPORT

This message is sent by the AMF and is used for carrying NRPPa message over the NG interface.

Direction: AMF → NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
Routing ID	M		9.3.3.13		YES	reject
NRPPa-PDU	M		9.3.3.14		YES	reject

#### 9.2.9.2 UPLINK UE ASSOCIATED NRPPA TRANSPORT

This message is sent by the NG-RAN node and is used for carrying NRPPa message over the NG interface.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
Routing ID	M		9.3.3.13		YES	reject
NRPPa-PDU	M		9.3.3.14		YES	reject

#### 9.2.9.3 DOWNLINK NON UE ASSOCIATED NRPPA TRANSPORT

This message is sent by the AMF and is used for carrying NRPPa message over the NG interface.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
Routing ID	M		9.3.3.13		YES	reject
NRPPa-PDU	M		9.3.3.14		YES	reject

### 9.2.9.4 UPLINK NON UE ASSOCIATED NRPPA TRANSPORT

This message is sent by the NG-RAN node and is used for carrying NRPPa message over the NG interface.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
Routing ID	M		9.3.3.13		YES	reject
NRPPa-PDU	М		9.3.3.14		YES	reject

# 9.2.10 Trace Messages

#### 9.2.10.1 TRACE START

This message is sent by the AMF to initiate a trace session for a UE.

Direction: AMF → NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
Trace Activation	M		9.3.1.14		YES	ignore

#### 9.2.10.2 TRACE FAILURE INDICATION

This message is sent by the NG-RAN node to indicate that a Trace Start procedure or a Deactivate Trace procedure has failed for a UE.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
NG-RAN Trace ID	M		OCTET STRING (SIZE(8))	As per NG-RAN Trace ID in Trace Activation IE	YES	ignore
Cause	M		9.3.1.2		YES	ignore

### 9.2.10.3 DEACTIVATE TRACE

This message is sent by the AMF to deactivate a trace session.

Direction: AMF  $\rightarrow$  NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
NG-RAN Trace ID	M		OCTET	As per NG-RAN	YES	ignore
			STRING	Trace ID in Trace		
			(SIZE(8))	Activation IE		

### 9.2.10.4 CELL TRAFFIC TRACE

This message is sent by the NG-RAN node to transfer trace specific information.

Direction: NG-RAN node → AMF

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
			reference	description		Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
NG-RAN Trace ID	M		OCTET STRING (SIZE(8))	This IE is composed of the following: Trace Reference defined in TS 32.422 [11] (leftmost 6 octets, with PLMN information encoded as in 9.3.3.5), and Trace Recording Session Reference defined in TS 32.422 [11]	YES	ignore
NG-RAN CGI	M		9.3.1.73	(last 2 octets).	YES	ignore
	M			Defined in TS		ignore
Trace Collection Entity IP Address	IVI		Transport Layer Address 9.3.2.4	32.422 [11]	YES	ignore

# 9.2.11 Location Reporting Messages

#### 9.2.11.1 LOCATION REPORTING CONTROL

This message is used by the AMF to request the NG-RAN node to report the location of the UE.

Direction: AMF → NG-RAN node

Criticality
ES ignore
ES reject
ES reject
ES ignore

## 9.2.11.2 LOCATION REPORTING FAILURE INDICATION

This message is sent by the NG-RAN node and is used to indicate the failure of location reporting.

Direction: NG-RAN node  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
Cause	M		9.3.1.2		YES	ignore

### 9.2.11.3 LOCATION REPORT

This message is used to provide the UE's location.

Direction: NG-RAN node → AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
User Location Information	М		9.3.1.16		YES	ignore
UE Presence in Area of Interest List	0		9.3.1.67		YES	ignore
Location Reporting Request Type	М		9.3.1.65	Contains the Location Reporting Request Type to which the Location Report refers.	YES	ignore

# 9.2.12 UE TNLA Binding Messages

#### 9.2.12.1 UE TNLA BINDING RELEASE REQUEST

This message is sent by the AMF to request the NG-RAN node to release the TNLA binding for the respective UE.

Direction: AMF → NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject

# 9.2.13 UE Radio Capability Management Messages

### 9.2.13.1 UE RADIO CAPABILITY INFO INDICATION

This message is sent by the NG-RAN node to provide UE radio capability related information to the AMF.

Direction: NG-RAN node → AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	M		9.3.3.2		YES	reject
UE Radio Capability	M		9.3.1.74		YES	ignore
UE Radio Capability for	0		9.3.1.68		YES	ignore
Paging						

#### 9.2.13.2 UE RADIO CAPABILITY CHECK REQUEST

This message is sent by the AMF to request the NG-RAN node to check the compatibility between the UE radio capabilities and network configuration on IMS voice.

Direction: AMF → NG-RAN node

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	reject
RAN UE NGAP ID	М		9.3.3.2		YES	reject
UE Radio Capability	0		9.3.1.74		YES	ignore

## 9.2.13.3 UE RADIO CAPABILITY CHECK RESPONSE

This message is sent by the NG-RAN node to report IMS voice compatibility between the UE radio capabilities and network configuration.

Direction: NG-RAN node → AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.3.1.1		YES	reject
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	ignore
IMS Voice Support Indicator	М		9.3.1.89		YES	reject
Criticality Diagnostics	0		9.3.1.3		YES	ignore

# 9.2.14 Data Usage Reporting Messages

## 9.2.14.1 SECONDARY RAT DATA USAGE REPORT

This message is sent by the NG-RAN node to report Secondary RAT data usage.

Direction: NG-RAN  $\rightarrow$  AMF

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.2.1.1	description	YES	ignore
AMF UE NGAP ID	M		9.3.3.1		YES	ignore
RAN UE NGAP ID	M		9.3.3.2		YES	
PDU Session Resource	IVI	1	9.3.3.2		YES	ignore
Secondary RAT Usage		'			153	ignore
List						
>PDU Session		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Resource Secondary		ofPDUSes				
RAT Usage Item		sions>				
>>PDU Session ID	M		9.3.1.50		-	
>>Secondary RAT Data Usage Report Transfer	M		OCTET STRING	Containing the Secondary RAT Data Usage Report Transfer IE specified in subclause 9.3.4.23	-	
Handover Flag	0		ENUMERAT ED (handover_p reparation, )		YES	ignore
User Location Information	0		9.3.1.16		YES	ignore

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.

# 9.3 Information Element Definitions

# 9.3.1 Radio Network Layer Related IEs

# 9.3.1.1 Message Type

The Message Type IE uniquely identifies the message being sent. It is mandatory for all messages.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Procedure Code	M		INTEGER (0255)	
Type of Message	М		CHOICE (Initiating Message, Successful Outcome, Unsuccessful Outcome,)	

## 9.3.1.2 Cause

The purpose of the Cause IE is to indicate the reason for a particular event for the NGAP protocol.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE Cause Group	M			
>Radio Network Layer				
>>Radio Network Layer	M		ENUMERATED	
Cause			(Unspecified, TXnRELOCOverall expiry,	
			Successful handover,	
			Release due to NG-RAN generated	
			reason,	
			Release due to 5GC generated	
			reason,	
			Handover cancelled,	
			Partial handover,	
			Handover failure in target 5GC/NG-RAN node or target system,	
			Handover target not allowed,	
			TNGRELOCoverall expiry,	
			TNGRELOCprep expiry,	
			Cell not available,	
			Unknown target ID,	
			No radio resources available in target cell,	
			Unknown local UE NGAP ID,	
			Inconsistent remote UE NGAP ID,	
			Handover desirable for radio	
			reasons,	
			Time critical handover,	
			Resource optimisation handover,	
			Reduce load in serving cell, User inactivity,	
			Radio connection with UE lost,	
			Radio resources not available,	
			Invalid QoS combination,	
			Failure in the radio interface	
			procedure,	
			Interaction with other procedure, Unknown PDU Session ID,	
			Unknown QoS Flow ID,	
			Multiple PDU Session ID Instances,	
			Multiple QoS Flow ID Instances,	
			Encryption and/or integrity	
			protection algorithms not supported,	
			NG intra-system handover	
			triggered, NG inter-system handover	
			triggered,	
			Xn handover triggered,	
			Not supported 5QI value,	
			UE context transfer,	
			IMS voice EPS fallback or RAT fallback triggered,	
			UP integrity protection not possible,	
			UP confidentiality protection not	
			possible,	
			Slice(s) not supported,	
			UE in RRC_INACTIVE state not	
			reachable,	
			Redirection, Resources not available for the	
			slice(s),	
			UE maximum integrity protected	
			data rate reason,	
			Release due to CN-detected	
			mobility,	
			, N26 interface not available,	
			Release due to pre-emption, Multiple Location Reporting	
			Reference ID Instances)	
	1		Reference in maraness)	l

>Transport Layer		
>>Transport Layer Cause	M	ENUMERATED (Transport resource unavailable, Unspecified,)
>NAS		
>>NAS Cause	M	ENUMERATED (Normal release, Authentication failure, Deregister, Unspecified,)
>Protocol		
>>Protocol Cause	M	ENUMERATED (Transfer syntax error, Abstract syntax error (reject), Abstract syntax error (ignore and notify), Message not compatible with receiver state, Semantic error, Abstract syntax error (falsely constructed message), Unspecified,)
>Miscellaneous		
>>Miscellaneous Cause	М	ENUMERATED (Control processing overload, Not enough user plane processing resources, Hardware failure, O&M intervention, Unknown PLMN, Unspecified,)

The meaning of the different cause values is described in the following tables. In general, "not supported" cause values indicate that the related capability is missing. On the other hand, "not available" cause values indicate that the related capability is present, but insufficient resources were available to perform the requested action.

Radio Network Layer cause	Meaning
Unspecified	Sent for radio network layer cause when none of the specified cause values applies.
TXnRELOCOverall expiry	The timer guarding the handover that takes place over Xn has abnormally expired.
Successful handover	Successful handover.
Release due to NG-RAN generated reason	Release is initiated due to NG-RAN generated reason.
Release due to 5GC generated reason	Release is initiated due to 5GC generated reason.
Handover cancelled	The reason for the action is cancellation of Handover.
Partial handover	Provides a reason for the handover cancellation. The HANDOVER COMMAND message from AMF contained <i>PDU Session Resource to Release List</i> IE or <i>QoS flow to Release List</i> and the source NG-RAN node estimated service continuity for the UE would be better by not proceeding with handover towards this particular target NG-RAN node.
Handover failure in target 5GC/ NG- RAN node or target system	The handover failed due to a failure in target 5GC/NG-RAN node or target system.
Handover target not allowed	Handover to the indicated target cell is not allowed for the UE in question.
TNGRELOCoverall expiry	The reason for the action is expiry of timer TNGRELOCoverall.
TNGRELOCorep expiry	Handover Preparation procedure is cancelled when timer TNG <sub>RELOCprep</sub> expires.
Cell not available	The concerned cell is not available.
Unknown target ID	Handover rejected because the target ID is not known to the AMF.
No radio resources available in target cell	Load on target cell is too high.
Unknown local UE NGAP ID	The action failed because the receiving node does not recognise the local UE NGAP ID.
Inconsistent remote UE NGAP ID	The action failed because the receiving node considers that the received remote UE NGAP ID is inconsistent.
Handover desirable for radio reasons	The reason for requesting handover is radio related.
Time critical handover	Handover is requested for time critical reason i.e., this cause value is reserved to represent all critical cases where the connection is likely to be dropped if handover is not performed.
Resource optimisation handover	The reason for requesting handover is to improve the load distribution with the neighbour cells.
Reduce load in serving cell	Load on serving cell needs to be reduced. When applied to handover preparation, it indicates the handover is triggered due to load balancing.
User inactivity	The action is requested due to user inactivity on all PDU sessions, e.g., NG is requested to be released in order to optimise the radio resources.
Radio connection with UE lost	The action is requested due to losing the radio connection to the UE.
Radio resources not available	No requested radio resources are available.
Invalid QoS combination	The action was failed because of invalid QoS combination.
Failure in the radio interface procedure	Radio interface procedure has failed.
Interaction with other procedure	The action is due to an ongoing interaction with another procedure.
Unknown PDU Session ID	The action failed because the PDU Session ID is unknown in the NG-RAN node.
Unknown QoS Flow ID	The action failed because the QoS Flow ID is unknown in the NG-RAN node.
Multiple PDU Session ID instances	The action failed because multiple instance of the same PDU Session had been provided to/from the NG-RAN node.
Multiple QoS Flow ID instances	The action failed because multiple instances of the same QoS flow had been provided to the NG-RAN node.
Encryption and/or integrity protection algorithms not supported	The NG-RAN node is unable to support any of the encryption and/or integrity protection algorithms supported by the UE.
NG intra-system handover triggered	The action is due to a NG intra-system handover that has been triggered.
NG inter-system handover triggered	The action is due to a NG inter-system handover that has been triggered.
Xn handover triggered	The action is due to an Xn handover that has been triggered.
Not supported 5QI value UE context transfer	The QoS flow setup failed because the requested 5QI is not supported.  The action is due to a UE resumes from the NG-RAN node different from the one
IMS voice EPS fallback or RAT	which sent the UE into RRC_INACTIVE state.  The setup of QoS flow is failed due to EPS fallback or RAT fallback for IMS voice
fallback triggered UP integrity protection not possible	using handover or redirection.  The PDU session cannot be accepted according to the required user plane
UP confidentiality protection not	integrity protection policy.  The PDU session cannot be accepted according to the required user plane
possible Slice(s) not supported	confidentiality protection policy.  Slice(s) not supported.
Cilod(a) Hot supported	Onoo(o) not supported.

UE in RRC_INACTIVE state not reachable	The action is requested due to RAN paging failure.
Redirection	The release is requested due to inter-system redirection or intra-system redirection.
Resources not available for the slice(s)	The requested resources are not available for the slice(s).
UE maximum integrity protected data rate reason	The request is not accepted in order to comply with the maximum data rate for integrity protection supported by the UE.
Release due to CN-detected mobility	The context release is requested by the AMF because the UE is already served by another CN node (same or different system), or another NG interface of the same CN node.
N26 interface not available	The action failed due to a temporary failure of the N26 interface.
Release due to pre-emption	Release is initiated due to pre-emption.
Multiple Location Reporting Reference ID Instances	The action failed because multiple areas of interest are set with the same Location Reporting Reference ID.

Transport Layer cause	Meaning
Transport resource unavailable	The required transport resources are not available.
Unspecified	Sent when none of the above cause values applies but still the cause is
	Transport Network Layer related.

NAS cause	Meaning
Normal release	The release is normal.
Authentication failure	The action is due to authentication failure.
Deregister	The action is due to deregister.
Unspecified	Sent when none of the above cause values applies but still the cause is NAS related.

Protocol cause	Meaning
Transfer syntax error	The received message included a transfer syntax error.
Abstract syntax error (reject)	The received message included an abstract syntax error and the concerning criticality indicated "reject".
Abstract syntax error (ignore and notify)	The received message included an abstract syntax error and the concerning criticality indicated "ignore and notify".
Message not compatible with receiver state	The received message was not compatible with the receiver state.
Semantic error	The received message included a semantic error.
Abstract syntax error (falsely constructed message)	The received message contained IEs or IE groups in wrong order or with too many occurrences.
Unspecified	Sent when none of the above cause values applies but still the cause is Protocol related.

Miscellaneous cause	Meaning
Control processing overload	Control processing overload.
Not enough user plane processing resources	Not enough resources are available related to user plane processing.
Hardware failure	Action related to hardware failure.
O&M intervention	The action is due to O&M intervention.
Unknown PLMN	The AMF does not identify any PLMN provided by the NG-RAN node.
Unspecified failure	Sent when none of the above cause values applies and the cause is not related to any of the categories Radio Network Layer, Transport Network Layer, NAS or Protocol.

# 9.3.1.3 Criticality Diagnostics

The *Criticality Diagnostics* IE is sent by the NG-RAN node or the AMF when parts of a received message have not been comprehended or were missing, or if the message contained logical errors. When applicable, it contains information about which IEs were not comprehended or were missing.

For further details on how to use the *Criticality Diagnostics* IE, see clause 10.

IE/Group Name	Presence	Range	IE type and	Semantics description
			reference	
Procedure Code	0		INTEGER (0255)	Used if Criticality Diagnostics is
				part of Error Indication
				procedure, and not within the
				response message of the same
				procedure that caused the error.
Triggering Message	0		ENUMERATED	Used only if the Criticality
			(initiating message,	Diagnostics is part of Error
			successful outcome,	Indication procedure.
			unsuccessful	
			outcome)	
Procedure Criticality	0		ENUMERATED	Used for reporting the Criticality
			(reject, ignore,	of the Triggering message
			notify)	(Procedure).
Information Element		0 <maxnoofer< td=""><td></td><td></td></maxnoofer<>		
Criticality Diagnostics		rors>		
>IE Criticality	M		ENUMERATED	Used for reporting the criticality
			(reject, ignore,	of the triggering IE. The value
			notify)	'ignore' is not applicable.
>IE ID	M		INTEGER	The IE ID of the not understood
			(065535)	or missing IE.
>Type of Error	M		ENUMERATED (not	
			understood,	
			missing,)	

Range bound	Explanation
maxnoofErrors	Maximum no. of IE errors allowed to be reported with a single message.
	Value is 256.

### 9.3.1.4 Bit Rate

This IE indicates the number of bits delivered by NG-RAN in UL or to NG-RAN in DL within a period of time, divided by the duration of the period. It is used, for example, to indicate the maximum or guaranteed bit rate for a GBR QoS flow, or an aggregate maximum bit rate.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Bit Rate	M		INTEGER	The unit is: bit/s
			(04,000,000,000,000,	
			1)	

### 9.3.1.5 Global RAN Node ID

This IE is used to globally identify an NG-RAN node (see TS 38.300 [8]).

IE/Group Name	Presence	Range	IE type and	Semantics description
			reference	
CHOICE NG-RAN node	M			
>gNB				
>>Global gNB ID	M		9.3.1.6	
>ng-eNB				
>>Global ng-eNB ID	M		9.3.1.8	
>N3IWF				
>>Global N3IWF ID	M		9.3.1.57	

# 9.3.1.6 Global gNB ID

This IE is used to globally identify a gNB (see TS 38.300 [8]).

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PLMN Identity	M		9.3.3.5	
CHOICE gNB ID	M			
>gNB ID				
>>gNB ID	M		BIT STRING (SIZE(2232))	Equal to the leftmost bits of the NR Cell Identity IE contained in the NR CGI IE of each cell served by the gNB.

## 9.3.1.7 NR CGI

This IE is used to globally identify an NR cell (see TS 38.300 [8]).

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PLMN Identity	M		9.3.3.5	
NR Cell Identity	M		BIT STRING (SIZE(36))	The leftmost bits of the NR Cell Identity IE correspond to the gNB ID (defined in subclause 9.3.1.6).

## 9.3.1.8 Global ng-eNB ID

This IE is used to globally identify an ng-eNB (see TS 38.300 [8]).

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PLMN Identity	M		9.3.3.5	
CHOICE ng-eNB ID	M			
>Macro ng-eNB ID				
>>Macro ng-eNB ID	M		BIT STRING (SIZE(20))	Equal to the 20 leftmost bits of the <i>E-UTRA Cell Identity</i> IE contained in the <i>E-UTRA CGI</i> IE of each cell served by the ngeNB.
>Short Macro ng-eNB ID				
>>Short Macro ng-eNB ID	M		BIT STRING (SIZE(18))	Equal to the 18 leftmost bits of the <i>E-UTRA Cell Identity</i> IE contained in the <i>E-UTRA CGI</i> IE of each cell served by the ngeNB.
>Long Macro ng-eNB ID				
>>Long Macro ng-eNB ID	M		BIT STRING (SIZE(21))	Equal to the 21 leftmost bits of the <i>E-UTRA Cell Identity</i> IE contained in the <i>E-UTRA CGI</i> IE of each cell served by the ngeNB.

## 9.3.1.9 E-UTRA CGI

This IE is used to globally identify an E-UTRA cell (see TS 36.300 [17]).

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PLMN Identity	M		9.3.3.5	
E-UTRA Cell Identity	М		BIT STRING (SIZE(28))	The leftmost bits of the <i>E-UTRA Cell Identity</i> IE correspond to the ng-eNB ID (defined in subclause 9.3.1.8).

### 9.3.1.10 GBR QoS Flow Information

This IE indicates QoS parameters for a GBR QoS flow for downlink and uplink.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Maximum Flow Bit Rate Downlink	М		Bit Rate 9.3.1.4	Maximum Bit Rate in DL. Details in TS 23.501 [9].
Maximum Flow Bit Rate Uplink	M		Bit Rate 9.3.1.4	Maximum Bit Rate in UL. Details in TS 23.501 [9].
Guaranteed Flow Bit Rate Downlink	M		Bit Rate 9.3.1.4	Guaranteed Bit Rate (provided there is data to deliver) in DL. Details in TS 23.501 [9].
Guaranteed Flow Bit Rate Uplink	M		Bit Rate 9.3.1.4	Guaranteed Bit Rate (provided there is data to deliver). Details in TS 23.501 [9].
Notification Control	0		ENUMERATED (notification requested,)	Details in TS 23.501 [9].
Maximum Packet Loss Rate Downlink	0		Packet Loss Rate 9.3.1.79	Indicates the maximum rate for lost packets that can be tolerated in the downlink direction. Details in TS 23.501 [9].
Maximum Packet Loss Rate Uplink	0		Packet Loss Rate 9.3.1.79	Indicates the maximum rate for lost packets that can be tolerated in the uplink direction. Details in TS 23.501 [9].

## 9.3.1.11 Void

### 9.3.1.12 QoS Flow Level QoS Parameters

This IE defines the QoS parameters to be applied to a QoS flow.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE QoS Characteristics	М			
>Non-dynamic 5QI >>Non Dynamic 5QI	M		9.3.1.28	
Descriptor > Dynamic 5QI				
>>Dynamic 5QI Descriptor	M		9.3.1.18	
Allocation and Retention Priority	М		9.3.1.19	
GBR QoS Flow Information	0		9.3.1.10	This IE shall be present for GBR QoS flows and is ignored otherwise.
Reflective QoS Attribute	0		ENUMERATED (subject to,)	Details in TS 23.501 [9]. This IE may be present in case of Non-GBR QoS flows and is ignored otherwise.
Additional QoS Flow Information	0		ENUMERATED (more likely,)	This IE indicates that traffic for this QoS flow is likely to appear more often than traffic for other flows established for the PDU session.  This IE may be present in case of Non-GBR QoS flows and is ignored otherwise.

## 9.3.1.13 QoS Flow List with Cause

This IE contains a list of QoS flows with a cause value. It is used for example to indicate failed QoS flow(s) or QoS flow(s) to be released.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
QoS Flow Item		1 <maxnoofq oSFlows&gt;</maxnoofq 		
>QoS Flow Identifier	M		9.3.1.51	
>Cause	M		9.3.1.2	

Range bound	Explanation
maxnoofQoSFlows	Maximum no. of QoS flows allowed within one PDU session. Value is 64.

### 9.3.1.14 Trace Activation

This IE defines parameters related to a trace session activation.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
NG-RAN Trace ID	М		OCTET STRING (SIZE(8))	This IE is composed of the following: Trace Reference defined in TS 32.422 [11] (leftmost 6 octets, with PLMN information encoded as in 9.3.3.1), and Trace Recording Session Reference defined in TS 32.422 [11] (last 2 octets).
Interfaces to Trace	M		BIT STRING (SIZE(8))	Each position in the bitmap represents an NG-RAN node interface: first bit = NG-C, second bit = Xn-C, third bit = Uu, fourth bit = F1-C, fifth bit = E1: other bits reserved for future use. Value '1' indicates 'should be traced'. Value '0' indicates 'should not be traced'.
Trace Depth	M		ENUMERATED (minimum, medium, maximum, minimumWithoutVendor SpecificExtension, mediumWithoutVendorS pecificExtension, maximumWithoutVendor SpecificExtension,)	Defined in TS 32.422 [11].
Trace Collection Entity IP Address	М		Transport Layer Address 9.3.2.4	Defined in TS 32.422 [11]

## 9.3.1.15 Core Network Assistance Information for RRC INACTIVE

This IE provides assistance information for e.g. RRC\_INACTIVE configuration.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
UE Identity Index Value	M		9.3.3.23	
UE Specific DRX	0		Paging DRX 9.3.1.90	
Periodic Registration Update Timer	М		9.3.3.24	
MICO Mode Indication	0		9.3.1.23	
TAI List for RRC Inactive		1		
>TAI List for RRC Inactive Item		1 <maxnooft AlforInactive&gt;</maxnooft 		
>>TAI	M		9.3.3.11	
Expected UE Behaviour	0		9.3.1.93	

Range bound	Explanation
maxnoofTAlforInactive	Maximum no. of TAIs for RRC Inactive. Value is 16.

## 9.3.1.16 User Location Information

This IE is used to provide location information of the UE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
CHOICE User Location Information	М				-	-
>E-UTRA user location information						
>>E-UTRA CGI	M		9.3.1.9		-	
>>TAI	M		9.3.3.11		-	
>>Age of Location	0		Time Stamp 9.3.1.75	Indicates the UTC time when the location information was generated.	-	
>>PSCell Information	0		NG-RAN CGI 9.3.1.73		YES	ignore
>NR user location information						
>>NR CGI	M		9.3.1.7		-	
>>TAI	M		9.3.3.11		-	
>>Age of Location	0		Time Stamp 9.3.1.75	Indicates the UTC time when the location information was generated.	-	
>>PSCell Information	0		NG-RAN CGI 9.3.1.73		YES	ignore
>N3IWF user location information						
>>IP Address	M		Transport Layer Address 9.3.2.4	UE's local IP address used to reach the N3IWF	-	
>>Port Number	0		OCTET STRING (SIZE(2))	UDP or TCP source port number if NAT is detected.	-	

## 9.3.1.17 Slice Support List

This IE indicates the list of supported slices.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Slice Support Item		1 <maxnoofsli celtems&gt;</maxnoofsli 		
>S-NSSAI	М		9.3.1.24	

Range bound	Explanation
maxnoofSliceItems	Maximum no. of signalled slice support items. Value is 1024.

# 9.3.1.18 Dynamic 5QI Descriptor

This IE indicates the QoS Characteristics for a Non-standardised or not pre-configured 5QI for downlink and uplink.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Priority Level	M		9.3.1.84	Priority Level is specified in TS 23.501 [9].
Packet Delay Budget	М		9.3.1.80	Packet Delay Budget is specified in TS 23.501 [9].
Packet Error Rate	M		9.3.1.81	Packet Error Rate is specified in TS 23.501 [9].
5QI	0		INTEGER (0255,)	Indicates the dynamically assigned 5QI as specified in TS 23.501 [9].
Delay Critical	C- ifGBRflow		ENUMERATED (delay critical, non- delay critical,)	Indicates whether the GBR QoS flow is delay critical as specified in TS 23.501 [9].
Averaging Window	C- ifGBRflow		9.3.1.82	Averaging Window is specified in TS 23.501 [9].
Maximum Data Burst Volume	0		9.3.1.83	Maximum Data Burst Volume is specified in TS 23.501 [9]. This IE shall be included if the <i>Delay Critical</i> IE is set to "delay critical" and is ignored otherwise.

Condition	Explanation
ifGBRflow	This IE shall be present if the GBR QoS Flow Information IE is present in
	the QoS Flow Level QoS Parameters IE.

# 9.3.1.19 Allocation and Retention Priority

This IE specifies the relative importance of a QoS flow compared to other QoS flows for allocation and retention of NG-RAN resources.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Priority Level	М		INTEGER (115)	Desc.: This IE defines the relative importance of a resource request (see TS 23.501 [9]). Usage: Values are ordered in decreasing order of priority, i.e., with 1 as the highest priority and 15 as the lowest priority.
Pre-emption Capability	M		ENUMERATED (shall not trigger pre-emption, may trigger pre-emption,)	Desc.: This IE indicates the preemption capability of the request on other QoS flows (see TS 23.501 [9]).  Usage: The QoS flow shall not pre-empt other QoS flows or, the QoS flow may pre-empt other QoS flows.  Note: The Pre-emption Capability indicator applies to the allocation of resources for a QoS flow and as such it provides the trigger to the pre-emption procedures/processes of the NG-RAN node.
Pre-emption Vulnerability	M		ENUMERATED (not pre- emptable, pre-emptable, )	vulnerability of the QoS flow to pre-emption of other QoS flows (see TS 23.501 [9]).  Usage: The QoS flow shall not be pre-empted by other QoS flows or the QoS flow may be pre-empted by other QoS flows. Note: The Pre-emption Vulnerability indicator applies for the entire duration of the QoS flow, unless modified and as such indicates whether the QoS flow is a target of the pre-emption procedures/processes of the NG-RAN node.

# 9.3.1.20 Source to Target Transparent Container

This IE is used to transparently pass radio related information from the handover source to the handover target through the core network; it is produced by the source RAN node and is transmitted to the target RAN node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Source to Target Transparent Container	M		OCTET STRING	This IE includes a transparent container from the source RAN node to the target RAN node. The octets of the OCTET STRING are encoded according to the specifications of the target system.  Note: In the current version of the specification, this IE may carry either the Source NG-RAN Node to Target NG-RAN Node Transparent Container IE or the Source eNB to Target eNB Transparent Container IE as defined in TS 36.413 [16].

## 9.3.1.21 Target to Source Transparent Container

This IE is used to transparently pass radio related information from the handover target to the handover source through the core network; it is produced by the target RAN node and is transmitted to the source RAN node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Target to Source Transparent Container	M		OCTET STRING	This IE includes a transparent container from the target RAN node to the source RAN node. The octets of the OCTET STRING are encoded according to the specifications of the target system.  Note: In the current version of the specification, this IE may carry either the Target NG-RAN Node to Source NG-RAN Node Transparent Container IE or the Target eNB to Source eNB Transparent Container IE as defined in TS 36.413 [16].

## 9.3.1.22 Handover Type

This IE indicates which kind of handover was triggered in the source side.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Handover Type	M	_	ENUMERATED (Intra5GS, 5GStoEPS, EPSto5GS,)	Intra5GS: NG-RAN node to NG- RAN node 5GStoEPS: NG-RAN node to eNB EPSto5GS: eNB to NG-RAN node

### 9.3.1.23 MICO Mode Indication

This IE indicates that the UE is configured with MICO mode by the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
MICO Mode Indication	M		ENUMERATED (true,)	

### 9.3.1.24 S-NSSAI

This IE indicates the S-NSSAI as defined in TS 23.003 [23].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
SST	М		OCTET STRING (SIZE(1))	
SD	0		OCTET STRING (SIZE(3))	

## 9.3.1.25 Target ID

This IE identifies the target for the handover.

IE/Group Name	Presence	Range	IE type and	Semantics description
			reference	
CHOICE Target ID	M			
>NG-RAN				
>>Global RAN Node ID	M		9.3.1.5	
>>Selected TAI	M		TAI	
			9.3.3.11	
>E-UTRAN				
>>Global eNB ID	M		Global ng-eNB ID	
			9.3.1.8	
>>Selected EPS TAI	M		EPS TAI	
			9.3.3.17	

## 9.3.1.26 Emergency Fallback Indicator

The IE indicates emergency service fallback.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Emergency Fallback Request Indicator	М		ENUMERATED (emergency fallback requested,)	
Emergency Service Target CN	0		ENUMERATED (5GC, EPC,)	

## 9.3.1.27 Security Indication

This IE contains the user plane integrity protection indication and confidentiality protection indication which indicates the requirements on UP integrity protection and ciphering for corresponding PDU sessions, respectively. Additionally, this IE contains the maximum integrity protected data rate per UE for integrity protection for DRBs.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Integrity Protection Indication	M		ENUMERATED (required, preferred, not needed,)	Indicates whether UP integrity protection shall apply, should apply or shall not apply for the concerned PDU session.	-	•
Confidentiality Protection Indication	M		ENUMERATED (required, preferred, not needed,)	Indicates whether UP ciphering shall apply, should apply or shall not apply for the concerned PDU session.	-	
Maximum Integrity Protected Data Rate Uplink	C- ifIntegrityP rotectionR equiredor Preferred		Maximum Integrity Protected Data Rate 9.3.1.103	Indicates the maximum aggregate rate for integrity protected DRBs supported by the UE in UL. If the Maximum Integrity Protected Data Rate Downlink IE is absent, this IE applies to both UL and DL.	-	
Maximum Integrity Protected Data Rate Downlink	0		Maximum Integrity Protected Data Rate 9.3.1.103	Indicates the maximum aggregate rate for integrity protected DRBs supported by the UE in the DL.	YES	ignore

Condition	Explanation
ifIntegrityProtectionRequiredorPreferred	This IE shall be present if the Integrity Protection Indication IE within the
	Security Indication IE is present and set to "required" or "preferred".

# 9.3.1.28 Non Dynamic 5QI Descriptor

This IE indicates the QoS Characteristics for a standardized or pre-configured 5QI for downlink and uplink.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
5QI	M		INTEGER (0255,)	Indicates the standardized or pre-configured 5QI as specified in TS 23.501 [9].
Priority Level	0		9.3.1.84	Priority Level is specified in TS 23.501 [9]. When included, it overrides standardized or preconfigured value.
Averaging Window	0		9.3.1.82	Averaging Window is specified in TS 23.501 [9]. When included, it overrides standardized or preconfigured value.
Maximum Data Burst Volume	0		9.3.1.83	Maximum Data Burst Volume is specified in TS 23.501 [9]. When included, it overrides standardized or pre-configured value.

# 9.3.1.29 Source NG-RAN Node to Target NG-RAN Node Transparent Container

This IE is produced by the source NG-RAN node and is transmitted to the target NG-RAN node. For inter-system handovers to 5G, the IE is transmitted from the external handover source to the target NG-RAN node.

This IE is transparent to the 5GC.

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
DDC Contain on	N.4		reference OCTET	description Includes the RRC	_	Criticality
RRC Container	М		STRING	HandoverPreparat	-	
			STRING	ionInformation		
				message as		
				defined in TS		
				38.331 [18] if the		
				target is a gNB.		
				Includes the RRC		
				HandoverPreparat		
				ionInformation		
				message as		
				defined in TS		
				36.331 [21] if the		
				target is an ng- eNB.		
PDU Session		01		For intra-system	-	
Resource Information				handovers in NG-		
List				RAN.		
>PDU Session Resource		1 <maxnoo fPDUSessio</maxnoo 			-	
Information Item		ns>				
>>PDU Session ID	M	1132	9.3.1.50		-	
>>QoS Flow	IVI	1	9.5.1.50			
Information List		,				
>>>QoS Flow		1 <maxnoo< td=""><td></td><td></td><td>-</td><td></td></maxnoo<>			-	
Information Item		fQoSFlows				
		>				
>>>QoS Flow	M		9.3.1.51		-	
Identifier						
>>>>DL	0		9.3.1.33		-	
Forwarding					\/=0	
>>>>UL	0		9.3.1.118		YES	reject
Forwarding >>DRBs to QoS	0		9.3.1.34		_	
Flows Mapping List			9.5.1.54		-	
E-RAB Information		01		For inter-system	_	
List		0 1		handovers to 5G.	-	
>E-RAB Information		1 <maxnoo< td=""><td></td><td></td><td>-</td><td></td></maxnoo<>			-	
Item		fE-RABs>				
>>E-RAB ID	M		9.3.2.3		-	
>>DL Forwarding	0		9.3.1.33		-	
Target Cell ID	M		NG-RAN CGI 9.3.1.73		-	
Index to	0		9.3.1.61		-	
RAT/Frequency						
Selection Priority						
UE History Information	M		9.3.1.95		-	

Range bound	Explanation
maxnoofPDUSessions	Maximum no. of PDU sessions allowed towards one UE. Value is 256.
maxnoofQoSFlows	Maximum no. of QoS flows allowed within one PDU session. Value is 64.
maxnoofE-RABs	Maximum no. of E-RABs allowed towards one UE. Value is 256.

## 9.3.1.30 Target NG-RAN Node to Source NG-RAN Node Transparent Container

This IE is produced by the target NG-RAN node and is transmitted to the source NG-RAN node. For inter-system handovers to 5G, the IE is transmitted from the target NG-RAN node to the external relocation source.

This IE is transparent to the 5GC.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
RRC Container	M		OCTET STRING	Includes the RRC  HandoverCommand message as defined in TS 38.331 [18] if the target is a gNB.  Includes the RRC  HandoverCommand message as defined in TS 36.331 [21] if the target is an ng-eNB.

#### 9.3.1.31 Allowed NSSAI

This IE contains the allowed NSSAI.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Allowed S-NSSAI List		1		
>Allowed S-NSSAI Item		1 <maxnoofall owedS- NSSAls&gt;</maxnoofall 		
>>S-NSSAI	M		9.3.1.24	

Range bound	Explanation
maxnoofAllowedS-NSSAIs	Maximum no, of allowed S-NSSAI, Value is 8.

### 9.3.1.32 Relative AMF Capacity

This IE indicates the relative processing capacity of an AMF with respect to the other AMFs in the AMF Set in order to load-balance AMFs within an AMF Set defined in TS 23.501 [9].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Relative AMF Capacity	M		INTEGER (0255)	

## 9.3.1.33 DL Forwarding

This IE indicates that the QoS flow or E-RAB is proposed for forwarding of downlink packets.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
DL Forwarding	M		ENUMERATED (DL	
-			forwarding proposed,)	

### 9.3.1.34 DRBs to QoS Flows Mapping List

This IE contains a list of DRBs containing information about the mapped QoS flows.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
DRBs to QoS Flows		1 <maxnoofd< th=""><th></th><th></th></maxnoofd<>		
Mapping Item		RBs>		
>DRB ID	M		9.3.1.53	
>Associated QoS Flow List	М		9.3.1.99	Contains information of the QoS flows mapped to the DRB

Range bound	Explanation
maxnoofDRBs	Maximum no. of DRBs allowed towards one UE. Value is 32.

## 9.3.1.35 Message Identifier

This IE identifies the warning message. It is set by the AMF and transferred to the UE by the NG-RAN node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Message Identifier	M		BIT STRING (SIZE(16))	This IE is set by the 5GC, transferred to the UE by the NG-RAN node.

#### 9.3.1.36 Serial Number

This IE identifies a particular message from the source and type indicated by the Message Identifier and is altered every time the message with a given Message Identifier is changed.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Serial Number	М		BIT STRING	
			(SIZE(16))	

## 9.3.1.37 Warning Area List

This IE indicates the areas where the warning message needs to be broadcast or cancelled.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE Warning Area	M			
>E-UTRA Cell IDs				
>>EUTRA CGI List for Warning		1 <maxnoofc ellIDforWarnin g&gt;</maxnoofc 		
>>>E-UTRA CGI	М		9.3.1.9	
>NR Cell IDs				
>>NR CGI List for Warning		1 <maxnoofc ellIDforWarnin g&gt;</maxnoofc 		
>>>NR CGI	M		9.3.1.7	
>TAIs for Warning				
>>TAI List for Warning		1 <maxnooft AlforWarning&gt;</maxnooft 		
>>>TAI	M		9.3.3.11	
>Emergency Area IDs				
>>Emergency Area ID List		1 <maxnoofe mergencyAreal D&gt;</maxnoofe 		
>>>Emergency Area ID	М		9.3.1.48	

Range bound	Explanation
maxnoofCellIDforWarning	Maximum no. of Cell ID subject for warning message broadcast. Value is 65535.
maxnoofTAlforWarning	Maximum no. of TAI subject for warning message broadcast. Value is 65535.
maxnoofEmergencyAreaID	Maximum no. of Emergency Area ID subject for warning message broadcast. Value is 65535.

#### 9.3.1.38 Number of Broadcasts Requested

This IE indicates the number of times a message is to be broadcast.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Number of Broadcasts	M		INTEGER	
Requested			(065535)	

## 9.3.1.39 Warning Type

This IE indicates types of the disaster. This IE also indicates that a Primary Notification is included. This IE can be used by the UE to differentiate the type of alert according to the type of disaster.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Warning Type	M		OCTET STRING (SIZE(2))	

#### 9.3.1.40 Void

## 9.3.1.41 Data Coding Scheme

This IE identifies the alphabet or coding employed for the message characters and message handling at the UE (it is passed transparently from the 5GC to the UE).

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Data Coding Scheme	M		BIT STRING (SIZE(8))	

## 9.3.1.42 Warning Message Contents

This IE contains user information, e.g., the message with warning contents, and will be broadcast over the radio interface.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Warning Message Contents	М		OCTET STRING	
			(SIZE(19600))	

### 9.3.1.43 Broadcast Completed Area List

This IE indicates the areas where either resources are available to perform the broadcast or where broadcast is performed successfully.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE Broadcast	M		13.3.3.3.	
Completed Area >Cell ID Broadcast E-				
UTRA				
>>Completed Cell List		1 <maxnoofc ellIDforWarnin g&gt;</maxnoofc 		
>>>E-UTRA CGI	М		9.3.1.9	
>TAI Broadcast E-UTRA				
>>TAI Broadcast		1 <maxnooft AlforWarning&gt;</maxnooft 		
>>>TAI	М	<u> </u>	9.3.3.11	
>>>Completed Cell in TAI List		1 <maxnoofc ellinTAI&gt;</maxnoofc 		
>>>E-UTRA CGI	М		9.3.1.9	
>Emergency Area ID Broadcast E-UTRA			0.0.7.0	
>>Emergency Area ID		1 <maxnoofe< td=""><td></td><td></td></maxnoofe<>		
Broadcast		mergencyAreal D>		
>>>Emergency Area ID	М		9.3.1.48	
>>>Completed Cell in Emergency Area ID		1 <maxnoofc ellinEAI&gt;</maxnoofc 		
List				
>>>>E-UTRA CGI	M		9.3.1.9	
>Cell ID Broadcast NR				
>>Completed Cell List		1 <maxnoofc ellIDforWarnin g&gt;</maxnoofc 		
>>>NR-CGI	М		9.3.1.7	
>TAI Broadcast NR				
>>TAI Broadcast		1 <maxnooft AlforWarning&gt;</maxnooft 		
>>>TAI	М	Ĭ.	9.3.3.11	
>>>Completed Cell in TAI List		1 <maxnoofc ellinTAI&gt;</maxnoofc 		
>>>NR-CGI	М		9.3.1.7	
>Emergency Area ID Broadcast NR				
>>Emergency Area ID Broadcast		1 <maxnoofe mergencyAreal D&gt;</maxnoofe 		
>>>Emergency Area ID	M		9.3.1.48	
>>>Completed Cell in Emergency Area ID List		1 <maxnoofc ellinEAI&gt;</maxnoofc 		
>>>NR-CGI	M		9.3.1.7	
ININ 001	141	I	0.0.1.7	

Range bound	Explanation
maxnoofCellIDforWarning	Maximum no. of Cell ID subject for warning message broadcast. Value is 65535.
maxnoofTAlforWarning	Maximum no. of TAI subject for warning message broadcast. Value is 65535.
maxnoofEmergencyAreaID	Maximum no. of Emergency Area ID subject for warning message broadcast. Value is 65535.
maxnoofCellinTAI	Maximum no. of Cell ID within a TAI. Value is 65535.
maxnoofCellinEAI	Maximum no. of Cell ID within an Emergency Area. Value is 65535.

# 9.3.1.44 Broadcast Cancelled Area List

This IE indicates the areas where broadcast was stopped successfully.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE Broadcast Cancelled Area	М			
>Cell ID Cancelled E- UTRA				
>>Cancelled Cell List		1 <maxnoofc ellIDforWarnin g&gt;</maxnoofc 		
>>>E-UTRA CGI	М	9-	9.3.1.9	
>>>Number of Broadcasts	M		9.3.1.45	
>TAI Cancelled E-UTRA				
>>TAI Cancelled		1 <maxnooft AlforWarning &gt;</maxnooft 		
>>>TAI	M		9.3.3.11	
>>>Cancelled Cell in TAI List		1 <maxnoofc ellinTAI&gt;</maxnoofc 		
>>>E-UTRA CGI	M		9.3.1.9	
>>>>Number of Broadcasts	М		9.3.1.45	
>Emergency Area ID Cancelled E-UTRA				
>>Emergency Area ID Cancelled		1 <maxnoofe mergencyAreal D&gt;</maxnoofe 		
>>>Emergency Area ID	M		9.3.1.48	
>>>Cancelled Cell in Emergency Area ID List		1 <maxnoofc ellinEAI&gt;</maxnoofc 		
>>>E-UTRA CGI	M		9.3.1.9	
>>>Number of Broadcasts	М		9.3.1.45	
>Cell ID Cancelled NR				
>>Cancelled Cell List		1 <maxnoofc ellIDforWarnin g&gt;</maxnoofc 		
>>>NR-CGI	M	9.	9.3.1.7	
>>>Number of Broadcasts	M		9.3.1.45	
>TAI Cancelled NR				
>>TAI Cancelled		1 <maxnooft AlforWarning &gt;</maxnooft 		
>>>TAI	M	4	9.3.3.11	
>>>Cancelled Cell in TAI List		1 <maxnoofc ellinTAI&gt;</maxnoofc 	0.04.7	
>>>NR-CGI >>>>Number of	M		9.3.1.7 9.3.1.45	
Broadcasts	IVI		უ.ა. I . <del>4</del> მ	
>Emergency Area ID Cancelled NR				
>>Emergency Area ID Cancelled		1 <maxnoofe mergencyAreal D&gt;</maxnoofe 		
>>>Emergency Area ID	M	4	9.3.1.48	
>>>Cancelled Cell in Emergency Area ID List		1 <maxnoofc ellinEAI&gt;</maxnoofc 		
>>>NR-CGI	M		9.3.1.7	<u> </u>
>>>Number of	M		9.3.1.45	
Broadcasts				

Range bound	Explanation
maxnoofCellIDforWarning	Maximum no. of Cell ID subject for warning message broadcast. Value is 65535.
maxnoofTAlforWarning	Maximum no. of TAI subject for warning message broadcast. Value is 65535.
maxnoofEmergencyArealD	Maximum no. of Emergency Area ID subject for warning message broadcast. Value is 65535.
maxnoofCellinTAI	Maximum no. of Cell ID within a TAI. Value is 65535.
maxnoofCellinEAI	Maximum no. of Cell ID within an Emergency Area. Value is 65535.

#### 9.3.1.45 Number of Broadcasts

This IE indicates the number of times that a particular message has been broadcast in a given warning area.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Number of Broadcasts	M		INTEGER (065535)	This IE is set to '0' if valid results are not known or not available. It is set to 65535 if the counter results have overflowed.

## 9.3.1.46 Concurrent Warning Message Indicator

This IE indicates to the NG-RAN node that the received warning message is a new message to be scheduled for concurrent broadcast with any other ongoing broadcast of warning messages.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Concurrent Warning Message Indicator	М		ENUMERATED (true,)	This IE is used to identify a PWS type warning system which allows the broadcast of multiple concurrent warning messages over the radio.

## 9.3.1.47 Cancel-All Warning Messages Indicator

This IE indicates to the NG-RAN node to stop all already ongoing broadcast of warning messages in the NG-RAN node or in an area.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Cancel-All Warning	M		ENUMERATED	
Messages Indicator			(true,)	

## 9.3.1.48 Emergency Area ID

This IE is used to indicate the area which has the emergency impact.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Emergency Area ID	M		OCTET STRING (SIZE(3))	Emergency Area ID may consist of several cells. Emergency Area ID is defined by the operator.

### 9.3.1.49 Repetition Period

This IE indicates the periodicity of the warning message to be broadcast.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Repetition Period	M		INTEGER (02 <sup>17</sup> -1)	The unit of value 1 to 2 <sup>17</sup> -1 is [second].

#### 9.3.1.50 PDU Session ID

This IE identifies a PDU Session for a UE. The definition and use of the PDU Session ID is specified in TS 23.501 [9].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PDU Session ID	M		INTEGER (0255)	

#### 9.3.1.51 QoS Flow Identifier

This IE identifies a QoS flow within a PDU Session. The definition and use of the QoS Flow Identifier is specified in TS 23.501 [9].

	IE/Group Name	Presence	Range	IE type and reference	Semantics description
Q	oS Flow Identifier	M		INTEGER (063,)	

## 9.3.1.52 PDU Session Type

This IE indicates the PDU Session Type as specified in TS 23.501 [9].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PDU Session Type	M		ENUMERATED (lpv4, lpv6, lpv4v6, ethernet, unstructured,)	

#### 9.3.1.53 DRB ID

This IE contains the DRB ID.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
DRB ID	М		INTEGER (132)	

### 9.3.1.54 Masked IMEISV

This IE contains the IMEISV value with a mask, to identify a terminal model without identifying an individual Mobile Equipment.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Masked IMEISV	М		BIT STRING (SIZE(64))	Coded as the International Mobile station Equipment Identity and Software Version Number (IMEISV) defined in TS 23.003 [23] with the last 4 digits of the SNR masked by setting the corresponding bits to 1. The first to fourth bits correspond to the first digit of the IMEISV, the fifth to eighth bits correspond to the second digit of the IMEISV, and so on.

## 9.3.1.55 New Security Context Indicator

This IE indicates that the AMF has activated a new 5G NAS security context as described in TS 33.501 [13].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
New Security Context Indicator	М		ENUMERATED (true,)	The NSCI as defined in TS 33.501 [13].

#### 9.3.1.56 Time to Wait

This IE defines the minimum allowed waiting time.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Time to Wait	M		ENUMERATED (1s,	
			2s, 5s, 10s, 20s,	
			60s,)	ļ

## 9.3.1.57 Global N3IWF ID

This IE is used to globally identify an N3IWF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PLMN Identity	M		9.3.3.5	
CHOICE N3/WF ID	M			
>N3IWF ID				
>>N3IWF ID	M		BIT STRING (SIZE(16))	

## 9.3.1.58 UE Aggregate Maximum Bit Rate

This IE is applicable for all Non-GBR QoS flows per UE which is defined for the downlink and the uplink direction and a subscription parameter provided by the AMF to the NG-RAN node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
UE Aggregate Maximum Bit Rate		1		Applicable for Non-GBR QoS flows.
>UE Aggregate Maximum Bit Rate Downlink	M		Bit Rate 9.3.1.4	This IE indicates the UE Aggregate Maximum Bit Rate as specified in TS 23.501 [9] in the downlink direction.
>UE Aggregate Maximum Bit Rate Uplink	M		Bit Rate 9.3.1.4	This IE indicates the UE Aggregate Maximum Bit Rate as specified in TS 23.501 [9] in the uplink direction.

### 9.3.1.59 Security Result

This IE indicates whether the security policy indicated as "preferred" in the Security Indication IE is performed or not.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Integrity Protection Result	M		ENUMERATED (performed, not performed,)	Indicates whether UP integrity protection is performed or not for the concerned PDU session.
Confidentiality Protection Result	M		ENUMERATED (performed, not performed,)	Indicates whether UP ciphering is performed or not for the concerned PDU session.

## 9.3.1.60 User Plane Security Information

This IE indicates user plane security information related to security policy.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Security Result	M		9.3.1.59	
Security Indication	M		9.3.1.27	

### 9.3.1.61 Index to RAT/Frequency Selection Priority

This IE is used to define local configuration for RRM strategies such as camp priorities in Idle mode and control of inter-RAT/inter-frequency handover in Active mode (see TS 23.501 [9]).

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Index to RAT/Frequency	M		INTEGER (1256,	
Selection Priority			)	

## 9.3.1.62 Data Forwarding Accepted

This IE indicates that the NG-RAN node accepts the proposed DL data forwarding for the QoS flow which is subject to data forwarding.

IE/Group Name	Presence	Range	IE type and	Semantics description
			reference	
Data Forwarding Accepted	М		ENUMERATED (data forwarding	
			accepted,)	

### 9.3.1.63 Data Forwarding Not Possible

This IE indicates that the 5GC decided that the corresponding PDU session will not be subject to data forwarding.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Data Forwarding Not	M		ENUMERATED	
Possible			(data forwarding not	
			possible,)	

## 9.3.1.64 Direct Forwarding Path Availability

This IE indicates whether a direct forwarding path is available.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Direct Forwarding Path	M		ENUMERATED	
Availability			(direct path	
			available,)	

# 9.3.1.65 Location Reporting Request Type

This IE indicates the type of location request to be handled by the NG-RAN node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Event Type	M		ENUMERATED (direct, change of serving cell, UE presence in the area of interest, stop change of serving cell, stop UE presence in the area of interest, cancel location reporting for the UE,)	•		
Report Area	М		ENUMERATED (cell,)			
Area of Interest List		01	, ,			
>Area of Interest Item		1 <maxno ofAoI&gt;</maxno 				
>>Area of Interest	M		9.3.1.66			
>>Location Reporting Reference ID	М		9.3.1.76			
Location Reporting Reference ID to be Cancelled	C- ifEventTy peisStop UEPresin Aol		Location Reporting Reference ID 9.3.1.76			
Additional Location Information	0		ENUMERATED (Include PSCell,)		YES	ignore

Range bound	Explanation		
maxnoofAol	Maximum no. of areas of interest. Value is 64.		

Condition	Explanation		
ifEventTypeisStopUEPresinAoI	This IE shall be present if the Event Type IE is set to "stop UE presence in		
	the area of interest".		

### 9.3.1.66 Area of Interest

This IE indicates the area of interest.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Area of Interest TAI List		01		
>Area of Interest TAI		1 <maxnooft< th=""><th></th><th></th></maxnooft<>		
Item		AlinAol>		
>>TAI	M		9.3.3.11	
Area of Interest Cell List		01		
>Area of Interest Cell Item		1 <maxnoofc ellinAol&gt;</maxnoofc 		
>>NG-RAN CGI	M	EIIIIAUI>	9.3.3.73	
Area of Interest RAN Node List	IVI	01	3.3.3.73	
>Area of Interest RAN Node Item		1 <maxnoofr ANNodeinAol&gt;</maxnoofr 		
>>Global RAN Node ID	M		9.3.1.5	

Range bound	Explanation	
maxnoofTAlinAol	Maximum no. of tracking areas in an area of interest. Value is 16.	
maxnoofCellinAol	Maximum no. of cells in an area of interest. Value is 256.	
maxnoofRANNodeinAol	Maximum no. of NG-RAN nodes in an area of interest. Value is 64.	

### 9.3.1.67 UE Presence in Area of Interest List

This IE indicates the UE presence in the area of interest.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
UE Presence in Area of Interest Item		1 <maxnoofao I&gt;</maxnoofao 		
>Location Reporting Reference ID	М		9.3.1.76	
>UE Presence	М		ENUMERATED (in, out, unknown,)	

Range bound	Explanation	
maxnoofAol	Maximum no. of areas of interest. Value is 64.	

# 9.3.1.68 UE Radio Capability for Paging

This IE contains paging specific UE Radio Capability information.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
UE Radio Capability for Paging of NR	0		OCTET STRING	Includes the RRC UERadioPagingInformation message as defined in TS 38.331 [18].
UE Radio Capability for Paging of E-UTRA	0		OCTET STRING	Includes the RRC UERadioPagingInformation message as defined in TS 36.331 [21].

# 9.3.1.69 Assistance Data for Paging

This IE provides assistance information for paging optimisation.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Assistance Data for	0		9.3.1.70	
Recommended Cells				
Paging Attempt Information	0		9.3.1.72	

### 9.3.1.70 Assistance Data for Recommended Cells

This IE provides assistance information for paging in recommended cells.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Recommended Cells for Paging	M		9.3.1.71	

### 9.3.1.71 Recommended Cells for Paging

This IE contains the recommended cells for paging.

This IE is transparent to the 5GC.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Recommended Cell List		1		
>Recommended Cell Item		1 <maxnoofr ecommendedC ells&gt;</maxnoofr 		Includes visited and non-visited cells, where visited cells are listed in the order the UE visited them with the most recent cell being the first in the list. Non-visited cells are included immediately after the visited cell they are associated with.
>>NG-RAN CGI	M		9.3.1.73	
>>Time Stayed in Cell	0		INTEGER (04095)	This is included for visited cells and indicates the time a UE stayed in a cell in seconds. If the UE stays in a cell more than 4095 seconds, this IE is set to 4095.

Range bound	Explanation
maxnoofRecommendedCells	Maximum no. of recommended Cells. Value is 16.

### 9.3.1.72 Paging Attempt Information

This IE includes information related to the paging count over NG.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Paging Attempt Count	М		INTEGER (116,)	Paging attempt count (see TS 38.300 [8]).
Intended Number of Paging Attempts	М		INTEGER (116,)	Intended number of paging attempts (see TS 38.300 [8]).
Next Paging Area Scope	0		ENUMERATED (same, changed,)	Indicates whether the paging area scope will change or not at next paging attempt. Usage specified in TS 38.300 [8].

#### 9.3.1.73 NG-RAN CGI

This IE is used to globally identify a cell in NG-RAN.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE NG-RAN CGI	M			
>NR				
>>NR CGI	M		9.3.1.7	
>E-UTRA				
>>E-UTRA CGI	M		9.3.1.9	

### 9.3.1.74 UE Radio Capability

This IE contains UE Radio Capability information.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
UE Radio Capability	M		OCTET STRING	Includes the RRC UERadioAccessCapabilityInform ation message as defined in TS 38.331 [18].

### 9.3.1.75 Time Stamp

This IE contains UTC time information.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Time Stamp	M		OCTET STRING (SIZE(4))	Encoded in the same format as the first four octets of the 64-bit timestamp format as defined in section 6 of IETF RFC 5905 [25].

### 9.3.1.76 Location Reporting Reference ID

This IE contains the Location Reporting Reference ID.

Presence	Range	IE type and reference	Semantics description
М		INTEGER (164,)	
	M	M	reference

### 9.3.1.77 Data Forwarding Response DRB List

This IE indicates data forwarding related information.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Data Forwarding		1 <maxnoofd< td=""><td></td><td></td></maxnoofd<>		
Response DRB Item		RBs>		
>DRB ID	M		9.3.1.53	
>DL Forwarding UP TNL	0		UP Transport Layer	
Information			Information	
			9.3.2.2	
>UL Forwarding UP TNL	0		UP Transport Layer	
Information			Information	
			9.3.2.2	

	Range bound	Explanation
max	xnoofDRBs	Maximum no. of DRBs allowed towards one UE. Value is 32.

### 9.3.1.78 Paging Priority

This element indicates the paging priority for paging a UE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Paging Priority	M		ENUMERATED (PrioLevel1, PrioLevel2, PrioLevel3, PrioLevel4, PrioLevel6, PrioLevel6, PrioLevel7, PrioLevel8,)	Lower value codepoint indicates higher priority.

#### 9.3.1.79 Packet Loss Rate

This IE indicates the Packet Loss Rate for a QoS flow.

IE/Group Name	Presence	Range	IE type and	Semantics description
			reference	
Packet Loss Rate	М		INTEGER (01000,	Ratio of lost packets per number
			)	of packets sent, expressed in
				tenth of percent.

### 9.3.1.80 Packet Delay Budget

This IE indicates the Packet Delay Budget for a QoS flow.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Packet Delay Budget	M		INTEGER (01023,	Upper bound value for the delay
			)	that a packet may experience
				expressed in unit of 0.5ms.

#### 9.3.1.81 Packet Error Rate

This IE indicates the Packet Error Rate for a QoS flow.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Scalar	М		INTEGER (09,)	The packet error rate is expressed as <i>Scalar</i> x 10-k where k is the <i>Exponent</i> .
Exponent	M		INTEGER (09,)	

### 9.3.1.82 Averaging Window

This IE indicates the Averaging Window for a QoS flow, and applies to GBR QoS flows only.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Averaging Window	М		INTEGER (04095,)	Unit: ms. The default value of the IE is
			,	2000ms.

#### 9.3.1.83 Maximum Data Burst Volume

This IE indicates the Maximum Data Burst Volume for a QoS flow, and applies to delay critical GBR QoS flows only.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Maximum Data Burst Volume	М		INTEGER (04095,)	Unit: byte.

### 9.3.1.84 Priority Level

This IE indicates the Priority Level for a QoS flow.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Priority Level	M		INTEGER (1127,)	Values ordered in decreasing order of priority, i.e. with 1 as the highest priority and 127 as the lowest priority.

### 9.3.1.85 Mobility Restriction List

This IE defines roaming or access restrictions for subsequent mobility action for which the NG-RAN provides information about the target of the mobility action towards the UE, e.g., handover, or for SCG selection during dual connectivity operation or for assigning proper RNAs. NG-RAN behaviour upon receiving this IE is specified in TS 23.501 [9].

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Serving PLMN	М		PLMN Identity 9.3.3.5		-	
Equivalent PLMNs		0 <maxno ofEPLMNs &gt;</maxno 	9.3.3.3	Allowed PLMNs in addition to Serving PLMN. This list corresponds to the list of "equivalent PLMNs" as defined in TS 24.501 [26]. This list is part of the roaming restriction information. Roaming restrictions apply to PLMNs other than the Serving PLMN and Equivalent PLMNs.	-	
>PLMN Identity	М		9.3.3.5	1 LIVII VO.	_	
RAT Restrictions		0 <maxno ofEPLMNs PlusOne&gt;</maxno 		This IE contains RAT restriction related information as specified in TS 23.501 [9].	-	
>PLMN Identity	M		9.3.3.5		-	
>RAT Restriction Information	M		BIT STRING { e-UTRA (0), nR (1) } (SIZE(8,))	Each position in the bitmap represents a RAT. If a bit is set to "1", the respective RAT is restricted for the UE. If a bit is set to "0", the respective RAT is not restricted for the UE. Bits 2-7 reserved for future use.	-	
Forbidden Area Information		0 <maxno ofEPLMNs PlusOne&gt;</maxno 		This IE contains Forbidden Area information as specified in TS 23.501 [9].	-	
>PLMN Identity	M		9.3.3.5		-	
>Forbidden TACs		1 <maxno ofForbTA Cs&gt;</maxno 			-	
>>TAC	M		9.3.3.10	The TAC of the forbidden TAI.	-	
Service Area Information		0 <maxno ofEPLMNs PlusOne&gt;</maxno 		This IE contains Service Area Restriction information as specified in TS 23.501 [9].	-	
>PLMN Identity	М		9.3.3.5		-	
>Allowed TACs		0 <maxno ofAllowed Areas&gt;</maxno 			-	
>>TAC	М		9.3.3.10	The TAC of the allowed TAI.	-	

>Not Allowed TACs		0 <maxno ofAllowed Areas&gt;</maxno 			-	
>>TAC	М		9.3.3.10	The TAC of the not-allowed TAI.	-	
Last E-UTRAN PLMN Identity	0		PLMN Identity 9.3.3.5	Indicates the E- UTRAN PLMN ID from where the UE formerly handed over to 5GS and which is preferred in case of subsequent mobility to EPS.	YES	ignore
Core Network Type Restriction for Serving PLMN	0		ENUMERATED (EPCForbidden ,)	Indicates whether the UE is restricted to connect to EPC for the Serving PLMN as specified in TS 23.501 [9].	YES	ignore
Core Network Type Restriction for Equivalent PLMNs		0 <maxno ofEPLMNs &gt;</maxno 			YES	ignore
>PLMN Identity	M		9.3.3.5	Includes any of the Equivalent PLMNs listed in the Mobility Restriction List IE for which CN Type restriction applies as specified in TS 23.501 [9].	-	
>Core Network Type Restriction	М		ENUMERATED (EPCForbidden , 5GCForbidden, )	Indicates whether the UE is restricted to connect to EPC or to 5GC for this PLMN.		

Range bound	Explanation
maxnoofEPLMNs	Maximum no. of equivalent PLMNs. Value is 15.
maxnoofEPLMNsPlusOne	Maximum no. of allowed PLMNs. Value is 16.
maxnoofForbTACs	Maximum no. of forbidden Tracking Area Codes. Value is 4096.
maxnoofAllowedAreas	Maximum no. of allowed or not allowed Tracking Areas. Value is 16.

# 9.3.1.86 UE Security Capabilities

This IE defines the supported algorithms for encryption and integrity protection in the UE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
NR Encryption Algorithms	M		BIT STRING (SIZE(16,))	Each position in the bitmap represents an encryption algorithm:  "all bits equal to 0" – UE supports no other algorithm than NEA0,  "first bit" – 128-NEA1,  "second bit" – 128-NEA2,  "third bit" – 128-NEA3,  other bits reserved for future use.  Value '1' indicates support and value '0' indicates no support of the algorithm.  Algorithms are defined in TS 33.501 [13].
NR Integrity Protection Algorithms	M		BIT STRING (SIZE(16,))	Each position in the bitmap represents an integrity protection algorithm:  "all bits equal to 0" – UE supports no other algorithm than NIA0,  "first bit" – 128-NIA1,  "second bit" – 128-NIA2,  "third bit" – 128-NIA3,  other bits reserved for future use.  Value '1' indicates support and value '0' indicates no support of the algorithm.  Algorithms are defined in TS 33.501 [13].
E-UTRA Encryption Algorithms	M		BIT STRING (SIZE(16,))	Each position in the bitmap represents an encryption algorithm:  "all bits equal to 0" – UE supports no other algorithm than EEA0,  "first bit" – 128-EEA1,  "second bit" – 128-EEA2,  "third bit" – 128-EEA3,  other bits reserved for future use.  Value '1' indicates support and value '0' indicates no support of the algorithm.  Algorithms are defined in TS 33.401 [27].
E-UTRA Integrity Protection Algorithms	M		BIT STRING (SIZE(16,))	Each position in the bitmap represents an encryption algorithm:  "all bits equal to 0" – UE supports no other algorithm than EIAO,  "first bit" – 128-EIA1,  "second bit" – 128-EIA2,  "third bit" – 128-EIA3, other bits reserved for future use.  Value '1' indicates support and value '0' indicates no support of the algorithm.  Algorithms are defined in TS 33.401 [27].

### 9.3.1.87 Security Key

This IE is used to apply security in the NG-RAN for different scenarios as defined in TS 33.501 [13].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Security Key	М		BIT STRING (SIZE(256))	Key material for NG-RAN node or Next Hop Key as defined in TS 33.501 [13]

### 9.3.1.88 Security Context

This IE provides security related parameters to the NG-RAN node which are used to derive security keys for user plane traffic and RRC signalling messages and for security parameter generation for subsequent mobility, see TS 33.501 [13].

IE/Group Name	Presence	Range	IE type and	Semantics description
			reference	
Next Hop Chaining Count	М		INTEGER (07)	Next Hop Chaining Counter (NCC) defined in TS 33.501 [13].
Next-Hop NH	M		Security Key 9.3.1.87	The NH together with the NCC is used to derive the security configuration as defined in TS 33.501 [13].

### 9.3.1.89 IMS Voice Support Indicator

This IE is set by the NG-RAN node to indicate whether the UE radio capabilities are compatible with the network configuration for IMS voice.

IE/Group Name	Presence	Range	IE type and	Semantics description
			reference	
IMS Voice Support	M		ENUMERATED	
Indicator			(Supported, Not	
			Supported,)	

### 9.3.1.90 Paging DRX

This IE indicates the Paging DRX as defined in TS 38.304 [12] and TS 36.304 [29].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Paging DRX	M		ENUMERATED (32,	
			64. 128. 256)	

### 9.3.1.91 RRC Inactive Transition Report Request

This IE is used to request the NG-RAN node to report or stop reporting to the 5GC when the UE enters or leaves RRC\_INACTIVE state.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
RRC Inactive Transition Report Request	M		ENUMERATED (Subsequent state transition report, Single RRC connected state report, Cancel report,)	

#### 9.3.1.92 RRC State

This IE indicates the RRC state of the UE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
RRC State	M		ENUMERATED	Indicates the current RRC state
			(Inactive,	of the UE.
			Connected,)	

### 9.3.1.93 Expected UE Behaviour

This IE indicates the behaviour of a UE with predictable activity and/or mobility behaviour, to assist the NG-RAN node in e.g. determining the optimum RRC connection time or helping with the RRC\_INACTIVE state transition and RNA configuration (e.g. size and shape of the RNA).

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Expected UE Activity Behaviour	0		9.3.1.94	
Expected HO Interval	0		ENUMERATED (sec15, sec30, sec60, sec90, sec120, sec180, long-time,)	Indicates the expected time interval between inter NG-RAN node handovers.  If "long-time" is included, the interval between inter NG-RAN node handovers is expected to be longer than 180 seconds.
Expected UE Mobility	0		ENUMERATED (stationary, mobile,)	Indicates whether the UE is expected to be stationary or mobile.
Expected UE Moving Trajectory		01		Indicates the UE's expected geographical movement.
>Expected UE Moving Trajectory Item		1 <maxnoofc ellsUEMovingT rajectory&gt;</maxnoofc 		Includes list of visited and non- visited cells, where visited cells are listed in the order the UE visited them with the most recent cell being the first in the list. Non- visited cells are included immediately after the visited cell they are associated with.
>>NG-RAN CGI	M		9.3.1.73	
>>Time Stayed in Cell	0		INTEGER (04095)	Included for visited cells and indicates the time a UE stayed in a cell in seconds. If the UE stays in a cell more than 4095 seconds, this IE is set to 4095.

Range bound	Explanation
maxnoofCellsUEMovingTrajectory	Maximum no. of cells of UE moving trajectory. Value is 16.

### 9.3.1.94 Expected UE Activity Behaviour

This IE indicates information about the expected "UE activity behaviour" as defined in TS 23.501 [9].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Expected Activity Period	0		INTEGER (130 40 50 60 80  100 120 150 180  181,)	If set to "181" the expected activity time is longer than 180 seconds. The remaining values indicate the expected activity time in [seconds].
Expected Idle Period	0		INTEGER (130 40 50 60 80  100 120 150 180  181,)	If set to "181" the expected idle time is longer than 180 seconds. The remaining values indicate the expected idle time in [seconds].
Source of UE Activity Behaviour Information	0		ENUMERATED (subscription information, statistics,)	If "subscription information" is indicated, the information contained in the <i>Expected Activity Period</i> IE and the <i>Expected Idle Period</i> IE, if present, is derived from subscription information. If "statistics" is indicated, the information contained in the <i>Expected Activity Period</i> IE and the <i>Expected Idle Period</i> IE, if present, is derived from statistical information.

### 9.3.1.95 UE History Information

This IE contains information about cells that a UE has been served by in active state prior to the target cell.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Last Visited Cell Item		1 <maxnoofc ellsinUEHistory Info&gt;</maxnoofc 		Most recent information is added to the top of this list.
>Last Visited Cell Information	М		9.3.1.96	

Range bound	Explanation
maxnoofCellsinUEHistoryInfo	Maximum no. of cells in the UE history information. Value is 16.

#### 9.3.1.96 Last Visited Cell Information

This IE may contain cell specific information.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE Last Visited Cell Information	М			
>NG-RAN Cell				
>>Last Visited NG-RAN Cell Information	М		9.3.1.97	
>E-UTRAN Cell				
>>Last Visited E-UTRAN Cell Information	М		OCTET STRING	Defined in TS 36.413 [16].
>UTRAN Cell				
>>Last Visited UTRAN Cell Information	M		OCTET STRING	Defined in TS 25.413 [28].
>GERAN Cell				
>>Last Visited GERAN Cell Information	М		OCTET STRING	Defined in TS 36.413 [16].

#### 9.3.1.97 Last Visited NG-RAN Cell Information

This IE contains information about a cell. In case of NR cell, this IE contains information about a set of NR cells with the same NR ARFCN for reference point A, and the *Global Cell ID* IE identifies one of the NR cells in the set. The information is to be used for RRM purposes.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Global Cell ID	М		NG-RAN CGI 9.3.1.73	
Cell Type	M		9.3.1.98	
Time UE Stayed in Cell	М		INTEGER (04095)	The duration of time the UE stayed in the cell, or set of NR cells with the same NR ARFCN for reference point A, in seconds. If the duration is more than 4095s, this IE is set to 4095.
Time UE Stayed in Cell Enhanced Granularity	0		INTEGER (040950)	The duration of time the UE stayed in the cell, or set of NR cells with the same NR ARFCN for reference point A, in 1/10 seconds. If the duration is more than 4095s, this IE is set to 40950.
HO Cause Value	0		Cause 9.3.1.2	The cause for the handover.

### 9.3.1.98 Cell Type

This IE provides the cell coverage area.

IE/Group Name	Presence	Range	IE type and	Semantics description
			reference	
Cell Size	M		ENUMERATED	
			(verysmall, small,	
			medium, large,)	

#### 9.3.1.99 Associated QoS Flow List

This IE indicates the list of QoS flows associated with e.g. a DRB or UP TNL endpoint.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Associated QoS Flow Item		1 <maxnoofq oSFlows&gt;</maxnoofq 		
>QoS Flow Identifier	M		9.3.1.51	
>QoS Flow Mapping Indication	0		ENUMERATED (ul, dl,)	

Range bound	Explanation
maxnoofQoSFlows	Maximum no. of QoS flows allowed within one PDU session. Value is 64.

### 9.3.1.100 Information on Recommended Cells and RAN Nodes for Paging

This IE provides information on recommended cells and NG-RAN nodes for paging.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Recommended Cells for Paging	М		9.3.1.71	
Recommended RAN Nodes for Paging	М		9.3.1.101	

### 9.3.1.101 Recommended RAN Nodes for Paging

This IE contains recommended NG-RAN nodes for paging.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Recommended RAN Node List		1		
>Recommended RAN Node Item		1 <maxnoofr ecommendedR ANNodes&gt;</maxnoofr 		Includes visited and non-visited NG-RAN nodes, where visited NG-RAN nodes are listed in the order the UE visited them with the most recent NG-RAN node being the first in the list. Non-visited NG-RAN nodes are included after the visited NG-RAN node they are associated with.
>>CHOICE AMF Paging Target				The AMF paging target is either an NG-RAN node identity or a TAI as specified in TS 38.300 [8].
>>>RAN Node				
>>>>Global RAN Node	M		9.3.1.5	
>>>TAI				
>>>TAI	M		9.3.3.11	

Range bound	Explanation
maxnoofRedommendedRANNodes	Maximum no. of recommended NG-RAN nodes. Value is 16.

### 9.3.1.102 PDU Session Aggregate Maximum Bit Rate

This IE is applicable for all Non-GBR QoS flows per PDU session which is defined for the downlink and the uplink direction and is provided by the SMF to the NG-RAN node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PDU Session Aggregate Maximum Bit Rate		1		Applicable for Non-GBR QoS flows.
>PDU Session Aggregate Maximum Bit Rate Downlink	M		Bit Rate 9.3.1.4	Indicates the PDU session Aggregate Maximum Bit Rate as specified in TS 23.501 [9] in the downlink direction.
>PDU Session Aggregate Maximum Bit Rate Uplink	М		Bit Rate 9.3.1.4	Indicates the PDU session Aggregate Maximum Bit Rate as specified in TS 23.501 [9] in the uplink direction.

### 9.3.1.103 Maximum Integrity Protected Data Rate

This IE indicates the maximum aggregate data rate for integrity protected DRBs for a UE as defined in TS 38.300 [8].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Maximum Integrity Protected Data Rate	М		ENUMERATED (64kbps, max UE rate,)	Defines the upper bound of the aggregate data rate of user plane integrity protected data for either UL or DL.

### 9.3.1.104 Overload Response

This IE indicates the required behaviour of the NG-RAN node in an overload situation.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE Overload Response	М			
>Overload Action				
>>Overload Action	M		9.3.1.105	

#### 9.3.1.105 Overload Action

This IE indicates which signalling traffic is subject to rejection by the NG-RAN node in an AMF overload situation as defined in TS 23.501 [9].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Overload Action	M		ENUMERATED	-
			(Reject RRC connection	
			establishments for non-	
			emergency MO DT,	
			Reject RRC connection	
			establishments for	
			Signalling, Permit	
			Emergency Sessions	
			and mobile terminated	
			services only, Permit	
			High Priority Sessions	
			and mobile terminated	
			services only,)	

#### 9.3.1.106 Traffic Load Reduction Indication

This IE indicates the percentage of the type of traffic relative to the instantaneous incoming rate at the NG-RAN node, as indicated in the *Overload Action* IE, to be rejected.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Traffic Load Reduction Indication	М		INTEGER (199)	

#### 9.3.1.107 Slice Overload List

This IE indicates the list of overloaded slices.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Slice Overload Item		1 <maxnoofsli celtems&gt;</maxnoofsli 		
>S-NSSAI	M		9.3.1.24	

Range bound	Explanation
maxnoofSliceItems	Maximum no. of signalled slice support items. Value is 1024.

### 9.3.1.108 RAN Status Transfer Transparent Container

This IE is produced by the source NG-RAN node and is transmitted to the target NG-RAN node. It is used for intra 5GC NG handover.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
DRBs Subject to Status Transfer List		1			-	
>DRBs Subject to Status Transfer Item		1 <maxn oof DRBs&gt;</maxn 			-	
>>DRB ID	M		9.3.1.53		-	
>>CHOICE UL DRB Status	М				-	
>>> 12 bits						
>>>>UL COUNT Value	M		COUNT Value for PDCP SN Length 12 9.3.1.109	PDCP-SN and HFN of the first missing UL PDCP SDU in case of 12 bit long PDCP- SN.	-	
>>>>Receive Status of UL PDCP SDUs	0		BIT STRING (SIZE(12048))	The IE is used in case of 12 bit long PDCP-SN. The first bit indicates the status of the SDU after the First Missing UL PDCP SDU. The Nh bit indicates the status of the UL PDCP SDU in position (N + First Missing SDU Number) modulo (1 + the maximum value of the PDCP-SN).  0: PDCP SDU has not been received. 1: PDCP SDU has been received correctly.	-	
>>>18 bits >>>>UL COUNT Value	M		COUNT Value for PDCP SN Length 18 9.3.1.110	PDCP-SN and HFN of the first missing UL PDCP SDU in case of 18 bit long PDCP- SN.	-	

>>>>Receive Status of UL PDCP SDUs	O	BIT STRING (SIZE(1131072 ))	The IE is used in case of 18 bit long PDCP-SN. The first bit indicates the status of the SDU after the First Missing UL PDCP SDU. The N <sup>th</sup> bit indicates the status of the UL PDCP SDU in position (N + First Missing SDU Number) modulo (1 + the maximum value of the PDCP-SN).  0: PDCP SDU has not been received. 1: PDCP SDU has been received correctly.	-	
>>CHOICE DL DRB Status	М			-	
>>> 12 bits			_		
>>>>DL COUNT Value	М	COUNT Value for PDCP SN Length 12 9.3.1.109	PDCP-SN and HFN that the target NG-RAN node should assign for the next DL PDCP SDU not having an SN yet in case of 12 bit long PDCP- SN.		
>>> 18 bits					
>>>>DL COUNT Value	М	COUNT Value for PDCP SN Length 18 9.3.1.110	PDCP-SN and HFN that the target NG-RAN node should assign for the next DL PDCP SDU not having an SN yet in case of 18 bit long PDCP- SN.	-	
>>Old Associated QoS Flow List - UL End Marker Expected	0	Associated QoS Flow List 9.3.1.99	Indicates that the source NG-RAN node has initiated QoS flow remapping and has not yet received SDAP end markers, as described in TS 38.300 [8].	YES	reject

Range bound	Explanation
maxnoofDRBs	Maximum no. of DRBs allowed towards one UE. Value is 32.

### 9.3.1.109 COUNT Value for PDCP SN Length 12

This IE contains a PDCP sequence number and a hyper frame number in case of 12 bit long PDCP-SN.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PDCP SN Length 12	M		INTEGER (04095)	
HFN for PDCP SN Length	M		INTEGER	
12			(01048575)	

### 9.3.1.110 COUNT Value for PDCP SN Length 18

This IE contains a PDCP sequence number and a hyper frame number in case of 18 bit long PDCP-SN.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PDCP SN Length 18	М		INTEGER (0262143)	
HFN for PDCP SN Length 18	М		INTEGER (016383)	

#### 9.3.1.111 RRC Establishment Cause

This IE indicates the reason for RRC Connection Establishment as received from the UE in the *EstablishmentCause* defined in TS 38.331 [18] and TS 36.331 [21], or the reason for RRC Connection Resume as received from the UE in the *ResumceCause* defined in TS 38.331 [18].

	IE/Group Name	Presence	Range	IE type and reference	Semantics description
mcs-PriorityAccess,, notAvailable)	RRC Establishment Cause	M		(emergency, highPriorityAccess, mt-Access, mo-Signalling, mo-Data, mo-VoiceCall, mo-VideoCall, mo-SMS, mps-PriorityAccess, mcs-PriorityAccess,	fallback to RRC connection establishment as described in [18], or the <i>ResumceCause</i> received from the UE does not map to any other value of the

#### 9.3.1.112 Warning Area Coordinates

This IE contains the affected alert area coordinates of a warning message, and will be broadcast over the radio interface.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Warning Area Coordinates	М		OCTET STRING (SIZE(11024))	

#### 9.3.1.113 Network Instance

This IE provides the network instance to be used by the NG-RAN node when selecting a particular transport network resource as described in TS 23.501 [9].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Network Instance	М		INTEGER (1256,)	

### 9.3.1.114 Secondary RAT Usage Information

This IE provides information on the secondary resources used with MR-DC.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PDU Session Usage Report		01		
>RAT Type	М		ENUMERATED (nR, e-UTRA,)	
>PDU Session Timed Report List	M		Volume Timed Report List 9.3.1.115	
QoS Flows Usage Report List		01		
>QoS Flow Usage Report Item		1 <maxnoofq oSFlows&gt;</maxnoofq 		
>>QoS Flow Indicator	M		9.3.1.51	
>>RAT Type	М		ENUMERATED (nR, e-UTRA,)	
>>QoS Flows Timed Report List	М		Volume Timed Report List 9.3.1.115	

Range bound	Explanation
maxnoofQoSFlows	Maximum no. of QoS flows allowed within one PDU session. Value is 64.

### 9.3.1.115 Volume Timed Report List

This IE provides information on the data usage.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Volume Timed Report Item		1 <maxnoofti mePeriods&gt;</maxnoofti 		
>Start Timestamp	М		OCTET STRING (SIZE(4))	UTC time encoded in the same format as the first four octets of the 64-bit timestamp format as defined in section 6 of IETF RFC 5905 [14]. It indicates the start time of the collecting period of the included Usage Count UL IE and Usage Count DL IE.
>End Timestamp	М		OCTET STRING (SIZE(4))	UTC time encoded in the same format as the first four octets of the 64-bit timestamp format as defined in section 6 of IETF RFC 5905 [14]. It indicates the end time of the collecting period of the included Usage Count UL IE and Usage Count DL IE.
>Usage Count UL	M		INTEGER (02 <sup>64</sup> -1)	The unit is: octets.
>Usage Count DL	M		INTEGER (02 <sup>64</sup> -1)	The unit is: octets.

Range bound	Explanation
maxnoofTimePeriods	Maximum no. of time reporting periods. Value is 2.

#### 9.3.1.116 Redirection for Voice EPS Fallback

This IE is used to indicate that the AMF and the UE support the redirection for voice for EPS Fallback.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Redirection for Voice EPS	M		ENUMERATED	
Fallback			(possible, not-	
			possible,)	

#### 9.3.1.117 UE Retention Information

This IE allows the NG-RAN node and the AMF to indicate whether prior UE related contexts and related UE-associated logical NG-connections and RRC connections are intended to be retained.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
UE Retention Information	M		ENUMERATED	
			(ues-retained,)	

### 9.3.1.118 UL Forwarding

This IE indicates that the QoS flow is proposed for forwarding of uplink packets.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
UL Forwarding	M		ENUMERATED (UL	
_			forwarding proposed,)	

### 9.3.1.119 CN Assisted RAN Parameters Tuning

This IE provides information for assisting in parameters tuning of the NG-RAN node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Expected UE Behaviour	0		9.3.1.93	This IE may be present in case the Core Network Assistance Information for RRC INACTIVE IE is not included and is ignored otherwise.

#### 9.3.1.120 Common Network Instance

This IE provides the common network instance to be used by the NG-RAN node when selecting a particular transport network resource as described in TS 23.501 [9] in a format common with 5GC.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Common Network Instance	M		OCTET STRING	

## 9.3.2 Transport Network Layer Related IEs

#### 9.3.2.1 QoS Flow per TNL Information List

This IE is used to provide a list of additional UP transport layer information for a split PDU session, along with the associated QoS flows.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
QoS Flow per TNL Information Item		1 <maxnoofm ultiConnectivity MinusOne&gt;</maxnoofm 		
>QoS Flow per TNL Information	M		9.3.2.8	

Range bound	Explanation
maxnoofMultiConnectivityMinusOne	Maximum no. of connectivity allowed for a UE minus one. Value is 3. The
	current version of the specification supports 1.

### 9.3.2.2 UP Transport Layer Information

This IE is used to provide the NG user plane transport layer information associated with a PDU session for an NG-RAN node – AMF pair. In this release it corresponds to an IP address and a GTP Tunnel Endpoint Identifier.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE UP Transport Layer Information	M			
>GTP tunnel				
>>Endpoint IP Address	M		Transport Layer Address 9.3.2.4	
>>GTP-TEID	M		9.3.2.5	

#### 9.3.2.3 E-RAB ID

This IE is the identifier of the LTE E-RAB.

	E/Group Name	Presence	Range	IE type and reference	Semantics description
E-RAI	3 ID	M		INTEGER (015,)	

### 9.3.2.4 Transport Layer Address

This IE is an IP address.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Transport Layer Address	M		BIT STRING (SIZE(1160,))	The Radio Network Layer is not supposed to interpret the address information. It should pass it to the Transport Layer for interpretation.  For details, see TS 38.414 [14].

#### 9.3.2.5 GTP-TEID

This IE is the GTP Tunnel Endpoint Identifier to be used for the user plane transport between the NG-RAN node and the UPF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
GTP-TEID	М		OCTET STRING (SIZE(4))	For details and range, see TS 29.281 [15].

### 9.3.2.6 CP Transport Layer Information

This IE is used to provide the NG control plane transport layer information associated with an NG-RAN node – AMF pair.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
CHOICE CP Transport						
Layer Information						
>Endpoint-IP-address					-	
>>Endpoint IP Address	M		Transport Layer Address 9.3.2.4		-	
>Endpoint-IP-address- and-port					YES	reject
>>Endpoint IP Address	M		Transport Layer Address 9.3.2.4		-	
>>Port Number	М		OCTET STRING (SIZE(2))		-	

#### 9.3.2.7 TNL Association List

This IE contains a list of TNL associations. It is used for example to indicate failed TNL association(s).

IE/Group Name	Presence	Range	IE type and reference	Semantics description
TNL Association Item		1 <maxnooft NLAssociation s&gt;</maxnooft 		
>TNL Association Address	M		CP Transport Layer Information 9.3.2.6	
>Cause	M		9.3.1.2	

Range bound	Explanation
maxnoofTNLAssociations	Maximum no. of TNL Associations between the NG-RAN node and the
	AMF. Value is 32.

### 9.3.2.8 QoS Flow per TNL Information

This IE indicates the NG-U transport layer information and associated list of QoS flows.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
UP Transport Layer Information	М		9.3.2.2	
Associated QoS Flow List	M		9.3.1.99	

### 9.3.2.9 TNL Association Usage

This IE indicates the usage of the TNL association.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
TNL Association Usage	0		ENUMERATED (ue, non-ue, both,)	Indicates whether the TNL association is only used for UE-associated signalling, or non-UE-associated signalling, or both.

### 9.3.2.10 TNL Address Weight Factor

This IE indicates the weight factor of the TNL address.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
TNL Address Weight Factor	М		INTEGER (0255)	Value 0 indicates the TNL address is not permitted for the initial NGAP message. If the value for each TNL address is the same, it indicates the deployments that rely solely on 5GC-based load balancing.

### 9.3.2.11 UP Transport Layer Information Pair List

This IE is used to provide a list of uplink UP transport layer information and associated downlink UP transport layer information for a split PDU session.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
UP Transport Layer Information Pair Item		1 <maxnoofm ultiConnectivity MinusOne&gt;</maxnoofm 		
>UL NG-U UP TNL Information	M		UP Transport Layer Information 9.3.2.2	
>DL NG-U UP TNL Information	M		UP Transport Layer Information 9.3.2.2	

Range bound	Explanation	
maxnoofMultiConnectivityMinusOne	Maximum no. of connectivity allowed for a UE minus one. Value is 3. The	
	current version of the specification supports 1.	

### 9.3.2.12 UP Transport Layer Information List

This IE is used to provide a list of additional UP transport layer information for a split PDU session.

IE/Group Name	Presence	Range	IE type and	Semantics description
			reference	
UP Transport Layer		1 <maxnoofm< th=""><th></th><th></th></maxnoofm<>		
Information Item		ultiConnectivity		
		MinusOne>		
>NG-U UP TNL	M		UP Transport Layer	
Information			Information	
			9.3.2.2	

Range bound	Explanation	
maxnoofMultiConnectivityMinusOne	Maximum no. of connectivity allowed for a UE minus one. Value is 3. The	
	current version of the specification supports 1.	

### 9.3.2.13 QoS Flow List with Data Forwarding

This IE is used to provide a list of QoS flows with indication if forwarding is accepted.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
QoS Flow Item with Data Forwarding		1 <maxnoofq oSFlows&gt;</maxnoofq 		
>QoS Flow Identifier	M		9.3.1.51	
>Data Forwarding Accepted	0		9.3.1.62	

Range bound	Explanation
maxnoofQoSFlows	Maximum no. of QoS flows allowed within one PDU session. Value is 64.

### 9.3.3 NAS Related IEs

### 9.3.3.1 AMF UE NGAP ID

This IE uniquely identifies the UE association over the NG interface, as described in TS 38.401 [2].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
AMF UE NGAP ID	M		INTEGER (02 <sup>40</sup> -1)	

#### 9.3.3.2 RAN UE NGAP ID

This IE uniquely identifies the UE association over the NG interface within the NG-RAN node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
RAN UE NGAP ID	M		INTEGER (02 <sup>32</sup> -1)	

#### 9.3.3.3 GUAMI

This IE indicates the AMF identity.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PLMN Identity	M		9.3.3.5	
AMF Region ID	M		BIT STRING (SIZE(8))	
AMF Set ID	М		9.3.3.12	
AMF Pointer	М		9.3.3.19	

#### 9.3.3.4 NAS-PDU

This IE contains a 5GC – UE or UE – 5GC message that is transferred without interpretation in the NG-RAN node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
NAS-PDU	M		OCTET STRING	The content is defined in TS 24.501 [26].

### 9.3.3.5 PLMN Identity

This IE indicates the PLMN Identity.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PLMN Identity	М		OCTET STRING (SIZE(3))	Digits 0 to 9 encoded 0000 to 1001, 1111 used as filler digit.
				Two digits per octet: - bits 4 to 1 of octet n encoding digit 2n-1 - bits 8 to 5 of octet n encoding digit 2n
				PLMN Identity consists of 3 digits from MCC followed by either: - a filler digit plus 2 digits from MNC (in case of 2 digit MNC) or - 3 digits from MNC (in case of 3 digit MNC).

### 9.3.3.6 SON Configuration Transfer

This IE contains the configuration information, used by e.g., SON functionality, and additionally includes the NG-RAN node identifier of the destination of this configuration information and the NG-RAN node identifier of the source of this information.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Target RAN Node ID	M			
>Global RAN Node ID	M		9.3.1.5	
>Selected TAI	M		TAI	
			9.3.3.11	
Source RAN Node ID	M			
>Global RAN Node ID	M		9.3.1.5	
>Selected TAI	M		TAI	
			9.3.3.11	
SON Information	M		9.3.3.7	
Xn TNL Configuration Info	C- ifSONInfor mationRe quest		9.3.3.9	Source NG-RAN node Xn TNL Configuration Info.

Condition	Explanation
ifSONInformationRequest	This IE shall be present if the SON Information IE contains the SON
	Information Request IE set to "Xn TNL Configuration Info"

### 9.3.3.7 SON Information

This IE identifies the nature of the configuration information transferred, i.e., a request, a reply or a report.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE SON Information	M			
>SON Information				
Request				
>>SON Information Request	М		ENUMERATED (Xn TNL Configuration Info,)	
>SON Information Reply				
>>SON Information Reply	M		9.3.3.8	

### 9.3.3.8 SON Information Reply

This IE contains the configuration information to be replied to the NG-RAN node.

	IE/Group Name	Presence	Range	IE type and reference	Semantics description
Ī	Xn TNL Configuration Info	0		9.3.3.9	

### 9.3.3.9 Xn TNL Configuration Info

This IE is used for signalling Xn TNL Configuration information for automatic Xn SCTP association establishment.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Xn Transport Layer Addresses		1 <maxnoo fXnTLAs&gt;</maxnoo 			-	
>Transport Layer Address	M		9.3.2.4	Transport Layer Addresses for Xn SCTP endpoint.	-	
Xn Extended Transport Layer Addresses		0 <maxnoo fXnExtTLAs &gt;</maxnoo 			-	
>IP-Sec Transport Layer Address	0		Transport Layer Address 9.3.2.4	Transport Layer Addresses for IP- Sec endpoint.	-	
>Xn GTP Transport Layer Addresses		0 <maxnoo fXnGTP- TLAs&gt;</maxnoo 			-	
>>GTP Transport Layer Address	M		Transport Layer Address 9.3.2.4	GTP Transport Layer Addresses for GTP end-points (used for data forwarding over Xn).	-	
>Xn SCTP Transport Layer Addresses		0 <maxnoo fXnTLAs&gt;</maxnoo 			YES	ignore
>>Transport Layer Address SCTP	<u>M</u>		Transport Layer Address 9.3.2.4	Transport Layer Addresses for Xn SCTP endpoint.	-	

Range bound	Explanation
maxnoofXnTLAs	Maximum no. of Xn Transport Layer Addresses for an SCTP end-point.
	Value is 2.
maxnoofXnExtTLAs	Maximum no. of Xn Extended Transport Layer Addresses in the message. Value is 16.
maxnoofXnGTP-TLAs	Maximum no. of Xn GTP Transport Layer Addresses for a GTP end-point in the message. Value is 16.

### 9.3.3.10 TAC

This IE is used to uniquely identify a Tracking Area Code.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
TAC	М		OCTET STRING (SIZE(3))	

#### 9.3.3.11 TAI

This IE is used to uniquely identify a Tracking Area.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PLMN Identity	M		9.3.3.5	
TAC	M		9.3.3.10	

#### 9.3.3.12 AMF Set ID

This IE is used to uniquely identify an AMF Set within the AMF Region.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
AMF Set ID	M		BIT STRING (SIZE(10))	

### 9.3.3.13 Routing ID

This IE is used to identify an LMF within the 5GC.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Routing ID	M		OCTET STRING	

#### 9.3.3.14 NRPPa-PDU

This IE contains an NG-RAN node - LMF or LMF - NG-RAN node message that is transferred without interpretation in the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
NRPPa-PDU	M		OCTET STRING	

### 9.3.3.15 RAN Paging Priority

This IE contains the service priority as defined in TS 23.501 [9].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
RAN Paging Priority	М		INTEGER (1256)	Values ordered in decreasing order of priority, i.e. with 1 as the highest priority and 256 as the lowest priority

### 9.3.3.16 EPS TAC

This IE is used to uniquely identify an EPS Tracking Area Code.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
EPS TAC	M		OCTET STRING (SIZE(2))	

#### 9.3.3.17 EPS TAI

This IE is used to uniquely identify an EPS Tracking Area.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PLMN Identity	M		9.3.3.5	
EPS TAC	M		9.3.3.16	

### 9.3.3.18 UE Paging Identity

This IE represents the Identity with which the UE is paged.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE UE Paging Identity	М			
>5G-S-TMSI				
>>5G-S-TMSI	M		9.3.3.20	

#### 9.3.3.19 AMF Pointer

This IE is used to identify one or more AMF(s) within the AMF Set.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
AMF Pointer	М		BIT STRING (SIZE(6))	

#### 9.3.3.20 5G-S-TMSI

This IE is used for security reasons, to hide the identity of a subscriber.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
AMF Set ID	M		9.3.3.12	
AMF Pointer	M		9.3.3.19	
5G-TMSI	M		OCTET STRING (SIZE(4))	5G-TMSI is unique within the AMF that allocated it.

#### 9.3.3.21 AMF Name

This IE is used to uniquely identify the AMF (see TS 38.300 [8]). It may also be used as a human readable name of the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
AMF Name	M		PrintableString (SIZE(1150,))	

### 9.3.3.22 Paging Origin

This IE indicates whether Paging is originated due to the PDU sessions from the non-3GPP access.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Paging Origin	М		ENUMERATED (non-3GPP,)	

### 9.3.3.23 UE Identity Index Value

This IE is used by the NG-RAN node to calculate the Paging Frame as specified in TS 38.304 [12] and TS 36.304 [29].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE UE Identity Index Value				
>Index Length 10				
>>Index Length 10	M		BIT STRING (SIZE(10))	Coded as specified in TS 38.304 [12] and TS 36.304 [29].

### 9.3.3.24 Periodic Registration Update Timer

This IE is used to assist NG-RAN to generate corresponding timer for periodic RNA update for RRC\_INACTIVE UEs.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Periodic Registration Update Timer	M		BIT STRING (SIZE(8))	Bits 5 to 1 represent the binary coded timer value.
				Bits 6 to 8 define the timer value unit for the Periodic Registration Update Timer as follows:
				Bits 8 7 6 0 0 0 value is incremented in multiples of 10 minutes 0 0 1 value is incremented in multiples of 1 hour 0 1 0 value is incremented in multiples of 10 hours 0 1 1 value is incremented in multiples of 2 seconds 1 0 0 value is incremented in multiples of 30 seconds 1 0 1 value is incremented in multiples of 1 minute 1 1 1 value indicates that the timer is deactivated.
				1 1 0 value is incremented in multiples of 1 hour in this version of the protocol.

# 9.3.3.25 UE-associated Logical NG-connection List

This IE contains a list of UE-associated logical NG-connections.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
UE-associated Logical NG-connection Item		1 <maxnoofn GConnections ToReset&gt;</maxnoofn 		
>AMF UE NGAP ID	0		9.3.3.1	
>RAN UE NGAP ID	0		9.3.3.2	

Range bound	Explanation
	Maximum no. of UE-associated logical NG-connections allowed to reset in
	one message. Value is 65536.

### 9.3.3.26 NAS Security Parameters from NG-RAN

This IE provides security related parameters for inter-system handover from NG-RAN to E-UTRAN via the eNB to the UE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
NAS Security Parameters from NG-RAN	М		OCTET STRING	Refers to the N1 mode to S1 mode NAS transparent container IE, the details of the IE definition and the encoding are specified in TS 24.501 [26].

### 9.3.3.27 Source to Target AMF Information Reroute

This IE is used to transparently pass information provided by NSSF from the source AMF to the target AMF through the NG-RAN node; it is produced by the source core network node and is transmitted to the target core network node.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Configured NSSAI	0		OCTET STRING (SIZE(128))	The maximum number of S-NSSAI in Configured NSSAI is 16. This IE contains optional mapping S-NSSAI.  When present, this IE shall be transmitted transparent from the source Core network node to the target Core network node.  The octets of the OCTET STRING are encoded according to description in TS 29.531 [30]
Rejected NSSAI in PLMN	0		OCTET STRING (SIZE(32))	This IE contain the rejected NSSAI(s) in the PLMN. When present, this IE shall be transmitted transparent from the source Core network node to the target Core network node. The octets of the OCTET STRING are encoded according to description in TS 29.531 [30].
Rejected NSSAI in TA	0		OCTET STRING (SIZE(32))	This IE contain the rejected NSSAI(s) in the TA. When present, this IE shall be transmitted transparent from the source Core network node to the target Core network node. The octets of the OCTET STRING are encoded according to description in TS 29.531 [30].

### 9.3.4 SMF Related IEs

# 9.3.4.1 PDU Session Resource Setup Request Transfer

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
PDU Session Aggregate Maximum Bit Rate	0		9.3.1.102	This IE shall be present when at least one Non-GBR QoS flow is being setup and is ignored otherwise.	YES	reject
UL NG-U UP TNL Information	M		UP Transport Layer Information 9.3.2.2	UPF endpoint of the NG-U transport bearer, for delivery of UL PDUs.	YES	reject
Additional UL NG-U UP TNL Information	0		UP Transport Layer Information List 9.3.2.12	UPF endpoint of the additional NG- U transport bearer(s), for delivery of UL PDUs for split PDU session.	YES	reject
Data Forwarding Not Possible	0		9.3.1.63	This IE may be present in case of HANDOVER REQUEST message and is ignored otherwise.	YES	reject
PDU Session Type	M		9.3.1.52		YES	reject
Security Indication	0		9.3.1.27		YES	reject
Network Instance	0		9.3.1.113	This IE is ignored if the Common Network Instance IE is included.	YES	reject
QoS Flow Setup Request List		1			YES	reject
>QoS Flow Setup Request Item		1 <maxno ofQoSFlo ws&gt;</maxno 			-	
>>QoS Flow Identifier	М		9.3.1.51		-	
>>QoS Flow Level QoS Parameters	М		9.3.1.12		-	
>>E-RAB ID	0		9.3.2.3		-	
Common Network Instance	0		9.3.1.120		YES	ignore

Range bound	Explanation
maxnoofQoSFlows	Maximum no. of QoS flows allowed within one PDU session. Value is 64.

# 9.3.4.2 PDU Session Resource Setup Response Transfer

IE/Group Name	Presence	Range	IE type and reference	Semantics description
DL QoS Flow per TNL Information	M		QoS Flow per TNL Information 9.3.2.8	NG-RAN node endpoint of the NG-U transport bearer for delivery of DL PDUs, together with associated QoS flows.
Additional DL QoS Flow per TNL Information	0		QoS Flow per TNL Information List 9.3.2.1	NG-RAN node endpoint of the additional NG-U transport bearer(s) for delivery of DL PDUs for split PDU session, together with associated QoS flows.
Security Result	0		9.3.1.59	
QoS Flow Failed to Setup List	0		QoS Flow List with Cause 9.3.1.13	

# 9.3.4.3 PDU Session Resource Modify Request Transfer

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
PDU Session Aggregate Maximum Bit Rate	0		9.3.1.102		YES	reject
UL NG-U UP TNL Modify List		01			YES	reject
>UL NG-U UP TNL Modify Item		1 <maxno ofMultiCon nectivity&gt;</maxno 			-	
>>UL NG-U UP TNL Information	M		UP Transport Layer Information 9.3.2.2	UPF endpoint of the NG-U transport bearer, for delivery of UL PDUs.	-	
>>DL NG-U UP TNL Information	M		UP Transport Layer Information 9.3.2.2	Identifies the NG- U transport bearer at the NG-RAN node.	-	
Network Instance	0		9.3.1.113	This IE is ignored if the Common Network Instance IE is included.	YES	reject
QoS Flow Add or Modify Request List		01			YES	reject
>QoS Flow Add or Modify Request Item		1 <maxno ofQoSFlo ws&gt;</maxno 			-	
>>QoS Flow Identifier	M		9.3.1.51		-	
>>QoS Flow Level QoS Parameters	0		9.3.1.12		-	
>>E-RAB ID	0		9.3.2.3		-	
QoS Flow to Release List	0		QoS Flow List with Cause 9.3.1.13		YES	reject
Additional UL NG-U UP TNL Information	0		UP Transport Layer Information List 9.3.2.12	UPF endpoint of the additional NG- U transport bearer(s) proposed for delivery of UL PDUs for split PDU session.	YES	reject
Common Network Instance	0		9.3.1.120		YES	ignore

Range bound	Explanation
maxnoofQoSFlows	Maximum no. of QoS flows allowed within one PDU session. Value is 64.
maxnoofMultiConnectivity	Maximum no. of connectivity allowed for a UE. Value is 4. The current version
	of the specification supports up to 2 connectivity.

### 9.3.4.4 PDU Session Resource Modify Response Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and	Semantics	Criticality	Assigned
DL NG-U UP TNL	0		reference UP Transport	description NG-RAN node	_	Criticality
Information			Layer	endpoint of the	_	
			Information	NG-U transport		
			9.3.2.2	bearer, for delivery		
				of DL PDUs.		
UL NG-U UP TNL	0		UP Transport	Identifies the NG-	-	
Information			Layer Information	U transport bearer at the 5GC node.		
			9.3.2.2	at the 5GC flode.		
QoS Flow Add or		01	0.0.2.2		-	
Modify Response List						
>QoS Flow Add or		1 <maxno< td=""><td></td><td></td><td>-</td><td></td></maxno<>			-	
Modify Response		ofQoSFlo				
ltem		WS>	0.04.54			
>>QoS Flow Identifier Additional DL QoS Flow	M O		9.3.1.51	NG-RAN node	-	
per TNL Information	U		QoS Flow per TNL Information	endpoint of the	-	
per me information			List	additional NG-U		
			9.3.2.1	transport bearer(s)		
				for delivery of DL		
				PDUs for split		
				PDU session,		
				together with		
				associated QoS flows.		
QoS Flow Failed to Add	0		QoS Flow List	nows.	_	
or Modify List			with Cause			
•			9.3.1.13			
Additional NG-U UP	0		UP Transport	NG-RAN node	YES	ignore
TNL Information			Layer	endpoint of the		
			Information Pair List	NG-U transport bearer		
			9.3.2.11	corresponding to		
			9.5.2.11	the modified UPF		
				endpoint received		
				in the PDU		
				Session Resource		
				Modify Request		
				Transfer IE in case of PDU session		
				split.		
			1	οριιι.		

Range bound	Explanation
maxnoofQoSFlows	Maximum no. of QoS flows allowed within one PDU session. Value is 64.

# 9.3.4.5 PDU Session Resource Notify Transfer

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
QoS Flow Notify List		01			-	
>QoS Flow Notify Item		1 <maxno ofQoSFlo ws&gt;</maxno 			-	
>>QoS Flow Identifier	M		9.3.1.51		-	
>>Notification Cause	М		ENUMERATED (fullfilled, not fulfilled,)		-	
QoS Flow Released List	0		QoS Flow List with Cause 9.3.1.13		-	
Secondary RAT Usage Information	0		9.3.1.114		YES	ignore

Range bound	Explanation		
maxnoofQoSFlows	Maximum no. of QoS flows allowed within one PDU session. Value is 64.		

# 9.3.4.6 PDU Session Resource Modify Indication Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
DL QoS Flow per TNL Information	M		QoS Flow per TNL Information 9.3.2.8	NG-RAN node endpoint of the NG-U transport bearer for delivery of DL PDUs, together with associated QoS flows.	-	
Additional DL QoS Flow per TNL Information	0		QoS Flow per TNL Information List 9.3.2.1	NG-RAN node endpoint of the additional NG-U transport bearer(s) for delivery of DL PDUs for split PDU session, together with associated QoS flows	-	
Secondary RAT Usage Information	0		9.3.1.114		YES	ignore
Security Result	0		9.3.1.59	Current UP security status	YES	ignore

### 9.3.4.7 PDU Session Resource Modify Confirm Transfer

IE/Group Name	Presence	Range	IE type and reference	Semantics description
QoS Flow Modify Confirm List		1		
>QoS Flow Modify Confirm Item		1 <maxnoofq oSFlows&gt;</maxnoofq 		
>>QoS Flow Identifier	M		9.3.1.51	
UL NG-U UP TNL Information	M		UP Transport Layer Information 9.3.2.2	UPF endpoint of the NG-U transport bearer corresponding to the DL NG-U UP TNL Information IE received in the PDU Session Resource Modify Indication Transfer IE.
Additional NG-U UP TNL Information	0		UP Transport Layer Information Pair List 9.3.2.11	NG-RAN node endpoint of the NG-U transport bearer indicated in the <i>PDU Session Resource Modify Indication Transfer</i> IE and the corresponding UPF endpoint for split PDU session.
QoS Flow Failed to Modify List	0		QoS Flow List with Cause 9.3.1.13	

Range bound	Explanation		
maxnoofQoSFlows	Maximum no. of QoS flows allowed within one PDU session. Value is 64.		

# 9.3.4.8 Path Switch Request Transfer

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
DL NG-U UP TNL Information	M		UP Transport Layer Information 9.3.2.2	NG-RAN node endpoint of the NG-U transport bearer, for delivery of DL PDUs.	-	
DL NG-U TNL Information Reused	0		ENUMERATED (true,)	Indicates that DL NG-U TNL Information has been reused.	-	
User Plane Security Information	0		9.3.1.60		-	
QoS Flow Accepted List		1		QoS flows associated with the DL NG-U UP TNL Information IE.	-	
>QoS Flow Accepted Item		1 <maxno ofQoSFlo ws&gt;</maxno 			-	
>>QoS Flow Identifier Additional DL QoS Flow per TNL Information	O		9.3.1.51  QoS Flow per TNL Information List 9.3.2.1	NG-RAN node endpoint of the additional NG-U transport bearer(s) for delivery of DL PDUs for split PDU session, together with associated QoS flows.	YES	ignore

Range bound	Explanation			
maxnoofQoSFlows	Maximum no. of QoS flows allowed within one PDU session. Value is 64.			

### 9.3.4.9 Path Switch Request Acknowledge Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
UL NG-U UP TNL Information	0		UP Transport Layer Information 9.3.2.2	UPF endpoint of the NG-U transport bearer corresponding to the DL NG-U UP TNL Information IE received in the Path Switch Request Transfer IE.	-	
Security Indication	0		9.3.1.27		-	
Additional NG-U UP TNL Information	0		UP Transport Layer Information Pair List 9.3.2.11	NG-RAN node endpoint of the NG-U transport bearer indicated in the Path Switch Request Transfer IE and the corresponding UPF endpoint for split PDU session.	YES	ignore

### 9.3.4.10 Handover Command Transfer

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
DL Forwarding UP TNL Information	0		UP Transport Layer Information 9.3.2.2	To deliver forwarded DL PDUs.	-	
QoS Flow to be Forwarded List		01		QoS flows associated with the DL Forwarding UP TNL Information IE.	-	
>QoS Flow to be Forwarded Item		1 <maxno ofQoSFlo ws&gt;</maxno 			-	
>>QoS Flow Identifier	M		9.3.1.51		-	
Data Forwarding Response DRB List	0		9.3.1.77		-	
Additional DL Forwarding UP TNL Information	0		QoS Flow per TNL Information List 9.3.2.1	NG-RAN node endpoint to deliver forwarded DL PDUs for split PDU session, together with associated QoS flows to be forwarded.	YES	ignore
UL Forwarding UP TNL Information	0		UP Transport Layer Information 9.3.2.2	To deliver forwarded UL PDUs	YES	reject
Additional UL Forwarding UP TNL Information	0		UP Transport Layer Information List 9.3.2.12	NG-RAN node endpoint to deliver forwarded UL PDUs for split PDU session.	YES	reject

Range bound	Explanation
maxnoofQoSFlows	Maximum no. of QoS flows allowed within one PDU session. Value is 64.

# 9.3.4.11 Handover Request Acknowledge Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
DL NG-U UP TNL Information	M		UP Transport Layer Information 9.3.2.2	NG-RAN node endpoint of the NG-U transport bearer, for delivery of DL PDUs.	-	
DL Forwarding UP TNL Information	0		UP Transport Layer Information 9.3.2.2	To deliver forwarded DL PDUs.	-	
Security Result	0		9.3.1.59		-	
QoS Flow Setup Response List	M		QoS Flow List with Data Forwarding 9.3.2.13	QoS flows associated with the DL NG-U UP TNL Information IE.	-	
QoS Flow Failed to Setup List	0		QoS Flow List with Cause 9.3.1.13		-	
Data Forwarding Response DRB List	0		9.3.1.77		-	
Additional DL UP TNL Information for HO List		01			YES	ignore
>Additional DL UP TNL Information for HO Item		1 <maxno ofMultiCon nectivityMi nusOne&gt;</maxno 		Additional DL UP TNL Information for split PDU session, in the same order as the UPF endpoint of the additional NG-U transport bearer(s) received in the PDU Session Request Setup Transfer IE of the Handover Request message.	-	
>>Additional DL NG- U UP TNL Information	M		UP Transport Layer Information 9.3.2.2	NG-RAN node endpoint of the additional NG-U transport bearer for delivery of DL PDUs.	-	
>>Additional QoS Flow Setup Response List	M		QoS Flow List with Data Forwarding 9.3.2.13	QoS flows associated with the Additional DL NG-U UP TNL Information IE.	-	
>>Additional DL Forwarding UP TNL Information	0		UP Transport Layer Information 9.3.2.2	NG-RAN node endpoint to deliver forwarded DL PDUs.	-	
UL Forwarding UP TNL Information	0		UP Transport Layer Information 9.3.2.2	To deliver forwarded UL PDUs	YES	reject
Additional UL Forwarding UP TNL Information	0		UP Transport Layer Information List 9.3.2.12	NG-RAN node endpoint to deliver forwarded UL PDUs for split PDU session.	YES	reject

Range bound	Explanation		
maxnoofQoSFlows	Maximum no. of QoS flows allowed within one PDU session. Value is 64.		
maxnoofMultiConnectivityMinusOne	Maximum no. of connectivity allowed for a UE minus one. Value is 3. The current version of the specification supports 1.		

#### 9.3.4.12 PDU Session Resource Release Command Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Cause	M		9.3.1.2	

#### 9.3.4.13 PDU Session Resource Notify Released Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Cause	M		9.3.1.2		-	
Secondary RAT Usage Information	0		9.3.1.114		YES	ignore

#### 9.3.4.14 Handover Required Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Direct Forwarding Path Availability	0		9.3.1.64	

#### 9.3.4.15 Path Switch Request Setup Failed Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Cause	M		9.3.1.2	

#### 9.3.4.16 PDU Session Resource Setup Unsuccessful Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Cause	M		9.3.1.2	
Criticality Diagnostics	0		9.3.1.3	

#### 9.3.4.17 PDU Session Resource Modify Unsuccessful Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Cause	M		9.3.1.2	
Criticality Diagnostics	0		9.3.1.3	

#### 9.3.4.18 Handover Preparation Unsuccessful Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Cause	M		9.3.1.2	

#### 9.3.4.19 Handover Resource Allocation Unsuccessful Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Cause	M		9.3.1.2	
Criticality Diagnostics	0		9.3.1.3	

#### 9.3.4.20 Path Switch Request Unsuccessful Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Cause	M		9.3.1.2	

#### 9.3.4.21 PDU Session Resource Release Response Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Secondary RAT Usage Information	0		9.3.1.114		YES	ignore

#### 9.3.4.22 PDU Session Resource Modify Indication Unsuccessful Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Cause	M		9.3.1.2	

#### 9.3.4.23 Secondary RAT Data Usage Report Transfer

This IE is transparent to the AMF.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Secondary RAT Usage Information	0		9.3.1.114	

# 9.4 Message and Information Element Abstract Syntax (with ASN.1)

#### 9.4.1 General

NGAP ASN.1 definition conforms to ITU-T Rec. X.691 [4], ITU-T Rec. X.680 [5] and ITU-T Rec. X.681 [6].

The ASN.1 definition specifies the structure and content of NGAP messages. NGAP messages can contain any IEs specified in the object set definitions for that message without the order or number of occurrence being restricted by ASN.1. However, for this version of the standard, a sending entity shall construct an NGAP message according to the PDU definitions module and with the following additional rules:

- IEs shall be ordered (in an IE container) in the order they appear in object set definitions.
- Object set definitions specify how many times IEs may appear. An IE shall appear exactly once if the presence field in an object has value "mandatory". An IE may appear at most once if the presence field in an object has value "optional" or "conditional". If in a tabular format there is multiplicity specified for an IE (i.e., an IE list) then in the corresponding ASN.1 definition the list definition is separated into two parts. The first part defines an IE container list where the list elements reside. The second part defines list elements. The IE container list appears as an IE of its own. For this version of the standard an IE container list may contain only one kind of list elements.

NOTE: In the above "IE" means an IE in the object set with an explicit ID. If one IE needs to appear more than once in one object set, then the different occurrences will have different IE IDs.

If an NGAP message that is not constructed as defined above is received, this shall be considered as Abstract Syntax Error, and the message shall be handled as defined for Abstract Syntax Error in subclause 10.3.6.

### 9.4.2 Usage of private message mechanism for non-standard use

The private message mechanism for non-standard use may be used:

- for special operator- (and/or vendor) specific features considered not to be part of the basic functionality, i.e., the
  functionality required for a complete and high-quality specification in order to guarantee multivendor
  interoperability;
- by vendors for research purposes, e.g., to implement and evaluate new algorithms/features before such features are proposed for standardisation.

The private message mechanism shall not be used for basic functionality. Such functionality shall be standardised.

## 9.4.3 Elementary Procedure Definitions

```
-- ASN1START
__ **********************************
-- Elementary Procedure definitions
__ *******************
NGAP-PDU-Descriptions {
itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
ngran-Access (22) modules (3) ngap (1) version1 (1) ngap-PDU-Descriptions (0)}
DEFINITIONS AUTOMATIC TAGS ::=
BEGIN
    -- IE parameter types from other modules.
__ **********************
IMPORTS
   Criticality,
   ProcedureCode
FROM NGAP-CommonDataTypes
   AMFConfigurationUpdate,
   AMFConfigurationUpdateAcknowledge,
   AMFConfigurationUpdateFailure,
   AMFStatusIndication,
   CellTrafficTrace,
   DeactivateTrace,
   DownlinkNASTransport,
   DownlinkNonUEAssociatedNRPPaTransport,
   DownlinkRANConfigurationTransfer,
   DownlinkRANStatusTransfer,
   DownlinkUEAssociatedNRPPaTransport,
   ErrorIndication,
   HandoverCancel,
   HandoverCancelAcknowledge,
   HandoverCommand,
   HandoverFailure,
   HandoverNotify,
   HandoverPreparationFailure,
   HandoverRequest,
   HandoverRequestAcknowledge,
   HandoverRequired,
   InitialContextSetupFailure,
   InitialContextSetupRequest,
   InitialContextSetupResponse,
```

```
InitialUEMessage,
LocationReport,
LocationReportingControl,
LocationReportingFailureIndication,
NASNonDeliveryIndication,
NGReset,
NGResetAcknowledge,
NGSetupFailure,
NGSetupRequest,
NGSetupResponse,
OverloadStart,
OverloadStop,
Paging,
PathSwitchRequest,
PathSwitchRequestAcknowledge,
PathSwitchRequestFailure,
PDUSessionResourceModifyConfirm,
PDUSessionResourceModifyIndication,
PDUSessionResourceModifyRequest,
PDUSessionResourceModifyResponse,
PDUSessionResourceNotify,
PDUSessionResourceReleaseCommand,
PDUSessionResourceReleaseResponse,
PDUSessionResourceSetupRequest,
PDUSessionResourceSetupResponse,
PrivateMessage,
PWSCancelRequest,
PWSCancelResponse,
PWSFailureIndication,
PWSRestartIndication,
RANConfigurationUpdate,
RANConfigurationUpdateAcknowledge,
RANConfigurationUpdateFailure,
RerouteNASRequest,
RRCInactiveTransitionReport,
SecondaryRATDataUsageReport,
TraceFailureIndication,
TraceStart,
UEContextModificationFailure,
UEContextModificationRequest,
UEContextModificationResponse,
UEContextReleaseCommand,
UEContextReleaseComplete,
UEContextReleaseRequest,
UERadioCapabilityCheckRequest,
UERadioCapabilityCheckResponse,
UERadioCapabilityInfoIndication,
UETNLABindingReleaseRequest,
UplinkNASTransport,
UplinkNonUEAssociatedNRPPaTransport,
UplinkRANConfigurationTransfer,
UplinkRANStatusTransfer,
UplinkUEAssociatedNRPPaTransport,
WriteReplaceWarningRequest,
```

WriteReplaceWarningResponse FROM NGAP-PDU-Contents id-AMFConfigurationUpdate, id-AMFStatusIndication. id-CellTrafficTrace, id-DeactivateTrace, id-DownlinkNASTransport, id-DownlinkNonUEAssociatedNRPPaTransport, id-DownlinkRANConfigurationTransfer, id-DownlinkRANStatusTransfer, id-DownlinkUEAssociatedNRPPaTransport, id-ErrorIndication, id-HandoverCancel. id-HandoverNotification, id-HandoverPreparation, id-HandoverResourceAllocation, id-InitialContextSetup, id-InitialUEMessage, id-LocationReport, id-LocationReportingControl, id-LocationReportingFailureIndication, id-NASNonDeliveryIndication, id-NGReset, id-NGSetup, id-OverloadStart, id-OverloadStop, id-Paging, id-PathSwitchRequest, id-PDUSessionResourceModify, id-PDUSessionResourceModifyIndication, id-PDUSessionResourceNotify, id-PDUSessionResourceRelease, id-PDUSessionResourceSetup, id-PrivateMessage, id-PWSCancel, id-PWSFailureIndication, id-PWSRestartIndication, id-RANConfigurationUpdate, id-RerouteNASRequest, id-RRCInactiveTransitionReport, id-SecondaryRATDataUsageReport, id-TraceFailureIndication, id-TraceStart. id-UEContextModification, id-UEContextRelease, id-UEContextReleaseRequest, id-UERadioCapabilityCheck, id-UERadioCapabilityInfoIndication, id-UETNLABindingRelease, id-UplinkNASTransport, id-UplinkNonUEAssociatedNRPPaTransport, id-UplinkRANConfigurationTransfer, id-UplinkRANStatusTransfer,

```
id-UplinkUEAssociatedNRPPaTransport,
    id-WriteReplaceWarning
FROM NGAP-Constants;
-- Interface Elementary Procedure Class
NGAP-ELEMENTARY-PROCEDURE ::= CLASS {
    &InitiatingMessage
    &SuccessfulOutcome
                                                OPTIONAL,
    &UnsuccessfulOut.come
                                                OPTIONAL,
    &procedureCode
                                ProcedureCode UNIQUE,
    &criticality
                                Criticality DEFAULT ignore
WITH SYNTAX {
    INITIATING MESSAGE
                                &InitiatingMessage
    [SUCCESSFUL OUTCOME
                                &SuccessfulOutcomel
                                &UnsuccessfulOutcome]
    [UNSUCCESSFUL OUTCOME
                                &procedureCode
    PROCEDURE CODE
    [CRITICALITY
                                &criticality]
  Interface PDU Definition
NGAP-PDU ::= CHOICE {
    initiatingMessage
                                InitiatingMessage,
    successfulOutcome
                                SuccessfulOutcome.
    unsuccessfulOutcome
                                UnsuccessfulOutcome,
InitiatingMessage ::= SEOUENCE
    procedureCode NGAP-ELEMENTARY-PROCEDURE.&procedureCode
                                                                     ({NGAP-ELEMENTARY-PROCEDURES}),
                                                                     ({NGAP-ELEMENTARY-PROCEDURES}{@procedureCode}),
    criticality
                    NGAP-ELEMENTARY-PROCEDURE.&criticality
    value
                                                                    ({NGAP-ELEMENTARY-PROCEDURES}{@procedureCode})
                    NGAP-ELEMENTARY-PROCEDURE.&InitiatingMessage
SuccessfulOutcome ::= SEQUENCE {
    procedureCode NGAP-ELEMENTARY-PROCEDURE.&procedureCode
                                                                     ({NGAP-ELEMENTARY-PROCEDURES}),
                                                                    ({NGAP-ELEMENTARY-PROCEDURES}{@procedureCode}),
    criticality
                    NGAP-ELEMENTARY-PROCEDURE.&criticality
                                                                    ({NGAP-ELEMENTARY-PROCEDURES}{@procedureCode})
    value
                    NGAP-ELEMENTARY-PROCEDURE.&SuccessfulOutcome
UnsuccessfulOutcome ::= SEOUENCE {
    procedureCode NGAP-ELEMENTARY-PROCEDURE.&procedureCode
                                                                     ({NGAP-ELEMENTARY-PROCEDURES}),
    criticality
                                                                     ({NGAP-ELEMENTARY-PROCEDURES}{@procedureCode}),
                    NGAP-ELEMENTARY-PROCEDURE.&criticality
```

```
NGAP-ELEMENTARY-PROCEDURE. & UnsuccessfulOutcome ({NGAP-ELEMENTARY-PROCEDURES}{@procedureCode})
           *************
-- Interface Elementary Procedure List
__ *******************
NGAP-ELEMENTARY-PROCEDURES NGAP-ELEMENTARY-PROCEDURE ::= {
   NGAP-ELEMENTARY-PROCEDURES-CLASS-1
   NGAP-ELEMENTARY-PROCEDURES-CLASS-2,
NGAP-ELEMENTARY-PROCEDURES-CLASS-1 NGAP-ELEMENTARY-PROCEDURE ::=
   aMFConfigurationUpdate
   handoverCancel
   handoverPreparation
   handoverResourceAllocation
   initialContextSetup
   nGReset
   nGSetup
   pathSwitchRequest
   pDUSessionResourceModify
   pDUSessionResourceModifyIndication
   pDUSessionResourceRelease
   pDUSessionResourceSetup
   pWSCancel
   rANConfigurationUpdate
   uEContextModification
   uEContextRelease
   uERadioCapabilityCheck
   writeReplaceWarning
NGAP-ELEMENTARY-PROCEDURES-CLASS-2 NGAP-ELEMENTARY-PROCEDURE ::=
   aMFStatusIndication
   cellTrafficTrace
   deactivateTrace
   downlinkNASTransport
   downlinkNonUEAssociatedNRPPaTransport
   downlinkRANConfigurationTransfer
   downlinkRANStatusTransfer
   downlinkUEAssociatedNRPPaTransport
   errorIndication
   handoverNotification
   initialUEMessage
   locationReport
   locationReportingControl
   locationReportingFailureIndication
   nASNonDeliveryIndication
   overloadStart
   overloadStop
```

```
paging
   pDUSessionResourceNotify
   privateMessage
   pWSFailureIndication
   pWSRestartIndication
   rerouteNASRequest
   rRCInactiveTransitionReport
   secondaryRATDataUsageReport
   traceFailureIndication
   traceStart
   uEContextReleaseRequest
   uERadioCapabilityInfoIndication
   uETNLABindingRelease
   uplinkNASTransport
   uplinkNonUEAssociatedNRPPaTransport
   uplinkRANConfigurationTransfer
   uplinkRANStatusTransfer
   uplinkUEAssociatedNRPPaTransport
    -- Interface Elementary Procedures
__ **********************
aMFConfigurationUpdate NGAP-ELEMENTARY-PROCEDURE ::= {
                          AMFConfigurationUpdate
   INITIATING MESSAGE
                          AMFConfigurationUpdateAcknowledge
   SUCCESSFUL OUTCOME
                          AMFConfigurationUpdateFailure
   UNSUCCESSFUL OUTCOME
   PROCEDURE CODE
                          id-AMFConfigurationUpdate
   CRITICALITY
                          reject
aMFStatusIndication NGAP-ELEMENTARY-PROCEDURE ::={
   INITIATING MESSAGE
                          AMFStatusIndication
   PROCEDURE CODE
                          id-AMFStatusIndication
   CRITICALITY
                          ignore
cellTrafficTrace NGAP-ELEMENTARY-PROCEDURE ::={
                          CellTrafficTrace
   INITIATING MESSAGE
   PROCEDURE CODE
                          id-CellTrafficTrace
   CRITICALITY
                          ignore
deactivateTrace NGAP-ELEMENTARY-PROCEDURE ::= {
   INITIATING MESSAGE
                          DeactivateTrace
   PROCEDURE CODE
                          id-DeactivateTrace
   CRITICALITY
                          ignore
downlinkNASTransport NGAP-ELEMENTARY-PROCEDURE ::= {
   INITIATING MESSAGE
                          DownlinkNASTransport
```

```
id-DownlinkNASTransport
    PROCEDURE CODE
    CRITICALITY
                            ignore
downlinkNonUEAssociatedNRPPaTransport NGAP-ELEMENTARY-PROCEDURE ::= {
                            DownlinkNonUEAssociatedNRPPaTransport
    INITIATING MESSAGE
    PROCEDURE CODE
                            id-DownlinkNonUEAssociatedNRPPaTransport
    CRITICALITY
                            ignore
downlinkRANConfigurationTransfer NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            DownlinkRANConfigurationTransfer
    PROCEDURE CODE
                            id-DownlinkRANConfigurationTransfer
    CRITICALITY
                            ignore
downlinkRANStatusTransfer NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            DownlinkRANStatusTransfer
                            id-DownlinkRANStatusTransfer
    PROCEDURE CODE
    CRITICALITY
                            ignore
downlinkUEAssociatedNRPPaTransport NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            DownlinkUEAssociatedNRPPaTransport
    PROCEDURE CODE
                            id-DownlinkUEAssociatedNRPPaTransport
    CRITICALITY
                            ignore
errorIndication NGAP-ELEMENTARY-PROCEDURE ::= {
                            ErrorIndication
    INITIATING MESSAGE
    PROCEDURE CODE
                            id-ErrorIndication
    CRITICALITY
                            ignore
handoverCancel NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            HandoverCancel
    SUCCESSFUL OUTCOME
                            HandoverCancelAcknowledge
    PROCEDURE CODE
                            id-HandoverCancel
    CRITICALITY
                            reject
handoverNotification NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            HandoverNotify
    PROCEDURE CODE
                            id-HandoverNotification
    CRITICALITY
                            ignore
handoverPreparation NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            HandoverRequired
                            HandoverCommand
    SUCCESSFUL OUTCOME
                            HandoverPreparationFailure
    UNSUCCESSFUL OUTCOME
    PROCEDURE CODE
                            id-HandoverPreparation
    CRITICALITY
                            reject
```

```
handoverResourceAllocation NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            HandoverRequest
    SUCCESSFUL OUTCOME
                            HandoverRequestAcknowledge
    UNSUCCESSFUL OUTCOME
                            HandoverFailure
                            id-HandoverResourceAllocation
    PROCEDURE CODE
    CRITICALITY
                            reject
initialContextSetup NGAP-ELEMENTARY-PROCEDURE ::= {
                            InitialContextSetupRequest
    INITIATING MESSAGE
                            InitialContextSetupResponse
    SUCCESSFUL OUTCOME
    UNSUCCESSFUL OUTCOME
                            InitialContextSetupFailure
    PROCEDURE CODE
                            id-InitialContextSetup
    CRITICALITY
                            reject
initialUEMessage NGAP-ELEMENTARY-PROCEDURE ::= {
                            InitialUEMessage
    INITIATING MESSAGE
    PROCEDURE CODE
                            id-InitialUEMessage
    CRITICALITY
                            ignore
locationReport NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            LocationReport
    PROCEDURE CODE
                            id-LocationReport
    CRITICALITY
                            ignore
locationReportingControl NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            LocationReportingControl
    PROCEDURE CODE
                            id-LocationReportingControl
    CRITICALITY
                            ignore
locationReportingFailureIndication NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            LocationReportingFailureIndication
    PROCEDURE CODE
                            id-LocationReportingFailureIndication
    CRITICALITY
                            ignore
nASNonDeliveryIndication NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            NASNonDeliveryIndication
    PROCEDURE CODE
                            id-NASNonDeliveryIndication
    CRITICALITY
                            ignore
nGReset NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            NGReset
    SUCCESSFUL OUTCOME
                            NGResetAcknowledge
    PROCEDURE CODE
                            id-NGReset
    CRITICALITY
                            reject
```

```
nGSetup NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            NGSetupRequest
    SUCCESSFUL OUTCOME
                            NGSetupResponse
    UNSUCCESSFUL OUTCOME
                            NGSetupFailure
    PROCEDURE CODE
                            id-NGSetup
    CRITICALITY
                            reject
overloadStart NGAP-ELEMENTARY-PROCEDURE ::= {
                            OverloadStart
    INITIATING MESSAGE
    PROCEDURE CODE
                            id-OverloadStart
    CRITICALITY
                            ignore
overloadStop NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            OverloadStop
    PROCEDURE CODE
                            id-OverloadStop
    CRITICALITY
                            reject
paging NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            Paging
    PROCEDURE CODE
                            id-Paging
    CRITICALITY
                            ignore
pathSwitchRequest NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            PathSwitchRequest
                            PathSwitchRequestAcknowledge
    SUCCESSFUL OUTCOME
                            PathSwitchRequestFailure
    UNSUCCESSFUL OUTCOME
    PROCEDURE CODE
                            id-PathSwitchRequest
    CRITICALITY
                            reject
pDUSessionResourceModify NGAP-ELEMENTARY-PROCEDURE ::= {
                            PDUSessionResourceModifyRequest
    INITIATING MESSAGE
    SUCCESSFUL OUTCOME
                            PDUSessionResourceModifyResponse
                            id-PDUSessionResourceModify
    PROCEDURE CODE
    CRITICALITY
                            reject
pDUSessionResourceModifyIndication NGAP-ELEMENTARY-PROCEDURE ::= {
                            PDUSessionResourceModifyIndication
    INITIATING MESSAGE
    SUCCESSFUL OUTCOME
                            PDUSessionResourceModifyConfirm
                            id-PDUSessionResourceModifyIndication
    PROCEDURE CODE
    CRITICALITY
                            reject
pDUSessionResourceNotify NGAP-ELEMENTARY-PROCEDURE ::= {
                            PDUSessionResourceNotify
    INITIATING MESSAGE
                            id-PDUSessionResourceNotify
    PROCEDURE CODE
    CRITICALITY
                            ignore
```

```
pDUSessionResourceRelease NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            PDUSessionResourceReleaseCommand
    SUCCESSFUL OUTCOME
                            PDUSessionResourceReleaseResponse
    PROCEDURE CODE
                            id-PDUSessionResourceRelease
    CRITICALITY
                            reject
pDUSessionResourceSetup NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            PDUSessionResourceSetupRequest
    SUCCESSFUL OUTCOME
                            PDUSessionResourceSetupResponse
    PROCEDURE CODE
                            id-PDUSessionResourceSetup
    CRITICALITY
                            reject
privateMessage NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            PrivateMessage
                            id-PrivateMessage
    PROCEDURE CODE
    CRITICALITY
                            ignore
pWSCancel NGAP-ELEMENTARY-PROCEDURE ::= {
                            PWSCancelRequest
    INITIATING MESSAGE
                            PWSCancelResponse
    SUCCESSFUL OUTCOME
    PROCEDURE CODE
                            id-PWSCancel
    CRITICALITY
                            reject
pWSFailureIndication NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            PWSFailureIndication
    PROCEDURE CODE
                            id-PWSFailureIndication
    CRITICALITY
                            ignore
pWSRestartIndication NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            PWSRestartIndication
                            id-PWSRestartIndication
    PROCEDURE CODE
    CRITICALITY
                            ignore
rANConfigurationUpdate NGAP-ELEMENTARY-PROCEDURE ::= {
                            RANConfigurationUpdate
    INITIATING MESSAGE
    SUCCESSFUL OUTCOME
                            RANConfigurationUpdateAcknowledge
                            RANConfigurationUpdateFailure
    UNSUCCESSFUL OUTCOME
                            id-RANConfigurationUpdate
    PROCEDURE CODE
                            reject
    CRITICALITY
rerouteNASRequest NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            RerouteNASRequest
    PROCEDURE CODE
                            id-RerouteNASRequest
    CRITICALITY
                            reject
rRCInactiveTransitionReport NGAP-ELEMENTARY-PROCEDURE ::=
```

```
RRCInactiveTransitionReport
    INITIATING MESSAGE
    PROCEDURE CODE
                            id-RRCInactiveTransitionReport
    CRITICALITY
                            ignore
secondaryRATDataUsageReport NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            SecondaryRATDataUsageReport
    PROCEDURE CODE
                            id-SecondaryRATDataUsageReport
    CRITICALITY
                            ignore
traceFailureIndication NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            TraceFailureIndication
    PROCEDURE CODE
                            id-TraceFailureIndication
    CRITICALITY
                            ignore
traceStart NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            TraceStart
    PROCEDURE CODE
                            id-TraceStart
    CRITICALITY
                            ignore
uEContextModification NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            UEContextModificationRequest
                            UEContextModificationResponse
    SUCCESSFUL OUTCOME
                            UEContextModificationFailure
    UNSUCCESSFUL OUTCOME
    PROCEDURE CODE
                            id-UEContextModification
                            reject
    CRITICALITY
uEContextRelease NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            UEContextReleaseCommand
    SUCCESSFUL OUTCOME
                            UEContextReleaseComplete
    PROCEDURE CODE
                            id-UEContextRelease
    CRITICALITY
                            reject
uEContextReleaseRequest NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            UEContextReleaseRequest
    PROCEDURE CODE
                            id-UEContextReleaseRequest
    CRITICALITY
                            ignore
uERadioCapabilityCheck NGAP-ELEMENTARY-PROCEDURE ::= {
                            UERadioCapabilityCheckRequest
    INITIATING MESSAGE
                            UERadioCapabilityCheckResponse
    SUCCESSFUL OUTCOME
                            id-UERadioCapabilityCheck
    PROCEDURE CODE
    CRITICALITY
                            reject
uERadioCapabilityInfoIndication NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            UERadioCapabilityInfoIndication
    PROCEDURE CODE
                            id-UERadioCapabilityInfoIndication
```

196

```
CRITICALITY
                            ignore
uETNLABindingRelease NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            UETNLABindingReleaseRequest
    PROCEDURE CODE
                            id-UETNLABindingRelease
    CRITICALITY
                            ignore
uplinkNASTransport NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            UplinkNASTransport
    PROCEDURE CODE
                            id-UplinkNASTransport
    CRITICALITY
                            ignore
uplinkNonUEAssociatedNRPPaTransport NGAP-ELEMENTARY-PROCEDURE ::= {
                            UplinkNonUEAssociatedNRPPaTransport
    INITIATING MESSAGE
                            id-UplinkNonUEAssociatedNRPPaTransport
    PROCEDURE CODE
    CRITICALITY
                            ignore
uplinkRANConfigurationTransfer NGAP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            UplinkRANConfigurationTransfer
                            id-UplinkRANConfigurationTransfer
    PROCEDURE CODE
    CRITICALITY
                            ignore
uplinkRANStatusTransfer NGAP-ELEMENTARY-PROCEDURE ::= {
                            UplinkRANStatusTransfer
    INITIATING MESSAGE
    PROCEDURE CODE
                            id-UplinkRANStatusTransfer
    CRITICALITY
                            ignore
uplinkUEAssociatedNRPPaTransport NGAP-ELEMENTARY-PROCEDURE ::= {
                            UplinkUEAssociatedNRPPaTransport
    INITIATING MESSAGE
                            id-UplinkUEAssociatedNRPPaTransport
    PROCEDURE CODE
    CRITICALITY
                            ignore
writeReplaceWarning NGAP-ELEMENTARY-PROCEDURE ::= {
                            WriteReplaceWarningRequest
    INITIATING MESSAGE
                            WriteReplaceWarningResponse
    SUCCESSFUL OUTCOME
                            id-WriteReplaceWarning
    PROCEDURE CODE
    CRITICALITY
                            reject
END
-- ASN1STOP
```

#### 9.4.4 PDU Definitions

```
-- PDU definitions for NGAP.
__ **********************
NGAP-PDU-Contents {
itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
ngran-Access (22) modules (3) ngap (1) version1 (1) ngap-PDU-Contents (1) }
DEFINITIONS AUTOMATIC TAGS ::=
BEGIN
  *****************
-- IE parameter types from other modules.
__ *******************
IMPORTS
   AllowedNSSAI,
   AMFName,
   AMFSetID,
   AMF-TNLAssociationSetupList,
   AMF-TNLAssociationToAddList,
   AMF-TNLAssociationToRemoveList,
   AMF-TNLAssociationToUpdateList,
   AMF-UE-NGAP-ID,
   AssistanceDataForPaging,
   BroadcastCancelledAreaList,
   BroadcastCompletedAreaList,
   CancelAllWarningMessages,
   Cause,
   CellIDListForRestart,
   CNAssistedRANTuning,
   ConcurrentWarningMessageInd,
   CoreNetworkAssistanceInformationForInactive,
   CPTransportLayerInformation,
   CriticalityDiagnostics,
   DataCodingScheme,
   DirectForwardingPathAvailability,
   EmergencyAreaIDListForRestart,
   EmergencyFallbackIndicator,
   EN-DCSONConfigurationTransfer,
   EUTRA-CGI,
   FiveG-S-TMSI,
   GlobalRANNodeID,
   GUAMI,
   HandoverFlag,
   HandoverType,
   IMSVoiceSupportIndicator,
   IndexToRFSP,
   InfoOnRecommendedCellsAndRANNodesForPaging,
```

```
LocationReportingRequestType,
MaskedIMEISV.
MessageIdentifier.
MobilityRestrictionList,
NAS-PDU.
NASSecurityParametersFromNGRAN,
NewSecurityContextInd,
NGRAN-CGI,
NGRAN-TNLAssociationToRemoveList,
NGRANTraceID,
NR-CGI,
NRPPa-PDU,
NumberOfBroadcastsRequested,
OverloadResponse,
OverloadStartNSSAIList,
PagingDRX,
PagingOrigin,
PagingPriority,
PDUSessionAggregateMaximumBitRate,
PDUSessionResourceAdmittedList,
PDUSessionResourceFailedToModifyListModCfm,
PDUSessionResourceFailedToModifyListModRes,
PDUSessionResourceFailedToSetupListCxtFail,
PDUSessionResourceFailedToSetupListCxtRes.
PDUSessionResourceFailedToSetupListHOAck,
PDUSessionResourceFailedToSetupListPSReg,
PDUSessionResourceFailedToSetupListSURes,
PDUSessionResourceHandoverList,
PDUSessionResourceListCxtRelCpl,
PDUSessionResourceListCxtRelReg,
PDUSessionResourceListHORad,
PDUSessionResourceModifyListModCfm,
PDUSessionResourceModifyListModInd,
PDUSessionResourceModifyListModReq,
PDUSessionResourceModifyListModRes,
PDUSessionResourceNotifyList,
PDUSessionResourceReleasedListNot,
PDUSessionResourceReleasedListPSAck,
PDUSessionResourceReleasedListPSFail,
PDUSessionResourceReleasedListRelRes,
PDUSessionResourceSecondaryRATUsageList,
PDUSessionResourceSetupListCxtReg,
PDUSessionResourceSetupListCxtRes,
PDUSessionResourceSetupListHOReq,
PDUSessionResourceSetupListSUReq.
PDUSessionResourceSetupListSURes,
PDUSessionResourceSwitchedList,
PDUSessionResourceToBeSwitchedDLList,
PDUSessionResourceToReleaseListHOCmd,
PDUSessionResourceToReleaseListRelCmd,
PLMNIdentity,
PLMNSupportList,
PWSFailedCellIDList,
RANNodeName,
```

```
RANPagingPriority,
    RANStatusTransfer-TransparentContainer,
    RAN-UE-NGAP-ID.
    RedirectionVoiceFallback,
    RelativeAMFCapacity,
    RepetitionPeriod,
    ResetType,
    RoutingID,
    RRCEstablishmentCause,
    RRCInactiveTransitionReportRequest,
    RRCState,
    SecurityContext,
    SecurityKey,
    Serial Number.
    ServedGUAMIList,
    SliceSupportList,
    S-NSSAI,
    SONConfigurationTransfer,
    SourceToTarget-TransparentContainer,
    SourceToTarget-AMFInformationReroute,
    SupportedTAList,
    TAIListForPaging,
    TAIListForRestart,
    TargetID,
    TargetToSource-TransparentContainer,
    TimeToWait,
    TNLAssociationList,
   TraceActivation,
   TrafficLoadReductionIndication,
    TransportLayerAddress,
    UEAggregateMaximumBitRate,
    UE-associatedLogicalNG-connectionList,
   UEContextRequest,
    UE-NGAP-IDs,
    UEPagingIdentity,
    UEPresenceInAreaOfInterestList,
    UERadioCapability,
    UERadioCapabilityForPaging,
    UERetentionInformation,
    UESecurityCapabilities,
    UnavailableGUAMIList,
    UserLocationInformation,
    WarningAreaCoordinates,
    WarningAreaList,
    WarningMessageContents,
    WarningSecurityInfo,
    WarningType
FROM NGAP-IEs
    PrivateIE-Container{},
    ProtocolExtensionContainer{},
    ProtocolIE-Container{},
    ProtocolIE-ContainerList{},
```

```
ProtocolIE-ContainerPair{},
    ProtocolIE-SingleContainer{},
   NGAP-PRIVATE-IES.
   NGAP-PROTOCOL-EXTENSION,
   NGAP-PROTOCOL-IES.
    NGAP-PROTOCOL-IES-PAIR
FROM NGAP-Containers
    id-AllowedNSSAT.
    id-AMFName,
    id-AMFOverloadResponse,
    id-AMFSetID,
    id-AMF-TNLAssociationFailedToSetupList,
    id-AMF-TNLAssociationSetupList,
    id-AMF-TNLAssociationToAddList,
    id-AMF-TNLAssociationToRemoveList,
    id-AMF-TNLAssociationToUpdateList,
    id-AMFTrafficLoadReductionIndication,
    id-AMF-UE-NGAP-ID,
    id-AssistanceDataForPaging,
    id-BroadcastCancelledAreaList,
    id-BroadcastCompletedAreaList,
    id-CancelAllWarningMessages,
    id-Cause,
    id-CellIDListForRestart,
    id-CNAssistedRANTuning,
    id-ConcurrentWarningMessageInd,
    id-CoreNetworkAssistanceInformationForInactive,
    id-CriticalityDiagnostics,
    id-DataCodingScheme,
    id-DefaultPagingDRX,
    id-DirectForwardingPathAvailability,
    id-EmergencyAreaIDListForRestart,
    id-EmergencyFallbackIndicator,
    id-ENDC-SONConfigurationTransferDL,
    id-ENDC-SONConfigurationTransferUL,
    id-EUTRA-CGI,
    id-FiveG-S-TMSI,
    id-GlobalRANNodeID,
    id-GUAMI,
    id-HandoverFlag,
    id-HandoverType,
    id-IMSVoiceSupportIndicator,
    id-IndexToRFSP,
    id-InfoOnRecommendedCellsAndRANNodesForPaging,
    id-LocationReportingRequestType,
    id-MaskedIMEISV.
    id-MessageIdentifier,
    id-MobilityRestrictionList,
    id-NAS-PDU,
    id-NASC,
    id-NASSecurityParametersFromNGRAN,
    id-NewAMF-UE-NGAP-ID,
    id-NewGUAMI,
```

```
id-NewSecurityContextInd,
id-NGAP-Message,
id-NGRAN-CGI.
id-NGRAN-TNLAssociationToRemoveList,
id-NGRANTraceID.
id-NR-CGI,
id-NRPPa-PDU,
id-NumberOfBroadcastsRequested,
id-OldAMF,
id-OverloadStartNSSAIList,
id-PagingDRX,
id-PagingOrigin,
id-PagingPriority,
id-PDUSessionResourceAdmittedList,
id-PDUSessionResourceFailedToModifyListModCfm,
id-PDUSessionResourceFailedToModifyListModRes,
id-PDUSessionResourceFailedToSetupListCxtFail,
id-PDUSessionResourceFailedToSetupListCxtRes,
id-PDUSessionResourceFailedToSetupListHOAck,
id-PDUSessionResourceFailedToSetupListPSReq,
id-PDUSessionResourceFailedToSetupListSURes,
id-PDUSessionResourceHandoverList,
id-PDUSessionResourceListCxtRelCpl,
id-PDUSessionResourceListCxtRelReg.
id-PDUSessionResourceListHORqd,
id-PDUSessionResourceModifyListModCfm,
id-PDUSessionResourceModifyListModInd,
id-PDUSessionResourceModifyListModReg,
id-PDUSessionResourceModifyListModRes,
id-PDUSessionResourceNotifyList,
id-PDUSessionResourceReleasedListNot,
id-PDUSessionResourceReleasedListPSAck.
id-PDUSessionResourceReleasedListPSFail,
id-PDUSessionResourceReleasedListRelRes,
id-PDUSessionResourceSecondaryRATUsageList.
id-PDUSessionResourceSetupListCxtReq,
id-PDUSessionResourceSetupListCxtRes,
id-PDUSessionResourceSetupListHOReq,
id-PDUSessionResourceSetupListSUReg,
id-PDUSessionResourceSetupListSURes,
id-PDUSessionResourceSwitchedList,
id-PDUSessionResourceToBeSwitchedDLList,
id-PDUSessionResourceToReleaseListHOCmd,
id-PDUSessionResourceToReleaseListRelCmd,
id-PLMNSupportList,
id-PWSFailedCellIDList,
id-RANNodeName,
id-RANPagingPriority,
id-RANStatusTransfer-TransparentContainer,
id-RAN-UE-NGAP-ID,
id-RedirectionVoiceFallback,
id-RelativeAMFCapacity,
id-RepetitionPeriod,
id-ResetType,
```

```
id-RoutingID,
   id-RRCEstablishmentCause,
   id-RRCInactiveTransitionReportRequest,
   id-RRCState,
   id-SecurityContext,
   id-SecurityKey,
   id-SelectedPLMNIdentity,
   id-SerialNumber,
   id-ServedGUAMIList,
   id-SliceSupportList,
   id-SONConfigurationTransferDL,
   id-SONConfigurationTransferUL,
   id-SourceAMF-UE-NGAP-ID,
   id-SourceToTarget-TransparentContainer,
   id-SourceToTarget-AMFInformationReroute,
   id-SupportedTAList,
   id-TAIListForPaging,
   id-TAIListForRestart,
   id-TargetID,
   id-TargetToSource-TransparentContainer,
   id-TimeToWait,
   id-TraceActivation,
   id-TraceCollectionEntityIPAddress,
   id-UEAggregateMaximumBitRate,
   id-UE-associatedLogicalNG-connectionList,
   id-UEContextRequest,
   id-UE-NGAP-IDs,
   id-UEPagingIdentity,
   id-UEPresenceInAreaOfInterestList,
   id-UERadioCapability,
   id-UERadioCapabilityForPaging,
   id-UERetentionInformation,
   id-UESecurityCapabilities,
   id-UnavailableGUAMIList,
   id-UserLocationInformation,
   id-WarningAreaCoordinates,
   id-WarningAreaList,
   id-WarningMessageContents,
   id-WarningSecurityInfo,
   id-WarningType
FROM NGAP-Constants;
     *****************
-- PDU SESSION MANAGEMENT ELEMENTARY PROCEDURES
    -- PDU Session Resource Setup Elementary Procedure
__ *********************
```

```
-- PDU SESSION RESOURCE SETUP REQUEST
__ **********************
PDUSessionResourceSetupRequest ::= SEOUENCE {
   protocolIEs
                  ProtocolIE-Container
                                            { {PDUSessionResourceSetupRequestIEs} },
   . . .
PDUSessionResourceSetupRequestIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                                        PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                                                                        PRESENCE mandatory
                                                CRITICALITY reject TYPE RAN-UE-NGAP-ID
     ID id-RANPagingPriority
                                                CRITICALITY ignore TYPE RANPagingPriority
                                                                                                        PRESENCE optional
     ID id-NAS-PDU
                                                CRITICALITY reject TYPE NAS-PDU
                                                                                                        PRESENCE optional
     ID id-PDUSessionResourceSetupListSUReg
                                                CRITICALITY reject TYPE PDUSessionResourceSetupListSUReq
                                                                                                        PRESENCE mandatory
    { ID id-UEAggregateMaximumBitRate
                                                CRITICALITY ignore TYPE UEAggregateMaximumBitRate
                                                                                                        PRESENCE optional
-- PDU SESSION RESOURCE SETUP RESPONSE
__ ********************************
PDUSessionResourceSetupResponse ::= SEQUENCE {
                  ProtocolIE-Container
                                            { {PDUSessionResourceSetupResponseIEs} },
   protocolIEs
   . . .
PDUSessionResourceSetupResponseIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                    CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                                                   PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                   CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                                                   PRESENCE mandatory
     ID id-PDUSessionResourceSetupListSURes
                                                                                                                   PRESENCE optional
                                                    CRITICALITY ignore TYPE PDUSessionResourceSetupListSURes
     ID id-PDUSessionResourceFailedToSetupListSURes
                                                   CRITICALITY ignore TYPE PDUSessionResourceFailedToSetupListSURes
                                                                                                                   PRESENCE optional
    ID id-CriticalityDiagnostics
                                                    CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                                                   PRESENCE optional
      -- PDU Session Resource Release Elementary Procedure
-- PDU SESSION RESOURCE RELEASE COMMAND
```

```
PDUSessionResourceReleaseCommand ::= SEQUENCE {
   protocolIEs
                 ProtocolIE-Container
                                           { { PDUSessionResourceReleaseCommandIEs } },
PDUSessionResourceReleaseCommandIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                  CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                                             PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                                                                             PRESENCE mandatory
                                                  CRITICALITY reject TYPE RAN-UE-NGAP-ID
     ID id-RANPagingPriority
                                                  CRITICALITY ignore TYPE RANPagingPriority
                                                                                                             PRESENCE optional
    { ID id-NAS-PDU
                                                  CRITICALITY ignore TYPE NAS-PDU
                                                                                                             PRESENCE optional
   { ID id-PDUSessionResourceToReleaseListRelCmd
                                                  CRITICALITY reject TYPE PDUSessionResourceToReleaseListRelCmd
                                                                                                            PRESENCE mandatory
-- PDU SESSION RESOURCE RELEASE RESPONSE
__ ********************
PDUSessionResourceReleaseResponse ::= SEOUENCE {
   protocolIEs
                 ProtocolIE-Container
                                           { {PDUSessionResourceReleaseResponseIEs} },
   . . .
PDUSessionResourceReleaseResponseIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                  CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                                             PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                  CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                                             PRESENCE mandatory
     ID id-PDUSessionResourceReleasedListRelRes
                                                     CRITICALITY ignore TYPE PDUSessionResourceReleasedListRelRes PRESENCE mandatory
     ID id-UserLocationInformation
                                                  CRITICALITY ignore TYPE UserLocationInformation
                                                                                                             PRESENCE optional
                                                  CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                                             PRESENCE optional
   { ID id-CriticalityDiagnostics
    -- PDU Session Resource Modify Elementary Procedure
    ******************
-- PDU SESSION RESOURCE MODIFY REQUEST
__ *******************
PDUSessionResourceModifyRequest ::= SEQUENCE {
                 ProtocolIE-Container
                                           { {PDUSessionResourceModifyRequestIEs} },
   protocolIEs
   . . .
```

```
PDUSessionResourceModifyRequestIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                               CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                                     PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                               CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                                     PRESENCE mandatory
     ID id-RANPagingPriority
                                               CRITICALITY ignore TYPE RANPagingPriority
                                                                                                     PRESENCE optional
    ID id-PDUSessionResourceModifyListModReg
                                               CRITICALITY reject TYPE PDUSessionResourceModifyListModReg PRESENCE mandatory
-- PDU SESSION RESOURCE MODIFY RESPONSE
__ *********************
PDUSessionResourceModifyResponse ::= SEQUENCE {
   protocolIEs
                  ProtocolIE-Container
                                           { {PDUSessionResourceModifyResponseIEs} },
   . . .
PDUSessionResourceModifyResponseIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                      CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                                                   PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                      CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                                                   PRESENCE mandatory
     ID id-PDUSessionResourceModifyListModRes
                                                      CRITICALITY ignore TYPE PDUSessionResourceModifyListModRes
                                                                                                                   PRESENCE optional
     ID id-PDUSessionResourceFailedToModifyListModRes
                                                      CRITICALITY ignore TYPE PDUSessionResourceFailedToModifyListModRes
                                                                                                                     PRESENCE optional
     ID id-UserLocationInformation
                                                      CRITICALITY ignore TYPE UserLocationInformation
                                                                                                                   PRESENCE optional
     ID id-CriticalityDiagnostics
                                                      CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                                                   PRESENCE optional
       -- PDU Session Resource Notify Elementary Procedure
-- PDU SESSION RESOURCE NOTIFY
  PDUSessionResourceNotify ::= SEQUENCE {
                                           { {PDUSessionResourceNotifyIEs} },
   protocolIEs
                  ProtocolIE-Container
PDUSessionResourceNotifyIEs NGAP-PROTOCOL-IES ::= {
```

205

```
ID id-AMF-UE-NGAP-ID
                                        CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                         PRESENCE mandatory
    ID id-RAN-UE-NGAP-ID
                                        CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                         PRESENCE mandatory
    ID id-PDUSessionResourceNotifyList
                                        CRITICALITY reject TYPE PDUSessionResourceNotifyList
                                                                                         PRESENCE optional
    ID id-PDUSessionResourceReleasedListNot
                                        CRITICALITY ignore TYPE PDUSessionResourceReleasedListNot
                                                                                         PRESENCE optional
   { ID id-UserLocationInformation
                                        CRITICALITY ignore TYPE UserLocationInformation
                                                                                         PRESENCE optional
  ****************
-- PDU Session Resource Modify Indication Elementary Procedure
  **********
-- PDU SESSION RESOURCE MODIFY INDICATION
*****************
PDUSessionResourceModifyIndication ::= SEQUENCE
                                     protocolIEs
               ProtocolIE-Container
   . . .
PDUSessionResourceModifyIndicationIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                                        CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                         PRESENCE mandatory
    ID id-RAN-UE-NGAP-ID
                                        CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                         PRESENCE mandatory
   { ID id-PDUSessionResourceModifyListModInd
                                        CRITICALITY reject TYPE PDUSessionResourceModifyListModInd
                                                                                         PRESENCE mandatory
  -- PDU SESSION RESOURCE MODIFY CONFIRM
********************
PDUSessionResourceModifyConfirm ::= SEQUENCE {
                                     { {PDUSessionResourceModifyConfirmIEs} },
   protocolIEs
               ProtocolIE-Container
   . . .
PDUSessionResourceModifyConfirmIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                                           CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                           PRESENCE mandatory
    ID id-RAN-UE-NGAP-ID
                                           CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                           PRESENCE mandatory
    ID id-PDUSessionResourceModifyListModCfm
                                           CRITICALITY ignore TYPE PDUSessionResourceModifyListModCfm
                                                                                           PRESENCE optional } |
    PRESENCE optional } |
   { ID id-CriticalityDiagnostics
                                           CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                           PRESENCE optional
__ **********************
```

```
-- UE CONTEXT MANAGEMENT ELEMENTARY PROCEDURES
-- Initial Context Setup Elementary Procedure
    ************
-- INITIAL CONTEXT SETUP REQUEST
      InitialContextSetupRequest ::= SEOUENCE {
                                             { {InitialContextSetupRequestIEs} },
   protocolIEs
                  ProtocolIE-Container
InitialContextSetupRequestIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                                               PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                                               PRESENCE mandatory
     ID id-OldAMF
                                                CRITICALITY reject TYPE AMFName
                                                                                                               PRESENCE optional
                                                CRITICALITY reject TYPE UEAggregateMaximumBitRate
     ID id-UEAggregateMaximumBitRate
                                                                                                               PRESENCE conditional }
     ID id-CoreNetworkAssistanceInformationForInactive
                                                        CRITICALITY ignore TYPE CoreNetworkAssistanceInformationForInactive
optional
     ID id-GUAMI
                                                CRITICALITY reject TYPE GUAMI
                                                                                                               PRESENCE mandatory
     ID id-PDUSessionResourceSetupListCxtReg
                                                CRITICALITY reject TYPE PDUSessionResourceSetupListCxtReq
                                                                                                               PRESENCE optional
     ID id-AllowedNSSAI
                                                CRITICALITY reject TYPE AllowedNSSAI
                                                                                                               PRESENCE mandatory
     ID id-UESecurityCapabilities
                                                CRITICALITY reject TYPE UESecurityCapabilities
                                                                                                               PRESENCE mandatory
                                                                                                               PRESENCE mandatory
     ID id-SecurityKey
                                                CRITICALITY reject TYPE SecurityKey
     ID id-TraceActivation
                                                CRITICALITY ignore TYPE TraceActivation
                                                                                                               PRESENCE optional
     ID id-MobilityRestrictionList
                                                CRITICALITY ignore TYPE MobilityRestrictionList
                                                                                                               PRESENCE optional
     ID id-UERadioCapability
                                                CRITICALITY ignore TYPE UERadioCapability
                                                                                                               PRESENCE optional
     ID id-IndexToRFSP
                                                CRITICALITY ignore TYPE IndexToRFSP
                                                                                                               PRESENCE optional
     ID id-MaskedIMEISV
                                                CRITICALITY ignore TYPE MaskedIMEISV
                                                                                                               PRESENCE optional
     ID id-NAS-PDU
                                                CRITICALITY ignore TYPE NAS-PDU
                                                                                                               PRESENCE optional
     ID id-EmergencyFallbackIndicator
                                                CRITICALITY reject TYPE EmergencyFallbackIndicator
                                                                                                               PRESENCE optional
     ID id-RRCInactiveTransitionReportRequest
                                                CRITICALITY ignore TYPE RRCInactiveTransitionReportRequest
                                                                                                               PRESENCE optional
     ID id-UERadioCapabilityForPaging
                                                CRITICALITY ignore TYPE UERadioCapabilityForPaging
                                                                                                               PRESENCE optional
     ID id-RedirectionVoiceFallback
                                                CRITICALITY ignore TYPE RedirectionVoiceFallback
                                                                                                               PRESENCE optional
     ID id-LocationReportingRequestType
                                                CRITICALITY ignore TYPE LocationReportingRequestType
                                                                                                               PRESENCE optional
     ID id-CNAssistedRANTuning
                                                CRITICALITY ignore TYPE CNAssistedRANTuning
                                                                                                               PRESENCE optional
-- INITIAL CONTEXT SETUP RESPONSE
  *****************
```

```
InitialContextSetupResponse ::= SEQUENCE {
   protocolIEs
                  ProtocolIE-Container
                                            InitialContextSetupResponseIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                   CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                                                     PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                   CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                                                     PRESENCE mandatory
     ID id-PDUSessionResourceSetupListCxtRes
                                                   CRITICALITY ignore TYPE PDUSessionResourceSetupListCxtRes
                                                                                                                     PRESENCE optional
     ID id-PDUSessionResourceFailedToSetupListCxtRes
                                                   CRITICALITY ignore TYPE PDUSessionResourceFailedToSetupListCxtRes
                                                                                                                     PRESENCE optional
     ID id-CriticalityDiagnostics
                                                   CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                                                     PRESENCE optional
  *****************
  INITIAL CONTEXT SETUP FAILURE
InitialContextSetupFailure ::= SEQUENCE {
                                            { {InitialContextSetupFailureIEs} },
   protocolIEs
                  ProtocolIE-Container
InitialContextSetupFailureIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                   CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                                                     PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                   CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                                                     PRESENCE mandatory
     ID id-PDUSessionResourceFailedToSetupListCxtFail
                                                   CRITICALITY ignore TYPE PDUSessionResourceFailedToSetupListCxtFail
                                                                                                                     PRESENCE optional
     ID id-Cause
                                                   CRITICALITY ignore TYPE Cause
                                                                                                                     PRESENCE mandatory
     ID id-CriticalityDiagnostics
                                                   CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                                                     PRESENCE optional
     ****************
-- UE Context Release Request Elementary Procedure
```

```
-- UE CONTEXT RELEASE REQUEST
__ *********************
UEContextReleaseRequest ::= SEQUENCE {
                                        { {UEContextReleaseRequest-IEs} },
   protocolIEs
               ProtocolIE-Container
   . . .
UEContextReleaseRequest-IES NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                                                                                            PRESENCE mandatory
                                        CRITICALITY reject TYPE AMF-UE-NGAP-ID
    ID id-RAN-UE-NGAP-ID
                                        CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                             PRESENCE mandatory
    ID id-PDUSessionResourceListCxtRelReg
                                        CRITICALITY reject TYPE PDUSessionResourceListCxtRelReq
                                                                                             PRESENCE optional
   { ID id-Cause
                                        CRITICALITY ignore TYPE Cause
                                                                                             PRESENCE mandatory
    ******************
-- UE Context Release Elementary Procedure
__ *********************
-- UE CONTEXT RELEASE COMMAND
  ******************
UEContextReleaseCommand ::= SEQUENCE {
   protocolIEs
                ProtocolIE-Container
                                        { {UEContextReleaseCommand-IEs} },
UEContextReleaseCommand-IEs NGAP-PROTOCOL-IES ::= {
   { ID id-UE-NGAP-IDs
                     CRITICALITY reject TYPE UE-NGAP-IDs
                                                                       PRESENCE mandatory } |
   { ID id-Cause
                              CRITICALITY ignore TYPE Cause
                                                                       PRESENCE mandatory },
__ ********************************
-- UE CONTEXT RELEASE COMPLETE
__ *********************
UEContextReleaseComplete ::= SEOUENCE {
   protocolIEs
              ProtocolIE-Container
                                        { {UEContextReleaseComplete-IEs} },
UEContextReleaseComplete-IEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                                               CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                                         PRESENCE mandatory
   { ID id-RAN-UE-NGAP-ID
                                               CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                                         PRESENCE mandatory
```

```
ID id-UserLocationInformation
                                                CRITICALITY ignore TYPE UserLocationInformation
                                                                                                          PRESENCE optional
     ID id-PDUSessionResourceListCxtRelCpl
                                                CRITICALITY reject TYPE PDUSessionResourceListCxtRelCpl
                                                                                                          PRESENCE optional
    ID id-CriticalityDiagnostics
                                                CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                                          PRESENCE optional
    *****************
-- UE Context Modification Elementary Procedure
  -- UE CONTEXT MODIFICATION REQUEST
  ********************
UEContextModificationRequest ::= SEQUENCE {
   protocolIEs
                 ProtocolIE-Container
                                         { {UEContextModificationRequestIEs} },
   . . .
UEContextModificationRequestIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                                                                  PRESENCE mandatory
                                            CRITICALITY reject TYPE AMF-UE-NGAP-ID
     ID id-RAN-UE-NGAP-ID
                                                                                                  PRESENCE mandatory
                                            CRITICALITY reject TYPE RAN-UE-NGAP-ID
     ID id-RANPagingPriority
                                            CRITICALITY ignore TYPE RANPagingPriority
                                                                                                  PRESENCE optional
     ID id-SecurityKey
                                            CRITICALITY reject TYPE SecurityKey
                                                                                                  PRESENCE optional
     ID id-IndexToRFSP
                                            CRITICALITY ignore TYPE IndexToRFSP
                                                                                                   PRESENCE optional
     ID id-UEAggregateMaximumBitRate
                                            CRITICALITY ignore TYPE UEAggregateMaximumBitRate
                                                                                                  PRESENCE optional
     ID id-UESecurityCapabilities
                                            CRITICALITY reject TYPE UESecurityCapabilities
                                                                                                  PRESENCE optional
    ID id-CoreNetworkAssistanceInformationForInactive
                                                   CRITICALITY ignore TYPE CoreNetworkAssistanceInformationForInactive
                                                                                                                    PRESENCE
optional
     ID id-EmergencyFallbackIndicator
                                            CRITICALITY reject TYPE EmergencyFallbackIndicator
                                                                                                   PRESENCE optional
     ID id-NewAMF-UE-NGAP-ID
                                            CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                                   PRESENCE optional
     ID id-RRCInactiveTransitionReportRequest
                                            CRITICALITY ignore TYPE RRCInactiveTransitionReportRequest
                                                                                                   PRESENCE optional
     ID id-NewGUAMI
                                            CRITICALITY reject TYPE GUAMI
                                                                                                   PRESENCE optional
    ID id-CNAssistedRANTuning
                                            CRITICALITY ignore TYPE CNAssistedRANTuning
                                                                                                  PRESENCE optional
-- UE CONTEXT MODIFICATION RESPONSE
  ····
UEContextModificationResponse ::= SEQUENCE {
                                         { {UEContextModificationResponseIEs} },
   protocolIEs
                 ProtocolIE-Container
UEContextModificationResponseIEs NGAP-PROTOCOL-IES ::= {
```

```
ID id-AMF-UE-NGAP-ID
                                     CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                       PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                     CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                      PRESENCE mandatory
     ID id-RRCState
                                     CRITICALITY ignore TYPE RRCState
                                                                                       PRESENCE optional
     ID id-UserLocationInformation
                                     CRITICALITY ignore TYPE UserLocationInformation
                                                                                      PRESENCE optional
    { ID id-CriticalityDiagnostics
                                     CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                       PRESENCE optional
-- UE CONTEXT MODIFICATION FAILURE
__ ********************
UEContextModificationFailure ::= SEQUENCE {
   protocolIEs
                  ProtocolIE-Container
                                             { {UEContextModificationFailureIEs} },
   . . .
UEContextModificationFailureIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                     CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                      PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                     CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                      PRESENCE mandatory
     ID id-Cause
                                     CRITICALITY ignore TYPE Cause
                                                                                       PRESENCE mandatory
                                     CRITICALITY ignore TYPE CriticalityDiagnostics
    { ID id-CriticalityDiagnostics
                                                                                       PRESENCE optional
-- RRC INACTIVE TRANSITION REPORT
__ *********************
RRCInactiveTransitionReport ::= SEQUENCE {
   protocolIEs
                                             { {RRCInactiveTransitionReportIEs} },
                  ProtocolIE-Container
   . . .
RRCInactiveTransitionReportIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                     CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                          PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                                                          PRESENCE mandatory
                                     CRITICALITY reject TYPE RAN-UE-NGAP-ID
     ID id-RRCState
                                     CRITICALITY ignore TYPE RRCState
                                                                                          PRESENCE mandatory
    { ID id-UserLocationInformation
                                     CRITICALITY ignore TYPE UserLocationInformation
                                                                                          PRESENCE mandatory },
-- UE MOBILITY MANAGEMENT ELEMENTARY PROCEDURES
```

```
-- Handover Preparation Elementary Procedure
-- HANDOVER REQUIRED
HandoverRequired ::= SEQUENCE {
                                               { {HandoverRequiredIEs} },
   protocolIEs
                   ProtocolIE-Container
HandoverRequiredIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                   CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                                                 PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                   CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                                                 PRESENCE mandatory
     ID id-HandoverType
                                                   CRITICALITY reject TYPE HandoverType
                                                                                                                 PRESENCE mandatory
     ID id-Cause
                                                   CRITICALITY ignore TYPE Cause
                                                                                                                 PRESENCE mandatory
     ID id-TargetID
                                                   CRITICALITY reject TYPE TargetID
                                                                                                                 PRESENCE mandatory
     ID id-DirectForwardingPathAvailability
                                                   CRITICALITY ignore TYPE DirectForwardingPathAvailability
                                                                                                                 PRESENCE optional
     ID id-PDUSessionResourceListHORqd
                                                   CRITICALITY reject TYPE PDUSessionResourceListHORqd
                                                                                                                 PRESENCE mandatory
                                                                                                                 PRESENCE mandatory
     ID id-SourceToTarget-TransparentContainer
                                                   CRITICALITY reject TYPE SourceToTarget-TransparentContainer
-- HANDOVER COMMAND
__ *********************
HandoverCommand ::= SEQUENCE {
   protocolIEs
                   ProtocolIE-Container
                                               { {HandoverCommandIEs} },
HandoverCommandIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                       CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                                                          PRESENCE mandatory
                                                                                                                          PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                       CRITICALITY reject TYPE RAN-UE-NGAP-ID
     ID id-HandoverType
                                                       CRITICALITY reject TYPE HandoverType
                                                                                                                          PRESENCE mandatory
                                                                                                                          PRESENCE conditional }
    { ID id-NASSecurityParametersFromNGRAN
                                                       CRITICALITY reject TYPE NASSecurityParametersFromNGRAN
    -- This IE shall be present if HandoverType IE is set to value "5GStoEPPS" --
     ID id-PDUSessionResourceHandoverList
                                                                                                                          PRESENCE optional } |
                                                       CRITICALITY ignore TYPE PDUSessionResourceHandoverList
     ID id-PDUSessionResourceToReleaseListHOCmd
                                                       CRITICALITY ignore TYPE PDUSessionResourceToReleaseListHOCmd
                                                                                                                          PRESENCE optional
     ID id-TargetToSource-TransparentContainer
                                                       CRITICALITY reject TYPE TargetToSource-TransparentContainer
                                                                                                                          PRESENCE mandatory
     ID id-CriticalityDiagnostics
                                                       CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                                                          PRESENCE optional
```

```
-- HANDOVER PREPARATION FAILURE
HandoverPreparationFailure ::= SEOUENCE {
                                                { {HandoverPreparationFailureIEs} },
    protocolIEs
                   ProtocolIE-Container
    . . .
HandoverPreparationFailureIEs NGAP-PROTOCOL-IES ::= +
     ID id-AMF-UE-NGAP-ID
                                       CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                            PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                       CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                            PRESENCE mandatory
     ID id-Cause
                                       CRITICALITY ignore TYPE Cause
                                                                                            PRESENCE mandatory
    { ID id-CriticalityDiagnostics
                                       CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                            PRESENCE optional
-- Handover Resource Allocation Elementary Procedure
-- HANDOVER REQUEST
HandoverRequest ::= SEQUENCE {
    protocolIEs
                    ProtocolIE-Container
                                                { {HandoverRequestIEs} },
HandoverRequestIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                    CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                                                   PRESENCE mandatory
     ID id-HandoverType
                                                    CRITICALITY reject TYPE HandoverType
                                                                                                                   PRESENCE mandatory
     ID id-Cause
                                                    CRITICALITY ignore TYPE Cause
                                                                                                                   PRESENCE mandatory
     ID id-UEAggregateMaximumBitRate
                                                    CRITICALITY reject TYPE UEAggregateMaximumBitRate
                                                                                                                   PRESENCE mandatory
     ID id-CoreNetworkAssistanceInformationForInactive
                                                            CRITICALITY ignore TYPE CoreNetworkAssistanceInformationForInactive
                                                                                                                                        PRESENCE
optional
     ID id-UESecurityCapabilities
                                                    CRITICALITY reject TYPE UESecurityCapabilities
                                                                                                                   PRESENCE mandatory
     ID id-SecurityContext
                                                    CRITICALITY reject TYPE SecurityContext
                                                                                                                   PRESENCE mandatory
                                                                                                                   PRESENCE optional
     ID id-NewSecurityContextInd
                                                    CRITICALITY reject TYPE NewSecurityContextInd
                                                                                                                   PRESENCE optional
     ID id-NASC
                                                    CRITICALITY reject TYPE NAS-PDU
     ID id-PDUSessionResourceSetupListHOReq
                                                    CRITICALITY reject TYPE PDUSessionResourceSetupListHOReq
                                                                                                                   PRESENCE mandatory
     ID id-AllowedNSSAI
                                                    CRITICALITY reject TYPE AllowedNSSAI
                                                                                                                   PRESENCE mandatory
     ID id-TraceActivation
                                                    CRITICALITY ignore TYPE TraceActivation
                                                                                                                   PRESENCE optional
                                                                                                                   PRESENCE optional
     ID id-MaskedIMEISV
                                                    CRITICALITY ignore TYPE MaskedIMEISV
     ID id-SourceToTarget-TransparentContainer
                                                    CRITICALITY reject TYPE SourceToTarget-TransparentContainer
                                                                                                                   PRESENCE mandatory
     ID id-MobilityRestrictionList
                                                    CRITICALITY ignore TYPE MobilityRestrictionList
                                                                                                                   PRESENCE optional
     ID id-LocationReportingRequestType
                                                    CRITICALITY ignore TYPE LocationReportingRequestType
                                                                                                                   PRESENCE optional
     ID id-RRCInactiveTransitionReportRequest
                                                    CRITICALITY ignore TYPE RRCInactiveTransitionReportRequest
                                                                                                                   PRESENCE optional
     ID id-GUAMI
                                                    CRITICALITY reject TYPE GUAMI
                                                                                                                   PRESENCE mandatory
```

-- HANDOVER NOTIFY

```
ID id-RedirectionVoiceFallback
                                                CRITICALITY ignore TYPE RedirectionVoiceFallback
                                                                                                          PRESENCE optional
     ID id-CNAssistedRANTuning
                                                CRITICALITY ignore TYPE CNAssistedRANTuning
                                                                                                          PRESENCE optional
-- HANDOVER REQUEST ACKNOWLEDGE
  *****************
HandoverRequestAcknowledge ::= SEQUENCE {
                                            { {HandoverRequestAcknowledgeIEs} },
   protocolIEs
                  ProtocolIE-Container
HandoverRequestAcknowledgeIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                                                                                  PRESENCE mandatory
                                                   CRITICALITY ignore TYPE AMF-UE-NGAP-ID
     ID id-RAN-UE-NGAP-ID
                                                   CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                                                  PRESENCE mandatory
     ID id-PDUSessionResourceAdmittedList
                                                   CRITICALITY ignore TYPE PDUSessionResourceAdmittedList
                                                                                                                  PRESENCE mandatory
     ID id-PDUSessionResourceFailedToSetupListHOAck
                                                   CRITICALITY ignore TYPE PDUSessionResourceFailedToSetupListHOAck
                                                                                                                  PRESENCE optional
     ID id-TargetToSource-TransparentContainer
                                                   CRITICALITY reject TYPE TargetToSource-TransparentContainer
                                                                                                                  PRESENCE mandatory
    ID id-CriticalityDiagnostics
                                                                                                                  PRESENCE optional
                                                   CRITICALITY ignore TYPE CriticalityDiagnostics
-- HANDOVER FAILURE
__ *********************
HandoverFailure ::= SEQUENCE {
   protocolIEs
                  ProtocolIE-Container
                                            { { HandoverFailureIEs} },
   . . .
HandoverFailureIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                    CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                     PRESENCE mandatory
     ID id-Cause
                                    CRITICALITY ignore TYPE Cause
                                                                                     PRESENCE mandatory
    { ID id-CriticalityDiagnostics
                                    CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                    PRESENCE optional
   ******************
-- Handover Notification Elementary Procedure
```

```
HandoverNotify ::= SEQUENCE {
   protocolIEs
                 ProtocolIE-Container
                                          { { HandoverNotifyIEs} },
HandoverNotifyIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                   CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                  PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                   CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                  PRESENCE mandatory
   { ID id-UserLocationInformation
                                   CRITICALITY ignore TYPE UserLocationInformation
                                                                                 PRESENCE mandatory
       *******************
-- Path Switch Request Elementary Procedure
  *****************
-- PATH SWITCH REOUEST
  ****************
PathSwitchRequest ::= SEOUENCE {
                                          { { PathSwitchRequestIEs} },
   protocolIEs
                 ProtocolIE-Container
PathSwitchRequestIEs NGAP-PROTOCOL-IES ::= {
     ID id-RAN-UE-NGAP-ID
                                                  CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                                               PRESENCE mandatory
     ID id-SourceAMF-UE-NGAP-ID
                                                  CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                                               PRESENCE mandatory
                                                                                                               PRESENCE mandatory
     ID id-UserLocationInformation
                                                  CRITICALITY ignore TYPE UserLocationInformation
     ID id-UESecurityCapabilities
                                                  CRITICALITY ignore TYPE UESecurityCapabilities
                                                                                                               PRESENCE mandatory
     ID id-PDUSessionResourceToBeSwitchedDLList
                                                  CRITICALITY reject TYPE PDUSessionResourceToBeSwitchedDLList
                                                                                                               PRESENCE mandatory
   { ID id-PDUSessionResourceFailedToSetupListPSReq
                                                 CRITICALITY ignore TYPE PDUSessionResourceFailedToSetupListPSReg
                                                                                                               PRESENCE optional
-- PATH SWITCH REQUEST ACKNOWLEDGE
__ *******************
PathSwitchRequestAcknowledge ::= SEQUENCE {
                 ProtocolIE-Container
                                          { { PathSwitchRequestAcknowledgeIEs} },
   protocolIEs
   . . .
```

```
PathSwitchRequestAcknowledgeIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                     CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                                                  PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                     CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                                                  PRESENCE mandatory
     ID id-UESecurityCapabilities
                                                     CRITICALITY reject TYPE UESecurityCapabilities
                                                                                                                  PRESENCE optional
     ID id-SecurityContext
                                                     CRITICALITY reject TYPE SecurityContext
                                                                                                                  PRESENCE mandatory
     ID id-NewSecurityContextInd
                                                     CRITICALITY reject TYPE NewSecurityContextInd
                                                                                                                  PRESENCE optional
     ID id-PDUSessionResourceSwitchedList
                                                     CRITICALITY ignore TYPE PDUSessionResourceSwitchedList
                                                                                                                  PRESENCE mandatory
     ID id-PDUSessionResourceReleasedListPSAck
                                                     CRITICALITY ignore TYPE PDUSessionResourceReleasedListPSAck
                                                                                                                  PRESENCE optional
     TD id-AllowedNSSAT
                                                     CRITICALITY reject TYPE AllowedNSSAI
                                                                                                                  PRESENCE mandatory
     ID id-CoreNetworkAssistanceInformationForInactive
                                                            CRITICALITY ignore TYPE CoreNetworkAssistanceInformationForInactive
                                                                                                                                   PRESENCE
optional
             } |
     ID id-RRCInactiveTransitionReportRequest
                                                     CRITICALITY ignore TYPE RRCInactiveTransitionReportRequest
                                                                                                                  PRESENCE optional
     ID id-CriticalityDiagnostics
                                                     CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                                                  PRESENCE optional
     ID id-RedirectionVoiceFallback
                                                    CRITICALITY ignore TYPE RedirectionVoiceFallback
                                                                                                                  PRESENCE optional
     ID id-CNAssistedRANTuning
                                                    CRITICALITY ignore TYPE CNAssistedRANTuning
                                                                                                                  PRESENCE optional
  *****************
-- PATH SWITCH REQUEST FAILURE
__ *********************
PathSwitchRequestFailure ::= SEOUENCE {
                  ProtocolIE-Container
                                             { { PathSwitchRequestFailureIEs} },
   protocolIEs
   . . .
PathSwitchRequestFailureIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                 CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                                             PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                 CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                                             PRESENCE mandatory
     ID id-PDUSessionResourceReleasedListPSFail
                                                 CRITICALITY ignore TYPE PDUSessionResourceReleasedListPSFail PRESENCE mandatory
    ID id-CriticalityDiagnostics
                                                 CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                                             PRESENCE optional
      ********************
-- Handover Cancellation Elementary Procedure
-- HANDOVER CANCEL
HandoverCancel ::= SEQUENCE {
   protocolIEs
                  ProtocolIE-Container
                                             { { HandoverCancelIEs} },
```

```
HandoverCancelIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                    PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                            CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                    PRESENCE mandatory
    { ID id-Cause
                            CRITICALITY ignore TYPE Cause
                                                                    PRESENCE mandatory },
-- HANDOVER CANCEL ACKNOWLEDGE
__ *********************
HandoverCancelAcknowledge ::= SEOUENCE {
   protocolIEs
                  ProtocolIE-Container
                                           { { HandoverCancelAcknowledgeIEs} },
HandoverCancelAcknowledgeIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                   CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                  PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                   CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                  PRESENCE mandatory
                                                                                  PRESENCE optional },
   { ID id-CriticalityDiagnostics
                                   CRITICALITY ignore TYPE CriticalityDiagnostics
-- Uplink RAN Status Transfer Elementary Procedure
  *****************
  *****************
-- UPLINK RAN STATUS TRANSFER
UplinkRANStatusTransfer ::= SEQUENCE {
   protocolIEs
                 ProtocolIE-Container
                                           { {UplinkRANStatusTransferIEs} },
UplinkRANStatusTransferIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                                  CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                                               PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                                  CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                                               PRESENCE mandatory
    { ID id-RANStatusTransfer-TransparentContainer
                                                  CRITICALITY reject TYPE RANStatusTransfer-TransparentContainer
                                                                                                               PRESENCE mandatory
-- Downlink RAN Status Transfer Elementary Procedure
```

```
__ *********************
-- DOWNLINK RAN STATUS TRANSFER
  *******************
DownlinkRANStatusTransfer ::= SEQUENCE {
                                      { {DownlinkRANStatusTransferIEs} },
   protocolIEs
               ProtocolIE-Container
DownlinkRANStatusTransferIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                                            CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                                  PRESENCE mandatory
    ID id-RAN-UE-NGAP-ID
                                            CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                                  PRESENCE mandatory
    ID id-RANStatusTransfer-TransparentContainer
                                            CRITICALITY reject TYPE RANStatusTransfer-TransparentContainer
                                                                                                  PRESENCE mandatory
  -- PAGING ELEMENTARY PROCEDURE
__ ********************************
-- PAGING
Paging ::= SEQUENCE
                                      { {PagingIEs} },
   protocolIEs
               ProtocolIE-Container
PagingIEs NGAP-PROTOCOL-IES ::= {
    ID id-UEPagingIdentity
                                  CRITICALITY ignore TYPE UEPagingIdentity
                                                                             PRESENCE mandatory
    ID id-PagingDRX
                                  CRITICALITY ignore TYPE PagingDRX
                                                                             PRESENCE optional
    ID id-TAIListForPaging
                                  CRITICALITY ignore TYPE TAIListForPaging
                                                                             PRESENCE mandatory
    ID id-PagingPriority
                                  CRITICALITY ignore TYPE PagingPriority
                                                                             PRESENCE optional
    ID id-UERadioCapabilityForPaging
                                  CRITICALITY ignore TYPE UERadioCapabilityForPaging
                                                                             PRESENCE optional
    ID id-PagingOrigin
                                  CRITICALITY ignore TYPE PagingOrigin
                                                                             PRESENCE optional
    ID id-AssistanceDataForPaging
                                  CRITICALITY ignore TYPE AssistanceDataForPaging
                                                                             PRESENCE optional
  -- NAS TRANSPORT ELEMENTARY PROCEDURES
  ******************
```

```
__ *********************
-- INITIAL UE MESSAGE
  *****************
InitialUEMessage ::= SEOUENCE {
                                          { {InitialUEMessage-IEs} },
   protocolIEs
                 ProtocolIE-Container
InitialUEMessage-IEs NGAP-PROTOCOL-IES ::= {
     ID id-RAN-UE-NGAP-ID
                                              CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                                      PRESENCE mandatory
     ID id-NAS-PDU
                                              CRITICALITY reject TYPE NAS-PDU
                                                                                                      PRESENCE mandatory
     ID id-UserLocationInformation
                                              CRITICALITY reject TYPE UserLocationInformation
                                                                                                      PRESENCE mandatory
     ID id-RRCEstablishmentCause
                                              CRITICALITY ignore TYPE RRCEstablishmentCause
                                                                                                      PRESENCE mandatory
                                                                                                      PRESENCE optional
     ID id-FiveG-S-TMSI
                                              CRITICALITY reject TYPE FiveG-S-TMSI
     ID id-AMFSetID
                                              CRITICALITY ignore TYPE AMFSetID
                                                                                                      PRESENCE optional
     ID id-UEContextRequest
                                              CRITICALITY ignore TYPE UEContextRequest
                                                                                                      PRESENCE optional
     ID id-AllowedNSSAI
                                              CRITICALITY reject TYPE AllowedNSSAI
                                                                                                      PRESENCE optional
     ID id-SourceToTarget-AMFInformationReroute
                                              CRITICALITY ignore TYPE SourceToTarget-AMFInformationReroute
                                                                                                      PRESENCE optional
   { ID id-SelectedPLMNIdentity
                                              CRITICALITY ignore TYPE PLMNIdentity
                                                                                                      PRESENCE optional
    **************
-- DOWNLINK NAS TRANSPORT
         *****************
DownlinkNASTransport ::= SEQUENCE {
   protocolIEs
                 ProtocolIE-Container
                                          { {DownlinkNASTransport-IEs} },
DownlinkNASTransport-IEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                       CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                      PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                       CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                      PRESENCE mandatory
     ID id-OldAMF
                                       CRITICALITY reject TYPE AMFName
                                                                                      PRESENCE optional
                                                                                      PRESENCE optional
     ID id-RANPagingPriority
                                       CRITICALITY ignore TYPE RANPagingPriority
     ID id-NAS-PDU
                                       CRITICALITY reject TYPE NAS-PDU
                                                                                      PRESENCE mandatory
     ID id-MobilityRestrictionList
                                       CRITICALITY ignore TYPE MobilityRestrictionList
                                                                                      PRESENCE optional
     ID id-IndexToRFSP
                                       CRITICALITY ignore TYPE IndexToRFSP
                                                                                      PRESENCE optional
     ID id-UEAggregateMaximumBitRate
                                       CRITICALITY ignore TYPE UEAggregateMaximumBitRate
                                                                                      PRESENCE optional
     ID id-AllowedNSSAI
                                       CRITICALITY reject TYPE AllowedNSSAI
                                                                                      PRESENCE optional
    **************
-- UPLINK NAS TRANSPORT
__ **********************
```

```
UplinkNASTransport ::= SEQUENCE {
   protocolIEs
               ProtocolIE-Container
                                       { {UplinkNASTransport-IEs} },
UplinkNASTransport-IEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                   CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                     PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                                   CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                     PRESENCE mandatory
     ID id-NAS-PDU
                                   CRITICALITY reject TYPE NAS-PDU
                                                                                     PRESENCE mandatory
                                   CRITICALITY ignore TYPE UserLocationInformation
                                                                                     PRESENCE mandatory }
   { ID id-UserLocationInformation
  ****************
-- NAS NON DELIVERY INDICATION
  NASNonDeliveryIndication ::= SEQUENCE {
                                          { {NASNonDeliveryIndication-IEs} },
   protocolIEs
                 ProtocolIE-Container
NASNonDeliveryIndication-IEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                            CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                   PRESENCE mandatory
     ID id-RAN-UE-NGAP-ID
                            CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                   PRESENCE mandatory
     ID id-NAS-PDU
                            CRITICALITY ignore TYPE NAS-PDU
                                                                   PRESENCE mandatory
   { ID id-Cause
                            CRITICALITY ignore TYPE Cause
                                                                   PRESENCE mandatory
  -- REROUTE NAS REQUEST
  *************************
RerouteNASRequest ::= SEOUENCE {
                                          { {RerouteNASRequest-IEs} },
   protocolIEs
                 ProtocolIE-Container
RerouteNASRequest-IEs NGAP-PROTOCOL-IES ::= {
     ID id-RAN-UE-NGAP-ID
                                              CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                                      PRESENCE mandatory } |
     ID id-AMF-UE-NGAP-ID
                                              CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                                      PRESENCE optional }
     ID id-NGAP-Message
                                              CRITICALITY reject TYPE OCTET STRING
                                                                                                      PRESENCE mandatory
     ID id-AMFSetID
                                              CRITICALITY reject TYPE AMFSetID
                                                                                                      PRESENCE mandatory
     ID id-AllowedNSSAI
                                              CRITICALITY reject TYPE AllowedNSSAI
                                                                                                      PRESENCE optional } |
   { ID id-SourceToTarget-AMFInformationReroute
                                              CRITICALITY ignore TYPE SourceToTarget-AMFInformationReroute PRESENCE optional },
   . . .
```

```
__ *********************
-- INTERFACE MANAGEMENT ELEMENTARY PROCEDURES
-- NG Setup Elementary Procedure
__ *********************
-- NG SETUP REQUEST
NGSetupRequest ::= SEOUENCE {
                                            { {NGSetupRequestIEs} },
   protocolIEs
                ProtocolIE-Container
NGSetupRequestIEs NGAP-PROTOCOL-IES ::= {
     ID id-GlobalRANNodeID
                                                                                 PRESENCE mandatory } |
                           CRITICALITY reject TYPE GlobalRANNodeID
     ID id-RANNodeName
                           CRITICALITY ignore TYPE KANNOGENAU
CRITICALITY reject TYPE SupportedT
CRITICALITY ignore TYPE PagingDRX
                                                                                 PRESENCE optional }
                                 CRITICALITY ignore TYPE RANNodeName
                                                                                 PRESENCE mandatory }
     ID id-SupportedTAList
                                 CRITICALITY reject TYPE SupportedTAList
     ID id-DefaultPagingDRX
                                                                                 PRESENCE mandatory }
                                                                                 PRESENCE optional },
    { ID id-UERetentionInformation CRITICALITY ignore TYPE UERetentionInformation
   *****************
-- NG SETUP RESPONSE
NGSetupResponse ::= SEQUENCE {
   protocolIEs
                  ProtocolIE-Container
                                            { {NGSetupResponseIEs} },
NGSetupResponseIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMFName
                                     CRITICALITY reject TYPE AMFName
                                                                                     PRESENCE mandatory
     ID id-ServedGUAMIList
                                    CRITICALITY reject TYPE ServedGUAMIList
                                                                                     PRESENCE mandatory
     ID id-RelativeAMFCapacity
                                    CRITICALITY ignore TYPE RelativeAMFCapacity
                                                                                     PRESENCE mandatory
     ID id-PLMNSupportList
                                     CRITICALITY reject TYPE PLMNSupportList
                                                                                     PRESENCE mandatory
     ID id-CriticalityDiagnostics
                                     CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                     PRESENCE optional } |
    { ID id-UERetentionInformation
                                     CRITICALITY ignore TYPE UERetentionInformation
                                                                                     PRESENCE optional
__ ***********************
```

```
-- NG SETUP FAILURE
__ **********************
NGSetupFailure ::= SEQUENCE {
   protocolIEs
                  ProtocolIE-Container
                                             { {NGSetupFailureIEs} },
NGSetupFailureIEs NGAP-PROTOCOL-IES ::= {
     ID id-Cause
                                     CRITICALITY ignore TYPE Cause
                                                                                      PRESENCE mandatory
     ID id-TimeToWait
                                     CRITICALITY ignore TYPE TimeToWait
                                                                                      PRESENCE optional
    { ID id-CriticalityDiagnostics
                                     CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                      PRESENCE optional
-- RAN Configuration Update Elementary Procedure
-- RAN CONFIGURATION UPDATE
RANConfigurationUpdate ::= SEQUENCE {
   protocolIEs
                  ProtocolIE-Container
                                             { {RANConfigurationUpdateIEs} },
RANConfigurationUpdateIEs NGAP-PROTOCOL-IES ::= {
     ID id-RANNodeName
                                                 CRITICALITY ignore TYPE RANNodeName
                                                                                                            PRESENCE optional }
     ID id-SupportedTAList
                                                 CRITICALITY reject TYPE SupportedTAList
                                                                                                            PRESENCE optional
                                                                                                            PRESENCE optional
     ID id-DefaultPagingDRX
                                                 CRITICALITY ignore TYPE PagingDRX
     ID id-GlobalRANNodeID
                                                 CRITICALITY ignore TYPE GlobalRANNodeID
                                                                                                            PRESENCE optional }
    { ID id-NGRAN-TNLAssociationToRemoveList
                                                 CRITICALITY reject TYPE NGRAN-TNLAssociationToRemoveList
                                                                                                            PRESENCE optional },
-- RAN CONFIGURATION UPDATE ACKNOWLEDGE
  *****************
RANConfigurationUpdateAcknowledge ::= SEQUENCE {
                  ProtocolIE-Container
                                             { {RANConfigurationUpdateAcknowledgeIEs} },
   protocolIEs
    . . .
```

```
RANConfigurationUpdateAcknowledgeIEs NGAP-PROTOCOL-IES ::= {
   { ID id-CriticalityDiagnostics
                                 CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                             PRESENCE optional
   . . .
  -- RAN CONFIGURATION UPDATE FAILURE
*****************
RANConfigurationUpdateFailure ::= SEQUENCE {
                                        { {RANConfigurationUpdateFailureIEs} },
   protocolIEs
                ProtocolIE-Container
   . . .
RANConfigurationUpdateFailureIEs NGAP-PROTOCOL-IES ::= {
     ID id-Cause
                                 CRITICALITY ignore TYPE Cause
                                                                             PRESENCE mandatory
     ID id-TimeToWait
                                 CRITICALITY ignore TYPE TimeToWait
                                                                             PRESENCE optional
    ID id-CriticalityDiagnostics
                                 CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                             PRESENCE optional
    *****************
-- AMF Configuration Update Elementary Procedure
     ********************
-- AMF CONFIGURATION UPDATE
__ *********************
AMFConfigurationUpdate ::= SEQUENCE {
   protocolIEs
                ProtocolIE-Container
                                        { {AMFConfigurationUpdateIEs} },
   . . .
AMFConfigurationUpdateIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMFName
                                        CRITICALITY reject TYPE AMFName
                                                                                          PRESENCE optional
     ID id-ServedGUAMIList
                                        CRITICALITY reject TYPE ServedGUAMIList
                                                                                          PRESENCE optional
    ID id-RelativeAMFCapacity
                                        CRITICALITY ignore TYPE RelativeAMFCapacity
                                                                                          PRESENCE optional
     ID id-PLMNSupportList
                                        CRITICALITY reject TYPE PLMNSupportList
                                                                                          PRESENCE optional
     ID id-AMF-TNLAssociationToAddList
                                        CRITICALITY ignore TYPE AMF-TNLAssociationToAddList
                                                                                          PRESENCE optional
     ID id-AMF-TNLAssociationToRemoveList
                                        CRITICALITY ignore TYPE AMF-TNLAssociationToRemoveList
                                                                                         PRESENCE optional
    ID id-AMF-TNLAssociationToUpdateList
                                        CRITICALITY ignore TYPE AMF-TNLAssociationToUpdateList
                                                                                          PRESENCE optional
  -- AMF CONFIGURATION UPDATE ACKNOWLEDGE
```

```
****************
AMFConfigurationUpdateAcknowledge ::= SEQUENCE {
   protocolIEs
               ProtocolIE-Container
                                    { {AMFConfigurationUpdateAcknowledgeIEs} },
AMFConfigurationUpdateAcknowledgeIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-TNLAssociationSetupList CRITICALITY ignore TYPE AMF-TNLAssociationSetupList
                                                                                     PRESENCE optional
    PRESENCE optional
   { ID id-CriticalityDiagnostics
                                       CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                     PRESENCE optional
      -- AMF CONFIGURATION UPDATE FAILURE
__ *********************
AMFConfigurationUpdateFailure ::= SEQUENCE {
                                    { {AMFConfigurationUpdateFailureIEs} },
   protocolIEs
               ProtocolIE-Container
   . . .
AMFConfigurationUpdateFailureIEs NGAP-PROTOCOL-IES ::= {
    ID id-Cause
                              CRITICALITY ignore TYPE Cause
                                                                     PRESENCE mandatory
    ID id-TimeToWait
                              CRITICALITY ignore TYPE TimeToWait
                                                                     PRESENCE optional
   { ID id-CriticalityDiagnostics
                              CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                     PRESENCE optional
  -- AMF Status Indication Elementary Procedure
    *****************
-- AMF STATUS INDICATION
  *******************
AMFStatusIndication ::= SEQUENCE {
   protocolIEs
             ProtocolIE-Container
                                    { {AMFStatusIndicationIEs} },
AMFStatusIndicationIEs NGAP-PROTOCOL-IES ::= {
   { ID id-UnavailableGUAMIList
                          CRITICALITY reject TYPE UnavailableGUAMIList
                                                                     PRESENCE mandatory },
```

```
-- NG Reset Elementary Procedure
__ **********************
  *****************
-- NG RESET
__ ********************
NGReset ::= SEOUENCE {
  protocolIEs
              ProtocolIE-Container
                                  { {NGResetIEs} },
NGResetIEs NGAP-PROTOCOL-IES ::= {
   { ID id-Cause
                             CRITICALITY ignore TYPE Cause
                                                                  PRESENCE mandatory } |
   { ID id-ResetType
                            CRITICALITY reject TYPE ResetType
                                                                  PRESENCE mandatory
   . . .
__ ********************
-- NG RESET ACKNOWLEDGE
__ ********************************
NGResetAcknowledge ::= SEQUENCE {
  protocolIEs
            ProtocolIE-Container
                                  { {NGResetAcknowledgeIEs} },
   . . .
NGResetAcknowledgeIEs NGAP-PROTOCOL-IES ::= {
    ID id-UE-associatedLogicalNG-connectionList
                                           CRITICALITY ignore TYPE UE-associatedLogicalNG-connectionList
                                                                                              PRESENCE optional
    ID id-CriticalityDiagnostics
                                           CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                              PRESENCE optional
   -- Error Indication Elementary Procedure
   -- ERROR INDICATION
__ ********************************
```

```
ErrorIndication ::= SEQUENCE {
   protocolIEs ProtocolIE-Container
                                         { {ErrorIndicationIEs} },
ErrorIndicationIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID
                                  CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                               PRESENCE optional
     ID id-RAN-UE-NGAP-ID
                                  CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                               PRESENCE optional
                                  CRITICALITY ignore TYPE Cause
                                                                               PRESENCE optional
     ID id-Cause
   { ID id-CriticalityDiagnostics
                                  CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                               PRESENCE optional
  *****************
-- OVERLOAD START
  ******************
OverloadStart ::= SEQUENCE {
                                         { {OverloadStartIEs} },
   protocolIEs ProtocolIE-Container
OverloadStartIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMFOverloadResponse
                                             CRITICALITY reject TYPE OverloadResponse
                                                                                                 PRESENCE optional
     ID id-AMFTrafficLoadReductionIndication
                                            CRITICALITY ignore TYPE TrafficLoadReductionIndication
                                                                                                 PRESENCE optional
   { ID id-OverloadStartNSSAIList
                                             CRITICALITY ignore TYPE OverloadStartNSSAIList
                                                                                                 PRESENCE optional
  *****************
-- OVERLOAD STOP
OverloadStop ::= SEQUENCE {
   protocolIEs
                 ProtocolIE-Container
                                         { {OverloadStopIEs} },
   . . .
OverloadStopIEs NGAP-PROTOCOL-IES ::= {
-- CONFIGURATION TRANSFER ELEMENTARY PROCEDURES
__ **********************
```

```
-- UPLINK RAN CONFIGURATION TRANSFER
__ **********************
UplinkRANConfigurationTransfer ::= SEQUENCE {
   protocolIEs
               ProtocolIE-Container
                                      { {UplinkRANConfigurationTransferIEs} },
UplinkRANConfigurationTransferIEs NGAP-PROTOCOL-IES ::= {
    ID id-SONConfigurationTransferUL
                                      CRITICALITY ignore TYPE SONConfigurationTransfer
                                                                                  PRESENCE optional }
   ID id-ENDC-SONConfigurationTransferUL
                                      CRITICALITY ignore TYPE EN-DCSONConfigurationTransfer PRESENCE optional },
  DOWNLINK RAN CONFIGURATION TRANSFER
  DownlinkRANConfigurationTransfer ::= SEQUENCE {
                                      { {DownlinkRANConfigurationTransferIEs} },
   protocolIEs
               ProtocolIE-Container
DownlinkRANConfigurationTransferIEs NGAP-PROTOCOL-IES ::= {
    ID id-SONConfigurationTransferDL
                                      CRITICALITY ignore TYPE SONConfigurationTransfer
                                                                                  PRESENCE optional }
   { ID id-ENDC-SONConfigurationTransferDL
                                      CRITICALITY ignore TYPE EN-DCSONConfigurationTransfer PRESENCE optional },
-- WARNING MESSAGE TRANSMISSION ELEMENTARY PROCEDURES
    -- Write-Replace Warning Elementary Procedure
    **********************
    -- WRITE-REPLACE WARNING REQUEST
  ****************
WriteReplaceWarningRequest ::= SEQUENCE {
                                      { {WriteReplaceWarningRequestIEs} },
   protocolIEs
               ProtocolIE-Container
   . . .
```

```
WriteReplaceWarningRequestIEs NGAP-PROTOCOL-IES ::= {
     ID id-MessageIdentifier
                                          CRITICALITY reject TYPE MessageIdentifier
                                                                                                  PRESENCE mandatory
     ID id-SerialNumber
                                          CRITICALITY reject TYPE SerialNumber
                                                                                                  PRESENCE mandatory
     ID id-WarningAreaList
                                                                                                  PRESENCE optional
                                          CRITICALITY ignore TYPE WarningAreaList
     ID id-RepetitionPeriod
                                          CRITICALITY reject TYPE RepetitionPeriod
                                                                                                  PRESENCE mandatory
                                          CRITICALITY reject TYPE NumberOfBroadcastsRequested
     ID id-NumberOfBroadcastsRequested
                                                                                                  PRESENCE mandatory
     ID id-WarningType
                                          CRITICALITY ignore TYPE WarningType
                                                                                                  PRESENCE optional
     ID id-WarningSecurityInfo
                                          CRITICALITY ignore TYPE WarningSecurityInfo
                                                                                                  PRESENCE optional
     ID id-DataCodingScheme
                                          CRITICALITY ignore TYPE DataCodingScheme
                                                                                                  PRESENCE optional
                                          CRITICALITY ignore TYPE WarningMessageContents
     ID id-WarningMessageContents
                                                                                                  PRESENCE optional
     ID id-ConcurrentWarningMessageInd
                                          CRITICALITY reject TYPE ConcurrentWarningMessageInd
                                                                                                  PRESENCE optional
     ID id-WarningAreaCoordinates
                                          CRITICALITY ignore TYPE WarningAreaCoordinates
                                                                                                  PRESENCE optional
  WRITE-REPLACE WARNING RESPONSE
  ****************
WriteReplaceWarningResponse ::= SEOUENCE {
   protocolIEs
                       ProtocolIE-Container
                                                   { {WriteReplaceWarningResponseIEs} },
    . . .
WriteReplaceWarningResponseIEs NGAP-PROTOCOL-IES ::= {
     ID id-MessageIdentifier
                                                                                                  PRESENCE mandatory
                                          CRITICALITY reject TYPE MessageIdentifier
                                          CRITICALITY reject TYPE SerialNumber
     ID id-SerialNumber
                                                                                                  PRESENCE mandatory
     ID id-BroadcastCompletedAreaList
                                          CRITICALITY ignore TYPE BroadcastCompletedAreaList
                                                                                                  PRESENCE optional
    ID id-CriticalityDiagnostics
                                          CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                                  PRESENCE optional
-- PWS Cancel Elementary Procedure
-- PWS CANCEL REQUEST
PWSCancelRequest ::= SEQUENCE {
                                               { {PWSCancelRequestIEs} },
   protocolIEs
                   ProtocolIE-Container
PWSCancelRequestIEs NGAP-PROTOCOL-IES ::= -
```

```
ID id-MessageIdentifier
                                  CRITICALITY reject TYPE MessageIdentifier
                                                                                   PRESENCE mandatory
     ID id-SerialNumber
                                  CRITICALITY reject TYPE SerialNumber
                                                                                   PRESENCE mandatory
     ID id-WarningAreaList
                                  CRITICALITY ignore TYPE WarningAreaList
                                                                                   PRESENCE optional
    ID id-CancelAllWarningMessages
                                  CRITICALITY reject TYPE CancelAllWarningMessages
                                                                                   PRESENCE optional
  ******************
-- PWS CANCEL RESPONSE
  *****************
PWSCancelResponse ::= SEQUENCE {
   protocolIEs
                 ProtocolIE-Container
                                         { {PWSCancelResponseIEs} },
PWSCancelResponseIEs NGAP-PROTOCOL-IES ::= {
     ID id-MessageIdentifier
                                  CRITICALITY reject TYPE MessageIdentifier
                                                                                   PRESENCE mandatory }
     ID id-SerialNumber
                                  CRITICALITY reject TYPE SerialNumber
                                                                                   PRESENCE mandatory
     ID id-BroadcastCancelledAreaList CRITICALITY ignore TYPE BroadcastCancelledAreaList
                                                                                   PRESENCE optional
                                  CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                   PRESENCE optional
   { ID id-CriticalityDiagnostics
   . . .
-- PWS Restart Indication Elementary Procedure
  ***************
  *****************
-- PWS RESTART INDICATION
PWSRestartIndication ::= SEQUENCE {
   protocolIEs
                 ProtocolIE-Container
                                         { {PWSRestartIndicationIEs} },
PWSRestartIndicationIEs NGAP-PROTOCOL-IES ::= {
     ID id-CellIDListForRestart
                                      CRITICALITY reject TYPE CellIDListForRestart
                                                                                       PRESENCE mandatory
     ID id-GlobalRANNodeID
                                      CRITICALITY reject TYPE GlobalRANNodeID
                                                                                       PRESENCE mandatory
     ID id-TAIListForRestart
                                      CRITICALITY reject TYPE TAIListForRestart
                                                                                       PRESENCE mandatory
    ID id-EmergencyAreaIDListForRestart CRITICALITY reject TYPE EmergencyAreaIDListForRestart PRESENCE optional
    **************
-- PWS Failure Indication Elementary Procedure
```

```
********************
-- PWS FAILURE INDICATION
__ *********************
PWSFailureIndication ::= SEQUENCE {
                                    { {PWSFailureIndicationIEs} },
   protocolIEs
             ProtocolIE-Container
   . . .
PWSFailureIndicationIEs NGAP-PROTOCOL-IES ::= {
    ID id-PWSFailedCellIDList
                         CRITICALITY reject TYPE PWSFailedCellIDList
                                                                   PRESENCE mandatory } |
    ID id-GlobalRANNodeID
                                                                   PRESENCE mandatory },
                              CRITICALITY reject TYPE GlobalRANNodeID
  -- NRPPA TRANSPORT ELEMENTARY PROCEDURES
__ ********************************
-- DOWNLINK UE ASSOCIATED NRPPA TRANSPORT
__ *********************
DownlinkUEAssociatedNRPPaTransport ::= SEQUENCE
                                    protocolIEs
               ProtocolIE-Container
   . . .
DownlinkUEAssociatedNRPPaTransportIEs NGAP-PROTOCOL-IES ::= {
                                                                   PRESENCE mandatory }
    ID id-AMF-UE-NGAP-ID CRITICALITY reject TYPE AMF-UE-NGAP-ID
    ID id-RAN-UE-NGAP-ID
                         CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                   PRESENCE mandatory
                                                                   PRESENCE mandatory }
    ID id-RoutingID
                          CRITICALITY reject TYPE RoutingID
   { ID id-NRPPa-PDU
                           CRITICALITY reject TYPE NRPPa-PDU
                                                                   PRESENCE mandatory },
   . . .
  -- UPLINK UE ASSOCIATED NRPPA TRANSPORT
__ ********************************
UplinkUEAssociatedNRPPaTransport ::= SEQUENCE {
   protocolIEs
               ProtocolIE-Container
                                    { {UplinkUEAssociatedNRPPaTransportIEs} },
   . . .
```

```
UplinkUEAssociatedNRPPaTransportIEs NGAP-PROTOCOL-IES ::= {
     ID id-AMF-UE-NGAP-ID CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                              PRESENCE mandatory }
    ID id-RAN-UE-NGAP-ID CRITICALITY reject TYPE RAN-UE-NGAP-ID ID id-RoutingID CRITICALITY reject TYPE ROUTINGID ID id-NRPPa-PDU CRITICALITY reject TYPE NRPPa-PDU
                                                                              PRESENCE mandatory }
                                                                              PRESENCE mandatory }
   { ID id-NRPPa-PDU
                                                                              PRESENCE mandatory },
      -- DOWNLINK NON UE ASSOCIATED NRPPA TRANSPORT
__ *********************
DownlinkNonUEAssociatedNRPPaTransport ::= SEOUENCE {
   protocolIEs
                 ProtocolIE-Container
                                     { {DownlinkNonUEAssociatedNRPPaTransportIEs} },
   . . .
DownlinkNonUEAssociatedNRPPaTransportIEs NGAP-PROTOCOL-IES ::= {
                     CRITICALITY reject TYPE RoutingID
                                                                              PRESENCE mandatory } |
     ID id-RoutingID
                             CRITICALITY reject TYPE NRPPa-PDU
   { ID id-NRPPa-PDU
                                                                              PRESENCE mandatory },
-- UPLINK NON UE ASSOCIATED NRPPA TRANSPORT
__ ********************
UplinkNonUEAssociatedNRPPaTransport ::= SEQUENCE {
                                          { {UplinkNonUEAssociatedNRPPaTransportIEs} }.
   protocolIEs
                 ProtocolIE-Container
UplinkNonUEAssociatedNRPPaTransportIEs NGAP-PROTOCOL-IES ::= {
     ID id-RoutingID
                     CRITICALITY reject TYPE RoutingID
                                                                              PRESENCE mandatory } |
   { ID id-NRPPa-PDU
                              CRITICALITY reject TYPE NRPPa-PDU
                                                                              PRESENCE mandatory },
  -- TRACE ELEMENTARY PROCEDURES
-- TRACE START
```

```
__ *********************
TraceStart ::= SEOUENCE {
                                        { {TraceStartIEs} },
   protocolIEs ProtocolIE-Container
TraceStartIEs NGAP-PROTOCOL-IES ::= {
   { ID id-AMF-UE-NGAP-ID
                                 CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                            PRESENCE mandatory
                                 CRITICALITY reject TYPE RAN-UE-NGAP-ID
    ID id-RAN-UE-NGAP-ID
                                                                            PRESENCE mandatory
   { ID id-TraceActivation
                                 CRITICALITY ignore TYPE TraceActivation
                                                                            PRESENCE mandatory
__ *********************
-- TRACE FAILURE INDICATION
  ******************
TraceFailureIndication ::= SEQUENCE {
                                        { {TraceFailureIndicationIEs} },
   protocolIEs ProtocolIE-Container
TraceFailureIndicationIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                                 CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                             PRESENCE mandatory
                                                                             PRESENCE mandatory
    ID id-RAN-UE-NGAP-ID
                                 CRITICALITY reject TYPE RAN-UE-NGAP-ID
    ID id-NGRANTraceID
                                 CRITICALITY ignore TYPE NGRANTraceID
                                                                             PRESENCE mandatory
                                 CRITICALITY ignore TYPE Cause
   { ID id-Cause
                                                                             PRESENCE mandatory
   . . .
__ ********************
-- DEACTIVATE TRACE
__ **********************
DeactivateTrace ::= SEQUENCE {
                                        { {DeactivateTraceIEs} },
   protocolIEs ProtocolIE-Container
DeactivateTraceIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                                 CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                            PRESENCE mandatory
    ID id-RAN-UE-NGAP-ID
                                 CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                            PRESENCE mandatory
   { ID id-NGRANTraceID
                                 CRITICALITY ignore TYPE NGRANTraceID
                                                                            PRESENCE mandatory },
__ ********************************
-- CELL TRAFFIC TRACE
```

```
CellTrafficTrace ::= SEOUENCE {
   protocolIEs
              ProtocolIE-Container
                                        { {CellTrafficTraceIEs} },
CellTrafficTraceIEs NGAP-PROTOCOL-IES ::= {
   {ID id-AMF-UE-NGAP-ID
                                     CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                PRESENCE mandatory
   ID id-RAN-UE-NGAP-ID
                                                                                 PRESENCE mandatory
                                    CRITICALITY reject TYPE RAN-UE-NGAP-ID
   {ID id-NGRANTraceID
                                    CRITICALITY ignore TYPE NGRANTraceID
                                                                                PRESENCE mandatory
   {ID id-NGRAN-CGI
                                    CRITICALITY ignore TYPE NGRAN-CGI
                                                                                 PRESENCE mandatory }
   PRESENCE mandatory },
-- LOCATION REPORTING ELEMENTARY PROCEDURES
-- LOCATION REPORTING CONTROL
LocationReportingControl ::= SEQUENCE {
   protocolIEs
                 ProtocolIE-Container
                                           { {LocationReportingControlIEs} },
LocationReportingControlIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                                    CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                    PRESENCE mandatory
    ID id-RAN-UE-NGAP-ID
                                    CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                    PRESENCE mandatory
    PRESENCE mandatory
-- LOCATION REPORTING FAILURE INDICATION
__ ********************
LocationReportingFailureIndication ::= SEQUENCE {
   protocolIEs
                   ProtocolIE-Container
                                            { {LocationReportingFailureIndicationIEs} },
   . . .
LocationReportingFailureIndicationIEs NGAP-PROTOCOL-IES ::= {
   { ID id-AMF-UE-NGAP-ID
                                                                          PRESENCE mandatory } |
                          CRITICALITY reject TYPE AMF-UE-NGAP-ID
```

```
ID id-RAN-UE-NGAP-ID
                                                                        PRESENCE mandatory } |
                             CRITICALITY reject TYPE RAN-UE-NGAP-ID
    ID id-Cause
                             CRITICALITY ignore TYPE Cause
                                                                       PRESENCE mandatory },
  -- LOCATION REPORT
__ *********************
LocationReport ::= SEQUENCE {
                                          { {LocationReportIEs} },
   protocolIEs
                  ProtocolIE-Container
LocationReportIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                                       CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                       PRESENCE mandatory
    ID id-RAN-UE-NGAP-ID
                                       CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                       PRESENCE mandatory
    ID id-UserLocationInformation
                                       CRITICALITY ignore TYPE UserLocationInformation
                                                                                       PRESENCE mandatory
    ID id-UEPresenceInAreaOfInterestList
                                       CRITICALITY ignore TYPE UEPresenceInAreaOfInterestList
                                                                                       PRESENCE optional
   { ID id-LocationReportingRequestType
                                       CRITICALITY ignore TYPE LocationReportingRequestType
                                                                                       PRESENCE mandatory
  ****************
-- UE TNLA BINDING ELEMENTARY PROCEDURES
    -- UE TNLA BINDING RELEASE REQUEST
__ *********************
UETNLABindingReleaseRequest ::= SEQUENCE {
   protocolIEs
                   ProtocolIE-Container
                                          { {UETNLABindingReleaseRequestIEs} },
   . . .
UETNLABindingReleaseRequestIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                         CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                              PRESENCE mandatory } |
    ID id-RAN-UE-NGAP-ID
                         CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                              PRESENCE mandatory },
-- UE RADIO CAPABILITY MANAGEMENT ELEMENTARY PROCEDURES
  *****************
```

```
__ *********************
-- UE RADIO CAPABILITY INFO INDICATION
  *****************
UERadioCapabilityInfoIndication ::= SEQUENCE {
   protocolIEs
                   ProtocolIE-Container
                                          { {UERadioCapabilityInfoIndicationIEs} },
UERadioCapabilityInfoIndicationIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                                    CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                                PRESENCE mandatory
    ID id-RAN-UE-NGAP-ID
                                   CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                                PRESENCE mandatory
                                                                                PRESENCE mandatory
    ID id-UERadioCapability
                                    CRITICALITY ignore TYPE UERadioCapability
   { ID id-UERadioCapabilityForPaging
                                    CRITICALITY ignore TYPE UERadioCapabilityForPaging PRESENCE optional
-- UE Radio Capability Check Elementary Procedure
  *****************
    *************
-- UE RADIO CAPABILITY CHECK REQUEST
  ********************
UERadioCapabilityCheckRequest ::= SEQUENCE {
   protocolIEs
                ProtocolIE-Container
                                       { {UERadioCapabilityCheckRequestIEs} },
   . . .
UERadioCapabilityCheckRequestIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                       CRITICALITY reject TYPE AMF-UE-NGAP-ID
                                                                     PRESENCE mandatory
    ID id-RAN-UE-NGAP-ID
                             CRITICALITY reject TYPE RAN-UE-NGAP-ID
                                                                     PRESENCE mandatory
   { ID id-UERadioCapability
                             CRITICALITY ignore TYPE UERadioCapability
                                                                     PRESENCE optional
-- UE RADIO CAPABILITY CHECK RESPONSE
  UERadioCapabilityCheckResponse ::= SEOUENCE {
                                       { {UERadioCapabilityCheckResponseIEs} },
   protocolIEs
                ProtocolIE-Container
   . . .
```

```
UERadioCapabilityCheckResponseIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                                 CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                 PRESENCE mandatory
    ID id-RAN-UE-NGAP-ID
                                    CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                 PRESENCE mandatory
    ID id-IMSVoiceSupportIndicator
ID id-CriticalityDiagnostics
                                    CRITICALITY reject TYPE IMSVoiceSupportIndicator
                                                                                 PRESENCE mandatory
   { ID id-CriticalityDiagnostics
                                    CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                 PRESENCE optional
      -- PRIVATE MESSAGE ELEMENTARY PROCEDURE
-- PRIVATE MESSAGE
  ******************
PrivateMessage ::= SEQUENCE {
                                    { { PrivateMessageIEs } },
   privateIEs
              PrivateIE-Container
PrivateMessageIEs NGAP-PRIVATE-IES ::= {
  -- DATA USAGE REPORTING ELEMENTARY PROCEDURES
  -- SECONDARY RAT DATA USAGE REPORT
__ ********************************
SecondaryRATDataUsageReport ::= SEQUENCE {
                ProtocolIE-Container
                                        { {SecondaryRATDataUsageReportIEs} },
   protocolIEs
   . . .
SecondaryRATDataUsageReportIEs NGAP-PROTOCOL-IES ::= {
    ID id-AMF-UE-NGAP-ID
                                               CRITICALITY ignore TYPE AMF-UE-NGAP-ID
                                                                                                          PRESENCE mandatory
    ID id-RAN-UE-NGAP-ID
                                               CRITICALITY ignore TYPE RAN-UE-NGAP-ID
                                                                                                          PRESENCE mandatory
    ID id-PDUSessionResourceSecondaryRATUsageList
                                              CRITICALITY ignore TYPE PDUSessionResourceSecondaryRATUsageList
                                                                                                          PRESENCE mandatory
```

## 9.4.5 Information Element Definitions

```
-- ASN1START
  *****************
-- Information Element Definitions
  *****************
NGAP-IEs {
itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
ngran-Access (22) modules (3) ngap (1) version1 (1) ngap-IEs (2)
DEFINITIONS AUTOMATIC TAGS ::=
BEGIN
IMPORTS
   id-AdditionalDLForwardingUPTNLInformation,
   id-AdditionalULForwardingUPTNLInformation,
   id-AdditionalDLOosFlowPerTNLInformation,
   id-AdditionalDLUPTNLInformationForHOList,
   id-AdditionalNGU-UP-TNLInformation,
   id-AdditionalUL-NGU-UP-TNLInformation,
   id-Cause,
   id-CNTypeRestrictionsForEquivalent,
   id-CNTypeRestrictionsForServing,
   id-CommonNetworkInstance,
   id-DataForwardingNotPossible,
   id-DL-NGU-UP-TNLInformation,
   id-EndpointIPAddressAndPort,
   id-LastEUTRAN-PLMNIdentity,
   id-LocationReportingAdditionalInfo,
    id-MaximumIntegrityProtectedDataRate-DL,
   id-NetworkInstance,
   id-OldAssociatedQosFlowList-ULendmarkerexpected,
   id-PDUSessionAggregateMaximumBitRate,
   id-PDUSessionResourceFailedToSetupListCxtFail,
   id-PDUSessionResourceReleaseResponseTransfer,
   id-PDUSessionType,
   id-PSCellInformation,
```

```
id-QosFlowAddOrModifyRequestList,
id-OosFlowSetupRequestList,
id-OosFlowToReleaseList.
id-SCTP-TLAs,
id-SecondaryRATUsageInformation,
id-SecurityIndication,
id-SecurityResult,
id-S-NSSAI,
id-TNLAssociationTransportLayerAddressNGRAN,
id-UL-NGU-UP-TNLInformation,
id-UL-NGU-UP-TNLModifyList,
id-ULForwarding,
id-ULForwardingUP-TNLInformation,
maxnoofAllowedAreas,
maxnoofAllowedS-NSSAIs,
maxnoofBPLMNs.
maxnoofCellIDforWarning,
maxnoofCellinAoI,
maxnoofCellinEAI,
maxnoofCellsingNB,
maxnoofCellsinngeNB,
maxnoofCellinTAI,
maxnoofCellsinUEHistoryInfo,
maxnoofCellsUEMovingTrajectory,
maxnoofDRBs,
maxnoofEmergencyAreaID,
maxnoofEAIforRestart,
maxnoofEPLMNs,
maxnoofEPLMNsPlusOne,
maxnoofE-RABs,
maxnoofErrors,
maxnoofForbTACs,
maxnoofMultiConnectivity,
maxnoofMultiConnectivityMinusOne,
maxnoofNGConnectionsToReset,
maxnoofPDUSessions.
maxnoofPLMNs,
maxnoofOosFlows,
maxnoofRANNodeinAoI,
maxnoofRecommendedCells,
maxnoofRecommendedRANNodes,
maxnoofAoI.
maxnoofServedGUAMIs,
maxnoofSliceItems,
maxnoofTACs,
maxnoofTAIforInactive,
maxnoofTAIforPaging,
maxnoofTAIforRestart,
maxnoofTAIforWarning,
maxnoofTAIinAoI,
maxnoofTimePeriods,
maxnoofTNLAssociations,
maxnoofXnExtTLAs,
maxnoofXnGTP-TLAs,
```

```
maxnoofXnTLAs
FROM NGAP-Constants
    Criticality,
    ProcedureCode,
    ProtocolIE-ID,
    TriggeringMessage
FROM NGAP-CommonDataTypes
    ProtocolExtensionContainer{},
    ProtocolIE-Container{},
    NGAP-PROTOCOL-EXTENSION,
    ProtocolIE-SingleContainer{},
    NGAP-PROTOCOL-IES
FROM NGAP-Containers;
-- A
AdditionalDLUPTNLInformationForHOList ::= SEQUENCE (SIZE(1..maxnoofMultiConnectivityMinusOne)) OF AdditionalDLUPTNLInformationForHOItem
AdditionalDLUPTNLInformationForHOItem ::= SEQUENCE {
    additionalDL-NGU-UP-TNLInformation
                                                     UPTransportLayerInformation,
    additionalQosFlowSetupResponseList
                                                     OosFlowListWithDataForwarding,
    additionalDLForwardingUPTNLInformation
                                                     UPTransportLayerInformation
                                                                                                         OPTIONAL,
    iE-Extensions
                        ProtocolExtensionContainer { { AdditionalDLUPTNLInformationForHOItem-ExtIEs} } OPTIONAL,
AdditionalDLUPTNLInformationForHOItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
AdditionalQosFlowInformation ::= ENUMERATED {
    more-likely,
    . . .
AllocationAndRetentionPriority ::= SEQUENCE {
    priorityLevelARP
                                    PriorityLevelARP,
                                    Pre-emptionCapability,
    pre-emptionCapability
                                    Pre-emptionVulnerability,
    pre-emptionVulnerability
    iE-Extensions
                       ProtocolExtensionContainer { {AllocationAndRetentionPriority-ExtIEs} } OPTIONAL,
AllocationAndRetentionPriority-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
AllowedNSSAI ::= SEQUENCE (SIZE(1..maxnoofAllowedS-NSSAIs)) OF AllowedNSSAI-Item
AllowedNSSAI-Item ::= SEQUENCE {
    s-NSSAI
                        S-NSSAI,
```

```
ProtocolExtensionContainer { {AllowedNSSAI-Item-ExtIEs} } OPTIONAL,
    iE-Extensions
AllowedNSSAI-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
AllowedTACs ::= SEQUENCE (SIZE(1..maxnoofAllowedAreas)) OF TAC
AMFName ::= PrintableString (SIZE(1..150, ...))
AMFPagingTarget ::= CHOICE {
    globalRANNodeID
                            GlobalRANNodeID,
    choice-Extensions
                            ProtocolIE-SingleContainer { {AMFPagingTarget-ExtIEs} }
AMFPagingTarget-ExtIEs NGAP-PROTOCOL-IES ::= {
AMFPointer ::= BIT STRING (SIZE(6))
AMFRegionID ::= BIT STRING (SIZE(8))
AMFSetID ::= BIT STRING (SIZE(10))
AMF-TNLAssociationSetupList ::= SEQUENCE (SIZE(1..maxnoofTNLAssociations)) OF AMF-TNLAssociationSetupItem
AMF-TNLAssociationSetupItem ::= SEQUENCE {
    aMF-TNLAssociationAddress
                                    CPTransportLayerInformation,
    iE-Extensions
                       ProtocolExtensionContainer { {AMF-TNLAssociationSetupItem-ExtIEs} } OPTIONAL,
AMF-TNLAssociationSetupItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
AMF-TNLAssociationToAddList ::= SEQUENCE (SIZE(1..maxnoofTNLAssociations)) OF AMF-TNLAssociationToAddItem
AMF-TNLAssociationToAddItem ::= SEQUENCE {
                                   CPTransportLayerInformation,
    aMF-TNLAssociationAddress
    tNLAssociationUsage
                                    TNLAssociationUsage
                                                                                            OPTIONAL,
    tNLAddressWeightFactor
                                   TNLAddressWeightFactor,
    iE-Extensions ProtocolExtensionContainer { {AMF-TNLAssociationToAddItem-ExtIEs} } OPTIONAL,
AMF-TNLAssociationToAddItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
```

```
AMF-TNLAssociationToRemoveList ::= SEQUENCE (SIZE(1..maxnoofTNLAssociations)) OF AMF-TNLAssociationToRemoveItem
AME-TNLAssociationToRemoveItem ::= SEQUENCE {
    aMF-TNLAssociationAddress
                                    CPTransportLayerInformation,
    iE-Extensions
                        ProtocolExtensionContainer { {AMF-TNLAssociationToRemoveItem-ExtIEs} } OPTIONAL,
AMF-TNLAssociationToRemoveItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    {ID id-TNLAssociationTransportLayerAddressNGRAN CRITICALITY reject EXTENSION CPTransportLayerInformation PRESENCE optional},
AMF-TNLAssociationToUpdateList ::= SEOUENCE (SIZE(1..maxnoofTNLAssociations)) OF AMF-TNLAssociationToUpdateItem
AMF-TNLAssociationToUpdateItem ::= SEQUENCE {
                                   CPTransportLayerInformation,
    aMF-TNLAssociationAddress
                                    TNLAssociationUsage
    tNLAssociationUsage
                                                                                                OPTIONAL,
    tNLAddressWeightFactor
                                    TNLAddressWeightFactor
                                                                                                OPTIONAL,
                       ProtocolExtensionContainer { {AMF-TNLAssociationToUpdateItem-ExtIEs} } OPTIONAL,
    iE-Extensions
AMF-TNLAssociationToUpdateItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
AMF-UE-NGAP-ID ::= INTEGER (0..1099511627775)
AreaOfInterest ::= SEQUENCE {
    areaOfInterestTAIList
                                    AreaOfInterestTAIList
                                                                                OPTIONAL,
                                   AreaOfInterestCellList
    areaOfInterestCellList
                                                                                OPTIONAL,
    areaOfInterestRANNodeList
                                   AreaOfInterestRANNodeList
                                                                                OPTIONAL,
                       ProtocolExtensionContainer { {AreaOfInterest-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
AreaOfInterest-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
AreaOfInterestCellList ::= SEOUENCE (SIZE(1..maxnoofCellinAoI)) OF AreaOfInterestCellItem
AreaOfInterestCellItem ::= SEQUENCE {
    nGRAN-CGI
                       NGRAN-CGI,
    iE-Extensions
                        ProtocolExtensionContainer { {AreaOfInterestCellItem-ExtIEs} } OPTIONAL,
AreaOfInterestCellItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
AreaOfInterestList ::= SEOUENCE (SIZE(1..maxnoofAoI)) OF AreaOfInterestItem
```

```
AreaOfInterestItem ::= SEOUENCE {
    areaOfInterest
                                        AreaOfInterest.
    locationReportingReferenceID
                                       LocationReportingReferenceID,
                   ProtocolExtensionContainer { {AreaOfInterestItem-ExtIEs} } OPTIONAL,
    iE-Extensions
AreaOfInterestItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
AreaOfInterestRANNodeList ::= SEQUENCE (SIZE(1..maxnoofRANNodeinAoI)) OF AreaOfInterestRANNodeItem
AreaOfInterestRANNodeItem ::= SEOUENCE {
    globalRANNodeID
                     GlobalRANNodeID,
                       ProtocolExtensionContainer { {AreaOfInterestRANNodeItem-ExtIEs} }
    iE-Extensions
AreaOfInterestRANNodeItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
AreaOfInterestTAIList ::= SEOUENCE (SIZE(1..maxnoofTAIinAoI)) OF AreaOfInterestTAIItem
AreaOfInterestTAIItem ::= SEOUENCE {
    t.AI
                       TAI,
                       ProtocolExtensionContainer { {AreaOfInterestTAIItem-ExtIEs} }
    iE-Extensions
AreaOfInterestTAIItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
AssistanceDataForPaging ::= SEQUENCE {
    assistanceDataForRecommendedCells
                                            AssistanceDataForRecommendedCells
                                                                                        OPTIONAL,
    pagingAttemptInformation
                                            PagingAttemptInformation
                                                                                        OPTIONAL,
    iE-Extensions
                       ProtocolExtensionContainer { {AssistanceDataForPaging-ExtIEs} } OPTIONAL,
AssistanceDataForPaging-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    . . .
AssistanceDataForRecommendedCells ::= SEQUENCE {
    recommendedCellsForPaging
                                    RecommendedCellsForPaging,
                       ProtocolExtensionContainer { {AssistanceDataForRecommendedCells-ExtIEs} } OPTIONAL,
    iE-Extensions
AssistanceDataForRecommendedCells-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
```

```
AssociatedOosFlowList ::= SEOUENCE (SIZE(1..maxnoofOosFlows)) OF AssociatedOosFlowItem
AssociatedOosFlowItem ::= SEOUENCE {
    gosFlowIdentifier
                                    OosFlowIdentifier,
    qosFlowMappingIndication
                                    ENUMERATED {ul, dl, ...}
                                                                                         OPTIONAL,
   iE-Extensions
                        ProtocolExtensionContainer { {AssociatedQosFlowItem-ExtIEs} }
                                                                                         OPTIONAL,
AssociatedQosFlowItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
AveragingWindow ::= INTEGER (0..4095, ...)
-- B
BitRate ::= INTEGER (0..400000000000, ...)
BroadcastCancelledAreaList ::= CHOICE {
    cellIDCancelledEUTRA
                                        CellIDCancelledEUTRA,
    tAICancelledEUTRA
                                        TAICancelledEUTRA,
    emergencyAreaIDCancelledEUTRA
                                        EmergencyAreaIDCancelledEUTRA,
    cellIDCancelledNR
                                        CellIDCancelledNR,
    tAICancelledNR
                                        TAICancelledNR,
                                        EmergencyAreaIDCancelledNR,
    emergencyAreaIDCancelledNR
                            ProtocolIE-SingleContainer { {BroadcastCancelledAreaList-ExtIEs} }
    choice-Extensions
BroadcastCancelledAreaList-ExtIEs NGAP-PROTOCOL-IES ::= {
BroadcastCompletedAreaList ::= CHOICE {
    cellIDBroadcastEUTRA
                                        CellIDBroadcastEUTRA,
    tAIBroadcastEUTRA
                                        TAIBroadcastEUTRA,
    emergencyAreaIDBroadcastEUTRA
                                        EmergencyAreaIDBroadcastEUTRA,
    cellIDBroadcastNR
                                        CellIDBroadcastNR,
    tAIBroadcastNR
                                        TAIBroadcastNR,
                                        EmergencyAreaIDBroadcastNR,
    emergencyAreaIDBroadcastNR
                            ProtocolIE-SingleContainer { {BroadcastCompletedAreaList-ExtIEs} }
    choice-Extensions
BroadcastCompletedAreaList-ExtIEs NGAP-PROTOCOL-IES ::= {
BroadcastPLMNList ::= SEQUENCE (SIZE(1..maxnoofBPLMNs)) OF BroadcastPLMNItem
BroadcastPLMNItem ::= SEQUENCE {
   pLMNIdentity
                            PLMNIdentity,
```

```
tAISliceSupportList
                           SliceSupportList,
   iE-Extensions
                      ProtocolExtensionContainer { {BroadcastPLMNItem-ExtIEs} } OPTIONAL,
BroadcastPLMNItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
-- C
CancelAllWarningMessages ::= ENUMERATED {
   true,
CancelledCellsInEAI-EUTRA ::= SEQUENCE (SIZE(1..maxnoofCellinEAI)) OF CancelledCellsInEAI-EUTRA-Item
CancelledCellsInEAI-EUTRA-Item ::= SEQUENCE {
   eUTRA-CGI
                          EUTRA-CGI,
   numberOfBroadcasts
                          NumberOfBroadcasts,
   iE-Extensions ProtocolExtensionContainer { {CancelledCellsInEAI-EUTRA-Item-ExtIEs} } OPTIONAL,
CancelledCellsInEAI-EUTRA-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
CancelledCellsInEAI-NR ::= SEQUENCE (SIZE(1..maxnoofCellinEAI)) OF CancelledCellsInEAI-NR-Item
CancelledCellsInEAI-NR-Item ::= SEQUENCE {
                          NR-CGI,
   numberOfBroadcasts
                          NumberOfBroadcasts,
                   ProtocolExtensionContainer { {CancelledCellsInEAI-NR-Item-ExtIEs} } OPTIONAL,
   iE-Extensions
CancelledCellsInEAI-NR-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
CancelledCellsInTAI-EUTRA ::= SEQUENCE (SIZE(1..maxnoofCellinTAI)) OF CancelledCellsInTAI-EUTRA-Item
CancelledCellsInTAI-EUTRA-Item ::= SEOUENCE
   eUTRA-CGI
                         EUTRA-CGI,
   numberOfBroadcasts NumberOfBroadcasts,
   iE-Extensions ProtocolExtensionContainer { {CancelledCellsInTAI-EUTRA-Item-ExtIEs} } OPTIONAL,
CancelledCellsInTAI-EUTRA-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
```

```
CancelledCellsInTAI-NR ::= SEQUENCE (SIZE(1..maxnoofCellinTAI)) OF CancelledCellsInTAI-NR-Item
CancelledCellsInTAI-NR-Item ::= SEQUENCE{
                            NR-CGI.
    numberOfBroadcasts
                            NumberOfBroadcasts,
    iE-Extensions
                        ProtocolExtensionContainer { {CancelledCellsInTAI-NR-Item-ExtIEs} } OPTIONAL,
CancelledCellsInTAI-NR-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
Cause ::= CHOICE {
    radioNetwork
                        CauseRadioNetwork,
    transport
                        CauseTransport,
                        CauseNas,
    nas
    protocol
                        CauseProtocol,
    misc
                        CauseMisc,
    choice-Extensions
                            ProtocolIE-SingleContainer { {Cause-ExtIEs} }
Cause-ExtIEs NGAP-PROTOCOL-IES ::= {
CauseMisc ::= ENUMERATED {
    control-processing-overload,
    not-enough-user-plane-processing-resources,
    hardware-failure,
    om-intervention,
    unknown-PLMN,
    unspecified,
    . . .
CauseNas ::= ENUMERATED {
    normal-release,
    authentication-failure,
    deregister,
    unspecified,
    . . .
CauseProtocol ::= ENUMERATED {
    transfer-syntax-error,
    abstract-syntax-error-reject,
    abstract-syntax-error-ignore-and-notify,
    message-not-compatible-with-receiver-state,
    semantic-error,
    abstract-syntax-error-falsely-constructed-message,
    unspecified,
    . . .
```

```
CauseRadioNetwork ::= ENUMERATED {
    unspecified,
    txnrelocoverall-expiry,
    successful-handover,
    release-due-to-ngran-generated-reason,
    release-due-to-5gc-generated-reason,
    handover-cancelled,
    partial-handover,
    ho-failure-in-target-5GC-ngran-node-or-target-system,
    ho-target-not-allowed,
    tngrelocoverall-expiry,
    tngrelocprep-expiry,
    cell-not-available,
    unknown-targetID,
    no-radio-resources-available-in-target-cell,
    unknown-local-UE-NGAP-ID,
    inconsistent-remote-UE-NGAP-ID,
    handover-desirable-for-radio-reason,
    time-critical-handover.
    resource-optimisation-handover,
    reduce-load-in-serving-cell,
    user-inactivity,
    radio-connection-with-ue-lost,
    radio-resources-not-available,
    invalid-gos-combination,
    failure-in-radio-interface-procedure,
    interaction-with-other-procedure,
    unknown-PDU-session-ID,
    unkown-gos-flow-ID,
    multiple-PDU-session-ID-instances,
    multiple-gos-flow-ID-instances,
    encryption-and-or-integrity-protection-algorithms-not-supported,
    ng-intra-system-handover-triggered,
    ng-inter-system-handover-triggered,
    xn-handover-triggered,
    not-supported-50I-value,
    ue-context-transfer,
    ims-voice-eps-fallback-or-rat-fallback-triggered,
    up-integrity-protection-not-possible,
    up-confidentiality-protection-not-possible,
    slice-not-supported,
    ue-in-rrc-inactive-state-not-reachable,
    redirection.
    resources-not-available-for-the-slice,
    ue-max-integrity-protected-data-rate-reason,
    release-due-to-cn-detected-mobility,
    . . . ,
    n26-interface-not-available,
    release-due-to-pre-emption,
    multiple-location-reporting-reference-ID-instances
```

```
CauseTransport ::= ENUMERATED {
    transport-resource-unavailable,
    unspecified,
CellIDBroadcastEUTRA ::= SEQUENCE (SIZE(1..maxnoofCellIDforWarning)) OF CellIDBroadcastEUTRA-Item
CellIDBroadcastEUTRA-Item ::= SEQUENCE {
    eUTRA-CGI
                       EUTRA-CGI,
   iE-Extensions
                       ProtocolExtensionContainer { {CellIDBroadcastEUTRA-Item-ExtIEs} } OPTIONAL,
    . . .
CellIDBroadcastEUTRA-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
CellIDBroadcastNR ::= SEOUENCE (SIZE(1..maxnoofCellIDforWarning)) OF CellIDBroadcastNR-Item
CellIDBroadcastNR-Item ::= SEQUENCE {
   nR-CGI
                       NR-CGI,
                       ProtocolExtensionContainer { {CellIDBroadcastNR-Item-ExtIEs} } OPTIONAL,
   iE-Extensions
    . . .
CellIDBroadcastNR-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
CellIDCancelledEUTRA ::= SEQUENCE (SIZE(1..maxnoofCellIDforWarning)) OF CellIDCancelledEUTRA-Item
CellIDCancelledEUTRA-Item ::= SEQUENCE {
    eUTRA-CGI
                           EUTRA-CGI,
   numberOfBroadcasts
                           NumberOfBroadcasts,
   iE-Extensions ProtocolExtensionContainer { {CellIDCancelledEUTRA-Item-ExtIEs} } OPTIONAL,
CellIDCancelledEUTRA-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
CellIDCancelledNR ::= SEQUENCE (SIZE(1..maxnoofCellIDforWarning)) OF CellIDCancelledNR-Item
CellIDCancelledNR-Item ::= SEQUENCE {
   nR-CGI
                           NR-CGI,
   numberOfBroadcasts
                           NumberOfBroadcasts,
   iE-Extensions
                    ProtocolExtensionContainer { {CellIDCancelledNR-Item-ExtIEs} } OPTIONAL,
    . . .
CellIDCancelledNR-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    . . .
```

```
CellIDListForRestart ::= CHOICE {
    eUTRA-CGIListforRestart
                                EUTRA-CGIList,
    nR-CGIListforRestart
                                NR-CGIList,
                           ProtocolIE-SingleContainer { {CellIDListForRestart-ExtIEs} }
    choice-Extensions
CellIDListForRestart-ExtIEs NGAP-PROTOCOL-IES ::= {
CellSize ::= ENUMERATED {verysmall, small, medium, large, ...}
CellType ::= SEQUENCE {
    cellSize
    iE-Extensions
                       ProtocolExtensionContainer { {CellType-ExtIEs} }
                                                                           OPTIONAL,
    . . .
CellType-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
CNAssistedRANTuning ::= SEQUENCE {
    expectedUEBehaviour
                                        ExpectedUEBehaviour
                                                                                                     OPTIONAL,
    iE-Extensions
                                        ProtocolExtensionContainer { {CNAssistedRANTuning-ExtIEs} } OPTIONAL,
CNAssistedRANTuning-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
CNTypeRestrictionsForEquivalent ::= SEQUENCE (SIZE(1..maxnoofEPLMNs)) OF CNTypeRestrictionsForEquivalentItem
CNTypeRestrictionsForEquivalentItem ::= SEQUENCE
    plmnIdentity
                                        PLMNIdentity,
    cn-Type
                                        ENUMERATED {epc-forbidden, fiveGC-forbidden, ...},
                                        ProtocolExtensionContainer { {CNTypeRestrictionsForEquivalentItem-ExtIEs} }
    iE-Extensions
                                                                                                                            OPTIONAL,
CNTypeRestrictionsForEquivalentItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::={
CNTypeRestrictionsForServing ::= ENUMERATED {
    epc-forbidden,
CommonNetworkInstance ::= OCTET STRING
```

```
CompletedCellsInEAI-EUTRA ::= SEOUENCE (SIZE(1..maxnoofCellinEAI)) OF CompletedCellsInEAI-EUTRA-Item
CompletedCellsInEAI-EUTRA-Item ::= SEQUENCE {
    eUTRA-CGI
                    EUTRA-CGI.
                    ProtocolExtensionContainer { {CompletedCellsInEAI-EUTRA-Item-ExtIEs} } OPTIONAL,
   iE-Extensions
CompletedCellsInEAI-EUTRA-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
CompletedCellsInEAI-NR ::= SEQUENCE (SIZE(1..maxnoofCellinEAI)) OF CompletedCellsInEAI-NR-Item
CompletedCellsInEAI-NR-Item ::= SEQUENCE {
   nR-CGI
                       NR-CGI,
    iE-Extensions
                       ProtocolExtensionContainer { {CompletedCellsInEAI-NR-Item-ExtIEs} } OPTIONAL,
    . . .
CompletedCellsInEAI-NR-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
CompletedCellsInTAI-EUTRA ::= SEQUENCE (SIZE(1..maxnoofCellinTAI)) OF CompletedCellsInTAI-EUTRA-Item
CompletedCellsInTAI-EUTRA-Item ::= SEQUENCE{
    eUTRA-CGI
                       ProtocolExtensionContainer { {CompletedCellsInTAI-EUTRA-Item-ExtIEs} } OPTIONAL,
   iE-Extensions
CompletedCellsInTAI-EUTRA-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
CompletedCellsInTAI-NR ::= SEOUENCE (SIZE(1..maxnoofCellinTAI)) OF CompletedCellsInTAI-NR-Item
CompletedCellsInTAI-NR-Item ::= SEQUENCE{
   nR-CGI
                       ProtocolExtensionContainer { {CompletedCellsInTAI-NR-Item-ExtIEs} } OPTIONAL,
   iE-Extensions
CompletedCellsInTAI-NR-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
ConcurrentWarningMessageInd ::= ENUMERATED {
    true,
    . . .
```

```
ConfidentialityProtectionIndication ::= ENUMERATED {
   required,
   preferred.
   not-needed,
    . . .
ConfidentialityProtectionResult ::= ENUMERATED {
   performed,
   not-performed,
CoreNetworkAssistanceInformationForInactive ::= SEQUENCE {
   uEIdentityIndexValue
                                      UEIdentityIndexValue,
   uESpecificDRX
                                      PagingDRX
                                                                                              OPTIONAL,
   periodicRegistrationUpdateTimer
                                      PeriodicRegistrationUpdateTimer,
   mICOModeIndication
                                      MICOModeIndication
                                                                                              OPTIONAL,
    tAIListForInactive
                                      TAIListForInactive,
    expectedUEBehaviour
                                      ExpectedUEBehaviour
                                                                                              OPTIONAL,
   iE-Extensions
                      ProtocolExtensionContainer { {CoreNetworkAssistanceInformationForInactive-ExtIEs} }
                                                                                                         OPTIONAL,
CoreNetworkAssistanceInformationForInactive-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
COUNTValueForPDCP-SN12 ::= SEQUENCE
   pDCP-SN12
                      INTEGER (0..4095),
   hFN-PDCP-SN12
                      INTEGER (0..1048575),
                      ProtocolExtensionContainer { {COUNTValueForPDCP-SN12-ExtIEs} } OPTIONAL,
   iE-Extensions
    . . .
COUNTValueForPDCP-SN12-ExtIES NGAP-PROTOCOL-EXTENSION ::= {
COUNTValueForPDCP-SN18 ::= SEQUENCE
   pDCP-SN18
                       INTEGER (0..262143),
   hFN-PDCP-SN18
                       INTEGER (0..16383),
                       ProtocolExtensionContainer { {COUNTValueForPDCP-SN18-ExtIEs} } OPTIONAL,
   iE-Extensions
COUNTValueForPDCP-SN18-ExtIEs NGAP-PROTOCOL-EXTENSION ::=
CPTransportLayerInformation ::= CHOICE {
    endpointIPAddress
                          TransportLayerAddress,
   choice-Extensions
```

```
CPTransportLayerInformation-ExtIEs NGAP-PROTOCOL-IES ::= {
    { ID id-EndpointIPAddressAndPort
                                            CRITICALITY reject TYPE EndpointIPAddressAndPort
                                                                                                   PRESENCE mandatory },
CriticalityDiagnostics ::= SEQUENCE {
    procedureCode
                                    ProcedureCode
                                                                                             OPTIONAL,
    triggeringMessage
                                    TriggeringMessage
                                                                                             OPTIONAL,
                                    Criticality
    procedureCriticality
                                                                                             OPTIONAL,
                                    CriticalityDiagnostics-IE-List
                                                                                             OPTIONAL,
    iEsCriticalityDiagnostics
                        ProtocolExtensionContainer {{CriticalityDiagnostics-ExtIEs}}
    iE-Extensions
                                                                                             OPTIONAL,
CriticalityDiagnostics-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
CriticalityDiagnostics-IE-List ::= SEQUENCE (SIZE(1..maxnoofErrors)) OF CriticalityDiagnostics-IE-Item
CriticalityDiagnostics-IE-Item ::= SEQUENCE {
    iECriticality
                        Criticality,
   iE-ID
                        ProtocolIE-ID.
    typeOfError
                        TypeOfError,
                        ProtocolExtensionContainer {{CriticalityDiagnostics-IE-Item-ExtIEs}} OPTIONAL,
    iE-Extensions
    . . .
CriticalityDiagnostics-IE-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
-- D
DataCodingScheme ::= BIT STRING (SIZE(8))
DataForwardingAccepted ::= ENUMERATED {
    data-forwarding-accepted,
    . . .
DataForwardingNotPossible ::= ENUMERATED {
    data-forwarding-not-possible,
    . . .
DataForwardingResponseDRBList ::= SEQUENCE (SIZE(1..maxnoofDRBs)) OF DataForwardingResponseDRBItem
DataForwardingResponseDRBItem ::= SEQUENCE {
    dRB-ID
    dLForwardingUP-TNLInformation
                                        UPTransportLayerInformation
                                                                                                 OPTIONAL,
    uLForwardingUP-TNLInformation
                                        UPTransportLayerInformation
                                                                                                 OPTIONAL,
    iE-Extensions
                        ProtocolExtensionContainer {{DataForwardingResponseDRBItem-ExtIEs}}
                                                                                                 OPTIONAL,
```

```
DataForwardingResponseDRBItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
DelayCritical ::= ENUMERATED {
    delay-critical,
    non-delay-critical,
DLForwarding ::= ENUMERATED {
    dl-forwarding-proposed,
DL-NGU-TNLInformationReused ::= ENUMERATED {
    true,
    . . .
DirectForwardingPathAvailability ::= ENUMERATED {
    direct-path-available,
    . . .
DRB-ID ::= INTEGER (1...32, ...)
DRBsSubjectToStatusTransferList ::= SEQUENCE (SIZE(1..maxnoofDRBs)) OF DRBsSubjectToStatusTransferItem
DRBsSubjectToStatusTransferItem ::= SEQUENCE {
    dRB-ID
                        DRB-ID,
    dRBStatusUL
                        DRBStatusUL,
    dRBStatusDL
                        DRBStatusDL,
    iE-Extension
                        ProtocolExtensionContainer { {DRBsSubjectToStatusTransferItem-ExtIEs} } OPTIONAL,
    . . .
DRBsSubjectToStatusTransferItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
                                                          CRITICALITY reject EXTENSION AssociatedQosFlowList PRESENCE optional },
    { ID id-OldAssociatedQosFlowList-ULendmarkerexpected
    . . .
DRBStatusDL ::= CHOICE {
    dRBStatusDL12
                            DRBStatusDL12,
    dRBStatusDL18
                            DRBStatusDL18,
    choice-Extensions
                            ProtocolIE-SingleContainer { {DRBStatusDL-ExtIEs} }
DRBStatusDL-ExtIEs NGAP-PROTOCOL-IES ::= {
```

```
DRBStatusDL12 ::= SEQUENCE {
   dL-COUNTValue COUNTValueForPDCP-SN12.
   iE-Extension
                     OPTIONAL,
DRBStatusDL12-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
DRBStatusDL18 ::= SEQUENCE {
   dL-COUNTValue COUNTValueForPDCP-SN18,
   iE-Extension
                  ProtocolExtensionContainer { {DRBStatusDL18-ExtIEs} }
                                                                           OPTIONAL.
DRBStatusDL18-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
DRBStatusUL ::= CHOICE {
   dRBStatusUL12
                        DRBStatusUL12,
   dRBStatusUL18
                        DRBStatusUL18,
   choice-Extensions
                        DRBStatusUL-ExtIEs NGAP-PROTOCOL-IES ::= {
DRBStatusUL12 ::= SEQUENCE {
   uL-COUNTValue
                                COUNTValueForPDCP-SN12,
                                BIT STRING (SIZE(1..2048))
   receiveStatusOfUL-PDCP-SDUs
                                                                           OPTIONAL,
                ProtocolExtensionContainer { {DRBStatusUL12-ExtIEs} }
   iE-Extension
                                                                           OPTIONAL,
DRBStatusUL12-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
DRBStatusUL18 ::= SEQUENCE {
   uL-COUNTValue
                                COUNTValueForPDCP-SN18,
                                BIT STRING (SIZE(1..131072))
   receiveStatusOfUL-PDCP-SDUs
                                                                           OPTIONAL,
                ProtocolExtensionContainer { {DRBStatusUL18-ExtIEs} }
   iE-Extension
                                                                           OPTIONAL,
DRBStatusUL18-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
DRBsToQosFlowsMappingList ::= SEQUENCE (SIZE(1..maxnoofDRBs)) OF DRBsToQosFlowsMappingItem
```

```
DRBsToQosFlowsMappingItem ::= SEQUENCE {
                                        DRB-ID.
    associatedOosFlowList
                                        AssociatedOosFlowList,
    iE-Extensions
                        ProtocolExtensionContainer { {DRBsToOosFlowsMappingItem-ExtIEs} }
                                                                                                 OPTIONAL,
DRBsToQosFlowsMappingItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
Dynamic5QIDescriptor ::= SEQUENCE {
   priorityLevelQos
                                PriorityLevelQos,
    packetDelayBudget
                                PacketDelayBudget,
   packetErrorRate
                                PacketErrorRate,
    fiveOI
                                FiveOI
                                                                                         OPTIONAL,
    delayCritical
                                DelayCritical
                                                                                         OPTIONAL,
-- The above IE shall be present in case of GBR OoS flow
    averagingWindow
                                AveragingWindow
                                                                                         OPTIONAL,
-- The above IE shall be present in case of GBR QoS flow
    maximumDataBurstVolume
                                MaximumDataBurstVolume
                                                                                         OPTIONAL,
                        ProtocolExtensionContainer { {Dynamic5QIDescriptor-ExtIEs} }
    iE-Extensions
                                                                                         OPTIONAL,
    . . .
Dynamic5OIDescriptor-ExtlEs NGAP-PROTOCOL-EXTENSION ::= {
EmergencyAreaID ::= OCTET STRING (SIZE(3))
EmergencyAreaIDBroadcastEUTRA ::= SEQUENCE (SIZE(1..maxnoofEmergencyAreaID)) OF EmergencyAreaIDBroadcastEUTRA-Item
EmergencyAreaIDBroadcastEUTRA-Item ::= SEQUENCE {
    emergencyAreaID
                                    EmergencyAreaID,
    completedCellsInEAI-EUTRA
                                    CompletedCellsInEAI-EUTRA,
                        ProtocolExtensionContainer { {EmergencyAreaIDBroadcastEUTRA-Item-ExtIEs} } OPTIONAL,
    . . .
EmergencyAreaIDBroadcastEUTRA-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::=
    . . .
EmergencyAreaIDBroadcastNR ::= SEQUENCE (SIZE(1..maxnoofEmergencyAreaID)) OF EmergencyAreaIDBroadcastNR-Item
EmergencyAreaIDBroadcastNR-Item ::= SEQUENCE {
    emergencyAreaID
                                EmergencyAreaID,
    completedCellsInEAI-NR
                                CompletedCellsInEAI-NR,
    iE-Extensions
                        ProtocolExtensionContainer { {EmergencyAreaIDBroadcastNR-Item-ExtIEs} } OPTIONAL,
    . . .
```

```
EmergencyAreaIDBroadcastNR-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
EmergencyAreaIDCancelledEUTRA ::= SEOUENCE (SIZE(1..maxnoofEmergencyAreaID)) OF EmergencyAreaIDCancelledEUTRA-Item
EmergencyAreaIDCancelledEUTRA-Item ::= SEQUENCE {
    emergencyAreaID
                                    EmergencyAreaID,
    cancelledCellsInEAI-EUTRA
                                    CancelledCellsInEAI-EUTRA,
                       ProtocolExtensionContainer { { EmergencyAreaIDCancelledEUTRA-Item-ExtIEs} } OPTIONAL,
   iE-Extensions
EmergencyAreaIDCancelledEUTRA-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
EmergencyAreaIDCancelledNR ::= SEQUENCE (SIZE(1..maxnoofEmergencyAreaID)) OF EmergencyAreaIDCancelledNR-Item
EmergencyAreaIDCancelledNR-Item ::= SEQUENCE {
    emergencyAreaID
                               EmergencyAreaID,
    cancelledCellsInEAI-NR
                               CancelledCellsInEAI-NR,
    iE-Extensions
                   ProtocolExtensionContainer { {EmergencyAreaIDCancelledNR-Item-ExtIEs} } OPTIONAL,
    . . .
EmergencyAreaIDCancelledNR-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
EmergencyAreaIDList ::= SEQUENCE (SIZE(1..maxnoofEmergencyAreaID)) OF EmergencyAreaID
EmergencyAreaIDListForRestart ::= SEQUENCE (SIZE(1..maxnoofEAIforRestart)) OF EmergencyAreaID
EmergencyFallbackIndicator ::= SEQUENCE {
                                            EmergencyFallbackRequestIndicator,
    emergencyFallbackRequestIndicator
    emergencyServiceTargetCN
                                            EmergencyServiceTargetCN
                                                                                            OPTIONAL,
   iE-Extensions
                       ProtocolExtensionContainer { {EmergencyFallbackIndicator-ExtIEs} } OPTIONAL,
EmergencyFallbackIndicator-ExtIES NGAP-PROTOCOL-EXTENSION ::= {
    . . .
EmergencyFallbackRequestIndicator ::= ENUMERATED {
    emergency-fallback-requested,
    . . .
EmergencyServiceTargetCN ::= ENUMERATED {
    fiveGC,
```

```
epc,
EN-DCSONConfigurationTransfer ::= OCTET STRING
EndpointIPAddressAndPort ::=SEQUENCE {
    endpointIPAddress TransportLayerAddress,
    portNumber
                        PortNumber,
    iE-Extensions
                                    ProtocolExtensionContainer { { EndpointIPAddressAndPort-ExtIEs} } OPTIONAL
EndpointIPAddressAndPort-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
EquivalentPLMNs ::= SEQUENCE (SIZE(1..maxnoofEPLMNs)) OF PLMNIdentity
EPS-TAC ::= OCTET STRING (SIZE(2))
EPS-TAI ::= SEQUENCE {
   pLMNIdentity
                        PLMNIdentity,
    ePS-TAC
                        EPS-TAC,
                        ProtocolExtensionContainer { {EPS-TAI-ExtIEs} } OPTIONAL,
    iE-Extensions
EPS-TAI-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
E-RAB-ID ::= INTEGER (0..15, ...)
E-RABInformationList ::= SEQUENCE (SIZE(1..maxnoofE-RABs)) OF E-RABInformationItem
E-RABInformationItem ::= SEQUENCE {
    e-RAB-ID
                        E-RAB-ID,
                        DLForwarding
    dLForwarding
                                                                                         OPTIONAL,
                        ProtocolExtensionContainer { {E-RABInformationItem-ExtIEs} }
    iE-Extensions
                                                                                         OPTIONAL,
    . . .
E-RABInformationItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
EUTRACellIdentity ::= BIT STRING (SIZE(28))
EUTRA-CGI ::= SEQUENCE {
    pLMNIdentity
                            PLMNIdentity,
    eUTRACellIdentity
                            EUTRACellIdentity,
    iE-Extensions
                        ProtocolExtensionContainer { {EUTRA-CGI-ExtIEs} } OPTIONAL,
```

```
EUTRA-CGI-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
EUTRA-CGIList ::= SEOUENCE (SIZE(1..maxnoofCellsinngeNB)) OF EUTRA-CGI
EUTRA-CGIListForWarning ::= SEQUENCE (SIZE(1..maxnoofCellIDforWarning)) OF EUTRA-CGI
EUTRAencryptionAlgorithms ::= BIT STRING (SIZE(16, ...))
EUTRAintegrityProtectionAlgorithms ::= BIT STRING (SIZE(16, ...))
EventType ::= ENUMERATED {
    direct,
    change-of-serve-cell,
    ue-presence-in-area-of-interest,
    stop-change-of-serve-cell,
    stop-ue-presence-in-area-of-interest,
    cancel-location-reporting-for-the-ue,
ExpectedActivityPeriod ::= INTEGER (1...30|40|50|60|80|100|120|150|180|181, ...)
ExpectedHOInterval ::= ENUMERATED {
    sec15, sec30, sec60, sec90, sec120, sec180, long-time,
ExpectedIdlePeriod ::= INTEGER (1..30|40|50|60|80|100|120|150|180|181, ...)
ExpectedUEActivityBehaviour ::= SEQUENCE {
    expectedActivityPeriod
                                                ExpectedActivityPeriod
                                                                                             OPTIONAL,
    expectedIdlePeriod
                                                ExpectedIdlePeriod
                                                                                             OPTIONAL,
    sourceOfUEActivityBehaviourInformation
                                                SourceOfUEActivityBehaviourInformation
                                                                                             OPTIONAL,
    iE-Extensions
                        ProtocolExtensionContainer { {ExpectedUEActivityBehaviour-ExtIEs} } OPTIONAL,
    . . .
ExpectedUEActivityBehaviour-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
ExpectedUEBehaviour ::= SEOUENCE {
    expectedUEActivityBehaviour
                                    ExpectedUEActivityBehaviour
                                                                                     OPTIONAL,
    expectedH0Interval
                                    ExpectedHOInterval
                                                                                     OPTIONAL,
    expectedUEMobility
                                    ExpectedUEMobility
                                                                                     OPTIONAL,
    expectedUEMovingTrajectory
                                    ExpectedUEMovingTrajectory
                                                                                     OPTIONAL,
                        ProtocolExtensionContainer { {ExpectedUEBehaviour-ExtIEs} } OPTIONAL,
    iE-Extensions
ExpectedUEBehaviour-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
```

```
ExpectedUEMobility ::= ENUMERATED {
    stationary,
   mobile,
    . . .
ExpectedUEMovingTrajectory ::= SEQUENCE (SIZE(1..maxnoofCellsUEMovingTrajectory)) OF ExpectedUEMovingTrajectoryItem
ExpectedUEMovingTrajectoryItem ::= SEQUENCE {
    nGRAN-CGI
                           NGRAN-CGI,
    timeStayedInCell
                           INTEGER (0..4095)
                                                                                                OPTIONAL,
    iE-Extensions
                       ProtocolExtensionContainer { {ExpectedUEMovingTrajectoryItem-ExtIEs} } OPTIONAL,
ExpectedUEMovingTrajectoryItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
FiveG-S-TMSI ::= SEQUENCE {
    aMFSetID
                       AMFSetID,
                       AMFPointer,
    aMFPointer
    fiveG-TMSI
                       FiveG-TMSI,
                       ProtocolExtensionContainer { {FiveG-S-TMSI-ExtIEs} }
    iE-Extensions
                                                                                OPTIONAL,
FiveG-S-TMSI-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
FiveG-TMSI ::= OCTET STRING (SIZE(4))
FiveQI ::= INTEGER (0..255, ...)
ForbiddenAreaInformation ::= SEQUENCE (SIZE(1.. maxnoofEPLMNsPlusOne)) OF ForbiddenAreaInformation-Item
ForbiddenAreaInformation-Item ::= SEQUENCE {
    pLMNIdentity
                       PLMNIdentity,
    forbiddenTACs
                       ForbiddenTACs,
                       ProtocolExtensionContainer { {ForbiddenAreaInformation-Item-ExtIEs} } OPTIONAL,
    iE-Extensions
ForbiddenAreaInformation-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
ForbiddenTACs ::= SEQUENCE (SIZE(1..maxnoofForbTACs)) OF TAC
```

```
-- G
GBR-QosInformation ::= SEQUENCE {
    maximumFlowBitRateDL
                                BitRate.
    maximumFlowBitRateUL
                                BitRate,
    quaranteedFlowBitRateDL
                                BitRate,
    quaranteedFlowBitRateUL
                                BitRate,
    notificationControl
                                NotificationControl
                                                                                     OPTIONAL,
    maximumPacketLossRateDL
                                PacketLossRate
                                                                                     OPTIONAL,
    maximumPacketLossRateUL
                                PacketLossRate
                                                                                     OPTIONAL,
    iE-Extensions
                        ProtocolExtensionContainer { GBR-QosInformation-ExtIEs} }
                                                                                     OPTIONAL,
GBR-OosInformation-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    . . . }
GlobalGNB-ID ::= SEQUENCE
    pLMNIdentity
                        PLMNIdentity,
    gNB-ID
                        GNB-ID,
                        ProtocolExtensionContainer { {GlobalGNB-ID-ExtIEs} } OPTIONAL,
    iE-Extensions
GlobalGNB-ID-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
GlobalN3IWF-ID ::= SEQUENCE {
    pLMNIdentity
                        PLMNIdentity,
   n3IWF-ID
                        N3IWF-ID,
   iE-Extensions
                        ProtocolExtensionContainer { {GlobalN3IWF-ID-ExtIEs} } OPTIONAL,
GlobalN3IWF-ID-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
GlobalNgENB-ID ::= SEQUENCE {
    pLMNIdentity
                        PLMNIdentity,
   ngENB-ID
                        ProtocolExtensionContainer { GlobalNgENB-ID-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
GlobalNgENB-ID-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
GlobalRANNodeID ::= CHOICE
    globalGNB-ID
                        GlobalGNB-ID,
    globalNgENB-ID
                        GlobalNgENB-ID,
```

```
qlobalN3IWF-ID
                        GlobalN3IWF-ID,
    choice-Extensions
                            ProtocolIE-SingleContainer { {GlobalRANNodeID-ExtIEs} }
GlobalRANNodeID-ExtIEs NGAP-PROTOCOL-IES ::= {
GNB-ID ::= CHOICE {
    gNB-ID
                BIT STRING (SIZE(22..32)),
    choice-Extensions
                            ProtocolIE-SingleContainer { GNB-ID-ExtIEs} }
GNB-ID-ExtIEs NGAP-PROTOCOL-IES ::= {
GTP-TEID ::= OCTET STRING (SIZE(4))
GTPTunnel ::= SEQUENCE {
    transportLayerAddress
                                TransportLayerAddress,
    gTP-TEID
                                GTP-TEID,
                        ProtocolExtensionContainer { GTPTunnel-ExtIEs} } OPTIONAL,
   iE-Extensions
    . . .
GTPTunnel-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
GUAMI ::= SEQUENCE {
    pLMNIdentity
                        PLMNIdentity,
    aMFRegionID
                        AMFRegionID,
                        AMFSetID,
    aMFSetID
    aMFPointer
                        AMFPointer,
                        ProtocolExtensionContainer { GUAMI-ExtIEs} } OPTIONAL,
    iE-Extensions
GUAMI-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
-- H
HandoverCommandTransfer ::= SEQUENCE {
    dLForwardingUP-TNLInformation
                                        UPTransportLayerInformation
                                                                                         OPTIONAL,
    qosFlowToBeForwardedList
                                        QosFlowToBeForwardedList
                                                                                         OPTIONAL,
                                        DataForwardingResponseDRBList
    dataForwardingResponseDRBList
                                                                                         OPTIONAL,
                        ProtocolExtensionContainer { {HandoverCommandTransfer-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
```

```
HandoverCommandTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
      ID id-AdditionalDLForwardingUPTNLInformation CRITICALITY ignore EXTENSION OosFlowPerTNLInformationList
                                                                                                                     PRESENCE optional }
      ID id-ULForwardingUP-TNLInformation
                                                    CRITICALITY reject EXTENSION UPTransportLayerInformation
                                                                                                                     PRESENCE optional }
     ID id-AdditionalULForwardingUPTNLInformation CRITICALITY reject EXTENSION UPTransportLayerInformationList PRESENCE optional },
HandoverFlag ::= ENUMERATED {
    handover-preparation,
    . . .
HandoverPreparationUnsuccessfulTransfer ::= SEQUENCE {
    cause
                        Cause,
                        ProtocolExtensionContainer { {HandoverPreparationUnsuccessfulTransfer-ExtIEs} } OPTIONAL,
    iE-Extensions
HandoverPreparationUnsuccessfulTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
HandoverRequestAcknowledgeTransfer ::= SEQUENCE {
    dL-NGU-UP-TNLInformation
                                        UPTransportLayerInformation,
    dLForwardingUP-TNLInformation
                                        UPTransportLayerInformation
                                                                                                      OPTIONAL,
    securityResult
                                        SecurityResult
                                                                                                      OPTIONAL,
                                        OosFlowListWithDataForwarding,
    gosFlowSetupResponseList
    gosFlowFailedToSetupList
                                        OosFlowListWithCause
                                                                                                      OPTIONAL,
    dataForwardingResponseDRBList
                                        DataForwardingResponseDRBList
                                                                                                      OPTIONAL,
                        ProtocolExtensionContainer { {HandoverRequestAcknowledgeTransfer-ExtIEs} }
    iE-Extensions
                                                                                                      OPTIONAL,
    . . .
HandoverRequestAcknowledgeTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
      ID id-AdditionalDLUPTNLInformationForHOList
                                                        CRITICALITY ignore EXTENSION Additional DLUPTNLInformation For HOList
                                                                                                                                 PRESENCE optional } |
      ID id-ULForwardingUP-TNLInformation
                                                        CRITICALITY reject EXTENSION UPTransportLayerInformation
                                                                                                                                 PRESENCE optional } |
    { ID id-AdditionalULForwardingUPTNLInformation
                                                        CRITICALITY reject EXTENSION UPTransportLayerInformationList
                                                                                                                                 PRESENCE optional },
HandoverRequiredTransfer ::= SEQUENCE {
    directForwardingPathAvailability
                                            DirectForwardingPathAvailability
                                                                                             OPTIONAL.
                        ProtocolExtensionContainer { {HandoverRequiredTransfer-ExtIEs} }
    iE-Extensions
                                                                                             OPTIONAL,
HandoverRequiredTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
HandoverResourceAllocationUnsuccessfulTransfer ::= SEQUENCE {
                                Cause,
    criticalityDiagnostics
                                CriticalityDiagnostics
                                                                                                                  OPTIONAL,
                        ProtocolExtensionContainer { {HandoverResourceAllocationUnsuccessfulTransfer-ExtIEs} }
    iE-Extensions
                                                                                                                  OPTIONAL,
```

```
HandoverResourceAllocationUnsuccessfulTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
HandoverType ::= ENUMERATED {
   intra5gs,
   fivegs-to-eps,
    eps-to-5gs,
    . . .
IMSVoiceSupportIndicator ::= ENUMERATED {
    supported,
   not-supported,
    . . .
IndexToRFSP ::= INTEGER (1..256, ...)
InfoOnRecommendedCellsAndRANNodesForPaging ::= SEQUENCE
    recommendedCellsForPaging
                                    RecommendedCellsForPaging,
    recommendRANNodesForPaging
                                    RecommendedRANNodesForPaging,
                        ProtocolExtensionContainer { {InfoOnRecommendedCellsAndRANNodesForPaging-ExtIEs} } OPTIONAL,
    iE-Extensions
InfoOnRecommendedCellsAndRANNodesForPaging-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
IntegrityProtectionIndication ::= ENUMERATED {
    required,
   preferred,
   not-needed,
IntegrityProtectionResult ::= ENUMERATED {
    performed.
   not-performed,
    . . .
IntendedNumberOfPagingAttempts ::= INTEGER (1..16, ...)
InterfacesToTrace ::= BIT STRING (SIZE(8))
-- J
```

```
-- K
-- L
LastVisitedCellInformation ::= CHOICE {
    nGRANCell
                 LastVisitedNGRANCellInformation.
                    LastVisitedEUTRANCellInformation,
    eUTRANCell
    uTRANCell
                   LastVisitedUTRANCellInformation,
    qERANCell
                    LastVisitedGERANCellInformation,
                            ProtocolIE-SingleContainer { {LastVisitedCellInformation-ExtIEs} }
    choice-Extensions
LastVisitedCellInformation-ExtIEs NGAP-PROTOCOL-IES ::= {
LastVisitedCellItem ::= SEQUENCE {
    lastVisitedCellInformation
                                    LastVisitedCellInformation,
                        ProtocolExtensionContainer { {LastVisitedCellItem-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
LastVisitedCellItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
LastVisitedEUTRANCellInformation ::= OCTET STRING
LastVisitedGERANCellInformation ::= OCTET STRING
LastVisitedNGRANCellInformation::= SEQUENCE {
    globalCellID
                                                NGRAN-CGI,
    cellType
                                                CellType,
    timeUEStayedInCell
                                                TimeUEStayedInCell,
    timeUEStayedInCellEnhancedGranularity
                                                TimeUEStayedInCellEnhancedGranularity
                                                                                                 OPTIONAL,
    hOCauseValue
                                                                                                 OPTIONAL.
                        ProtocolExtensionContainer { {LastVisitedNGRANCellInformation-ExtIEs} } OPTIONAL,
    iE-Extensions
LastVisitedNGRANCellInformation-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
LastVisitedUTRANCellInformation ::= OCTET STRING
LocationReportingAdditionalInfo ::= ENUMERATED {
   includePSCell,
LocationReportingReferenceID ::= INTEGER (1..64, ...)
LocationReportingRequestType ::= SEQUENCE {
    eventType
                                                     EventType,
```

```
reportArea
                                                     ReportArea,
    areaOfInterestList
                                                    AreaOfInterestList
                                                                                                   OPTIONAL.
    locationReportingReferenceIDToBeCancelled
                                                    LocationReportingReferenceID
                                                                                                   OPTIONAL.
-- The above IE shall be present if the event type is set to "stop reporting UE presence in the area of interest"
    iE-Extensions
                        ProtocolExtensionContainer { {LocationReportingRequestType-ExtIEs} }
                                                                                                   OPTIONAL.
LocationReportingRequestType-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    { ID id-LocationReportingAdditionalInfo CRITICALITY ignore EXTENSION LocationReportingAdditionalInfo
                                                                                                               PRESENCE optional },
MaskedIMEISV ::= BIT STRING (SIZE(64))
MaximumDataBurstVolume ::= INTEGER (0..4095, ...)
MessageIdentifier ::= BIT STRING (SIZE(16))
MaximumIntegrityProtectedDataRate ::= ENUMERATED {
    bitrate64kbs.
    maximum-UE-rate,
MICOModeIndication ::= ENUMERATED {
    true,
    . . .
MobilityRestrictionList ::= SEQUENCE
    servingPLMN
                                PLMNIdentity,
                                EquivalentPLMNs
    equivalentPLMNs
                                                                                         OPTIONAL,
                                RATRestrictions
    rATRestrictions
                                                                                         OPTIONAL,
                                ForbiddenAreaInformation
    forbiddenAreaInformation
                                                                                         OPTIONAL,
                                ServiceAreaInformation
    serviceAreaInformation
                                                                                         OPTIONAL,
    iE-Extensions
                        ProtocolExtensionContainer { {MobilityRestrictionList-ExtIEs} } OPTIONAL,
    . . .
MobilityRestrictionList-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
      ID id-LastEUTRAN-PLMNIdentity
                                        CRITICALITY ignore EXTENSION PLMNIdentity
                                                                                         PRESENCE optional
      ID id-CNTypeRestrictionsForServing
                                                CRITICALITY ignore EXTENSION CNTypeRestrictionsForServing
                                                                                                              PRESENCE optional |
      ID id-CNTypeRestrictionsForEquivalent
                                                CRITICALITY ignore EXTENSION CNTypeRestrictionsForEquivalent PRESENCE optional },
-- N
N3IWF-ID ::= CHOICE {
    n3IWF-ID
                            BIT STRING (SIZE(16)),
```

```
ProtocolIE-SingleContainer { {N3IWF-ID-ExtIEs} }
    choice-Extensions
N3IWF-ID-ExtIEs NGAP-PROTOCOL-IES ::= {
NAS-PDU ::= OCTET STRING
NASSecurityParametersFromNGRAN ::= OCTET STRING
NetworkInstance ::= INTEGER (1..256, ...)
NewSecurityContextInd ::= ENUMERATED {
    true,
NextHopChainingCount ::= INTEGER (0..7)
NextPagingAreaScope ::= ENUMERATED {
    same,
    changed,
    . . .
NgENB-ID ::= CHOICE {
    macroNqENB-ID
                           BIT STRING (SIZE(20)),
    shortMacroNqENB-ID
                            BIT STRING (SIZE(18)),
    longMacroNgENB-ID
                            BIT STRING (SIZE(21)),
    choice-Extensions
                            ProtocolIE-SingleContainer { {NgENB-ID-ExtIEs} }
NgENB-ID-ExtIEs NGAP-PROTOCOL-IES ::= {
NGRAN-CGI ::= CHOICE {
                    NR-CGI,
    nR-CGI
    eUTRA-CGI
                    EUTRA-CGI,
                            ProtocolIE-SingleContainer { {NGRAN-CGI-ExtIEs} }
    choice-Extensions
NGRAN-CGI-ExtIEs NGAP-PROTOCOL-IES ::= {
    . . .
NGRAN-TNLAssociationToRemoveList ::= SEQUENCE (SIZE(1..maxnoofTNLAssociations)) OF NGRAN-TNLAssociationToRemoveItem
NGRAN-TNLAssociationToRemoveItem::= SEQUENCE {
    tNLAssociationTransportLayerAddress
                                            CPTransportLayerInformation,
    tNLAssociationTransportLayerAddressAMF
                                                CPTransportLayerInformation
                                                                                OPTIONAL,
                                    ProtocolExtensionContainer { { NGRAN-TNLAssociationToRemoveItem-ExtIEs} } OPTIONAL
    iE-Extensions
```

```
NGRAN-TNLAssociationToRemoveItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
NGRANTraceID ::= OCTET STRING (SIZE(8))
NonDynamic5QIDescriptor ::= SEQUENCE {
    fiveQI
    priorityLevelQos
                                PriorityLevelQos
                                                                                        OPTIONAL,
    averagingWindow
                                AveragingWindow
                                                                                        OPTIONAL,
                                MaximumDataBurstVolume
    maximumDataBurstVolume
                                                                                        OPTIONAL,
    iE-Extensions ProtocolExtensionContainer { {NonDynamic5QIDescriptor-ExtIEs} } OPTIONAL,
NonDynamic50IDescriptor-ExtlEs NGAP-PROTOCOL-EXTENSION ::= {
NotAllowedTACs ::= SEQUENCE (SIZE(1..maxnoofAllowedAreas)) OF TAC
NotificationCause ::= ENUMERATED {
    fulfilled,
    not-fulfilled,
    . . .
NotificationControl ::= ENUMERATED {
    notification-requested,
    . . .
NRCellIdentity ::= BIT STRING (SIZE(36))
NR-CGI ::= SEQUENCE {
    pLMNIdentity
                        PLMNIdentity,
    nRCellIdentity
                        NRCellIdentity,
                        ProtocolExtensionContainer { {NR-CGI-ExtIEs} } OPTIONAL,
    iE-Extensions
NR-CGI-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
NR-CGIList ::= SEQUENCE (SIZE(1..maxnoofCellsingNB)) OF NR-CGI
NR-CGIListForWarning ::= SEQUENCE (SIZE(1..maxnoofCellIDforWarning)) OF NR-CGI
NRencryptionAlgorithms ::= BIT STRING (SIZE(16, ...))
NRintegrityProtectionAlgorithms ::= BIT STRING (SIZE(16, ...))
```

```
NRPPa-PDU ::= OCTET STRING
NumberOfBroadcasts ::= INTEGER (0..65535)
NumberOfBroadcastsRequested ::= INTEGER (0..65535)
-- O
OverloadAction ::= ENUMERATED {
    reject-non-emergency-mo-dt,
    reject-rrc-cr-signalling,
    permit-emergency-sessions-and-mobile-terminated-services-only,
    permit-high-priority-sessions-and-mobile-terminated-services-only,
OverloadResponse ::= CHOICE {
    overloadAction
                            OverloadAction,
                            ProtocolIE-SingleContainer { {OverloadResponse-ExtIEs} }
    choice-Extensions
OverloadResponse-ExtIEs NGAP-PROTOCOL-IES ::= {
OverloadStartNSSAIList ::= SEQUENCE (SIZE (1..maxnoofSliceItems)) OF OverloadStartNSSAIItem
OverloadStartNSSAIItem ::= SEOUENCE {
    sliceOverloadList
                                            SliceOverloadList,
    sliceOverloadResponse
                                            OverloadResponse
                                                                                             OPTIONAL,
                                            TrafficLoadReductionIndication
    sliceTrafficLoadReductionIndication
                                                                                         OPTIONAL,
    iE-Extensions
                        ProtocolExtensionContainer { {OverloadStartNSSAIItem-ExtIEs} } OPTIONAL,
    . . .
OverloadStartNSSAIItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
-- P
PacketDelayBudget ::= INTEGER (0..1023, ...)
PacketErrorRate ::= SEQUENCE {
    pERScalar
                    INTEGER (0..9, ...),
    pERExponent
                    INTEGER (0..9, ...),
                        ProtocolExtensionContainer { {PacketErrorRate-ExtIEs} } OPTIONAL,
PacketErrorRate-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
```

```
PacketLossRate ::= INTEGER (0..1000, ...)
PagingAttemptInformation ::= SEOUENCE {
    pagingAttemptCount
                                        PagingAttemptCount,
    intendedNumberOfPagingAttempts
                                        IntendedNumberOfPagingAttempts,
    nextPagingAreaScope
                                        NextPagingAreaScope
                                                                                             OPTIONAL,
    iE-Extensions
                        ProtocolExtensionContainer { {PagingAttemptInformation-ExtIEs} }
                                                                                             OPTIONAL,
PagingAttemptInformation-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PagingAttemptCount ::= INTEGER (1..16, ...)
PagingDRX ::= ENUMERATED {
   v32,
    v64,
    v128,
   v256,
    . . .
PagingOrigin ::= ENUMERATED {
    non-3gpp,
    . . .
PagingPriority ::= ENUMERATED {
    priolevel1,
   priolevel2,
   priolevel3,
   priolevel4,
   priolevel5,
   priolevel6,
   priolevel7,
   priolevel8,
PathSwitchRequestAcknowledgeTransfer ::= SEQUENCE {
    uL-NGU-UP-TNLInformation
                                    UPTransportLayerInformation
                                                                                                      OPTIONAL,
    securityIndication
                                    SecurityIndication
                                                                                                      OPTIONAL,
                        ProtocolExtensionContainer { {PathSwitchRequestAcknowledgeTransfer-ExtIEs} } OPTIONAL,
   iE-Extensions
PathSwitchRequestAcknowledgeTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    { ID id-AdditionalNGU-UP-TNLInformation CRITICALITY ignore EXTENSION UPTransportLayerInformationPairList
                                                                                                                  PRESENCE optional },
PathSwitchRequestSetupFailedTransfer ::= SEQUENCE {
```

```
cause
   iE-Extensions
                       ProtocolExtensionContainer { {PathSwitchRequestSetupFailedTransfer-ExtIEs} } OPTIONAL,
PathSwitchRequestSetupFailedTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PathSwitchRequestTransfer ::= SEQUENCE
   dL-NGU-UP-TNLInformation
                                      UPTransportLayerInformation,
   dL-NGU-TNLInformationReused
                                       DL-NGU-TNLInformationReused
                                                                                         OPTIONAL,
   userPlaneSecurityInformation
                                      UserPlaneSecurityInformation
                                                                                         OPTIONAL,
    qosFlowAcceptedList
                                       QosFlowAcceptedList,
                       iE-Extensions
                                                                                         OPTIONAL,
PathSwitchRequestTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    { ID id-AdditionalDLQosFlowPerTNLInformation
                                                  CRITICALITY ignore EXTENSION QosflowPerTNLInformationList PRESENCE optional },
    . . .
PathSwitchRequestUnsuccessfulTransfer ::= SEQUENCE
    cause
                       Cause,
   iE-Extensions
                       ProtocolExtensionContainer { {PathSwitchRequestUnsuccessfulTransfer-ExtIEs} } OPTIONAL,
    . . .
PathSwitchRequestUnsuccessfulTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    . . .
PDUSessionAggregateMaximumBitRate ::= SEQUENCE {
   pDUSessionAggregateMaximumBitRateDL
                                          BitRate,
   pDUSessionAggregateMaximumBitRateUL
                                          BitRate,
                       ProtocolExtensionContainer { {PDUSessionAggregateMaximumBitRate-ExtIEs} } OPTIONAL,
   iE-Extensions
    . . .
PDUSessionAggregateMaximumBitRate-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionID ::= INTEGER (0..255)
PDUSessionResourceAdmittedList ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceAdmittedItem
PDUSessionResourceAdmittedItem ::= SEQUENCE
   pDUSessionID
   handoverRequestAcknowledgeTransfer
                                          OCTET STRING (CONTAINING HandoverRequestAcknowledgeTransfer),
   iE-Extensions
                       ProtocolExtensionContainer { {PDUSessionResourceAdmittedItem-ExtIEs} } OPTIONAL,
```

```
PDUSessionResourceAdmittedItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceFailedToModifyListModCfm ::= SEOUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceFailedToModifyItemModCfm
PDUSessionResourceFailedToModifyItemModCfm ::= SEOUENCE {
    pDUSessionID
                                                                PDUSessionID,
    pDUSessionResourceModifyIndicationUnsuccessfulTransfer
                                                                OCTET STRING (CONTAINING PDUSessionResourceModifyIndicationUnsuccessfulTransfer),
                        ProtocolExtensionContainer { {PDUSessionResourceFailedToModifyItemModCfm-ExtIEs} } OPTIONAL,
    . . .
PDUSessionResourceFailedToModifyItemModCfm-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceFailedToModifyListModRes ::= SEOUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceFailedToModifyItemModRes
PDUSessionResourceFailedToModifyItemModRes ::= SEQUENCE {
    pDUSessionID
    pDUSessionResourceModifyUnsuccessfulTransfer
                                                        OCTET STRING (CONTAINING PDUSessionResourceModifyUnsuccessfulTransfer),
   iE-Extensions
                       ProtocolExtensionContainer { {PDUSessionResourceFailedToModifyItemModRes-ExtIEs} } OPTIONAL,
PDUSessionResourceFailedToModifyItemModRes-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceFailedToSetupListCxtFail ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceFailedToSetupLtemCxtFail
PDUSessionResourceFailedToSetupItemCxtFail ::= SEQUENCE {
    pDUSessionID
                                                    PDUSessionID,
    pDUSessionResourceSetupUnsuccessfulTransfer
                                                    OCTET STRING (CONTAINING PDUSessionResourceSetupUnsuccessfulTransfer),
                        ProtocolExtensionContainer { {PDUSessionResourceFailedToSetupItemCxtFail-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
PDUSessionResourceFailedToSetupItemCxtFail-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceFailedToSetupListCxtRes ::= SEOUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceFailedToSetupItemCxtRes
PDUSessionResourceFailedToSetupItemCxtRes ::= SEOUENCE {
    pDUSessionID
                                                    PDUSessionID.
    pDUSessionResourceSetupUnsuccessfulTransfer
                                                    OCTET STRING (CONTAINING PDUSessionResourceSetupUnsuccessfulTransfer),
    iE-Extensions
                        ProtocolExtensionContainer { {PDUSessionResourceFailedToSetupItemCxtRes-ExtIEs} } OPTIONAL,
PDUSessionResourceFailedToSetupItemCxtRes-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
```

```
PDUSessionResourceFailedToSetupListHOAck ::= SEOUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceFailedToSetupLtemHOAck
PDUSessionResourceFailedToSetupItemHOAck ::= SEOUENCE {
    pDUSessionID
                                                        PDUSessionID,
    handoverResourceAllocationUnsuccessfulTransfer
                                                        OCTET STRING (CONTAINING HandoverResourceAllocationUnsuccessfulTransfer),
                       ProtocolExtensionContainer { {PDUSessionResourceFailedToSetupItemHOAck-ExtIEs} } OPTIONAL,
PDUSessionResourceFailedToSetupItemHOAck-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceFailedToSetupListPSReq ::= SEOUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceFailedToSetupLtemPSReq
PDUSessionResourceFailedToSetupItemPSReq ::= SEQUENCE {
    pDUSessionID
    pathSwitchRequestSetupFailedTransfer
                                               OCTET STRING (CONTAINING PathSwitchRequestSetupFailedTransfer),
                       ProtocolExtensionContainer { {PDUSessionResourceFailedToSetupItemPSReq-ExtIEs} } OPTIONAL,
    iE-Extensions
PDUSessionResourceFailedToSetupItemPSReq-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceFailedToSetupListSURes ::= SEOUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceFailedToSetupLtemSURes
PDUSessionResourceFailedToSetupItemSURes ::= SEQUENCE {
                                                    PDUSessionID,
    pDUSessionID
                                                   OCTET STRING (CONTAINING PDUSessionResourceSetupUnsuccessfulTransfer),
   pDUSessionResourceSetupUnsuccessfulTransfer
                       ProtocolExtensionContainer { {PDUSessionResourceFailedToSetupItemSURes-ExtIEs} } OPTIONAL,
PDUSessionResourceFailedToSetupItemSURes-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceHandoverList ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceHandoverItem
PDUSessionResourceHandoverItem ::= SEOUENCE {
    pDUSessionID
                                       PDUSessionID,
    handoverCommandTransfer
                                       OCTET STRING (CONTAINING HandoverCommandTransfer),
    iE-Extensions
                       ProtocolExtensionContainer { {PDUSessionResourceHandoverItem-ExtIEs} } OPTIONAL,
PDUSessionResourceHandoverItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
```

```
PDUSessionResourceInformationList ::= SEOUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceInformationItem
PDUSessionResourceInformationItem ::= SEQUENCE {
   pDUSessionID
                                 PDUSessionID.
                                 OosFlowInformationList,
   gosFlowInformationList
   dRBsToOosFlowsMappingList
                                 DRBsToOosFlowsMappingList
                                                                                            OPTIONAL.
   iE-Extensions
                      ProtocolExtensionContainer { {PDUSessionResourceInformationItem-ExtIEs} } OPTIONAL,
PDUSessionResourceInformationItem-ExtlEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceListCxtRelCpl ::= SEOUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceItemCxtRelCpl
PDUSessionResourceItemCxtRelCpl ::= SEQUENCE {
   pDUSessionID
                      PDUSessionID,
   iE-Extensions
                      ProtocolExtensionContainer { {PDUSessionResourceItemCxtRelCpl-ExtIEs} } OPTIONAL,
PDUSessionResourceItemCxtRelCpl-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
   PDUSessionResourceReleaseResponseTransfer) PRESENCE optional },
PDUSessionResourceListCxtRelReq ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceItemCxtRelReq
PDUSessionResourceItemCxtRelReq ::= SEQUENCE {
   pDUSessionID
                      PDUSessionID,
                      ProtocolExtensionContainer { {PDUSessionResourceItemCxtRelReq-ExtIEs} } OPTIONAL,
   iE-Extensions
PDUSessionResourceItemCxtRelReq-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceListHORqd ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceItemHORqd
PDUSessionResourceItemHORqd ::= SEQUENCE {
   pDUSessionID
                                         PDUSessionID.
   handoverRequiredTransfer
                                         OCTET STRING (CONTAINING HandoverRequiredTransfer),
   iE-Extensions ProtocolExtensionContainer { {PDUSessionResourceItemHORqd-ExtIEs} } OPTIONAL,
PDUSessionResourceItemHORqd-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
```

```
PDUSessionResourceModifyConfirmTransfer ::= SEOUENCE {
   gosFlowModifyConfirmList
                                     OosFlowModifyConfirmList,
   uLNGU-UP-TNLInformation
                                     UPTransportLaverInformation.
   additionalNG-UUPTNLInformation
                                     UPTransportLayerInformationPairList
                                                                                                OPTIONAL.
   gosFlowFailedToModifyList
                                     OosFlowListWithCause
                                                                                                OPTIONAL.
                      ProtocolExtensionContainer { {PDUSessionResourceModifyConfirmTransfer-ExtIEs} } OPTIONAL,
   iE-Extensions
   . . .
PDUSessionResourceModifyConfirmTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceModifyIndicationUnsuccessfulTransfer ::= SEQUENCE {
                      Cause,
   iE-Extensions
                      ProtocolExtensionContainer { {PDUSessionResourceModifyIndicationUnsuccessfulTransfer-ExtIEs} }
                                                                                                                 OPTIONAL.
PDUSessionResourceModifyIndicationUnsuccessfulTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceModifyRequestTransfer ::= SEOUENCE {
   protocolIEs
                  ProtocolIE-Container
                                            { {PDUSessionResourceModifyRequestTransferIEs} },
   . . .
PDUSessionResourceModifyRequestTransferIEs NGAP-PROTOCOL-IES ::= 
     PRESENCE optional
     ID id-UL-NGU-UP-TNLModifyList
                                            CRITICALITY reject TYPE UL-NGU-UP-TNLModifyList
                                                                                                      PRESENCE optional
     ID id-NetworkInstance
                                            CRITICALITY reject TYPE NetworkInstance
                                                                                                      PRESENCE optional
     ID id-QosFlowAddOrModifyRequestList
                                            CRITICALITY reject TYPE QosFlowAddOrModifyRequestList
                                                                                                      PRESENCE optional
                                                                                                      PRESENCE optional
     ID id-QosFlowToReleaseList
                                            CRITICALITY reject TYPE QosFlowListWithCause
     ID id-AdditionalUL-NGU-UP-TNLInformation CRITICALITY reject TYPE UPTransportLayerInformationList
                                                                                                      PRESENCE optional
     ID id-CommonNetworkInstance
                                            CRITICALITY ignore TYPE CommonNetworkInstance
                                                                                                      PRESENCE optional
PDUSessionResourceModifyResponseTransfer ::= SEQUENCE
   dL-NGU-UP-TNLInformation
                                         UPTransportLayerInformation
                                                                                                   OPTIONAL,
   uL-NGU-UP-TNLInformation
                                         UPTransportLayerInformation
                                                                                                   OPTIONAL,
   qosFlowAddOrModifyResponseList
                                         QosFlowAddOrModifyResponseList
                                                                                                   OPTIONAL,
   additionalDLQosFlowPerTNLInformation
                                         OosFlowPerTNLInformationList
                                                                                                   OPTIONAL,
   gosFlowFailedToAddOrModifvList
                                         OosFlowListWithCause
                                                                                                   OPTIONAL,
                      iE-Extensions
                                                                                                   OPTIONAL,
   . . .
PDUSessionResourceModifyResponseTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    { ID id-AdditionalNGU-UP-TNLInformation CRITICALITY ignore EXTENSION UPTransportLayerInformationPairList PRESENCE optional },
    . . .
```

```
PDUSessionResourceModifyIndicationTransfer ::= SEQUENCE {
    dLOosFlowPerTNLInformation
                                                OosFlowPerTNLInformation,
    additional DLOosFlowPerTNLInformation
                                                OosFlowPerTNLInformationList
                                                                                                            OPTIONAL.
    iE-Extensions
                        ProtocolExtensionContainer { {PDUSessionResourceModifyIndicationTransfer-ExtIEs} } OPTIONAL,
    . . .
PDUSessionResourceModifyIndicationTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
      ID id-SecondaryRATUsageInformation
                                                CRITICALITY ignore EXTENSION SecondaryRATUsageInformation
                                                                                                              PRESENCE optional } |
                                                CRITICALITY ignore EXTENSION SecurityResult
                                                                                                              PRESENCE optional },
     ID id-SecurityResult
PDUSessionResourceModifyListModCfm ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceModifyItemModCfm
PDUSessionResourceModifyItemModCfm ::= SEQUENCE {
    pDUSessionID
                                                PDUSessionID,
    pDUSessionResourceModifyConfirmTransfer
                                                OCTET STRING (CONTAINING PDUSessionResourceModifyConfirmTransfer),
                        ProtocolExtensionContainer { { PDUSessionResourceModifyItemModCfm-ExtIEs} } OPTIONAL,
    . . .
PDUSessionResourceModifyItemModCfm-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    . . .
PDUSessionResourceModifyListModInd ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceModifyItemModInd
PDUSessionResourceModifyItemModInd ::= SEQUENCE {
    pDUSessionID
                                                    PDUSessionID,
                                                    OCTET STRING (CONTAINING PDUSessionResourceModifyIndicationTransfer),
    pDUSessionResourceModifyIndicationTransfer
                        ProtocolExtensionContainer { {PDUSessionResourceModifyItemModInd-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
PDUSessionResourceModifyItemModInd-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceModifyListModReq ::= SEOUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceModifyItemModReq
PDUSessionResourceModifyItemModReg ::= SEQUENCE {
    pDUSessionID
                                                PDUSessionID,
    nAS-PDU
                                                NAS-PDU
                                                                                                      OPTIONAL,
                                                OCTET STRING (CONTAINING PDUSessionResourceModifyRequestTransfer),
    pDUSessionResourceModifyRequestTransfer
    iE-Extensions
                        ProtocolExtensionContainer { {PDUSessionResourceModifyItemModReq-ExtIEs} } OPTIONAL,
    . . .
PDUSessionResourceModifyItemModReg-ExtIEs NGAP-PROTOCOL-EXTENSION ::=
    {ID id-S-NSSAI
                        CRITICALITY reject EXTENSION S-NSSAI
                                                                     PRESENCE optional
    . . .
```

```
PDUSessionResourceModifyListModRes ::= SEOUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceModifyItemModRes
PDUSessionResourceModifyItemModRes ::= SEQUENCE {
    pDUSessionID
                                                    PDUSessionID,
    pDUSessionResourceModifyResponseTransfer
                                                    OCTET STRING (CONTAINING PDUSessionResourceModifyResponseTransfer),
                        ProtocolExtensionContainer { {PDUSessionResourceModifyItemModRes-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
PDUSessionResourceModifyItemModRes-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceModifyUnsuccessfulTransfer ::= SEQUENCE {
    criticalityDiagnostics
                                CriticalityDiagnostics
                                                                                                              OPTIONAL,
                        ProtocolExtensionContainer { {PDUSessionResourceModifyUnsuccessfulTransfer-ExtIEs} } OPTIONAL,
    iE-Extensions
PDUSessionResourceModifyUnsuccessfulTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceNotifyList ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceNotifyItem
PDUSessionResourceNotifyItem ::= SEQUENCE {
    pDUSessionID
                                        PDUSessionID,
    pDUSessionResourceNotifyTransfer
                                        OCTET STRING (CONTAINING PDUSessionResourceNotifyTransfer),
                        ProtocolExtensionContainer { {PDUSessionResourceNotifyItem-ExtIEs} }
    . . .
PDUSessionResourceNotifyItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceNotifyReleasedTransfer ::= SEQUENCE {
    cause
    iE-Extensions
                        ProtocolExtensionContainer { {PDUSessionResourceNotifyReleasedTransfer-ExtIEs} }
    . . .
PDUSessionResourceNotifyReleasedTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    { ID id-SecondaryRATUsageInformation
                                                CRITICALITY ignore EXTENSION SecondaryRATUsageInformation PRESENCE optional },
PDUSessionResourceNotifyTransfer ::= SEQUENCE {
    qosFlowNotifyList
                            OosFlowNotifyList
                                                                                                   OPTIONAL,
    gosFlowReleasedList
                            QosFlowListWithCause
                                                                                                   OPTIONAL,
    iE-Extensions
                        ProtocolExtensionContainer { {PDUSessionResourceNotifyTransfer-ExtIEs} } OPTIONAL,
```

```
PDUSessionResourceNotifyTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    { ID id-SecondaryRATUsageInformation
                                               CRITICALITY ignore EXTENSION SecondaryRATUsageInformation PRESENCE optional },
PDUSessionResourceReleaseCommandTransfer ::= SEQUENCE {
    iE-Extensions
                        ProtocolExtensionContainer { {PDUSessionResourceReleaseCommandTransfer-ExtIEs} } OPTIONAL,
PDUSessionResourceReleaseCommandTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceReleasedListNot ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceReleasedItemNot
PDUSessionResourceReleasedItemNot ::= SEQUENCE {
    pDUSessionID
                                                    PDUSessionID,
   pDUSessionResourceNotifyReleasedTransfer
                                                   OCTET STRING (CONTAINING PDUSessionResourceNotifyReleasedTransfer),
                       ProtocolExtensionContainer { {PDUSessionResourceReleasedItemNot-ExtIEs} } OPTIONAL,
    iE-Extensions
PDUSessionResourceReleasedItemNot-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceReleasedListPSAck ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceReleasedItemPSAck
PDUSessionResourceReleasedItemPSAck ::= SEQUENCE {
    pDUSessionID
                                                PDUSessionID,
                                                OCTET STRING (CONTAINING PathSwitchRequestUnsuccessfulTransfer),
    pathSwitchRequestUnsuccessfulTransfer
                       ProtocolExtensionContainer { {PDUSessionResourceReleasedItemPSAck-ExtIEs} } OPTIONAL,
PDUSessionResourceReleasedItemPSAck-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceReleasedListPSFail ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceReleasedItemPSFail
PDUSessionResourceReleasedItemPSFail ::= SEOUENCE {
    pDUSessionID
                                                PDUSessionID,
   pathSwitchRequestUnsuccessfulTransfer
                                                OCTET STRING (CONTAINING PathSwitchRequestUnsuccessfulTransfer),
    iE-Extensions
                       ProtocolExtensionContainer { {PDUSessionResourceReleasedItemPSFail-ExtIEs} } OPTIONAL,
PDUSessionResourceReleasedItemPSFail-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
```

```
PDUSessionResourceReleasedListRelRes ::= SEOUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceReleasedItemRelRes
PDUSessionResourceReleasedItemRelRes ::= SEQUENCE {
                                                    PDUSessionID.
    pDUSessionID
    pDUSessionResourceReleaseResponseTransfer
                                                    OCTET STRING (CONTAINING PDUSessionResourceReleaseResponseTransfer),
                       ProtocolExtensionContainer { {PDUSessionResourceReleasedItemRelRes-ExtIEs} } OPTIONAL,
    iE-Extensions
PDUSessionResourceReleasedItemRelRes-ExtIEs NGAP-PROTOCOL-EXTENSION ::=
PDUSessionResourceReleaseResponseTransfer ::= SEQUENCE {
    iE-Extensions
                        ProtocolExtensionContainer { {PDUSessionResourceReleaseResponseTransfer-ExtIEs} } OPTIONAL,
    . . .
PDUSessionResourceReleaseResponseTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    { ID id-SecondaryRATUsageInformation
                                               CRITICALITY ignore EXTENSION SecondaryRATUsageInformation PRESENCE optional },
    . . .
PDUSessionResourceSecondaryRATUsageList ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceSecondaryRATUsageItem
PDUSessionResourceSecondaryRATUsageItem ::= SEQUENCE {
    pDUSessionID
                                            PDUSessionID,
    secondaryRATDataUsageReportTransfer
                                            OCTET STRING (CONTAINING SecondaryRATDataUsageReportTransfer),
                        ProtocolExtensionContainer { {PDUSessionResourceSecondaryRATUsageItem-ExtIEs} } OPTIONAL,
    iE-Extensions
PDUSessionResourceSecondaryRATUsageItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceSetupListCxtReq ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceSetupItemCxtReq
PDUSessionResourceSetupItemCxtReg ::= SEQUENCE {
    pDUSessionID
                                                PDUSessionID,
    nAS-PDU
                                                NAS-PDU
                                                                                                  OPTIONAL,
    s-NSSAI
                                                S-NSSAI,
                                                OCTET STRING (CONTAINING PDUSessionResourceSetupRequestTransfer),
    pDUSessionResourceSetupRequestTransfer
                        ProtocolExtensionContainer { {PDUSessionResourceSetupItemCxtReq-ExtIEs} } OPTIONAL,
    iE-Extensions
PDUSessionResourceSetupItemCxtReq-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceSetupListCxtRes ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceSetupItemCxtRes
```

```
PDUSessionResourceSetupItemCxtRes ::= SEQUENCE {
    pDUSessionID
                                                PDUSessionID,
    pDUSessionResourceSetupResponseTransfer
                                                OCTET STRING (CONTAINING PDUSessionResourceSetupResponseTransfer),
    iE-Extensions
                        ProtocolExtensionContainer { {PDUSessionResourceSetupItemCxtRes-ExtIEs} } OPTIONAL,
PDUSessionResourceSetupItemCxtRes-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceSetupListHOReq ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceSetupItemHOReq
PDUSessionResourceSetupItemHOReq ::= SEQUENCE {
    pDUSessionID
                                PDUSessionID,
    s-NSSAI
                                S-NSSAI,
                                OCTET STRING (CONTAINING PDUSessionResourceSetupRequestTransfer),
    handoverRequestTransfer
                        ProtocolExtensionContainer { {PDUSessionResourceSetupItemHOReq-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
PDUSessionResourceSetupItemHOReq-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceSetupListSUReq ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceSetupItemSUReq
PDUSessionResourceSetupItemSUReg ::= SEQUENCE {
    pDUSessionID
                                                PDUSessionID,
   pDUSessionNAS-PDU
                                                NAS-PDU
                                                                                                   OPTIONAL,
    s-NSSAI
                                                S-NSSAI,
    pDUSessionResourceSetupRequestTransfer
                                                OCTET STRING (CONTAINING PDUSessionResourceSetupRequestTransfer),
   iE-Extensions
                        ProtocolExtensionContainer { {PDUSessionResourceSetupItemSUReq-ExtIEs} } OPTIONAL,
    . . .
PDUSessionResourceSetupItemSUReq-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceSetupListSURes ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceSetupItemSURes
PDUSessionResourceSetupItemSURes ::= SEQUENCE {
    pDUSessionID
                                                            PDUSessionID,
                                                            OCTET STRING (CONTAINING PDUSessionResourceSetupResponseTransfer),
    pDUSessionResourceSetupResponseTransfer
    iE-Extensions
                        ProtocolExtensionContainer { {PDUSessionResourceSetupItemSURes-ExtIEs} } OPTIONAL,
    . . .
PDUSessionResourceSetupItemSURes-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceSetupRequestTransfer ::= SEQUENCE {
```

```
{ {PDUSessionResourceSetupRequestTransferIEs} },
   protocolIEs
                  ProtocolIE-Container
PDUSessionResourceSetupRequestTransferIEs NGAP-PROTOCOL-IES ::= {
     PRESENCE optional
     ID id-UL-NGU-UP-TNLInformation
                                            CRITICALITY reject TYPE UPTransportLayerInformation
                                                                                                     PRESENCE mandatory
     ID id-AdditionalUL-NGU-UP-TNLInformation CRITICALITY reject TYPE UPTransportLayerInformationList
                                                                                                     PRESENCE optional
     ID id-DataForwardingNotPossible
                                            CRITICALITY reject TYPE DataForwardingNotPossible
                                                                                                     PRESENCE optional
     ID id-PDUSessionType
                                            CRITICALITY reject TYPE PDUSessionType
                                                                                                     PRESENCE mandatory
     ID id-SecurityIndication
                                                                                                     PRESENCE optional
                                            CRITICALITY reject TYPE SecurityIndication
     ID id-NetworkInstance
                                            CRITICALITY reject TYPE NetworkInstance
                                                                                                     PRESENCE optional
     ID id-QosFlowSetupRequestList
                                            CRITICALITY reject TYPE QosFlowSetupRequestList
                                                                                                     PRESENCE mandatory
     ID id-CommonNetworkInstance
                                            CRITICALITY ignore TYPE CommonNetworkInstance
                                                                                                     PRESENCE optional },
PDUSessionResourceSetupResponseTransfer ::= SEQUENCE {
   dLOosFlowPerTNLInformation
                                        OosFlowPerTNLInformation,
   additionalDLQosFlowPerTNLInformation
                                        QosFlowPerTNLInformationList
                                                                                                  OPTIONAL,
   securityResult
                                        SecurityResult
                                                                                                  OPTIONAL,
   gosFlowFailedToSetupList
                                        QosFlowListWithCause
                                                                                                  OPTIONAL,
                      ProtocolExtensionContainer { {PDUSessionResourceSetupResponseTransfer-ExtIEs} }
   iE-Extensions
                                                                                                  OPTIONAL,
   . . .
PDUSessionResourceSetupResponseTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceSetupUnsuccessfulTransfer ::= SEQUENCE {
                             Cause,
   criticalityDiagnostics
                             CriticalityDiagnostics
                                                                                                     OPTIONAL.
                      iE-Extensions
                                                                                                     OPTIONAL,
   . . .
PDUSessionResourceSetupUnsuccessfulTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceSwitchedList ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceSwitchedItem
PDUSessionResourceSwitchedItem ::= SEQUENCE {
   pDUSessionID
                                            PDUSessionID.
   pathSwitchRequestAcknowledgeTransfer
                                            OCTET STRING (CONTAINING PathSwitchRequestAcknowledgeTransfer),
                      ProtocolExtensionContainer { { PDUSessionResourceSwitchedItem-ExtIEs} } OPTIONAL,
PDUSessionResourceSwitchedItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
```

```
PDUSessionResourceToBeSwitchedDLList ::= SEOUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceToBeSwitchedDLItem
PDUSessionResourceToBeSwitchedDLItem ::= SEOUENCE {
    pDUSessionID
                                    PDUSessionID,
   pathSwitchRequestTransfer
                                    OCTET STRING (CONTAINING PathSwitchRequestTransfer),
                        ProtocolExtensionContainer { { PDUSessionResourceToBeSwitchedDLItem-ExtIEs} } OPTIONAL,
   iE-Extensions
    . . .
PDUSessionResourceToBeSwitchedDLItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionResourceToReleaseListHOCmd ::= SEOUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceToReleaseItemHOCmd
PDUSessionResourceToReleaseItemHOCmd ::= SEQUENCE {
    pDUSessionID
                                                PDUSessionID,
    handoverPreparationUnsuccessfulTransfer
                                                OCTET STRING (CONTAINING HandoverPreparationUnsuccessfulTransfer),
                        ProtocolExtensionContainer { {PDUSessionResourceToReleaseItemHOCmd-ExtIEs} } OPTIONAL,
    . . .
PDUSessionResourceToReleaseItemHOCmd-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    . . .
PDUSessionResourceToReleaseListRelCmd ::= SEQUENCE (SIZE(1..maxnoofPDUSessions)) OF PDUSessionResourceToReleaseItemRelCmd
PDUSessionResourceToReleaseItemRelCmd ::= SEQUENCE {
    pDUSessionID
                                                    PDUSessionID,
                                                    OCTET STRING (CONTAINING PDUSessionResourceReleaseCommandTransfer),
    pDUSessionResourceReleaseCommandTransfer
                        ProtocolExtensionContainer { {PDUSessionResourceToReleaseItemRelCmd-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
PDUSessionResourceToReleaseItemRelCmd-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PDUSessionType ::= ENUMERATED {
    ipv4,
    ipv6,
    ipv4v6,
    ethernet,
    unstructured,
    . . .
PDUSessionUsageReport ::= SEQUENCE {
                                        ENUMERATED {nr, eutra, ...},
   rATType
   pDUSessionTimedReportList
                                        VolumeTimedReportList,
                        ProtocolExtensionContainer { {PDUSessionUsageReport-ExtIEs} } OPTIONAL,
    iE-Extensions
```

```
PDUSessionUsageReport-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PeriodicRegistrationUpdateTimer ::= BIT STRING (SIZE(8))
PLMNIdentity ::= OCTET STRING (SIZE(3))
PLMNSupportList ::= SEQUENCE (SIZE(1..maxnoofPLMNs)) OF PLMNSupportItem
PLMNSupportItem ::= SEQUENCE {
                            PLMNIdentity,
    pLMNIdentity
                            SliceSupportList,
    sliceSupportList
    iE-Extensions
                        ProtocolExtensionContainer { {PLMNSupportItem-ExtIEs} } OPTIONAL,
PLMNSupportItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
PortNumber ::= OCTET STRING (SIZE(2))
Pre-emptionCapability ::= ENUMERATED {
    shall-not-trigger-pre-emption,
    may-trigger-pre-emption,
    . . .
Pre-emptionVulnerability ::= ENUMERATED {
    not-pre-emptable,
    pre-emptable,
    . . .
PriorityLevelARP ::= INTEGER (1..15)
PriorityLevelOos ::= INTEGER (1..127, ...)
PWSFailedCellIDList ::= CHOICE {
                                EUTRA-CGIList,
    eUTRA-CGI-PWSFailedList
    nR-CGI-PWSFailedList
                                NR-CGIList,
    choice-Extensions
                            ProtocolIE-SingleContainer { {PWSFailedCellIDList-ExtIEs} }
PWSFailedCellIDList-ExtIEs NGAP-PROTOCOL-IES ::= {
-- Q
QosCharacteristics ::= CHOICE {
    nonDynamic5QI
                       NonDynamic5QIDescriptor,
    dynamic5QI
                        Dynamic5QIDescriptor,
```

```
ProtocolIE-SingleContainer { {OosCharacteristics-ExtIEs} }
    choice-Extensions
QosCharacteristics-ExtIEs NGAP-PROTOCOL-IES ::= {
QosFlowAcceptedList ::= SEQUENCE (SIZE(1..maxnoofQosFlows)) OF QosFlowAcceptedItem
QosFlowAcceptedItem ::= SEQUENCE {
    gosFlowIdentifier
                            QosFlowIdentifier,
                        ProtocolExtensionContainer { {QosFlowAcceptedItem-ExtIEs} } OPTIONAL,
    iE-Extensions
OosFlowAcceptedItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
QosFlowAddOrModifyRequestList ::= SEQUENCE (SIZE(1..maxnoofQosFlows)) OF QosFlowAddOrModifyRequestItem
QosFlowAddOrModifyRequestItem ::= SEQUENCE {
    gosFlowIdentifier
                                    QosFlowIdentifier,
    qosFlowLevelQosParameters
                                    OosFlowLevelOosParameters
                                                                                                 OPTIONAL.
                                    E-RAB-ID
                                                                                                 OPTIONAL,
    e-RAB-ID
                        ProtocolExtensionContainer { QosFlowAddOrModifyRequestItem-ExtIEs} }
    iE-Extensions
                                                                                                OPTIONAL,
    . . .
OosflowAddOrModifyRequestItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    . . .
QosFlowAddOrModifyResponseList ::= SEQUENCE (SIZE(1..maxnoofQosFlows)) OF QosFlowAddOrModifyResponseItem
QosFlowAddOrModifyResponseItem ::= SEQUENCE {
    qosFlowIdentifier
                            QosFlowIdentifier,
                        ProtocolExtensionContainer { {OosFlowAddOrModifyResponseItem-ExtIEs} } OPTIONAL,
    iE-Extensions
OosflowAddOrModifyResponseItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
QosFlowIdentifier ::= INTEGER (0..63, ...)
QosFlowInformationList ::= SEQUENCE (SIZE(1..maxnoofQosFlows)) OF QosFlowInformationItem
OosFlowInformationItem ::= SEQUENCE {
    qosFlowIdentifier QosFlowIdentifier,
    dLForwarding
                        DLForwarding
                                                                                        OPTIONAL,
    iE-Extensions
                        ProtocolExtensionContainer { {QosFlowInformationItem-ExtIEs} } OPTIONAL,
    . . .
```

```
OosFlowInformationItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    {ID id-ULForwarding CRITICALITY reject EXTENSION ULForwarding PRESENCE optional},
    . . .
QosFlowLevelQosParameters ::= SEQUENCE {
    qosCharacteristics
                                        QosCharacteristics,
    allocationAndRetentionPriority
                                        AllocationAndRetentionPriority,
    gBR-QosInformation
                                        GBR-QosInformation
                                                                                             OPTIONAL,
    reflectiveQosAttribute
                                        ReflectiveQosAttribute
                                                                                             OPTIONAL,
                                        AdditionalQosFlowInformation
    additionalQosFlowInformation
                                                                                             OPTIONAL,
    iE-Extensions
                        ProtocolExtensionContainer { {QosFlowLevelQosParameters-ExtIEs} }
                                                                                            OPTIONAL,
OosFlowLevelOosParameters-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
QosFlowListWithCause ::= SEQUENCE (SIZE(1..maxnoofQosFlows)) OF QosFlowWithCauseItem
QosFlowWithCauseItem ::= SEQUENCE {
    qosFlowIdentifier
                            QosFlowIdentifier,
    cause
                            Cause,
                        ProtocolExtensionContainer { {OosFlowWithCauseItem-ExtIEs} } OPTIONAL,
    iE-Extensions
QosflowWithCauseItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
QosFlowModifyConfirmList ::= SEQUENCE (SIZE(1..maxnoofQosFlows)) OF QosFlowModifyConfirmItem
QosFlowModifyConfirmItem ::= SEQUENCE {
    gosFlowIdentifier
                            OosFlowIdentifier,
    iE-Extensions
                        ProtocolExtensionContainer { QosFlowModifyConfirmItem-ExtIEs} }
                                                                                             OPTIONAL,
    . . .
QosFlowModifyConfirmItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
QosFlowNotifyList ::= SEQUENCE (SIZE(1..maxnoofQosFlows)) OF QosFlowNotifyItem
QosFlowNotifyItem ::= SEQUENCE {
    gosFlowIdentifier
                                OosFlowIdentifier,
   notificationCause
                                NotificationCause,
   iE-Extensions
                        ProtocolExtensionContainer { QosFlowNotifyItem-ExtIEs} }
```

```
OosFlowNotifyItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
OosFlowPerTNLInformation ::= SEOUENCE {
    uPTransportLayerInformation
                                   UPTransportLayerInformation,
    associatedOosFlowList
                                   AssociatedOosFlowList,
    iE-Extensions
                       ProtocolExtensionContainer { { QosFlowPerTNLInformation-ExtIEs} }
                                                                                            OPTIONAL,
OosFlowPerTNLInformation-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
OosFlowPerTNLInformationList ::= SEOUENCE (SIZE(1..maxnoofMultiConnectivityMinusOne)) OF OosFlowPerTNLInformationItem
OosFlowPerTNLInformationItem ::= SEQUENCE {
    qosFlowPerTNLInformation
                                            QosFlowPerTNLInformation,
    iE-Extensions
                        ProtocolExtensionContainer { { QosFlowPerTNLInformationItem-ExtIEs} }
                                                                                                OPTIONAL,
QosFlowPerTNLInformationItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
OosFlowSetupRequestList ::= SEQUENCE (SIZE(1..maxnoofOosFlows)) OF OosFlowSetupRequestItem
QosFlowSetupRequestItem ::= SEQUENCE {
    gosFlowIdentifier
                                   QosFlowIdentifier,
    qosFlowLevelQosParameters
                                   QosFlowLevelQosParameters,
    e-RAB-ID
                                    E-RAB-ID
                                                                                        OPTIONAL,
    iE-Extensions
                    ProtocolExtensionContainer { {QosFlowSetupRequestItem-ExtIEs} } OPTIONAL,
OosFlowSetupRequestItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
QosFlowListWithDataForwarding ::= SEQUENCE (SIZE(1..maxnoofQosFlows)) OF QosFlowItemWithDataForwarding
QosFlowItemWithDataForwarding ::= SEQUENCE {
    gosFlowIdentifier
                                QosFlowIdentifier,
    dataForwardingAccepted
                                DataForwardingAccepted
                                                                                                OPTIONAL.
    iE-Extensions
                       ProtocolExtensionContainer { QosFlowItemWithDataForwarding-ExtIEs} }
                                                                                                OPTIONAL,
OosflowItemWithDataForwarding-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
```

```
OosFlowSetupResponseListSURes ::= SEOUENCE (SIZE(1..maxnoofOosFlows)) OF OosFlowSetupResponseItemSURes
QosFlowSetupResponseItemSURes ::= SEQUENCE {
    gosFlowIdentifier
                            OosFlowIdentifier,
                        ProtocolExtensionContainer { {OosFlowSetupResponseItemSURes-ExtIEs} } OPTIONAL,
    iE-Extensions
QosFlowSetupResponseItemSURes-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
OosFlowToBeForwardedList ::= SEOUENCE (SIZE(1..maxnoofOosFlows)) OF OosFlowToBeForwardedItem
OosFlowToBeForwardedItem ::= SEQUENCE {
    gosFlowIdentifier
                            OosFlowIdentifier,
    iE-Extensions
                        ProtocolExtensionContainer { {OosFlowToBeForwardedItem-ExtIEs} }
                                                                                            OPTIONAL,
    . . .
QosFlowToBeForwardedItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
QoSFlowsUsageReportList ::= SEQUENCE (SIZE(1..maxnoofQosFlows)) OF QoSFlowsUsageReport-Item
QoSFlowsUsageReport-Item ::= SEQUENCE {
                                        OosFlowIdentifier,
    gosFlowIdentifier
                                        ENUMERATED {nr, eutra, ...},
   rATType
    qoSFlowsTimedReportList
                                        VolumeTimedReportList,
                       ProtocolExtensionContainer { {QoSFlowsUsageReport-Item-ExtIEs} } OPTIONAL,
    iE-Extensions
QoSFlowsUsageReport-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
RANNodeName ::= PrintableString (SIZE(1..150, ...))
RANPagingPriority ::= INTEGER (1..256)
RANStatusTransfer-TransparentContainer ::= SEQUENCE {
    dRBsSubjectToStatusTransferList
                                        DRBsSubjectToStatusTransferList,
                        ProtocolExtensionContainer { {RANStatusTransfer-TransparentContainer-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
RANStatusTransfer-TransparentContainer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
```

```
RAN-UE-NGAP-ID ::= INTEGER (0..4294967295)
RATRESTRICTIONS ::= SEQUENCE (SIZE(1..maxnoofEPLMNsPlusOne)) OF RATRESTRICTIONS-Item
RATRestrictions-Item ::= SEQUENCE {
                                   PLMNIdentity,
   pLMNIdentity
   rATRestrictionInformation
                                   RATRestrictionInformation,
                   ProtocolExtensionContainer { {RATRestrictions-Item-ExtIEs} }
                                                                                          OPTIONAL,
RATRestrictions-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
RATRestrictionInformation ::= BIT STRING (SIZE(8, ...))
RecommendedCellsForPaging ::= SEOUENCE {
    recommendedCellList
                               RecommendedCellList,
   iE-Extensions
                      ProtocolExtensionContainer { {RecommendedCellsForPaging-ExtIEs} } OPTIONAL,
RecommendedCellsForPaging-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
RecommendedCellList ::= SEQUENCE (SIZE(1..maxnoofRecommendedCells)) OF RecommendedCellItem
RecommendedCellItem ::= SEQUENCE {
   nGRAN-CGI
                 NGRAN-CGI,
    timeStayedInCell INTEGER (0..4095)
                                                   OPTIONAL,
   iE-Extensions ProtocolExtensionContainer { {RecommendedCellItem-ExtIEs} } OPTIONAL,
RecommendedCellItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
RecommendedRANNodesForPaging ::= SEQUENCE {
                               RecommendedRANNodeList,
   recommendedRANNodeList
                       ProtocolExtensionContainer { {RecommendedRANNodesForPaging-ExtIEs} }
    iE-Extensions
                                                                                              OPTIONAL,
    . . .
RecommendedRANNodesForPaging-ExtlEs NGAP-PROTOCOL-EXTENSION ::= {
RecommendedRANNodeList::= SEQUENCE (SIZE(1..maxnoofRecommendedRANNodes)) OF RecommendedRANNodeItem
RecommendedRANNodeItem ::= SEQUENCE {
```

```
aMFPagingTarget
                        AMFPagingTarget,
   iE-Extensions
                        ProtocolExtensionContainer { {RecommendedRANNodeItem-ExtIEs} } OPTIONAL,
RecommendedRANNodeItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
RedirectionVoiceFallback ::= ENUMERATED {
    possible,
   not-possible,
    . . .
ReflectiveOosAttribute ::= ENUMERATED {
    subject-to,
ReferenceID ::= INTEGER (1..64, ...)
RelativeAMFCapacity ::= INTEGER (0..255)
ReportArea ::= ENUMERATED {
    cell,
    . . .
RepetitionPeriod ::= INTEGER (0..131071)
ResetAll ::= ENUMERATED {
    reset-all,
    . . .
ResetType ::= CHOICE {
    nG-Interface
                            ResetAll,
    partOfNG-Interface
                            UE-associatedLogicalNG-connectionList,
    choice-Extensions
                            ProtocolIE-SingleContainer { {ResetType-ExtIEs} }
ResetType-ExtIEs NGAP-PROTOCOL-IES ::= {
RoutingID ::= OCTET STRING
RRCContainer ::= OCTET STRING
RRCEstablishmentCause ::= ENUMERATED {
    emergency,
    highPriorityAccess,
    mt-Access,
```

```
mo-Signalling,
   mo-Data,
   mo-VoiceCall.
   mo-VideoCall,
   mo-SMS,
   mps-PriorityAccess,
   mcs-PriorityAccess,
   notAvailable
RRCInactiveTransitionReportRequest ::= ENUMERATED {
   subsequent-state-transition-report,
   single-rrc-connected-state-report,
   cancel-report,
RRCState ::= ENUMERATED {
   inactive,
   connected,
    . . .
-- S
          ::= SEQUENCE (SIZE(1..maxnoofXnTLAs)) OF TransportLayerAddress
SCTP-TLAs
SD ::= OCTET STRING (SIZE(3))
SecondaryRATUsageInformation ::= SEQUENCE {
   pDUSessionUsageReport
                              PDUSessionUsageReport
                                                                                            OPTIONAL,
   qosFlowsUsageReportList
                              QoSFlowsUsageReportList
                                                                                            OPTIONAL,
   iE-Extension
                       OPTIONAL,
    . . .
SecondaryRATUsageInformation-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
SecondaryRATDataUsageReportTransfer ::= SEQUENCE {
   secondaryRATUsageInformation
                                      SecondaryRATUsageInformation
                                                                                                OPTIONAL,
   iE-Extensions
                       ProtocolExtensionContainer { {SecondaryRATDataUsageReportTransfer-ExtIEs} } OPTIONAL,
    . . .
SecondaryRATDataUsageReportTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
SecurityContext ::= SEQUENCE {
   nextHopChainingCount
                              NextHopChainingCount,
   nextHopNH
                              SecurityKey,
```

```
ProtocolExtensionContainer { {SecurityContext-ExtIEs} } OPTIONAL,
    iE-Extensions
SecurityContext-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
SecurityIndication ::= SEQUENCE {
    integrityProtectionIndication
                                            IntegrityProtectionIndication,
    confidentialityProtectionIndication
                                            ConfidentialityProtectionIndication,
    maximumIntegrityProtectedDataRate-UL
                                            MaximumIntegrityProtectedDataRate
                                                                                    OPTIONAL,
-- The above IE shall be present if integrity protection is required or preferred
    iE-Extensions
                        ProtocolExtensionContainer { {SecurityIndication-ExtIEs} } OPTIONAL,
SecurityIndication-ExtIEs NGAP-PROTOCOL-EXTENSION ::=
    { ID id-MaximumIntegrityProtectedDataRate-DL
                                                   CRITICALITY ignore EXTENSION MaximumIntegrityProtectedDataRate PRESENCE optional },
    . . .
SecurityKey ::= BIT STRING (SIZE(256))
SecurityResult ::= SEQUENCE {
    integrityProtectionResult
                                        IntegrityProtectionResult,
                                        ConfidentialityProtectionResult,
    confidentialityProtectionResult
    iE-Extensions
                        ProtocolExtensionContainer { {SecurityResult-ExtIEs} } OPTIONAL,
SecurityResult-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
SerialNumber ::= BIT STRING (SIZE(16))
ServedGUAMIList ::= SEOUENCE (SIZE(1..maxnoofServedGUAMIs)) OF ServedGUAMIItem
ServedGUAMIItem ::= SEQUENCE {
    qUAMI
                        GUAMI,
    backupAMFName
                        AMFName
                                                                                OPTIONAL,
                        ProtocolExtensionContainer { {ServedGUAMIItem-ExtIEs} } OPTIONAL,
    iE-Extensions
ServedGUAMIItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::=
ServiceAreaInformation ::= SEQUENCE (SIZE(1.. maxnoofEPLMNsPlusOne)) OF ServiceAreaInformation-Item
ServiceAreaInformation-Item ::= SEQUENCE {
    pLMNIdentity
                        PLMNIdentity,
```

289

```
allowedTACs
                       AllowedTACs
                                                                                             OPTIONAL,
   notAllowedTACs
                       NotAllowedTACs
                                                                                             OPTIONAL,
   iE-Extensions
                       OPTIONAL,
ServiceAreaInformation-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
SliceOverloadList ::= SEQUENCE (SIZE(1..maxnoofSliceItems)) OF SliceOverloadItem
SliceOverloadItem ::= SEQUENCE
   s-NSSAI
   iE-Extensions
                       ProtocolExtensionContainer { {SliceOverloadItem-ExtIEs} }
                                                                                 OPTIONAL,
    . . .
SliceOverloadItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
SliceSupportList ::= SEQUENCE (SIZE(1..maxnoofSliceItems)) OF SliceSupportItem
SliceSupportItem ::= SEQUENCE -
   s-NSSAI
   iE-Extensions
                       ProtocolExtensionContainer { {SliceSupportItem-ExtIEs} }
                                                                                 OPTIONAL,
    . . .
SliceSupportItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
S-NSSAI ::= SEQUENCE {
   sST
                       SST,
                                                                          OPTIONAL,
   iE\text{-}Extensions
                       ProtocolExtensionContainer { { S-NSSAI-ExtIEs} }
                                                                          OPTIONAL,
S-NSSAI-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
SONConfigurationTransfer ::= SEQUENCE
   targetRANNodeID
                               TargetRANNodeID
   sourceRANNodeID
                               SourceRANNodeID,
   sONInformation
                               SONInformation,
   xnTNLConfigurationInfo
                               XnTNLConfigurationInfo
                                                                                         OPTIONAL,
-- The above IE shall be present if the SON Information IE contains the SON Information Request IE set to "Xn TNL Configuration Info"
   iE-Extensions
                       ProtocolExtensionContainer { {SONConfigurationTransfer-ExtIEs} }
                                                                                         OPTIONAL,
    . . .
```

```
SONConfigurationTransfer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
SONInformation ::= CHOICE {
    sONInformationRequest
                                SONInformationRequest,
    sONInformationReply
                                SONInformationReply,
                            ProtocolIE-SingleContainer { {SONInformation-ExtIEs} }
    choice-Extensions
SONInformation-ExtIEs NGAP-PROTOCOL-IES ::= {
SONInformationReply ::= SEQUENCE {
    xnTNLConfigurationInfo
                                XnTNLConfigurationInfo
                                                                                          OPTIONAL,
                        ProtocolExtensionContainer { {SONInformationReply-ExtIEs} }
    iE-Extensions
                                                                                          OPTIONAL,
    . . .
SONInformationReply-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    . . .
SONInformationRequest ::= ENUMERATED {
    xn-TNL-configuration-info,
    . . .
SourceNGRANNode-ToTargetNGRANNode-TransparentContainer ::= SEQUENCE {
    rRCContainer
                                             RRCContainer,
    pDUSessionResourceInformationList
                                             PDUSessionResourceInformationList
                                                                                                                         OPTIONAL,
    e-RABInformationList
                                             E-RABInformationList
                                                                                                                         OPTIONAL.
    targetCell-ID
                                            NGRAN-CGI,
    indexToRFSP
                                             IndexToRFSP
                                                                                                                         OPTIONAL,
                                             UEHistoryInformation,
    uEHistoryInformation
                        ProtocolExtensionContainer { {SourceNGRANNode-ToTargetNGRANNode-TransparentContainer-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
SourceNGRANNode-ToTargetNGRANNode-TransparentContainer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
SourceOfUEActivityBehaviourInformation ::= ENUMERATED {
    subscription-information,
    statistics.
    . . .
SourceRANNodeID ::= SEQUENCE {
    globalRANNodeID
                        GlobalRANNodeID,
```

```
selectedTAI
    iE-Extensions
                        ProtocolExtensionContainer { {SourceRANNodeID-ExtIEs} } OPTIONAL,
SourceRANNodeID-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
SourceToTarget-TransparentContainer ::= OCTET STRING
-- This IE includes a transparent container from the source RAN node to the target RAN node.
-- The octets of the OCTET STRING are encoded according to the specifications of the target system.
SourceToTarget-AMFInformationReroute ::= SEQUENCE {
configuredNSSAI
                                    ConfiguredNSSAI
                                                                                                   OPTIONAL,
rejectedNSSAIinPLMN
                                    RejectedNSSAIinPLMN
                                                                                                   OPTIONAL,
                                        RejectedNSSAIinTA
rejectedNSSAIinTA
                                                                                                        OPTIONAL,
    iE-Extensions
                        ProtocolExtensionContainer { {SourceToTarget-AMFInformationReroute-ExtIEs} } OPTIONAL,
    . . .
SourceToTarget-AMFInformationReroute-ExtlEs NGAP-PROTOCOL-EXTENSION ::= {
-- This IE includes information from the source Core node to the target Core node for reroute information provide by NSSF.
-- The octets of the OCTET STRING are encoded according to the specifications of the Core network.
ConfiguredNSSAI ::= OCTET STRING (SIZE(128))
RejectedNSSAIinPLMN ::= OCTET STRING (SIZE(32))
RejectedNSSAIinTA ::= OCTET STRING (SIZE(32))
SST ::= OCTET STRING (SIZE(1))
SupportedTAList ::= SEQUENCE (SIZE(1..maxnoofTACs)) OF SupportedTAItem
SupportedTAItem ::= SEQUENCE {
    tAC
                                        TAC,
    broadcast.PLMNList.
                            BroadcastPLMNList,
    iE-Extensions
                        ProtocolExtensionContainer { {SupportedTAItem-ExtIEs} } OPTIONAL,
SupportedTAItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::=
-- T
TAC ::= OCTET STRING (SIZE(3))
```

```
TAI ::= SEOUENCE {
   pLMNIdentity
                       PLMNIdentity,
    iE-Extensions
                       ProtocolExtensionContainer { {TAI-ExtIEs} } OPTIONAL,
TAI-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
TAIBroadcastEUTRA ::= SEQUENCE (SIZE(1..maxnoofTAIforWarning)) OF TAIBroadcastEUTRA-Item
TAIBroadcastEUTRA-Item ::= SEQUENCE {
    completedCellsInTAI-EUTRA
                                   CompletedCellsInTAI-EUTRA,
   iE-Extensions ProtocolExtensionContainer { {TAIBroadcastEUTRA-Item-ExtIEs} } OPTIONAL,
TAIBroadcastEUTRA-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
TAIBroadcastNR ::= SEQUENCE (SIZE(1..maxnoofTAIforWarning)) OF TAIBroadcastNR-Item
TAIBroadcastNR-Item ::= SEQUENCE {
    t.AI
                               TAI,
    completedCellsInTAI-NR
                               CompletedCellsInTAI-NR,
                       ProtocolExtensionContainer { {TAIBroadcastNR-Item-ExtIEs} } OPTIONAL,
    iE-Extensions
TAIBroadcastNR-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
TAICancelledEUTRA ::= SEOUENCE (SIZE(1..maxnoofTAIforWarning)) OF TAICancelledEUTRA-Item
TAICancelledEUTRA-Item ::= SEQUENCE {
                                   TAI,
    cancelledCellsInTAI-EUTRA
                                   CancelledCellsInTAI-EUTRA,
   iE-Extensions ProtocolExtensionContainer { {TAICancelledEUTRA-Item-ExtIEs} } OPTIONAL,
TAICancelledEUTRA-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
TAICancelledNR ::= SEQUENCE (SIZE(1..maxnoofTAIforWarning)) OF TAICancelledNR-Item
TAICancelledNR-Item ::= SEQUENCE {
    tAI
                               TAI,
```

```
cancelledCellsInTAI-NR
                                CancelledCellsInTAI-NR,
   iE-Extensions
                        ProtocolExtensionContainer { {TAICancelledNR-Item-ExtIEs} } OPTIONAL,
TAICancelledNR-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
TAIListForInactive ::= SEQUENCE (SIZE(1..maxnoofTAIforInactive)) OF TAIListForInactiveItem
TAIListForInactiveItem ::= SEQUENCE {
    tAI
   iE-Extensions
                        ProtocolExtensionContainer { {TAIListForInactiveItem-ExtIEs} } OPTIONAL,
TAIListForInactiveItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::=
TAIListForPaging ::= SEQUENCE (SIZE(1..maxnoofTAIforPaging)) OF TAIListForPagingItem
TAIListForPagingItem ::= SEQUENCE {
    tAI
    iE-Extensions
                        ProtocolExtensionContainer { {TAIListForPagingItem-ExtIEs} } OPTIONAL,
TAIListForPagingItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    . . .
TAIListForRestart ::= SEQUENCE (SIZE(1..maxnoofTAIforRestart)) OF TAI
TAIListForWarning ::= SEQUENCE (SIZE(1..maxnoofTAIforWarning)) OF TAI
TargeteNB-ID ::= SEQUENCE {
   qlobalENB-ID
                        GlobalNqENB-ID,
    selected-EPS-TAI
                       EPS-TAI,
                        ProtocolExtensionContainer { {TargeteNB-ID-ExtIEs} } OPTIONAL,
    iE-Extensions
TargeteNB-ID-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
TargetID ::= CHOICE {
    targetRANNodeID
                       TargetRANNodeID,
    targeteNB-ID
                       TargeteNB-ID,
    choice-Extensions
                            ProtocolIE-SingleContainer { {TargetID-ExtIEs} }
```

```
TargetID-ExtIEs NGAP-PROTOCOL-IES ::= {
TargetNGRANNode-ToSourceNGRANNode-TransparentContainer ::= SEQUENCE {
    rRCContainer
                       RRCContainer,
   iE-Extensions
                        ProtocolExtensionContainer { {TargetNGRANNode-ToSourceNGRANNode-TransparentContainer-ExtIEs} } OPTIONAL,
TargetNGRANNode-ToSourceNGRANNode-TransparentContainer-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
TargetRANNodeID ::= SEQUENCE {
   globalRANNodeID
                        GlobalRANNodeID,
    selectedTAI
                        ProtocolExtensionContainer { {TargetRANNodeID-ExtIEs} } OPTIONAL,
    iE-Extensions
TargetRANNodeID-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
TargetToSource-TransparentContainer ::= OCTET STRING
-- This IE includes a transparent container from the target RAN node to the source RAN node.
-- The octets of the OCTET STRING are encoded according to the specifications of the target system.
TimerApproachForGUAMIRemoval ::= ENUMERATED {
    apply-timer,
TimeStamp ::= OCTET STRING (SIZE(4))
TimeToWait ::= ENUMERATED {v1s, v2s, v5s, v10s, v20s, v60s, ...}
TimeUEStayedInCell ::= INTEGER (0..4095)
TimeUEStayedInCellEnhancedGranularity ::= INTEGER (0..40950)
TNLAddressWeightFactor ::= INTEGER (0..255)
TNLAssociationList ::= SEQUENCE (SIZE(1..maxnoofTNLAssociations)) OF TNLAssociationItem
TNLAssociationItem ::= SEOUENCE
    tNLAssociationAddress
                                CPTransportLayerInformation,
    cause
                        ProtocolExtensionContainer { {TNLAssociationItem-ExtIEs} } OPTIONAL,
    iE-Extensions
TNLAssociationItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
```

295

```
TNLAssociationUsage ::= ENUMERATED {
    non-ue,
    both,
    . . .
TraceActivation ::= SEQUENCE {
                                         NGRANTraceID,
    nGRANTraceID
    interfacesToTrace
                                         InterfacesToTrace,
    traceDepth
                                         TraceDepth,
    traceCollectionEntityIPAddress
                                         TransportLayerAddress,
    iE-Extensions
                        ProtocolExtensionContainer { {TraceActivation-ExtIEs} } OPTIONAL,
TraceActivation-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
TraceDepth ::= ENUMERATED {
    minimum,
    medium,
    maximum,
    minimumWithoutVendorSpecificExtension,
    mediumWithoutVendorSpecificExtension,
    maximumWithoutVendorSpecificExtension,
    . . .
TrafficLoadReductionIndication ::= INTEGER (1..99)
TransportLayerAddress ::= BIT STRING (SIZE(1..160, ...))
TypeOfError ::= ENUMERATED {
    not-understood,
    missing,
    . . .
-- IJ
UEAggregateMaximumBitRate ::= SEQUENCE {
    uEAggregateMaximumBitRateDL
                                     BitRate,
    uEAggregateMaximumBitRateUL
                                     BitRate,
    iE-Extensions
                        ProtocolExtensionContainer { {UEAggregateMaximumBitRate-ExtIEs} } OPTIONAL,
    . . .
UEAggregateMaximumBitRate-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    . . .
```

```
UE-associatedLogicalNG-connectionList ::= SEOUENCE (SIZE(1..maxnoofNGConnectionsToReset)) OF UE-associatedLogicalNG-connectionItem
UE-associatedLogicalNG-connectionItem ::= SEQUENCE {
                      AMF-UE-NGAP-ID
   aMF-UE-NGAP-ID
                                                                                                  OPTIONAL,
   rAN-UE-NGAP-ID
                      RAN-UE-NGAP-ID
                                                                                                  OPTIONAL,
   iE-Extensions
                      OPTIONAL,
UE-associatedLogicalNG-connectionItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
UEContextRequest ::= ENUMERATED {requested, ...}
UEHistoryInformation ::= SEQUENCE (SIZE(1..maxnoofCellsinUEHistoryInfo)) OF LastVisitedCellItem
UEIdentityIndexValue ::= CHOICE {
   indexLength10
                          BIT STRING (SIZE(10)),
   choice-Extensions
                          ProtocolIE-SingleContainer { {UEIdentityIndexValue-ExtIEs} }
UEIdentityIndexValue-ExtIEs NGAP-PROTOCOL-IES ::= {
UE-NGAP-IDs ::= CHOICE {
   uE-NGAP-ID-pair
                      UE-NGAP-ID-pair,
   aMF-UE-NGAP-ID
                      AMF-UE-NGAP-ID,
    choice-Extensions
                          ProtocolIE-SingleContainer { {UE-NGAP-IDs-ExtIEs} }
UE-NGAP-IDs-ExtIEs NGAP-PROTOCOL-IES ::= {
UE-NGAP-ID-pair ::= SEQUENCE{
   aMF-UE-NGAP-ID
                      AMF-UE-NGAP-ID,
   rAN-UE-NGAP-ID
                      RAN-UE-NGAP-ID,
                      ProtocolExtensionContainer { {UE-NGAP-ID-pair-ExtIEs} } OPTIONAL,
   iE-Extensions
UE-NGAP-ID-pair-ExtlEs NGAP-PROTOCOL-EXTENSION ::= {
UEPagingIdentity ::= CHOICE {
   fiveG-S-TMSI
                      FiveG-S-TMSI,
                          ProtocolIE-SingleContainer { {UEPagingIdentity-ExtIEs} }
   choice-Extensions
UEPagingIdentity-ExtIEs NGAP-PROTOCOL-IES ::= {
```

```
UEPresence ::= ENUMERATED {in, out, unknown, ...}
UEPresenceInAreaOfInterestList ::= SEOUENCE (SIZE(1..maxnoofAoI)) OF UEPresenceInAreaOfInterestItem
UEPresenceInAreaOfInterestItem ::= SEOUENCE {
    locationReportingReferenceID
                                        LocationReportingReferenceID,
    uEPresence
                                        UEPresence,
    iE-Extensions
                        ProtocolExtensionContainer { {UEPresenceInAreaOfInterestItem-ExtIEs} } OPTIONAL,
    . . .
UEPresenceInAreaOfInterestItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
UERadioCapability ::= OCTET STRING
UERadioCapabilityForPaging ::= SEQUENCE {
    uERadioCapabilityForPagingOfNR
                                            UERadioCapabilityForPagingOfNR
                                                                                     OPTIONAL,
                                            UERadioCapabilityForPagingOfEUTRA
    uERadioCapabilityForPagingOfEUTRA
                                                                                     OPTIONAL,
                        ProtocolExtensionContainer { {UERadioCapabilityForPaging-ExtIEs} } OPTIONAL,
   iE-Extensions
UERadioCapabilityForPaging-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
UERadioCapabilityForPagingOfNR ::= OCTET STRING
UERadioCapabilityForPagingOfEUTRA ::= OCTET STRING
UERetentionInformation ::= ENUMERATED {
    ues-retained,
    . . .
UESecurityCapabilities ::= SEQUENCE {
    nRencryptionAlgorithms
                                            NRencryptionAlgorithms,
    nRintegrityProtectionAlgorithms
                                            NRintegrityProtectionAlgorithms,
    eUTRAencryptionAlgorithms
                                            EUTRAencryptionAlgorithms,
    eUTRAintegrityProtectionAlgorithms
                                            EUTRAintegrityProtectionAlgorithms,
    iE-Extensions
                        ProtocolExtensionContainer { {UESecurityCapabilities-ExtIEs} } OPTIONAL,
UESecurityCapabilities-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    . . .
```

```
UL-NGU-UP-TNLModifyList ::= SEOUENCE (SIZE(1..maxnoofMultiConnectivity)) OF UL-NGU-UP-TNLModifyItem
UL-NGU-UP-TNLModifyItem ::= SEQUENCE {
    uL-NGU-UP-TNLInformation
                                    UPTransportLayerInformation,
    dL-NGU-UP-TNLInformation
                                    UPTransportLayerInformation,
                        ProtocolExtensionContainer { {UL-NGU-UP-TNLModifyItem-ExtIEs} } OPTIONAL,
   iE-Extensions
    . . .
UL-NGU-UP-TNLModifyItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
UnavailableGUAMIList ::= SEQUENCE (SIZE(1..maxnoofServedGUAMIS)) OF UnavailableGUAMIItem
UnavailableGUAMIItem ::= SEQUENCE {
                                        GUAMI,
    timerApproachForGUAMIRemoval
                                        TimerApproachForGUAMIRemoval
                                                                                         OPTIONAL,
    backupAMFName
                                                                                         OPTIONAL,
                        ProtocolExtensionContainer { {UnavailableGUAMIItem-ExtIEs} }
    iE-Extensions
                                                                                        OPTIONAL,
UnavailableGUAMIItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
ULForwarding ::= ENUMERATED {
    ul-forwarding-proposed,
UPTransportLayerInformation ::= CHOICE {
    gTPTunnel
                            ProtocolIE-SingleContainer { {UPTransportLayerInformation-ExtIEs} }
    choice-Extensions
UPTransportLayerInformation-ExtIEs NGAP-PROTOCOL-IES ::= {
UPTransportLayerInformationList ::= SEQUENCE (SIZE(1..maxnoofMultiConnectivityMinusOne)) OF UPTransportLayerInformationItem
UPTransportLayerInformationItem ::= SEQUENCE {
    nGU-UP-TNLInformation
                                UPTransportLaverInformation,
                        ProtocolExtensionContainer { {UPTransportLayerInformationItem-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
UPTransportLayerInformationItem-ExtIES NGAP-PROTOCOL-EXTENSION ::= {
```

```
UPTransportLayerInformationPairList ::= SEOUENCE (SIZE(1..maxnoofMultiConnectivityMinusOne)) OF UPTransportLayerInformationPairList
UPTransportLayerInformationPairItem ::= SEQUENCE {
   uL-NGU-UP-TNLInformation
                               UPTransportLayerInformation,
   dL-NGU-UP-TNLInformation
                                UPTransportLayerInformation,
                     ProtocolExtensionContainer { {UPTransportLayerInformationPairItem-ExtIEs} } OPTIONAL,
   iE-Extensions
   . . .
UPTransportLayerInformationPairItem-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
UserLocationInformation ::= CHOICE {
   userLocationInformationEUTRA
                               UserLocationInformationEUTRA,
   userLocationInformationNR
                                UserLocationInformationNR,
                               UserLocationInformationN3IWF,
   userLocationInformationN3IWF
   choice-Extensions
                        ProtocolIE-SingleContainer { {UserLocationInformation-ExtIEs} }
UserLocationInformation-ExtIEs NGAP-PROTOCOL-IES ::= {
UserLocationInformationEUTRA ::= SEQUENCE {
   eUTRA-CGI
                     EUTRA-CGI,
   tAI
                     TAI,
   timeStamp
                     TimeStamp
                                                                                     OPTIONAL,
                     iE-Extensions
                                                                                     OPTIONAL,
UserLocationInformationEUTRA-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
   PRESENCE optional },
   . . .
UserLocationInformationN3IWF ::= SEQUENCE {
                     TransportLayerAddress,
   iPAddress
   portNumber
                     PortNumber,
                     iE-Extensions
                                                                                     OPTIONAL,
UserLocationInformationN3IWF-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
UserLocationInformationNR ::= SEQUENCE {
   nR-CGI
                     NR-CGI,
   tAI
                     TAI,
   timeStamp
                     TimeStamp
                                                                                  OPTIONAL,
                     ProtocolExtensionContainer { {UserLocationInformationNR-ExtIEs} }
                                                                                 OPTIONAL,
   iE-Extensions
   . . .
```

```
UserLocationInformationNR-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    PRESENCE optional },
   . . .
UserPlaneSecurityInformation ::= SEQUENCE {
   securityResult
                          SecurityResult,
   securityIndication
                          SecurityIndication,
   iE-Extensions
                      ProtocolExtensionContainer { {UserPlaneSecurityInformation-ExtIEs} }
                                                                                            OPTIONAL,
    . . .
UserPlaneSecurityInformation-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
-- V
VolumeTimedReportList ::= SEQUENCE (SIZE(1..maxnoofTimePeriods)) OF VolumeTimedReport-Item
VolumeTimedReport-Item ::= SEQUENCE {
   startTimeStamp
                              OCTET STRING (SIZE(4)),
   endTimeStamp
                              OCTET STRING (SIZE(4)),
   usageCountUL
                              INTEGER (0..18446744073709551615),
                              INTEGER (0..18446744073709551615),
   usageCountDL
   iE-Extensions
                      ProtocolExtensionContainer { {VolumeTimedReport-Item-ExtIEs} } OPTIONAL,
VolumeTimedReport-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
WarningAreaCoordinates ::= OCTET STRING (SIZE(1..1024))
WarningAreaList ::= CHOICE {
   eUTRA-CGIListForWarning
                                  EUTRA-CGIListForWarning,
   nR-CGIListForWarning
                                  NR-CGIListForWarning
   tAIListForWarning
                                  TAIListForWarning,
    emergencyAreaIDList
                                  EmergencyAreaIDList,
    choice-Extensions
                          ProtocolIE-SingleContainer { {WarningAreaList-ExtIEs} }
WarningAreaList-ExtIEs NGAP-PROTOCOL-IES ::= {
WarningMessageContents ::= OCTET STRING (SIZE(1..9600))
WarningSecurityInfo ::= OCTET STRING (SIZE(50))
```

```
WarningType ::= OCTET STRING (SIZE(2))
-- X
XnExtTLAs ::= SEQUENCE (SIZE(1..maxnoofXnExtTLAs)) OF XnExtTLA-Item
XnExtTLA-Item ::= SEOUENCE {
   iPsecTLA
                                TransportLayerAddress
                                                            OPTIONAL,
                                XnGTP-TLAs
    aTP-TLAs
                                                            OPTIONAL,
    iE-Extensions ProtocolExtensionContainer { {XnExtTLA-Item-ExtIEs} } OPTIONAL,
XnExtTLA-Item-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
    { ID id-SCTP-TLAs
                           CRITICALITY ignore EXTENSION SCTP-TLAS
                                                                        PRESENCE optional },
    . . .
XnGTP-TLAs ::= SEQUENCE (SIZE(1..maxnoofXnGTP-TLAs)) OF TransportLayerAddress
XnTLAs ::= SEQUENCE (SIZE(1..maxnoofXnTLAs)) OF TransportLayerAddress
XnTNLConfigurationInfo ::= SEQUENCE {
    xnTransportLayerAddresses
                                        XnTLAs,
    xnExtendedTransportLayerAddresses
                                       XnExtTLAs
                                                                                        OPTIONAL,
    iE-Extensions
                       ProtocolExtensionContainer { {XnTNLConfigurationInfo-ExtIEs} } OPTIONAL,
XnTNLConfigurationInfo-ExtIEs NGAP-PROTOCOL-EXTENSION ::= {
-- Z
END
-- ASN1STOP
```

#### 9.4.6 Common Definitions

```
DEFINITIONS AUTOMATIC TAGS ::=
BEGIN
               ::= ENUMERATED { reject, ignore, notify }
Criticality
Presence
               ::= ENUMERATED { optional, conditional, mandatory }
PrivateIE-ID ::= CHOICE {
   local
                      INTEGER (0..65535),
    global
                       OBJECT IDENTIFIER
ProcedureCode
                 ::= INTEGER (0..255)
ProtocolExtensionID ::= INTEGER (0..65535)
ProtocolIE-ID
               ::= INTEGER (0..65535)
TriggeringMessage ::= ENUMERATED { initiating-message, successful-outcome, unsuccessfull-outcome }
END
-- ASN1STOP
```

#### 9.4.7 Constant Definitions

```
Elementary Procedures
  *******************
id-AMFConfigurationUpdate
                                           ProcedureCode ::= 0
id-AMFStatusIndication
                                           ProcedureCode ::= 1
id-CellTrafficTrace
                                           ProcedureCode ::= 2
                                           ProcedureCode ::= 3
id-DeactivateTrace
id-DownlinkNASTransport
                                           ProcedureCode ::= 4
id-DownlinkNonUEAssociatedNRPPaTransport
                                           ProcedureCode ::= 5
id-DownlinkRANConfigurationTransfer
                                           ProcedureCode ::= 6
id-DownlinkRANStatusTransfer
                                           ProcedureCode ::= 7
id-DownlinkUEAssociatedNRPPaTransport
                                           ProcedureCode ::= 8
id-ErrorIndication
                                           ProcedureCode ::= 9
id-HandoverCancel
                                           ProcedureCode ::= 10
                                           ProcedureCode ::= 11
id-HandoverNotification
id-HandoverPreparation
                                           ProcedureCode ::= 12
id-HandoverResourceAllocation
                                           ProcedureCode ::= 13
id-InitialContextSetup
                                           ProcedureCode ::= 14
id-InitialUEMessage
                                           ProcedureCode ::= 15
id-LocationReportingControl
                                           ProcedureCode ::= 16
id-LocationReportingFailureIndication
                                           ProcedureCode ::= 17
id-LocationReport
                                           ProcedureCode ::= 18
id-NASNonDeliveryIndication
                                           ProcedureCode ::= 19
id-NGReset
                                           ProcedureCode ::= 20
id-NGSetup
                                           ProcedureCode ::= 21
id-OverloadStart
                                           ProcedureCode ::= 22
id-OverloadStop
                                           ProcedureCode ::= 23
id-Paging
                                           ProcedureCode ::= 24
                                           ProcedureCode ::= 25
id-PathSwitchRequest
id-PDUSessionResourceModify
                                           ProcedureCode ::= 26
id-PDUSessionResourceModifyIndication
                                           ProcedureCode ::= 27
                                           ProcedureCode ::= 28
id-PDUSessionResourceRelease
                                           ProcedureCode ::= 29
id-PDUSessionResourceSetup
id-PDUSessionResourceNotify
                                           ProcedureCode ::= 30
id-PrivateMessage
                                           ProcedureCode ::= 31
id-PWSCancel
                                           ProcedureCode ::= 32
id-PWSFailureIndication
                                           ProcedureCode ::= 33
id-PWSRestartIndication
                                           ProcedureCode ::= 34
id-RANConfigurationUpdate
                                           ProcedureCode ::= 35
id-RerouteNASRequest
                                           ProcedureCode ::= 36
id-RRCInactiveTransitionReport
                                           ProcedureCode ::= 37
id-TraceFailureIndication
                                           ProcedureCode ::= 38
id-TraceStart
                                           ProcedureCode ::= 39
id-UEContextModification
                                           ProcedureCode ::= 40
                                           ProcedureCode ::= 41
id-UEContextRelease
                                           ProcedureCode ::= 42
id-UEContextReleaseRequest
id-UERadioCapabilityCheck
                                           ProcedureCode ::= 43
id-UERadioCapabilityInfoIndication
                                           ProcedureCode ::= 44
id-UETNLABindingRelease
                                           ProcedureCode ::= 45
```

```
id-UplinkNASTransport
                                        ProcedureCode ::= 46
id-UplinkNonUEAssociatedNRPPaTransport
                                        ProcedureCode ::= 47
                                        ProcedureCode ::= 48
id-UplinkRANConfigurationTransfer
id-UplinkRANStatusTransfer
                                        ProcedureCode ::= 49
id-UplinkUEAssociatedNRPPaTransport
                                        ProcedureCode ::= 50
id-WriteReplaceWarning
                                        ProcedureCode ::= 51
id-SecondaryRATDataUsageReport
                                        ProcedureCode ::= 52
-- Extension constants
__ ********************
maxPrivateIEs
                                     INTEGER ::= 65535
maxProtocolExtensions
                                    INTEGER ::= 65535
                                    INTEGER ::= 65535
maxProtocolIEs
    -- Lists
  ****************
   maxnoofAllowedAreas
                                     INTEGER ::= 16
   maxnoofAllowedS-NSSAIs
                                     INTEGER ::= 8
   maxnoofBPLMNs
                                     INTEGER ::= 12
   maxnoofCellIDforWarning
                                    INTEGER ::= 65535
   maxnoofCellinAoI
                                    INTEGER ::= 256
   maxnoofCellinEAI
                                    INTEGER ::= 65535
   maxnoofCellinTAI
                                    INTEGER ::= 65535
   maxnoofCellsingNB
                                    INTEGER ::= 16384
   maxnoofCellsinngeNB
                                    INTEGER ::= 256
   maxnoofCellsinUEHistoryInfo
                                    INTEGER ::= 16
   maxnoofCellsUEMovingTrajectory
                                     INTEGER ::= 16
   maxnoofDRBs
                                    INTEGER ::= 32
   maxnoofEmergencyAreaID
                                    INTEGER ::= 65535
   maxnoofEAIforRestart
                                     INTEGER ::= 256
   maxnoofEPLMNs
                                    INTEGER ::= 15
   maxnoofEPLMNsPlusOne
                                    INTEGER ::= 16
   maxnoofE-RABs
                                    INTEGER ::= 256
   maxnoofErrors
                                    INTEGER ::= 256
   maxnoofForbTACs
                                     INTEGER ::= 4096
   maxnoofMultiConnectivity
                                        INTEGER ::= 4
   maxnoofMultiConnectivityMinusOne
                                     INTEGER ::= 3
   maxnoofNGConnectionsToReset
                                     INTEGER ::= 65536
   maxnoofPDUSessions
                                     INTEGER ::= 256
   maxnoofPLMNs
                                    INTEGER ::= 12
   maxnoofOosFlows
                                     INTEGER ::= 64
   maxnoofRANNodeinAoI
                                    INTEGER ::= 64
   maxnoofRecommendedCells
                                    INTEGER ::= 16
   maxnoofRecommendedRANNodes
                                    INTEGER ::= 16
   maxnoofAoI
                                    INTEGER ::= 64
   maxnoofServedGUAMIs
                                     INTEGER ::= 256
```

```
maxnoofSliceItems
                                      INTEGER ::= 1024
   maxnoofTACs
                                      INTEGER ::= 256
                                      INTEGER ::= 16
   maxnoofTAIforInactive
   maxnoofTAIforPaging
                                      INTEGER ::= 16
   maxnoofTAIforRestart
                                      INTEGER ::= 2048
   maxnoofTAIforWarning
                                      INTEGER ::= 65535
   maxnoofTAIinAoI
                                      INTEGER ::= 16
   maxnoofTimePeriods
                                      INTEGER ::= 2
   maxnoofTNLAssociations
                                      INTEGER ::= 32
   maxnoofXnExtTLAs
                                      INTEGER ::= 16
   maxnoofXnGTP-TLAs
                                      INTEGER ::= 16
   maxnoofXnTLAs
                                      INTEGER ::= 2
   -- TES
  ********************
   id-AllowedNSSAI
                                                          ProtocolIE-ID ::= 0
   id-AMFName
                                                          ProtocolIE-ID ::= 1
   id-AMFOverloadResponse
                                                          ProtocolIE-ID ::= 2
   id-AMFSetID
                                                          ProtocolIE-ID ::= 3
   id-AMF-TNLAssociationFailedToSetupList
                                                          ProtocolIE-ID ::= 4
    id-AMF-TNLAssociationSetupList
                                                          ProtocolIE-ID ::= 5
    id-AMF-TNLAssociationToAddList
                                                          ProtocolIE-ID ::= 6
    id-AMF-TNLAssociationToRemoveList
                                                          ProtocolIE-ID ::= 7
    id-AMF-TNLAssociationToUpdateList
                                                          ProtocolIE-ID ::= 8
    id-AMFTrafficLoadReductionIndication
                                                          ProtocolIE-ID ::= 9
    id-AMF-UE-NGAP-ID
                                                          ProtocolIE-ID ::= 10
    id-AssistanceDataForPaging
                                                          ProtocolIE-ID ::= 11
    id-BroadcastCancelledAreaList
                                                          ProtocolIE-ID ::= 12
    id-BroadcastCompletedAreaList
                                                          ProtocolIE-ID ::= 13
   id-CancelAllWarningMessages
                                                          ProtocolIE-ID ::= 14
   id-Cause
                                                          ProtocolIE-ID ::= 15
   id-CellIDListForRestart
                                                          ProtocolIE-ID ::= 16
    id-ConcurrentWarningMessageInd
                                                          ProtocolIE-ID ::= 17
    id-CoreNetworkAssistanceInformationForInactive
                                                          ProtocolIE-ID ::= 18
    id-CriticalityDiagnostics
                                                          ProtocolIE-ID ::= 19
    id-DataCodingScheme
                                                          ProtocolIE-ID ::= 20
    id-DefaultPagingDRX
                                                          ProtocolIE-ID ::= 21
    id-DirectForwardingPathAvailability
                                                          ProtocolIE-ID ::= 22
    id-EmergencyAreaIDListForRestart
                                                          ProtocolIE-ID ::= 23
    id-EmergencyFallbackIndicator
                                                          ProtocolIE-ID ::= 24
   id-EUTRA-CGI
                                                          ProtocolIE-ID ::= 25
    id-FiveG-S-TMSI
                                                          ProtocolIE-ID ::= 26
   id-GlobalRANNodeID
                                                          ProtocolIE-ID ::= 27
   id-GUAMI
                                                          ProtocolIE-ID ::= 28
    id-HandoverType
                                                          ProtocolIE-ID ::= 29
    id-IMSVoiceSupportIndicator
                                                          ProtocolIE-ID ::= 30
    id-IndexToRFSP
                                                          ProtocolIE-ID ::= 31
    id-InfoOnRecommendedCellsAndRANNodesForPaging
                                                          ProtocolIE-ID ::= 32
    id-LocationReportingRequestType
                                                          ProtocolIE-ID ::= 33
   id-MaskedIMEISV
                                                          ProtocolIE-ID ::= 34
```

id-MessageIdentifier	ProtocolIE-ID ::= 35
id-MobilityRestrictionList	ProtocolIE-ID ::= 36
id-NASC	ProtocolIE-ID ::= 37
id-NAS-PDU	ProtocolIE-ID ::= 38
id-NASSecurityParametersFromNGRAN	ProtocolIE-ID ::= 39
id-NewAMF-UE-NGAP-ID	ProtocolIE-ID ::= 40
id-NewSecurityContextInd	ProtocolIE-ID ::= 41
id-NGAP-Message	ProtocolIE-ID ::= 42
id-NGRAN-CGI	ProtocolIE-ID ::= 43
id-NGRANTraceID	ProtocolIE-ID ::= 44
id-NR-CGI	ProtocolIE-ID ::= 45
id-NRPPa-PDU	ProtocolIE-ID ::= 46
id-NumberOfBroadcastsRequested	ProtocolIE-ID ::= 47
id-OldAMF	ProtocolIE-ID ::= 48
id-OverloadStartNSSAIList	ProtocolIE-ID ::= 49
id-PagingDRX	ProtocolIE-ID ::= 50
id-PagingOrigin	ProtocolIE-ID ::= 51
id-PagingPriority	ProtocolIE-ID ::= 52
id-PDUSessionResourceAdmittedList	ProtocolIE-ID ::= 53
id-PDUSessionResourceFailedToModifyListModRes	ProtocolIE-ID ::= 54
id-PDUSessionResourceFailedToSetupListCxtRes	ProtocolIE-ID ::= 55
id-PDUSessionResourceFailedToSetupListHOAck	ProtocolIE-ID ::= 56
id-PDUSessionResourceFailedToSetupListPSReq	ProtocolIE-ID ::= 57
id-PDUSessionResourceFailedToSetupListSURes	ProtocolIE-ID ::= 58
id-PDUSessionResourceHandoverList	ProtocolIE-ID ::= 59
id-PDUSessionResourceListCxtRelCpl	ProtocolIE-ID ::= 60
id-PDUSessionResourceListHORqd	ProtocolIE-ID ::= 61
id-PDUSessionResourceModifyListModCfm	ProtocolIE-ID ::= 62
id-PDUSessionResourceModifyListModInd	ProtocolIE-ID ::= 63
id-PDUSessionResourceModifyListModReq	ProtocolIE-ID ::= 64
id-PDUSessionResourceModifyListModRes	ProtocolIE-ID ::= 65
id-PDUSessionResourceNotifyList	ProtocolIE-ID ::= 66
id-PDUSessionResourceReleasedListNot	ProtocolIE-ID ::= 67
id-PDUSessionResourceReleasedListPSAck	ProtocolIE-ID ::= 68
id-PDUSessionResourceReleasedListPSFail	ProtocolIE-ID ::= 69
id-PDUSessionResourceReleasedListRelRes	ProtocolIE-ID ::= 70
id-PDUSessionResourceSetupListCxtReq	ProtocolIE-ID ::= 71
id-PDUSessionResourceSetupListCxtRes	ProtocolIE-ID ::= 72
id-PDUSessionResourceSetupListHOReq	ProtocolIE-ID ::= 73
id-PDUSessionResourceSetupListSUReq	ProtocolIE-ID ::= 74
id-PDUSessionResourceSetupListSURes	ProtocolIE-ID ::= 75
id-PDUSessionResourceToBeSwitchedDLList	ProtocolIE-ID ::= 76
id-PDUSessionResourceSwitchedList	ProtocolIE-ID ::= 77
id-PDUSessionResourceToReleaseListHOCmd	ProtocolIE-ID ::= 78
id-PDUSessionResourceToReleaseListRelCmd	ProtocolIE-ID ::= 79
id-PLMNSupportList	ProtocoliE-ID ::= 80
id-PWSFailedCellIDList	ProtocolIE-ID ::= 81
id-RANNodeName	ProtocolIE-ID ::= 81
	ProtocolIE-ID ::= 83
id-RANPagingPriority	
id-RANStatusTransfer-TransparentContainer	ProtocolIE-ID ::= 84
id-RAN-UE-NGAP-ID	ProtocolIE-ID ::= 85
id-RelativeAMFCapacity	ProtocolIE-ID ::= 86
id-RepetitionPeriod	ProtocolIE-ID ::= 87
id-ResetType	ProtocolIE-ID ::= 88

id-RoutingID	ProtocolIE-ID ::= 89
id-RRCEstablishmentCause	ProtocolIE-ID ::= 89 ProtocolIE-ID ::= 90
id-RRCInactiveTransitionReportRequest	ProtocolIE-ID ::= 91 ProtocolIE-ID ::= 92
id-RRCState	ProtocolIE-ID ::= 92 ProtocolIE-ID ::= 93
id-SecurityContext	
id-SecurityKey	ProtocolIE-ID ::= 94
id-SerialNumber	ProtocolIE-ID ::= 95
id-ServedGUAMIList	ProtocolIE-ID ::= 96
id-SliceSupportList	ProtocolIE-ID ::= 97
id-SONConfigurationTransferDL	ProtocolIE-ID ::= 98
id-SONConfigurationTransferUL	ProtocolIE-ID ::= 99
id-SourceAMF-UE-NGAP-ID	ProtocolIE-ID ::= 100
id-SourceToTarget-TransparentContainer	ProtocolIE-ID ::= 101
id-SupportedTAList	ProtocolIE-ID ::= 102
id-TAIListForPaging	ProtocolIE-ID ::= 103
id-TAIListForRestart	ProtocolIE-ID ::= 104
id-TargetID	ProtocolIE-ID ::= 105
id-TargetToSource-TransparentContainer	ProtocolIE-ID ::= 106
id-TimeToWait	ProtocolIE-ID ::= 107
id-TraceActivation	ProtocolIE-ID ::= 108
id-TraceCollectionEntityIPAddress	ProtocolIE-ID ::= 109
id-UEAggregateMaximumBitRate	ProtocolIE-ID ::= 110
id-UE-associatedLogicalNG-connectionList	ProtocolIE-ID ::= 111
id-UEContextRequest	ProtocolIE-ID ::= 112
id-UE-NGAP-IDs	ProtocolIE-ID ::= 114
id-UEPagingIdentity	ProtocolIE-ID ::= 115
id-UEPresenceInAreaOfInterestList	ProtocolIE-ID ::= 116
id-UERadioCapability	ProtocolIE-ID ::= 117
id-UERadioCapabilityForPaging	ProtocolIE-ID ::= 118
id-UESecurityCapabilities	ProtocolIE-ID ::= 119
id-UnavailableGUAMIList	ProtocolIE-ID ::= 120
id-UserLocationInformation	ProtocolIE-ID ::= 121
id-WarningAreaList	ProtocolIE-ID ::= 122
id-WarningMessageContents	ProtocolIE-ID ::= 123
id-WarningSecurityInfo	ProtocolIE-ID ::= 124
id-WarningType	ProtocolIE-ID ::= 125
id-AdditionalUL-NGU-UP-TNLInformation	ProtocolIE-ID ::= 126
id-DataForwardingNotPossible	ProtocoliE-ID ::= 127
id-DL-NGU-UP-TNLInformation	ProtocolIE-ID ::= 128
id-NetworkInstance	ProtocolIE-ID ::= 129
id-PDUSessionAggregateMaximumBitRate	ProtocolIE-ID ::= 130
id-PDUSessionResourceFailedToModifyListModCfm	ProtocolIE-ID ::= 131
id-PDUSessionResourceFailedToSetupListCxtFail	ProtocolIE-ID ::= 132
id-PDUSessionResourceListCxtRelReq	ProtocolIE-ID ::= 133
id-PDUSessionType	ProtocolIE-ID ::= 134
id-QosFlowAddOrModifyRequestList	ProtocolIE-ID ::= 135
id-QosFlowSetupRequestList	ProtocolIE-ID ::= 136
id-QosFlowToReleaseList	ProtocolIE-ID ::= 137
id-SecurityIndication	ProtocolIE-ID ::= 138
id-UL-NGU-UP-TNLInformation	ProtocolIE-ID ::= 139
id-UL-NGU-UP-TNLModifyList	ProtocolIE-ID ::= 140
id-WarningAreaCoordinates	ProtocolIE-ID ::= 141
id-PDUSessionResourceSecondaryRATUsageList	ProtocolIE-ID ::= 142
id-HandoverFlag	ProtocolIE-ID ::= 143

309

```
id-SecondaryRATUsageInformation
                                                        ProtocolIE-ID ::= 144
id-PDUSessionResourceReleaseResponseTransfer
                                                        ProtocolIE-ID ::= 145
id-RedirectionVoiceFallback
                                                        ProtocolIE-ID ::= 146
id-UERetentionInformation
                                                        ProtocolIE-ID ::= 147
id-S-NSSAI
                                                        ProtocolIE-ID ::= 148
id-PSCellInformation
                                                        ProtocolIE-ID ::= 149
id-LastEUTRAN-PLMNIdentity
                                                        ProtocolIE-ID ::= 150
id-MaximumIntegritvProtectedDataRate-DL
                                                        ProtocolIE-ID ::= 151
id-AdditionalDLForwardingUPTNLInformation
                                                        ProtocolIE-ID ::= 152
id-AdditionalDLUPTNLInformationForHOList
                                                        ProtocolIE-ID ::= 153
id-AdditionalNGU-UP-TNLInformation
                                                        ProtocolIE-ID ::= 154
id-AdditionalDLOosFlowPerTNLInformation
                                                        ProtocolIE-ID ::= 155
id-SecurityResult
                                                        ProtocolIE-ID ::= 156
id-ENDC-SONConfigurationTransferDL
                                                        ProtocolIE-ID ::= 157
id-ENDC-SONConfigurationTransferUL
                                                        ProtocolIE-ID ::= 158
id-OldAssociatedOosFlowList-ULendmarkerexpected
                                                        ProtocolIE-ID ::= 159
id-CNTypeRestrictionsForEquivalent
                                                        ProtocolIE-ID ::= 160
id-CNTypeRestrictionsForServing
                                                        ProtocolIE-ID ::= 161
id-NewGUAMI
                                                        ProtocolIE-ID ::= 162
id-ULForwarding
                                                        ProtocolIE-ID ::= 163
id-ULForwardingUP-TNLInformation
                                                        ProtocolIE-ID ::= 164
id-CNAssistedRANTuning
                                                        ProtocolIE-ID ::= 165
id-CommonNetworkInstance
                                                        ProtocolIE-ID ::= 166
id-NGRAN-TNLAssociationToRemoveList
                                                        ProtocolIE-ID ::= 167
id-TNLAssociationTransportLayerAddressNGRAN
                                                        ProtocolIE-ID ::= 168
id-EndpointIPAddressAndPort
                                                        ProtocolIE-ID ::= 169
id-LocationReportingAdditionalInfo
                                                        ProtocolIE-ID ::= 170
id-SourceToTarget-AMFInformationReroute
                                                        ProtocolIE-ID ::= 171
id-AdditionalULForwardingUPTNLInformation
                                                        ProtocolIE-ID ::= 172
id-SCTP-TLAs
                                                        ProtocolIE-ID ::= 173
id-SelectedPLMNIdentity
                                                        ProtocolIE-ID ::= 174
```

END

-- ASN1STOP

#### 9.4.8 Container Definitions

```
__ ***********************
-- IE parameter types from other modules.
__ ***********************
IMPORTS
   Criticality,
   Presence,
   PrivateIE-ID,
   ProtocolExtensionID,
   ProtocolIE-ID
FROM NGAP-CommonDataTypes
   maxPrivateIEs,
  maxProtocolExtensions,
   maxProtocolIEs
FROM NGAP-Constants;
  -- Class Definition for Protocol IEs
__ *********************
NGAP-PROTOCOL-IES ::= CLASS {
   &id
              ProtocolIE-ID
                                       UNIQUE,
   &criticality Criticality,
   &Value,
   &presence
               Presence
WITH SYNTAX {
               &id
   ID
               &criticality
   CRITICALITY
  TYPE
               &Value
   PRESENCE
               &presence
    *****************
-- Class Definition for Protocol IEs
__ *********************
NGAP-PROTOCOL-IES-PAIR ::= CLASS {
                 ProtocolIE-ID
                                       UNIQUE,
   &firstCriticality Criticality,
   &FirstValue,
   &secondCriticality Criticality,
   &SecondValue,
   &presence
                  Presence
WITH SYNTAX {
```

```
&id
   FIRST CRITICALITY
                           &firstCriticality
    FIRST TYPE
                           &FirstValue
    SECOND CRITICALITY
                           &secondCriticality
    SECOND TYPE
                           &SecondValue
    PRESENCE
                           &presence
-- Class Definition for Protocol Extensions
NGAP-PROTOCOL-EXTENSION ::= CLASS {
                   ProtocolExtensionID
                                               UNIQUE,
    &criticality
                   Criticality,
    &Extension,
    &presence
                   Presence
WITH SYNTAX {
   ID
                   &id
    CRITICALITY
                   &criticality
    EXTENSION
                   &Extension
    PRESENCE
                   &presence
-- Class Definition for Private IEs
__ ***********************************
NGAP-PRIVATE-IES ::= CLASS {
                   PrivateIE-ID,
    &criticality
                   Criticality,
    &Value,
    &presence
                   Presence
WITH SYNTAX {
                   &id
    ID
                   &criticality
    CRITICALITY
   TYPE
                   &Value
    PRESENCE
                   &presence
-- Container for Protocol IEs
ProtocolIE-Container {NGAP-PROTOCOL-IES : IEsSetParam} ::=
    SEQUENCE (SIZE (0..maxProtocolIEs)) OF
```

```
ProtocolIE-Field {{IEsSetParam}}
ProtocolIE-SingleContainer {NGAP-PROTOCOL-IES : IEsSetParam} ::=
   ProtocolIE-Field {{IEsSetParam}}
ProtocolIE-Field {NGAP-PROTOCOL-IES : IESSetParam} ::= SEQUENCE {
                NGAP-PROTOCOL-IES.&id
                                                ({IEsSetParam}),
   criticality NGAP-PROTOCOL-IES.&criticality
                                                ({IEsSetParam}{@id}),
   value
                NGAP-PROTOCOL-IES.&Value
                                                ({IEsSetParam}{@id})
  *****************
-- Container for Protocol IE Pairs
ProtocolIE-ContainerPair {NGAP-PROTOCOL-IES-PAIR : IEsSetParam} ::=
   SEQUENCE (SIZE (0..maxProtocolIEs)) OF
   ProtocolIE-FieldPair {{IEsSetParam}}
ProtocolIE-FieldPair {NGAP-PROTOCOL-IES-PAIR : IEsSetParam} ::= SEQUENCE {
                  NGAP-PROTOCOL-IES-PAIR.&id
                                                          ({IEsSetParam}),
   firstCriticality NGAP-PROTOCOL-IES-PAIR.&firstCriticality
                                                          ({IEsSetParam}{@id}),
   firstValue NGAP-PROTOCOL-IES-PAIR.&FirstValue
                                                          ({IEsSetParam}{@id}),
   secondCriticality NGAP-PROTOCOL-IES-PAIR.&secondCriticality
                                                         ({IEsSetParam}{@id}),
   secondValue
                                                          ({IEsSetParam}{@id})
                    NGAP-PROTOCOL-IES-PAIR.&SecondValue
         -- Container Lists for Protocol IE Containers
    ProtocolIE-ContainerList {INTEGER : lowerBound, INTEGER : upperBound, NGAP-PROTOCOL-IES : IEsSetParam} ::=
   SEQUENCE (SIZE (lowerBound..upperBound)) OF
   ProtocolIE-SingleContainer {{IEsSetParam}}
ProtocolIE-ContainerPairList {INTEGER : lowerBound, INTEGER : upperBound, NGAP-PROTOCOL-IES-PAIR : IESSetParam} ::=
   SEQUENCE (SIZE (lowerBound..upperBound)) OF
   ProtocolIE-ContainerPair {{IEsSetParam}}
     -- Container for Protocol Extensions
  ····
ProtocolExtensionContainer {NGAP-PROTOCOL-EXTENSION : ExtensionSetParam} ::=
   SEQUENCE (SIZE (1..maxProtocolExtensions)) OF
   ProtocolExtensionField {{ExtensionSetParam}}
ProtocolExtensionField {NGAP-PROTOCOL-EXTENSION : ExtensionSetParam} ::= SEQUENCE {
```

```
({ExtensionSetParam}),
                      NGAP-PROTOCOL-EXTENSION.&id
   criticality
                      NGAP-PROTOCOL-EXTENSION.&criticality
                                                           ({ExtensionSetParam}{@id}),
                                                            ({ExtensionSetParam}{@id})
   extensionValue
                      NGAP-PROTOCOL-EXTENSION. & Extension
   *****************
-- Container for Private IEs
PrivateIE-Container {NGAP-PRIVATE-IES : IEsSetParam } ::=
   SEQUENCE (SIZE (1..maxPrivateIEs)) OF
   PrivateIE-Field {{IEsSetParam}}
PrivateIE-Field {NGAP-PRIVATE-IES : IEsSetParam} ::= SEQUENCE {
                                                        ({IEsSetParam}),
                     NGAP-PRIVATE-IES.&id
   criticality
                                                        ({IEsSetParam}{@id}),
                      NGAP-PRIVATE-IES.&criticality
   value
                      NGAP-PRIVATE-IES.&Value
                                                        ({IEsSetParam}{@id})
END
-- ASN1STOP
```

## 9.5 Message Transfer Syntax

NGAP shall use the ASN.1 Basic Packed Encoding Rules (BASIC-PER) Aligned Variant as transfer syntax as specified in ITU-T Rec. X.691 [4].

## 9.6 Timers

## $TNG_{RELOCprep} \\$

- Specifies the maximum time for the Handover Preparation procedure in the source NG-RAN node.

## $TNG_{RELOCoverall} \\$

- Specifies the maximum time for the protection of the overall handover procedure in the source NG-RAN node.

#### $TXn_{RELOCOverall}$

- Specified in TS 38.423 [24].

## Handling of Unknown, Unforeseen and Erroneous Protocol Data

#### 10.1 General

Protocol Error cases can be divided into three classes:

- Transfer Syntax Error.
- Abstract Syntax Error.
- Logical Error.

Protocol errors can occur in the following functions within a receiving node:




Figure 10.1-1: Protocol Errors in NGAP.

The information stated in subclauses 10.2, 10.3 and 10.4, to be included in the message used when reporting an error, is what at minimum shall be included. Other optional information elements within the message may also be included, if available. This is also valid for the case when the reporting is done with a response message. The latter is an exception to what is stated in subclause 4.1.

## 10.2 Transfer Syntax Error

A Transfer Syntax Error occurs when the receiver is not able to decode the received physical message. Transfer syntax errors are always detected in the process of ASN.1 decoding. If a Transfer Syntax Error occurs, the receiver should initiate Error Indication procedure with appropriate cause value for the Transfer Syntax protocol error.

Examples for Transfer Syntax Errors are:

- Violation of value ranges in ASN.1 definition of messages. E.g., if an IE has a defined value range of 0 to 10 (ASN.1: INTEGER (0..10)), and 12 will be received, then this will be treated as a transfer syntax error.
- Violation in list element constraints. E.g., if a list is defined as containing 1 to 10 elements, and 12 elements will be received, then this case will be handled as a transfer syntax error.
- Missing mandatory elements in ASN.1 SEQUENCE definitions (as sent by the originator of the message).
- Wrong order of elements in ASN.1 SEQUENCE definitions (as sent by the originator of the message).

## 10.3 Abstract Syntax Error

#### 10.3.1 General

An Abstract Syntax Error occurs when the receiving functional NGAP entity:

1. receives IEs or IE groups that cannot be understood (unknown IE ID);

- 2. receives IEs for which the logical range is violated (e.g., ASN.1 definition: 0 to 15, the logical range is 0 to 10, while values 11 to 15 are undefined), and 12 will be received; this case will be handled as an abstract syntax error using criticality information sent by the originator of the message);
- 3. does not receive IEs or IE groups but according to the specified presence of the concerning object, the IEs or IE groups should have been present in the received message.
- 4. receives IEs or IE groups that are defined to be part of that message in wrong order or with too many occurrences of the same IE or IE group;
- 5. receives IEs or IE groups but according to the conditional presence of the concerning object and the specified condition, the IEs or IE groups should not have been present in the received message.

Cases 1 and 2 (not comprehended IE/IE group) are handled based on received Criticality information. Case 3 (missing IE/IE group) is handled based on Criticality information and Presence information for the missing IE/IE group specified in the version of the specification used by the receiver. Case 4 (IEs or IE groups in wrong order or with too many occurrences) and Case 5 (erroneously present conditional IEs or IE groups) result in rejecting the procedure.

If an Abstract Syntax Error occurs, the receiver shall read the remaining message and shall then for each detected Abstract Syntax Error that belong to cases 1-3 act according to the Criticality Information and Presence Information for the IE/IE group due to which Abstract Syntax Error occurred in accordance with subclauses 10.3.4 and 10.3.5. The handling of cases 4 and 5 is specified in subclause 10.3.6.

## 10.3.2 Criticality Information

In the NGAP messages there is criticality information set for individual IEs and/or IE groups. This criticality information instructs the receiver how to act when receiving an IE or an IE group that is not comprehended, i.e., the entire item (IE or IE group) which is not (fully or partially) comprehended shall be treated in accordance with its own criticality information as specified in subclause 10.3.4.

In addition, the criticality information is used in case of the missing IE/IE group abstract syntax error (see subclause 10.3.5).

The receiving node shall take different actions depending on the value of the Criticality Information. The three possible values of the Criticality Information for an IE/IE group are:

- Reject IE.
- Ignore IE and Notify Sender.
- Ignore IE.

The following rules restrict when a receiving entity may consider an IE, an IE group, or an EP not comprehended (not implemented), and when action based on criticality information is applicable:

- 1. IE or IE group: When one new or modified IE or IE group is implemented for one EP from a standard version, then other new or modified IEs or IE groups specified for that EP in that standard version shall be considered comprehended by a receiving entity (some may still remain unsupported).
- 2. EP: The comprehension of different EPs within a standard version or between different standard versions is not mandated. Any EP that is not supported may be considered not comprehended, even if another EP from that standard version is comprehended, and action based on criticality shall be applied.

#### 10.3.3 Presence Information

For many IEs/IE groups which are optional according to the ASN.1 transfer syntax, NGAP specifies separately if the presence of these IEs/IE groups is optional or mandatory with respect to RNS application by means of the presence field of the concerning object of class NGAP-PROTOCOL-IES, NGAP-PROTOCOL-IES-PAIR, NGAP-PROTOCOL-EXTENSION or NGAP-PRIVATE-IES.

The presence field of the indicated classes supports three values:

1. Optional;

- 2. Conditional;
- 3. Mandatory.

If an IE/IE group is not included in a received message and the presence of the IE/IE group is mandatory or the presence is conditional and the condition is true according to the version of the specification used by the receiver, an abstract syntax error occurs due to a missing IE/IE group.

If an IE/IE group is included in a received message and the presence of the IE/IE group is conditional and the condition is false according to the version of the specification used by the receiver, an abstract syntax error occurs due to this erroneously present conditional IE/IE group.

## 10.3.4 Not comprehended IE/IE group

#### 10.3.4.1 Procedure Code

The receiving node shall treat the different types of received criticality information of the *Procedure Code* IE according to the following:

#### **Reject IE:**

If a message is received with a *Procedure Code* IE marked with "*Reject IE*" which the receiving node does not comprehend, the receiving node shall reject the procedure using the Error Indication procedure.

#### Ignore IE and Notify Sender:

- If a message is received with a *Procedure Code* IE marked with "*Ignore IE and Notify Sender*" which the receiving node does not comprehend, the receiving node shall ignore the procedure and initiate the Error Indication procedure.

#### **Ignore IE:**

- If a message is received with a *Procedure Code* IE marked with "*Ignore IE*" which the receiving node does not comprehend, the receiving node shall ignore the procedure.

When using the Error Indication procedure to reject a procedure or to report an ignored procedure it shall include the *Procedure Code* IE, the *Triggering Message* IE, and the *Procedure Criticality* IE in the *Criticality Diagnostics* IE.

#### 10.3.4.1A Type of Message

When the receiving node cannot decode the *Type of Message* IE, the Error Indication procedure shall be initiated with an appropriate cause value.

#### 10.3.4.2 IEs other than the Procedure Code and Type of Message

The receiving node shall treat the different types of received criticality information of an IE/IE group other than the *Procedure Code* IE and *Type of Message* IE according to the following:

#### **Reject IE:**

- If a message *initiating* a procedure is received containing one or more IEs/IE group marked with "*Reject IE*" which the receiving node does not comprehend; none of the functional requests of the message shall be executed. The receiving node shall reject the procedure and report the rejection of one or more IEs/IE group using the message normally used to report unsuccessful outcome of the procedure. In case the information received in the initiating message was insufficient to determine a value for all IEs that are required to be present in the message used to report the unsuccessful outcome of the procedure, the receiving node shall instead terminate the procedure and initiate the Error Indication procedure.
- If a message *initiating* a procedure that does not have a message to report unsuccessful outcome is received containing one or more IEs/IE groups marked with "*Reject IE*" which the receiving node does not comprehend, the receiving node shall terminate the procedure and initiate the Error Indication procedure.

- If a *response* message is received containing one or more IEs marked with "*Reject IE*", that the receiving node does not comprehend, the receiving node shall consider the procedure as unsuccessfully terminated and initiate local error handling.

#### **Ignore IE and Notify Sender:**

- If a message *initiating* a procedure is received containing one or more IEs/IE groups marked with "*Ignore IE and Notify Sender*" which the receiving node does not comprehend, the receiving node shall ignore the content of the not comprehended IEs/IE groups, continue with the procedure as if the not comprehended IEs/IE groups were not received (except for the reporting) using the understood IEs/IE groups, and report in the response message of the procedure that one or more IEs/IE groups have been ignored. In case the information received in the initiating message was insufficient to determine a value for all IEs that are required to be present in the response message, the receiving node shall instead terminate the procedure and initiate the Error Indication procedure.
- if a message *initiating* a procedure that does not have a message to report the outcome of the procedure is received containing one or more IEs/IE groups marked with "*Ignore IE and Notify Sender*" which the receiving node does not comprehend, the receiving node shall ignore the content of the not comprehended IEs/IE groups, continue with the procedure as if the not comprehended IEs/IE groups were not received (except for the reporting) using the understood IEs/IE groups, and initiate the Error Indication procedure to report that one or more IEs/IE groups have been ignored.
- If a response message is received containing one or more IEs/IE groups marked with "Ignore IE and Notify Sender" which the receiving node does not comprehend, the receiving node shall ignore the content of the not comprehended IEs/IE groups, continue with the procedure as if the not comprehended IEs/IE groups were not received (except for the reporting) using the understood IEs/IE groups and initiate the Error Indication procedure.

#### **Ignore IE:**

- If a message initiating a procedure is received containing one or more IEs/IE groups marked with "Ignore IE" which the receiving node does not comprehend, the receiving node shall ignore the content of the not comprehended IEs/IE groups and continue with the procedure as if the not comprehended IEs/IE groups were not received using the understood IEs/IE groups.
- If a *response* message is received containing one or more IEs/IE groups marked with "*Ignore IE*" which the receiving node does not comprehend, the receiving node shall ignore the content of the not comprehended IEs/IE groups and continue with the procedure as if the not comprehended IEs/IE groups were not received using the understood IEs/IE groups.

When reporting not comprehended IEs/IE groups marked with "Reject IE" or "Ignore IE and Notify Sender" using a response message defined for the procedure, the Information Element Criticality Diagnostics IE shall be included in the Criticality Diagnostics IE for each reported IE/IE group.

When reporting not comprehended IEs/IE groups marked with "Reject IE" or "Ignore IE and Notify Sender" using the Error Indication procedure, the Procedure Code IE, the Triggering Message IE, Procedure Criticality IE, and the Information Element Criticality Diagnostics IE shall be included in the Criticality Diagnostics IE for each reported IE/IE group.

## 10.3.5 Missing IE or IE group

The receiving node shall treat the missing IE/IE group according to the criticality information for the missing IE/IE group in the received message specified in the version of this specification used by the receiver:

#### **Reject IE:**

- if a received message *initiating* a procedure is missing one or more IEs/IE groups with specified criticality "Reject IE"; none of the functional requests of the message shall be executed. The receiving node shall reject the procedure and report the missing IEs/IE groups using the message normally used to report unsuccessful outcome of the procedure. In case the information received in the initiating message was insufficient to determine a value for all IEs that are required to be present in the message used to report the unsuccessful outcome of the procedure, the receiving node shall instead terminate the procedure and initiate the Error Indication procedure.

- if a received message *initiating* a procedure that does not have a message to report unsuccessful outcome is missing one or more IEs/IE groups with specified criticality "*Reject IE*", the receiving node shall terminate the procedure and initiate the Error Indication procedure.
- if a received *response* message is missing one or more IEs/IE groups with specified criticality "*Reject IE*, the receiving node shall consider the procedure as unsuccessfully terminated and initiate local error handling.

#### Ignore IE and Notify Sender:

- if a received message *initiating* a procedure is missing one or more IEs/IE groups with specified criticality "Ignore IE and Notify Sender", the receiving node shall ignore that those IEs are missing and continue with the procedure based on the other IEs/IE groups present in the message and report in the response message of the procedure that one or more IEs/IE groups were missing. In case the information received in the initiating message was insufficient to determine a value for all IEs that are required to be present in the response message, the receiving node shall instead terminate the procedure and initiate the Error Indication procedure.
- if a received message *initiating* a procedure that does not have a message to report the outcome of the procedure is missing one or more IEs/IE groups with specified criticality "*Ignore IE and Notify Sender*", the receiving node shall ignore that those IEs are missing and continue with the procedure based on the other IEs/IE groups present in the message and initiate the Error Indication procedure to report that one or more IEs/IE groups were missing.
- if a received *response* message is missing one or more IEs/IE groups with specified criticality "*Ignore IE and Notify Sender*", the receiving node shall ignore that those IEs are missing and continue with the procedure based on the other IEs/IE groups present in the message and initiate the Error Indication procedure to report that one or more IEs/IE groups were missing.

#### **Ignore IE:**

- if a received message *initiating* a procedure is missing one or more IEs/IE groups with specified criticality "*Ignore IE*", the receiving node shall ignore that those IEs are missing and continue with the procedure based on the other IEs/IE groups present in the message.
- if a received *response* message is missing one or more IEs/IE groups with specified criticality "*Ignore IE*", the receiving node shall ignore that those IEs/IE groups are missing and continue with the procedure based on the other IEs/IE groups present in the message.

When reporting missing IEs/IE groups with specified criticality "Reject IE" or "Ignore IE and Notify Sender" using a response message defined for the procedure, the Information Element Criticality Diagnostics IE shall be included in the Criticality Diagnostics IE for each reported IE/IE group.

When reporting missing IEs/IE groups with specified criticality "Reject IE" or "Ignore IE and Notify Sender" using the Error Indication procedure, the Procedure Code IE, the Triggering Message IE, Procedure Criticality IE, and the Information Element Criticality Diagnostics IE shall be included in the Criticality Diagnostics IE for each reported IE/IE group.

# 10.3.6 IEs or IE groups received in wrong order or with too many occurrences or erroneously present

If a message with IEs or IE groups in wrong order or with too many occurrences is received or if IEs or IE groups with a conditional presence are present when the condition is not met (i.e., erroneously present), the receiving node shall behave according to the following:

- If a message *initiating* a procedure is received containing IEs or IE groups in wrong order or with too many occurrences or erroneously present, none of the functional requests of the message shall be executed. The receiving node shall reject the procedure and report the cause value "Abstract Syntax Error (Falsely Constructed Message)" using the message normally used to report unsuccessful outcome of the procedure. In case the information received in the initiating message was insufficient to determine a value for all IEs that are required to be present in the message used to report the unsuccessful outcome of the procedure, the receiving node shall instead terminate the procedure and initiate the Error Indication procedure.
- If a message *initiating* a procedure that does not have a message to report unsuccessful outcome is received containing IEs or IE groups in wrong order or with too many occurrences or erroneously present, the receiving

node shall terminate the procedure and initiate the Error Indication procedure, and use cause value "Abstract Syntax Error (Falsely Constructed Message)".

- If a *response* message is received containing IEs or IE groups in wrong order or with too many occurrences or erroneously present, the receiving node shall consider the procedure as unsuccessfully terminated and initiate local error handling.

When determining the correct order only the IEs specified in the specification version used by the receiver shall be considered.

## 10.4 Logical Error

Logical error situations occur when a message is comprehended correctly, but the information contained within the message is not valid (i.e., semantic error), or describes a procedure which is not compatible with the state of the receiver. In these conditions, the following behaviour shall be performed (unless otherwise specified) as defined by the class of the elementary procedure, irrespective of the criticality information of the IEs/IE groups containing the erroneous values.

#### Class 1:

Where the logical error occurs in a request message of a class 1 procedure, and the procedure has a message to report this unsuccessful outcome, this message shall be sent with an appropriate cause value. Typical cause values are:

- Semantic Error.
- Message not compatible with receiver state.

Where the logical error is contained in a request message of a class 1 procedure, and the procedure does not have a message to report this unsuccessful outcome, the procedure shall be terminated and the Error Indication procedure shall be initiated with an appropriate cause value. The *Procedure Code* IE and the *Triggering Message* IE within the *Criticality Diagnostics* IE shall then be included in order to identify the message containing the logical error.

Where the logical error exists in a response message of a class 1 procedure, the procedure shall be considered as unsuccessfully terminated and local error handling shall be initiated.

#### Class 2:

Where the logical error occurs in a message of a class 2 procedure, the procedure shall be terminated and the Error Indication procedure shall be initiated with an appropriate cause value. The *Procedure Code* IE and the *Triggering Message* IE within the *Criticality Diagnostics* IE shall then be included in order to identify the message containing the logical error.

## 10.5 Exceptions

The error handling for all the cases described hereafter shall take precedence over any other error handling described in the other subclauses of clause 10.

- If any type of error (Transfer Syntax Error, Abstract Syntax Error or Logical Error) is detected in the ERROR INDICATION message, it shall not trigger the Error Indication procedure in the receiving Node but local error handling.
- In case a response message or Error Indication message needs to be returned, but the information necessary to determine the receiver of that message is missing, the procedure shall be considered as unsuccessfully terminated and local error handling shall be initiated.
- If an error that terminates a procedure occurs, the returned cause value shall reflect the error that caused the termination of the procedure even if one or more abstract syntax errors with criticality "ignore and notify" have earlier occurred within the same procedure.
- If an AP ID error is detected, the error handling as described in subclause 10.6 shall be applied.

## 10.6 Handling of AP ID

NOTE:

The "first message", the "first returned message" and the "last message" as used below correspond to messages for a UE-associated logical connection. The "first message" has a new AP ID from the sending node and the "first returned message" is the first response message, which has a new AP ID from the node sending the "first returned message". Thereafter the two AP IDs are included in all messages over the UE-associated logical connection unless otherwise allowed by the specification. The "last message" is a message sent by a node in order to complete the termination of a given UE-associated logical connection, such that no other messages for the same connection are expected in either direction. The nodes should ensure as far as possible that previously allocated AP ID are not immediately reused.

If a node receives a first returned message that includes an unknown local AP ID, the receiving node shall initiate an Error Indication procedure with inclusion of the received AP IDs from the peer node and an appropriate cause value. Both nodes shall initiate a local release of any established UE-associated logical connection (for the same NG interface) having these AP IDs as local or remote identifier.

If a node receives a message (other than the first or first returned messages) including an erroneous AP ID that is either an unknown local AP ID, or an inconsistent remote AP ID (i.e. it is different to the remote AP ID stored previously for this UE-associated logical connection) for the same NG interface:

- if this message is not the last message for this UE-associated logical connection, the node shall initiate an Error Indication procedure with inclusion of the received AP ID(s) from the peer node and an appropriate cause value. Both nodes shall initiate a local release of any established UE-associated logical connection (for the same NG interface) having the erroneous AP ID as either the local or remote identifier.
- if this message is the last message for this UE-associated logical connection, the receiving node shall initiate a local release of any established UE-associated logical connection (for the same NG interface) having the erroneous AP ID as either the local or remote identifier.

# Annex A (informative): Change history

D-1	NA - 4*	T.1.	105	-	-	Change history	
Date	Meeting	Tdoc	CR	Rev	Cat	Subject/Comment	New version
2017-04	R3#95b	R3-171209	-	-	-	TS skeleton	0.0.0
2017-04	R3#95b	R3-171311	-	-	-	Incorporated agreed TPs from R3#95b	0.0.1
2017-05	R3#96	R3-171480	-	-	-	Update of title page and change history	0.0.2
2017-05	R3#96	R3-171975	-	-	-	Incorporated agreed TPs from R3#96	0.1.0
2017-07	R3 NR#2	R3-172604	-	-	-	Incorporated agreed TPs from R3 NR#2 Adhoc	0.2.0
2017-08	R3#97	R3-173447	-	-	-	Incorporated agreed TPs from R3#97	0.3.0
2017-10	R3#97b	R3-174239	-	-	-	Incorporated agreed TPs from R3#97b	0.4.0
2017-12	R3#98	R3-175056	-	-	-	Incorporated agreed TPs from R3#98	0.5.0
2018-01	R3 NR#1	R3-180651	-	-	-	Incorporated agreed TPs from R3 NR Adhoc 1801	0.6.0
2018-03	R3#99	R3-181588	-	-	-	Incorporated agreed TPs from R3#99	0.7.0
2018-04 2018-05	R3#99b	R3-182524 R3-183592	-	-	-	Incorporated agreed TPs from R3#99b Incorporated agreed TPs from R3#100	0.8.0
2018-05	R3#100 RAN#80	RP-180737	-	-	-	For approval	1.0.0
2018-06	RAN#80	-	<del> -</del>	_	-	Specification approved at TSG-RAN and placed under change	15.0.0
						control	
2018-09	RAN#81	RP-181922	0001	2	F	NR Corrections (38.413 Baseline CR covering RAN3-101 agreements)	15.1.0
2018-12	RAN#82	RP-182448	0003	2	F	Baseline CR for TS 38.413	15.2.0
2019-03	RAN#83	RP-190556	0005	3	F	NGAP Corrections for UP Security Handling in DC during PDU Session Lifetime	15.3.0
2019-03	RAN#83	RP-190555	0008	2	F	Separate UL/DL limits for UE's maximum IP rate	15.3.0
2019-03	RAN#83	RP-190554		1	F	Data volume reporting for MR-DC with 5GC	15.3.0
2019-03	RAN#83	RP-190554		3	F	Correction of PDU Session split at handover	15.3.0
2019-03	RAN#83	RP-190556		1	F	Correction of EPS Voice Fallback	15.3.0
2019-03	RAN#83	RP-190556		'	F	Correction of Slice support over NG	15.3.0
2019-03	RAN#83	RP-190556	0012	1	F	Rapporteur updates for TS 38.413	15.3.0
2019-03	RAN#83	RP-190556		-	F	Correction of User Location Information IE presence in	15.3.0
2019-03	RAN#83	RP-190556	0019	1	F	HANDOVER NOTIFY  Correction to PBC state report	15.3.0
2019-03				- 1		Correction to RRC state report	15.3.0
2019-03	RAN#83	RP-190555		-	F	Support of RAN initiated multiple SCTP associations	15.3.0
	RAN#83	RP-190556		-	F	Corrections on RAN/AMF Configuration Update	
2019-03	RAN#83	RP-190556		2	F	Correction of EPC interworking	15.3.0
2019-03	RAN#83	RP-190556		1	F	Correction of Emergency Fallback	15.3.0
2019-03	RAN#83	RP-190202		3	F	Transfer of the PSCell information to Core Network	15.3.0
2019-03	RAN#83	RP-190558		1	F	Release due to pre-emption	15.3.0
2019-03	RAN#83	RP-190558		-	F	Handling of APID for the first returned message	15.3.0
2019-03	RAN#83	RP-190556		-	F	Clarification on the usage of TNL information	15.3.0
2019-03	RAN#83	RP-190556		1	F	NG Setup Correction and UE context retention	15.3.0
2019-03	RAN#83	RP-190556	0045	1	F	UE AMBR handling in PDU Session Resouce Setup procedure	15.3.0
2019-03	RAN#83	RP-190556	0046	1	F	Remove the second tunnel in the PDU session split, 5GC initiated	15.3.0
2019-03	RAN#83	RP-190556	0048	1	F	When NG-RAN node fails to set up a QoS flow for IMS voice	15.3.0
2019-03	RAN#83	RP-190556		-	F	Correction of ASN.1 for PDU Session Resource Modify	15.3.0
						Response	
2019-03	RAN#83	RP-190556		1	F	Cause value in RRC fallback case	15.3.0
2019-03	RAN#83	RP-190556		2	F	S-NSSAI update during EPS to 5GS handover	15.3.0
2019-03	RAN#83	RP-190561	0064	1	F	Introduction of TNL Address discovery for EN-DC (using new container)	15.3.0
2019-03	RAN#83	RP-190200	0066	-	F	Correction of ASN.1 for SON Configuration Transfer and PDU Session Resource Modify Request Transfer	15.3.0
2019-07	RAN#84	RP-191394	0000	1	F	Rapporteur updates for TS 38.413	15.4.0
2019-07	RP-84	RP-191394 RP-191397		2	F	Support of ongoing re-mapping on source side during SDAP	15.4.0
2019-07	RP-84	RP-191397	0067	1	F	Mobility  NGAP Further Clarification of S-NSSAI Update for EPS to	15.4.0
2019-07	RP-84	RP-191394	0071	-	F	5GS HO CR38413 for Clarification on PDU Session resource modify	15.4.0
2019-07	RP-84	RP-191397		1	F	Correction of Core Network Type Restrictions	15.4.0
2019-07	RP-84	RP-191394		1	F	Correction of PDU Session Release	15.4.0
2019-07	RP-84	RP-191395		2		Removal of multiple SCTP associations	15.4.0
	54	M 191090	0004		'	PS: This CR was not implemented as it was not based on	.0.4.0
2019-07	RP-84	RP-191394	0005		F	the latest version of the spec.  Correction on Error Indication procedure	15.4.0
2013-01	117-04	NF-191394	0090		Г	Correction on Error indication procedure	15.4.0

2019-07	RP-84	RP-191394	0101	2	F	GUAMI update in case of AMF change	15.4.0
2019-07	RP-84	RP-191397		2	F	Data forwarding and QoS flow remapping	15.4.0
2019-07	RP-84	RP-191397		1	F	Correction of CN Assistance Information	15.4.0
2019-07	RP-84	RP-191397		•	F	Correction of Network Instance	15.4.0
2019-07	RP-84	RP-191394		1	F	Correction of AMF UE NGAP ID	15.4.0
2019-07	RP-84	RP-191394		1	F	Adding PSCell to the User Location Information	15.4.0
2019-07	RP-84	RP-191394		-	F	Correction on Handover Command message	15.4.0
2019-07	RP-84	RP-191394			F	Correction of duplicated descriptions on additional UL tunnel information	15.4.0
2019-09	RP-85	RP-192167	0084	4	F	Removal of multiple SCTP associations	15.5.0
2019-09	RP-85	RP-192166		2	F	Correction of secured signalling connection	15.5.0
2019-09	RP-85	RP-192167	0178	1	F	PDU Session fail in Path Switch Request procedure	15.5.0
2019-09	RP-85	RP-192167	0195	2	F	Reroute NSSF provided information	15.5.0
2019-09	RP-85	RP-192166	0199		F	Correction of Handover Command message	15.5.0
2019-09	RP-85	RP-192167	0220	1	F	NGAP correction of Initial Context Setup procedure text	15.5.0
2019-09	RP-85	RP-192167	0226	1	F	Rapporteur cleanup of IE semantics descriptions	15.5.0
2019-12	RP-86	RP-192915	0256	1	F	Correction of NAS transparent container	15.6.0
2019-12	RP-86	RP-192915	0258	1	F	Missing procedural texts for NG interface	15.6.0
2019-12	RP-86	RP-192915	0261		F	Correction of Handover Command	15.6.0
2019-12	RP-86	RP-192915	0262	1	F	Correction of S-NSSAI coding	15.6.0
2019-12	RP-86	RP-192916	0269	1	F	Correction of Port Number IE in tabular	15.6.0
2019-12	RP-86	RP-192915	0276	2	F	Enable inclusion of the Backup AMF Name IE	15.6.0
2019-12	RP-86	RP-192916	0281		F	Correction of NG Handover	15.6.0
2019-12	RP-86	RP-192896	0286	3	F	Addition of abnormal cases for location report procedure	15.6.0
2019-12	RP-86	RP-192916	0300	2	F	CR to 38.413 on clarifications to Xn TNL Configuration Info	15.6.0
2019-12	RP-86	RP-192916	0303		F	CR for Clarification on purpose of path switch request	15.6.0
2019-12	RP-86	RP-193055	0304	-	F	Correction of Xn TNL Configuration Info	15.6.0
2020-03	RP-87-e	RP-200428	0316		F	Correction of Warning Security Information in ETWS primary notification	15.7.0
2020-03	RP-87-e	RP-200429	0318		F	Correction of tabular for Xn TNL Configuration Info	15.7.0
2020-03	RP-87-e	RP-200428			F	Correction of RAN paging priority	15.7.0
2020-03	RP-87-e	RP-200428	0336	1	F	PDU session resource in UE context release	15.7.0
2020-07	RP-88-e	RP-201091	0356	2	F	Clarification the usage of the New AMF UE NGAP ID included in the UE CONTEXT MODIFICATION REQUEST message	15.8.0
2020-07	RP-88-e	RP-201091	0370	1	F	Correction of Revoke E-RAB ID	15.8.0
2020-07	RP-88-e	RP-201334	0378	2	F	Correction on AS rekeying handling	15.8.0
2020-07	RP-88-e	RP-201090	0388	3	F	Correction to PDU SESSION RESOURCE MODIFY CONFIRM	15.8.0
2020-07	RP-88-e	RP-201092	0391	1	F	Selected PLMN ID for untrusted non-3GPP access	15.8.0
2020-07	RP-88-e	RP-201090	0394	2	F	Correstion on PDU Session Resrouce Modification Procedures	15.8.0

## History

Document history				
V15.0.0	July 2018	Publication		
V15.1.0	September 2018	Publication		
V15.2.0	April 2019	Publication		
V15.3.0	May 2019	Publication		
V15.4.0	July 2019	Publication		
V15.5.0	October 2019	Publication		
V15.6.0	January 2020	Publication		
V15.7.0	April 2020	Publication		
V15.8.0	July 2020	Publication		