

# ETSI TS 129 333 V10.2.0 (2012-01)



Technical Specification

**Universal Mobile Telecommunications System (UMTS);  
Multimedia Resource Function Controller (MRFC)  
- Multimedia Resource Function Processor (MRFP)  
Mp interface;  
Stage 3  
(3GPP TS 29.333 version 10.2.0 Release 10)**



---

**Reference**

RTS/TSGC-0429333va20

---

**Keywords**

UMTS

**ETSI**

650 Route des Lucioles  
F-06921 Sophia Antipolis Cedex - FRANCE

---

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C  
Association à but non lucratif enregistrée à la  
Sous-Préfecture de Grasse (06) N° 7803/88

---

**Important notice**

---

Individual copies of the present document can be downloaded from:

<http://www.etsi.org>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<http://portal.etsi.org/tb/status/status.asp>

If you find errors in the present document, please send your comment to one of the following services:

[http://portal.etsi.org/chaicor/ETSI\\_support.asp](http://portal.etsi.org/chaicor/ETSI_support.asp)

---

**Copyright Notification**

---

No part may be reproduced except as authorized by written permission.  
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2012.

All rights reserved.

**DECT**<sup>™</sup>, **PLUGTESTS**<sup>™</sup>, **UMTS**<sup>™</sup> and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.  
**3GPP**<sup>™</sup> and **LTE**<sup>™</sup> are Trade Marks of ETSI registered for the benefit of its Members and  
of the 3GPP Organizational Partners.

**GSM**<sup>®</sup> and the GSM logo are Trade Marks registered and owned by the GSM Association.

---

## Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<http://ipr.etsi.org>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

---

## Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

# Contents

Intellectual Property Rights .....	2
Foreword.....	2
Foreword.....	6
1 Scope .....	7
2 References .....	7
3 Definitions and symbols.....	9
3.1 Definitions .....	9
3.2 Symbols.....	9
4. Abbreviations .....	9
5 Profile Description .....	10
5.1 Profile Identification.....	10
5.2 Summary .....	10
5.3 Gateway Control Protocol Version .....	10
5.4 Connection Model .....	10
5.5 Context Attributes .....	11
5.6 Terminations.....	11
5.6.1 Termination Names.....	11
5.6.1.1 General .....	11
5.6.1.2 ASN.1 encoding .....	11
5.6.1.3 ABNF encoding .....	12
5.6.2 Multiplexed Terminations.....	12
5.7 Descriptors .....	12
5.7.1 Stream Descriptor .....	12
5.7.1.1 LocalControl Descriptor.....	12
5.7.2 Events Descriptor.....	13
5.7.3 EventBuffer Descriptor.....	14
5.7.4 Signals Descriptor.....	14
5.7.5 DigitMap Descriptor .....	15
5.7.6 Statistics Descriptor .....	15
5.7.7 ObservedEvents Descriptor .....	15
5.7.8 Topology Descriptor .....	16
5.7.9 Error Descriptor .....	16
5.8 Command API.....	16
5.8.1 Add .....	16
5.8.2 Modify .....	16
5.8.3 Subtract.....	17
5.8.4 Move.....	17
5.8.5 AuditValue.....	18
5.8.6 AuditCapabilities .....	18
5.8.7 Notify.....	18
5.8.8 ServiceChange .....	18
5.8.9 Manipulating and Auditing Context Attributes.....	19
5.9 Generic Command Syntax and Encoding.....	20
5.10 Transactions .....	20
5.11 Messages .....	21
5.12 Transport .....	21
5.13 Security .....	22
5.14 Packages.....	22
5.14.1 Mandatory Packages .....	22
5.14.2 Optional Packages .....	23
5.14.3 Package Usage Information .....	25
5.14.3.1 Generic Package.....	25
5.14.3.2 Base Root Package.....	27

5.14.3.3	Overload Control Package .....	28
5.14.3.4	Network Package .....	28
5.14.3.5	RTP Package .....	29
5.14.3.6	DTMF Detection Package .....	30
5.14.3.7	Call Progress Tones Generator Package .....	30
5.14.3.8	Basic Services Tones Generator Package .....	31
5.14.3.9	Expanded Call Progress Tones Generator Package .....	32
5.14.3.10	Basic Announcement Syntax Package .....	32
5.14.3.11	Voice Variable Syntax Package .....	33
5.14.3.12	Announcement Set Syntax Package .....	33
5.14.3.13	General Text Variable Type Package .....	34
5.14.3.14	Advanced Audio Server Base Package .....	34
5.14.3.15	Basic Call Progress Tones Generator with Directionality .....	35
5.14.3.16	AAS Recording Package .....	36
5.14.3.17	Multimedia Play Package .....	37
5.14.3.18	Generic Announcement Package .....	37
5.14.3.19	Intrusion Tones Generator Package .....	38
5.14.3.20	Business Tones Generation Package .....	39
5.14.3.21	Conferencing Tones Generation Package .....	39
5.14.3.22	Inactivity Timer Package .....	40
5.14.3.23	MGC Information Package .....	40
5.14.3.24	Advanced audio server base package for TTS enhancement .....	41
5.14.3.25	ASR Package .....	42
5.14.3.26	Multimedia Recording Package .....	43
5.14.3.27	Tone Generator Package .....	43
5.14.3.28	Hanging Termination Detection Package .....	44
5.14.3.29	MSRP Statistics Package .....	44
5.14.3.30	Play Message Package .....	45
5.14.3.31	Message Filtering Package .....	46
5.14.3.32	Record Message Package .....	47
5.14.3.33	Floor Control Package .....	48
5.14.3.34	Floor Control Policy Package .....	48
5.14.3.35	Floor Status Change Handling Package .....	49
5.14.3.36	Floor Control Signalling Package .....	50
5.14.3.37	Explicit Congestion Notification for RTP-over-UDP Support (ecnrous) .....	51
5.15	Mandatory Support of SDP and Annex C Information Elements .....	52
5.16	Optional support of SDP and Annex C information elements .....	55
5.17	Procedures .....	55
5.17.1	Formats and Codes .....	55
5.17.2	Call Related Procedures .....	59
5.17.2.1	General .....	59
5.17.2.2	Reserve IMS Resources .....	61
5.17.2.3	Configure IMS Resources .....	62
5.17.2.4	Reserve and Configure IMS Resources .....	63
5.17.2.5	Release IMS Termination .....	64
5.17.2.6	Send Tone .....	65
5.17.2.7	Stop Tone .....	66
5.17.2.8	Tone Completed .....	66
5.17.2.9	Start Announcement .....	66
5.17.2.10	Stop Announcement .....	68
5.17.2.11	Announcement Completed .....	68
5.17.2.12	Start TTS .....	68
5.17.2.13	Stop TTS .....	69
5.17.2.14	TTS Completed .....	69
5.17.2.15	Start Audio Record .....	70
5.17.2.16	Stop Audio Record .....	71
5.17.2.17	Audio Record Complete .....	71
5.17.2.18	Detect DTMF .....	72
5.17.2.19	Report DTMF .....	73
5.17.2.20	Stop DTMF Detection .....	73
5.17.2.21	ASR Request .....	74
5.17.2.22	ASR Completed .....	75

5.17.2.23	Stop ASR .....	75
5.17.2.24	Start Playing Multimedia .....	76
5.17.2.25	Stop Playing Multimedia.....	77
5.17.2.26	Playing Multimedia Completed .....	77
5.17.2.27	Start Multimedia Record .....	77
5.17.2.28	Stop Multimedia Record .....	79
5.17.2.29	Multimedia Record Completed .....	79
5.17.2.30	Adhoc Audio Conference.....	80
5.17.2.31	Multi-Media Conferencing.....	80
5.17.2.32	Termination heartbeat indication .....	80
5.17.2.33	Configure BFCP Termination .....	80
5.17.2.34	Configure Conference .....	81
5.17.2.35	Designate Floor Chair .....	82
5.17.2.36	Floor Request Decision .....	83
5.17.2.37	Report Floor Request Decision .....	84
5.17.2.38	Modify Media .....	84
5.17.2.39	Confirm Media Update .....	85
5.17.2.40	Start Playing Message.....	85
5.17.2.41	Stop Playing Message .....	86
5.17.2.42	Playing Message Completed .....	86
5.17.2.43	Start Message Record.....	87
5.17.2.44	Stop Message Record.....	88
5.17.2.45	Message Record Completed.....	88
5.17.2.46	Configure Granted Quota .....	89
5.17.2.47	Report Message Statistics .....	90
5.17.2.48	Configure Filtering Rules.....	90
5.17.2.49	ECN Failure Indication .....	91
5.17.3	Non-Call Related Procedures.....	92
5.17.3.1	General .....	92
5.17.3.2	MRFP Out Of Service.....	92
5.17.3.3	MRFP Communication Up .....	93
5.17.3.4	MRFP Register.....	93
5.17.3.5	MRFC Restoration .....	94
5.17.3.6	MRFP Re-Register .....	94
5.17.3.7	MRFC Ordered Re-register.....	94
5.17.3.8	Audit Value .....	95
5.17.3.9	Audit Capabilities .....	96
5.17.3.10	Capability Update .....	96
5.17.3.11	MRFC Out of Service .....	97
5.17.3.12	MRFP Resource Congestion Handling – Activate.....	97
5.17.3.13	MRFP Resource Congestion Handling – Indication .....	97
5.17.3.14	Command Rejected .....	98
5.17.3.15	MRFP Restoration.....	98
<b>Annex A (normative):</b>	<b>The W3C SSML Profile for TTS function.....</b>	<b>99</b>
A.1	Introduction .....	99
A.2	TTS Profile.....	99
<b>Annex B (normative):</b>	<b>The W3C SRGS Profile for ASR function.....</b>	<b>103</b>
B.1	Introduction .....	103
B.2	SRGS Profile .....	103
<b>Annex C (informative):</b>	<b>Change history .....</b>	<b>106</b>
History .....		108

---

# Foreword

This Technical Specification has been produced by the 3<sup>rd</sup> Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

---

# 1 Scope

The present document describes the protocol to be used on the Multimedia Resource Function Controller (MRFC) – Multimedia Resource Function Processor (MRFP) interface (Mp interface). The IMS architecture is described in 3GPP TS 23.228 [1], the functional requirements are described in 3G TS 23.333 [25]

This specification defines a profile of the Gateway Control Protocol (H.248.1), for controlling Multimedia Resource Function Processor supporting in-band user interaction, conferencing and transcoding for multimedia-services.

The present document is valid for a 3<sup>rd</sup> generation PLMN (UMTS) complying with Release 7 and later.

---

# 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

- [1] 3GPP TS 23.228: "IP Multimedia Subsystem (IMS); Stage 2".
- [2] 3GPP TS 23.002: "Network architecture".
- [3] ITU-T Recommendation H.248.1 (05/2002), Gateway control protocol: Version 2 + Corrigendum 1 (03/2004) and ITU-T Recommendation H.248.1 (09/2005), Gateway control protocol: Version 3 for Floor Control requirements.
- [4] ITU-T Recommendation H.248.4 (11/2000), Gateway control protocol: Transport over Stream Control Transmission Protocol (SCTP) + Corrigendum 1 (03/2004).
- [5] ITU-T Recommendation H.248.7 (03/2004), Gateway control protocol: Generic announcement package.
- [6] ITU-T Recommendation H.248.9 (03/2002), Gateway control protocol: Advanced media server package.
- [7] ITU-T Recommendation H.248.11 (11/2002), Gateway control protocol: Media gateway overload control package.
- [8] IETF RFC 2960: "Stream Control Transmission Protocol".
- [9] ITU-T Recommendation H.248.14 (03/2002), Gateway control protocol: Inactivity timer package.
- [10] ITU-T Recommendation H.248.16 (11/2002), Gateway control protocol: Enhanced digit collection packages and procedures + Corrigendum 1 (03/2004).
- [11] ITU-T Recommendation H.248.19 (03/2004) Gateway control protocol: Decomposed Multipoint Control Unit, Audio, Video and Data Conferencing package
- [12] ITU-T Recommendation H.248.27 (07/2003), Gateway control protocol: Supplemental Tones package
- [13] ITU-T Recommendation Q.1950 (12/2002), Bearer independent call bearer control protocol.
- [14] ITU-T Recommendation G.711 (11/1988), Pulse code modulation (PCM) of voice frequencies.



- [15] ITU-T Recommendation G.711 Appendix I (09/1999), A high quality low-complexity algorithm for packet loss concealment with G.711.
  - [16] ITU-T Recommendation G.711 Appendix I (09/1999), A comfort noise payload definition for ITU-T G.711 use in packet-based multimedia communication systems.
  - [17] ITU-T Recommendation E.180 (03/1998), Technical characteristics of tones for the telephone service.
  - [18] TS 183 022: Telecommunication and Internet converged Services and Protocols for Advanced Networking (TISPAN); MGC Information Package.
  - [19] ES 201 970 Access and Terminals (AT); Public Switched Telephone Networks (PSTN); Harmonized specification of physical and electrical characteristics at a 2-wire analogue presented Network Termination Point (NTP).
  - [20] IETF RFC 2327 (1998): "SDP: Session Description Protocol".
  - [21] IETF RFC 3551 (2003): "RTP Profile for Audio and Video Conferences with Minimal Control".
  - [22] IETF RFC 2833 (2000): "RTP Payload for DTMF Digits, Telephony Tones and Telephony Signals".
  - [23] IETF RFC 4040 (2005): "RTP payload format for a 64 kbit/s transparent call".
  - [24] IETF RFC 3555 (2003): "MIME Type Registration of RTP Payload Formats".
  - [25] 3GPP TS 23.333: "Multimedia Resource Function Controller (MRFC) – Multimedia Resource Function Processor (MRFP) Mp interface: Procedures Descriptions".
  - [26] ITU-T Recommendation H.248.9a1 (03/2007), "Gateway control protocol: Advanced media server package (draft work in progress)".
  - [27] 3GPP TS 29.163: "Interworking between the IM CN subsystem and CS networks – Stage 3".
  - [28] W3C Recommendation (September 2004): "Speech Synthesis Markup Language (SSML) Version 1.0".
  - [29] W3C Recommendation (September 2004): "Speech Recognition Grammar Specification (SRGS) Version 1.0".
  - [30] ITU-T Recommendation H.248.36 (09/2005): "Hanging Termination Detection Package".
  - [31] 3GPP TS 26.235: "Packet switched conversational multimedia applications; Default codecs".
  - [32] IETF RFC 4583 (2006): "Session Description Protocol (SDP) Format for Binary Floor Control Protocol (BFCP) Streams".
  - [33] ITU-T H.248.19 Ammendment 2 (02/2009): "Gateway Control Protocol: Decomposed multipoint control unit, audio, video and data conferencing packages: Floor Control Enhancements".
  - [34] IETF RFC 4975 (2007): "The Message Session Relay Protocol (MSRP)".
  - [35] ITU-T H.248.69 (03/2009): "Gateway control protocol: Packages for interworking between MSRP and H.248".
  - [36] IETF RFC 3168: "The Addition of Explicit Congestion Notification (ECN) to IP".
  - [37] IETF draft-ietf-avtcore-ecn-for-rtp-05 (10/2011): "Explicit Congestion Notification (ECN) for RTP over UDP".
- Editor's note:** the above document cannot be formally referenced until it is published as a RFC.
- [38] 3GPP TS 29.238: "Interconnection Border Control Functions (IBCF) – Transition Gateway (TrGW) interface, Ix Interface; Stage 3".
  - [39] IETF RFC 4145 (2005): "TCP-Based Media Transport in the Session Description Protocol (SDP)".

- [40] IETF RFC 4585 (2006): "Extended RTP Profile for Real-time Transport Control Protocol (RTCP) - Based Feedback (RTP/AVPF)".
- [41] 3GPP TS 26.114: "IP Multimedia Subsystem (IMS); Multimedia Telephony; Media handling and interaction".

---

## 3 Definitions and symbols

### 3.1 Definitions

For the purposes of the present document, the [following] terms and definitions [given in ... and the following] apply.

**Media Gateway:** See Recommendation H.248.1 [3].

**Media Gateway Controller:** See Recommendation H.248.1 [3].

**MultiMedia Resource Function Controller:** See 3GPP TS 23.002 [2].

**MultiMedia Resource Function Processor:** See 3GPP TS 23.002 [2].

### 3.2 Symbols

None.

---

## 4. Abbreviations

For the purposes of the present document, the following abbreviations apply:

CDR	Call Data Record
CN	Comfort Noise
CRC	Cyclic Redundancy Check
DNS	Domain Name System
DTMF	Dual Tone Multi Frequency
CE	Congestion Experienced
ECN	Explicit Congestion Notification
FEC	Forward Error Correction
IP	Internet Protocol
IPsec	IP Security
MGC	Media Gateway Controller
MGW	Media Gateway
MID	Message Identifier
MRFC	MultiMedia Resource Function Controller
MRFP	MultiMedia Resource Function Processor
OAM	Operation, Administration and Maintenance
OoS	Out of Service
PLC	Packet Loss Concealment
PT	Payload Type
QoS	Quality of Service
SCTP	Stream Control Transmission Protocol
SDP	Session Description Protocol
SPNE	Signal Processing Network Equipment
SSRC	Synchronisation Source
TCP	Transmission Control Protocol
TLS	Transport Layer Security
TTL	Time To Live
UDP	User Datagram Protocol
VBD	Voiceband Data

---

## 5 Profile Description

### 5.1 Profile Identification

The name and version of the profile that is sent in the service change command are:

**Table 5.1.1: Profile Identification**

<b>Profile name:</b>	MRF
<b>Version:</b>	3

### 5.2 Summary

The profile defined in the present document enables the control of media resource function processors (MRFP) supporting in-band user interaction, conferencing and transcoding for multimedia services.

This Profile describes the minimum mandatory settings and procedures required to fulfil the Media Gateway control requirements for the MRF.

In addition optional settings and procedures are described which fulfil optional features and where supported, the minimum mandatory settings within the optional procedures and packages are identified that must be supported in order to support that feature.

"Optional" or "O" means that it is optional for either the sender or the receiver to implement an element. If the receiving entity receives an optional element that it has not implemented it should send an Error Code (e.g. 445 "Unsupported or Unknown Property", 501 "Not Implemented", etc.). "Mandatory" or "M" means that it is mandatory for the receiver to implement an element. Whether it is mandatory for the sender to implement depends on specific functions; detail of whether elements of the core protocol are mandatory to be sent are defined in the stage 2 procedures, stage 3 procedures and/or the descriptions of individual packages.

The setting or modification of elements described in the profile under the heading "Used in Command" has the meaning that the property can be set/modified with that command. The property may be present in other commands (in order to preserve its value in accordance with ITU-T H.248.1[3]) when those commands are used for other procedures that affect the same descriptor.

This profile supports Explicit Congestion Notification.

### 5.3 Gateway Control Protocol Version

**Version 2** shall be the minimum version supported. Support of this version implies conformance to ITU-T Recommendation H.248 Version 2 [3].

**Version 3** shall be supported for the optional MRFP based Floor Control Server functionality.

### 5.4 Connection Model

Media Resource Function Processors shall support ephemeral terminations that sink and source IP traffic. This type of H.248 Termination is denoted IP in the following clauses.

**Table 5.4.1: Connection Model**

<b>Maximum number of contexts:</b>	Provisioned (NOTE 1)
<b>Maximum number of terminations per context:</b>	Unspecified(NOTE 2)
<b>Allowed terminations type combinations in a context:</b>	Not Applicable
NOTE 1: The actual number of supported contexts can be audited by the MRFC using the MaxNrOfContexts property defined in the Base Root Package.	
NOTE 2: Support of 1 termination in a context is the basic requirement for the MRFP e.g. for voice record. 2 terminations in a context are required for transcoding or any inband media detection or insertion whilst an unspecified number terminations may be required if conferencing is supported.	

## 5.5 Context Attributes

**Table 5.5.1: Context Attributes**

Context Attribute	Supported	Values Supported
<b>Topology</b>	Yes	See § 5.7.8
<b>Priority Indicator</b>	TBD	0-15
<b>Emergency Indicator</b>	No	Not Applicable
<b>IEPS Indicator</b>	No	
<b>ContextAttribute Descriptor</b>	Yes	If "yes" see clause 5.8.9 for details of supported attributes
<b>ContextIDList Parameter</b>	<Yes/No>	NA

Is the AND/OR Select operation Context Attribute supported?

<b>AND/OR Context Attribute</b>	<Yes/No>	<AND/OR/BOTH>
---------------------------------	----------	---------------

## 5.6 Terminations

### 5.6.1 Termination Names

#### 5.6.1.1 General

The Termination ID structure is provisioned in the MRFC and MRFP and is known by the MRFP and the MRFC at or before start up.

With ephemeral IP endpoint bearer types the internal structure of Termination ID is irrelevant for MRFC and MRFP and therefore Termination ID is only a numeric identifier for the termination.

#### 5.6.1.2 ASN.1 encoding

The following general structure of TerminationID shall be used:

4 octets shall be used for the termination ID. The following defines the general structure for the termination ID:

**Table 5.6.1.2.1: Termination ID**

Termination type	X
------------------	---

Termination type:

Length 3 bits

Values:

000 Reserved

001 Ephemeral termination

011 - 110 Reserved

111 Reserved for ROOT termination Id (ROOT Termination Id = 0xFFFFFFFF)

X:

Length 29 bits.

For IP termination, its usage is un-specified.

### 5.6.1.3 ABNF encoding

The following general structure of termination ID shall be used:

TerminationID = "ROOT" / pathName / "\$" / "\*" ; according to ITU-T H.248.1 [3] Annex B.

## 5.6.2 Multiplexed Terminations

**Table 5.6.2.1: Multiplexed Terminations**

<b>Multiplex Terminations Supported?</b>	NO
------------------------------------------	----

## 5.7 Descriptors

### 5.7.1 Stream Descriptor

**Table 5.7.1.1: Stream Descriptor**

<b>Maximum number of streams per termination type</b>	ALL	Unspecified (NOTE)
NOTE:	At least 1 stream for each media (e.g. video+audio = 2 streams). If only one stream is applicable, then the MRFC may omit the Stream Descriptor and the MRFP shall assume that StreamID =1.	

#### 5.7.1.1 LocalControl Descriptor

The following tables specify the level of support required with regard to the properties in the local control descriptor.

**Table 5.7.1.1.1: Reserve Group and Reserve Value**

		<b>Termination Type</b>	<b>Stream Type</b>
<b>Reserve group used:</b>	NO (NOTE)	-	-
<b>Reserve value used:</b>	YES(NOTE1)	IP	Audio, Video
NOTE:	Support of Reserve Group in case of multiple p-time values requires further studies		
NOTE1:	Used for audio streams where RFC2833 is also specified and for conference where participants are invited to join the conference.		

Table 5.7.1.1.2: Stream Mode

Termination Type	Stream Type	Allowed StreamMode Values
ALL except ROOT	Any	Send, Receive, Send and Receive, Inactive

## 5.7.2 Events Descriptor

Table 5.7.2.1: Events Descriptor

Events settable on termination types and stream types:	Yes		
<i>If yes</i>	Event ID	Termination Type	Stream Type
	g/*	IP	Audio, Video
	nt/*	IP	Audio, Video
	rtp/*	IP	Audio, Video
	aasrec/*	IP	Audio, Video
	aasb/*	IP	Audio, Video
	dd/d0-dd	IP	Audio
	it/*	ROOT	Not Applicable
	ocp/mg_overload	ROOT	Not Applicable
	aastts/*	IP	Audio
	asr/*	IP	Audio
	mrp/*	IP	Audio, Video
	mpp/*	IP	Audio, Video
	vavsp/*	IP	Audio, Video
	Hangterm/thb	IP	Audio, Video
	msrpstat/mquota	IP	Message
	mess/*	IP	Message
	fschp/*	IP	Audio, Video
	ECN Failure (ecnrous/fail, 0x010b/0x0001) see 3GPP TS 29.238 Annex B [38]	IP	Audio, Video

Table 5.7.2.2: Event Buffer Control

Event Buffer Control used:	No
----------------------------	----

Table 5.7.2.3: Keep Active

Keepactive used on events:	Yes
----------------------------	-----

Table 5.7.2.4: Embedding in event

Embedded events in an event descriptor:	No
Embedded signals in an event descriptor:	No

Table 5.7.2.5: Notify Behaviour

NotifyBehaviour used on events:	NO
<i>If yes,</i>	Supported values
	Not Applicable

### 5.7.3 EventBuffer Descriptor

Table 5.7.3.1: Event Buffer

<b>Event Buffer descriptor used:</b>	No
--------------------------------------	----

### 5.7.4 Signals Descriptor

Table 5.7.4.1: Signals dependant on termination or streams

<b>Signals settable dependant on termination or streams types:</b>	Yes		
<i>If yes</i>	<b>Signal ID</b>	<b>Termination Type</b>	<b>Stream Type / ID</b>
	cg/*	IP	Audio
	srvtn/*	IP	Audio
	xcg/*	IP	Audio
	an/apf	IP	Audio, Video
	int/*	IP	Audio
	biztn/*	IP	Audio
	aasrec/*	IP	Audio, Video
	Aasdc	IP	Audio, Video
	aasb/*	IP	Audio, Video
	confn/*	All except ROOT	Audio
	Tonegen/*	IP	Audio
	bcg/*	IP	Audio
	aastts/*	IP	Audio
	asr/*	IP	Audio
	mrp/*	IP	Audio, video
	mpp/*	IP	Audio, video
	mess/*	IP	Message
	recmess/*	IP	Message
	fschp/*	IP	Audio, video

Table 5.7.4.2: Signal Lists

<b>Signals Lists supported:</b>	Yes	
<i>If yes</i>	<b>Termination Type Supporting Lists</b>	IP
	<b>Stream Type Supporting lists</b>	Audio, Video
	<b>Maximum number of signals per signal list</b>	Provisioned

Table 5.7.4.3: Signal type and duration

<b>Signal type and duration supported?</b>	Yes	
<i>If yes</i>	<b>Signal ID</b>	<b>Type or duration override</b>
	ALL	Both

Table 5.7.4.4: Signal Direction

<b>Signal Direction supported:</b>	No
------------------------------------	----

Table 5.7.4.5: Notify completion

<b>Notify completion supported:</b>	Yes	
<i>If yes</i>	<b>Signal ID</b>	<b>Type of completion supported</b>
	cg/*, svrtn/*, xcg/*, an/*, int/*, biztn/*, conftn/*, tonegen/*, bcg/*, aasb/*, aastts/*, mpp/*, fschp/*	ALL

Table 5.7.4.6: RequestID Parameter

<b>RequestID Parameter Supported:</b>	Yes
---------------------------------------	-----

Table 5.7.4.7: Signals played simultaneously

<b>Signals played simultaneously:</b>	No(NOTE)	
<i>If yes</i>	<b>Signal Ids that can be played simultaneously:</b>	-
NOTE: Signal for recording audio or multimedia may be played simultaneously with signals for playing announcement.		

Table 5.7.4.8: Keep Active

<b>Keepactive used on signals:</b>	Yes
------------------------------------	-----

## 5.7.5 DigitMap Descriptor

Table 5.7.5.1: DigitMap Descriptor

<b>DigitMaps supported:</b>	NO		
<i>If yes</i>	<b>DigitMap Name</b>	<b>Structure</b>	<b>Timers</b>

## 5.7.6 Statistics Descriptor

Table 5.7.6.1: Statistics Descriptor

<b>Statistics supported on:</b>	Both
---------------------------------	------

Table 5.7.6.2: Statistics reported on Subtract

<b>Statistics reported on Subtract:</b>	Yes		
<i>If yes</i>	<b>Statistic IDs Reported</b>	<b>Termination Type</b>	<b>Stream Type</b>
	msrpstat/*	IP	Message

## 5.7.7 ObservedEvents Descriptor

Table 5.7.7.1: ObservedEvents Descriptor

<b>Event detection time supported:</b>	Yes
----------------------------------------	-----



## 5.7.8 Topology Descriptor

**Table 5.7.8.1: Topology Descriptor**

<b>Allowed triples:</b>	(T1,T2, isolate) (T1,T2, oneway) (T1,T2, bothway)
-------------------------	---------------------------------------------------------

## 5.7.9 Error Descriptor

**Table 5.7.9.1: Error codes sent by the MRFC**

<b>Supported H.248.8 Error Codes:</b>	400-403, 406, 410, 411, 421, 422, 430, 431, 442, 443, 444, 446, 458, 501-506, 533
<b>Supported Error Codes defined in packages:</b>	All error codes defined in supported packages are supported.

**Table 5.7.9.2: Error codes sent by the MRFP**

<b>Supported H.248.8 Error Codes:</b>	400-411, 412, 421,422,430, 431, 432-435,440,441,442, 471, 500-517, 522-539.
<b>Supported Error Codes defined in packages:</b>	All error codes defined in supported packages are supported.

## 5.8 Command API

### 5.8.1 Add

**Table 5.8.1.1: Descriptors used by Add request**

<b>Descriptors used by Add request:</b>	- Events, Signals, Media (TerminationState, LocalControl, Local and Remote)
-----------------------------------------	-----------------------------------------------------------------------------

**Table 5.8.1.2: Descriptors used by Add reply**

<b>Descriptors used by Add reply:</b>	Events, Signals, Media (TerminationState, LocalControl, Local and Remote)Error  When command request excludes an Audit Descriptor, the MGW response shall only include descriptors which contained underspecified or overspecified properties in the command request. Furthermore, only those properties that were underspecified or overspecified in the request shall be sent in the reply. Exceptions to this rule are: <ul style="list-style-type: none"> <li>- The Error Descriptor</li> <li>- SDP properties returned in "Reserve IMS Resources" and "Reserve and Configure IMS Resources" procedures, as specified in 15.17.2.2 and 15.17.2.4</li> </ul>
---------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### 5.8.2 Modify

**Table 5.8.2.1: Descriptors used by Modify request**

<b>Descriptors used by Modify request:</b>	Events, Signals, Media (TerminationState, LocalControl, Local and Remote)
--------------------------------------------	---------------------------------------------------------------------------

**Table 5.8.2.2: Descriptors used by Modify reply**

<b>Descriptors used by Modify reply:</b>	<p>Events, Signals, Media (TerminationState, LocalControl, Local and Remote),Error</p> <p>When command request excludes an Audit Descriptor, the MGW response shall only include descriptors which contained underspecified or overspecified properties in the command request. Furthermore, only those properties that were underspecified or overspecified in the request shall be sent in the reply. Exceptions to this rule are:</p> <ul style="list-style-type: none"> <li>- -The Error Descriptor</li> <li>- SDP properties returned in "Configure IMS Resources" procedure as specified in 15.17.2.3.</li> </ul>
------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### 5.8.3 Subtract

**Table 5.8.3.1: Descriptors used in Subtract request**

<b>Descriptors used by Subtract request:</b>	Audit (empty) or None
----------------------------------------------	-----------------------

**Table 5.8.3.2: Descriptors used in Subtract reply**

<b>Descriptors used by Subtract reply:</b>	None
--------------------------------------------	------

### 5.8.4 Move

**Table 5.8.4.1: Command Move**

<b>Move command used:</b>	Yes
---------------------------	-----

**Table 5.8.4.2: Descriptor used by Move command**

<b>Descriptors used by Move Request:</b>	Events, Signals, Media (TerminationState, LocalControl, Local and Remote)
<b>Descriptors used by Move Reply:</b>	<p>Events, Signals, Media (TerminationState, LocalControl, Local and Remote), Error</p> <p>When command request excludes an Audit Descriptor, the MGW response shall only include descriptors which contained underspecified or overspecified properties in the command request. Furthermore, only those properties that were underspecified or overspecified in the request shall be sent in the reply. Exceptions to this rule are:</p> <ul style="list-style-type: none"> <li>- -The Error Descriptor</li> </ul>

## 5.8.5 AuditValue

**Table 5.8.5.1: Auditvalue**

<b>Audited Properties:</b>	<b>Property Name and Identity</b>	<b>Descriptor</b>
Termination ID	ServiceState: - Root (MGW Audit)	Termination State Descriptor
Termination ID	MGC information (mgcinfo) - individualtermination (NOTE1)	LocalControl Descriptor
Termination ID	For Packages: - Root	Packages Descriptor (NOTE2)
Termination ID	None (MGW Audit) : - Root	Audit (empty) Descriptor
<b>Audited Statistics:</b>	Supported Statistics (NOTE3) (NOTE2)	
<b>Audited Signals:</b>	ALL	
<b>Audited Events:</b>	ALL	
<b>Package Audit possible:</b>	Yes	
NOTE1: The purpose to audit an individual Termination is to retrieve MGC Information if supported.		
NOTE2: Optional		
NOTE3: The statistics defined in the MSRP Statistics Package can be obtained via the MRFC auditing the MRFP. The supported statistics are msrpstat/nms, msrpstat/nmr, msrpstat/vms and msrpstat/vmr.		

## 5.8.6 AuditCapabilities

**Table 5.8.6.1: AuditCapabilities**

<b>Audited Properties:</b>	<b>Property Name and Identity</b>	<b>Descriptor</b>
	FFS	FFS
<b>Audited Statistics:</b>	None	
<b>Audited Signals:</b>	None	
<b>Audited Events:</b>	None	

## 5.8.7 Notify

**Table 5.8.7.1: Notify**

<b>Descriptors used by Notify Request or Reply:</b>	ObservedEvents, Error
NOTE : The Error Descriptor shall not be used in Notify Request.	

## 5.8.8 ServiceChange

**Table 5.8.8.1: Service Change Methods and Reason sent by MRFC**

<b>Service Change Methods Supported:</b>	<b>ServiceChange Reasons supported:</b>
Restart (NOTE 1)	"900 Service Restored" "901 Cold Boot", "902 Warm Boot".
Graceful (NOTE 1)	"905 Termination Taken Out Of Service"
Forced (NOTE 1)	"905 Termination Taken Out Of Service"
Handoff (NOTE 1, NOTE 2)	"903 MGC Directed Change"
NOTE : When a Service Change command on the Root termination with a method other than Graceful is sent, the command shall always be sent as the only command in a message. The sending node shall always wait for the reply to a Service Change command on the Root termination with a method other than Graceful before sending further command requests. A Service Change command on the Root termination with method Graceful may be combined with other commands in a single message.	
NOTE 1: ROOT Only.	
NOTE 2: Not involving more than 1 MRFC. No support of handoff relates to a network deployment scenario with "primary H.248 systems only", which translates to no geographic redundancy of the MRFC.	

**Table 5.8.8.2: Service Change Methods and Reason sent by MRFP:**

<b>Service Change Methods Supported:</b>	<b>ServiceChange Reasons supported:</b>
Restart (NOTE 1)	"900 Service Restored", "901 Cold Boot", "902 Warm Boot".
Graceful (NOTE 1)	"908 MG Impending Failure "
Forced (NOTE 1)	"905 Termination Taken Out Of Service"
Handoff (NOTE 1, NOTE 2)	"903 MGC Directed Change"
Failover (NOTE 3)	"909 MGC Impending Failure"
Disconnected (NOTE 1)	"900 Service Restored"
<p>NOTE : When a Service Change command on the Root termination with a method other than Graceful is sent, the command shall always be sent as the only command in a message. The sending node shall always wait for the reply to a Service Change command on the Root termination with a method other than Graceful before sending further command requests. A Service Change command on the Root termination with method Graceful may be combined with other commands in a single message.</p> <p>NOTE 1: ROOT only.</p> <p>NOTE 2: In response to a MGC Ordered Re-Register</p> <p>NOTE 3: Only for TISPAN NGN MRF. Not involving more than 1 MRFP. No support of handoff relates to a network deployment scenario with "primary H.248 systems only", which translates to no geographic redundancy of the MGW.</p>	

**Table 5.8.8.3: Service Change Address**

<b>ServiceChangeAddress used:</b>	No
-----------------------------------	----

**Table 5.8.8.4: Service Change Delay**

<b>ServiceChangeDelay used:</b>	No
<i>If yes</i>	<b>Valid time period:</b> -

**Table 5.8.8.5: Service Change Incomplete Flag**

<b>ServiceChange Incomplete Flag used:</b>	No
--------------------------------------------	----

**Table 5.8.8.6: Service Change Version**

<b>Version used in ServiceChangeVersion:</b>	2
----------------------------------------------	---

**Table 5.8.8.7: Profile negotiation**

<b>Profile negotiation as per H.248.18:</b>	No
---------------------------------------------	----

## 5.8.9 Manipulating and Auditing Context Attributes

**Table 5.8.9.1: Manipulating and Auditing Context Attributes**

<b>Context Attributes Manipulated:</b>	ALL supported attributes (See table 5.5/1.) (NOTE1)
<b>Context Attributes Audited:</b>	ALL supported attributes (See table 5.5/1) (NOTE1)
<p>NOTE1: For ContextAttribute Descriptor, the details of supported attribute include: Floor Control Algorithm (fcpoli/fca), Max Floor Users (fcpoli/mfu), Floor Control Conference Identity (fcsig/fconfid) and Floor and Stream Association (fcsig/fsa)</p>	

## 5.9 Generic Command Syntax and Encoding

**Table 5.9.1: Encoding**

<b>Supported Encodings:</b>	Binary (optional) Text (optional) The receiver shall support: <ul style="list-style-type: none"> <li>• Short Token Notation</li> <li>• Long Token Notation</li> </ul>
-----------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## 5.10 Transactions

**Table 5.10.1: Transactions**

<b>Maximum number of Transaction Requests / Replies / TransResponseAcks / Segment Replies per message:</b>	10
NOTE : When more than one element are conveyed in one message, it is recommended that this message comprises a Transaction Request / Transaction Reply / Transaction Pending plus a Transaction Response Ack.	

**Table 5.10.2: Segmentation**

<b>Segmentation Supported:</b>	UDP : No SCTP : Inherent in transport
NOTE: The H.248 Segmentation Package according Annex E.14 of H.248.1 Version 3 is intended for H.248 transport technologies without the capability of automatic message segmentation. This method is not required for UDP- or SCTP-based H.248 signalling transport in this Profile.	

**Table 5.10.3: Commands per Transaction Request**

<b>Maximum number of commands per Transaction request:</b>	Unlimited
------------------------------------------------------------	-----------

**Table 5.10.4: Commands per Transaction Reply**

<b>Maximum number of commands per Transaction reply:</b>	Unlimited
----------------------------------------------------------	-----------

**Table 5.10.5: Optional Commands**

<b>Commands able to be marked "Optional":</b>	ALL
NOTE: The meaning of this table is that if one of the listed commands failed then the possibly present subsequent command within the same transaction will be processed.	

**Table 5.10.6: Transaction Timers**

<b>Transaction Timer:</b>	<b>Value</b>
NormalMGExecutionTime	Provisioned
NormalMGCEExecutionTime	Provisioned
MGOriginatedPendingLimit	Provisioned
MGCOrganatedPendingLimit	Provisioned
MGProvisionalResponseTimerValue	Provisioned
MGCProvisionalResponseTimerValue	Provisioned

## 5.11 Messages

It is recommended that MRFP and MRFC names are in the form of fully qualified domain name. For example the domain name of the MRFC may be of the form MRFC1.whatever.net and the name of the MRFP may be of the form mg1.whatever.net.

The fully qualified domain name will be used by the MRFP and MRFC as part of the "Message Identifier" in the H.248 messages which identifies the originator of the message.

The MRFC domain name is provisioned in the MRFP or retrieved from the DNS using SRV records.

The use of a domain name provides the following benefits:

- MRFPs and MRFCs are identified by their domain name, not their network addresses. Several addresses can be associated with a domain name. If a command cannot be forwarded to one of the network addresses, implementations shall retry the transmission using another address.
- MRFPs and MRFCs may move to another platform. The association between a logical name (domain name) and the actual platform are kept in the Domain Name Service (DNS). MRFP and MRFC shall keep track of the record's time-to-live read from the DNS. They shall query the DNS to refresh the information if the time-to-live has expired.

The domain name may be used by MRFC/MRFP for authentication purposes.

## 5.12 Transport

**Table 5.12.1: Transport**

<b>Supported Transports:</b>	Transport over SCTP shall be supported and shall conform to Recommendation H.248.4 [4]. Support of UDP is optional, dependent on a network operator's decision, based on the network configuration. <ul style="list-style-type: none"> <li>• SCTP(recommended) (NOTE1).</li> <li>• UDP(optional).</li> </ul>
NOTE: If using SCTP as defined in IETF RFC 2960 [8], the MRFP shall always be the node to perform the "Initiation".	
NOTE1: H.248 is "SCTP user" in this case of H.248/SCTP/IP based transport according ITU-T Rec. H.248.4. The number of used SCTP Streams for traffic of the H.248 Control Association must be defined, see § 8/H.248.4. A single SCTP Stream is the default assumption ("Single-Stream Mode") in this Profile.	

**Table 5.12.2: Segmentation**

<b>Segmentation Supported:</b>	No
--------------------------------	----

**Table 5.12.3: Control Association Monitoring**

<b>Control Association Monitoring Supported:</b>	Monitoring mechanism is dependent on used H.248 transport <ul style="list-style-type: none"> <li>• <b>SCTP:</b> inherent capability of SCTP (NOTE)</li> <li>• <b>UDP:</b> <ol style="list-style-type: none"> <li>1. H.248.14 (MRFP-driven monitoring)</li> <li>2. Empty AuditValue on ROOT (MRFC-driven monitoring)</li> </ol> </li> </ul>
NOTE: Use of H.248.14 for this is FFS.	

## 5.13 Security

**Table 5.13.1: Security**

<b>Supported Security:</b>	None
<b>NOTE:</b>	Both the MRFC and MRFP are assumed to be within a secure IP zone of a single operator.

## 5.14 Packages

### 5.14.1 Mandatory Packages

**Table 5.14.1: Mandatory packages**

<b>Mandatory Packages</b>		
<b>Package Name / Reference</b>	<b>Package ID</b>	<b>Version</b>
Generic (see ITU-T Recommendation H.248.1 [3])	g, (0x0001)	1
Base Root (see ITU-T Recommendation H.248.1 [3])	root, (0x0002)	2
Network (see ITU-T Recommendation H.248.1 [3])	nt, (0x000b)	1
Hanging Termination Detection (see ITU-T Recommendation H.248.36 [30]).	hangterm, (0x0098)	1

## 5.14.2 Optional Packages

**Table 5.14.2: Optional packages**

Optional Packages			
Package Name / Reference	Package ID	Version	Support dependent on:
DTMF Detection Package (see ITU-T Recommendation H.248.1 [3] Annex E.6);	dd, (0x0006)	1	Support is mandatory if DTMF Detection is supported.
Tone Generator Package (see ITU-T Recommendation H.248.1 [3])	tonegen, (0x0003)	1	This package is "extension only". It must be supported if extended but shall not be published over the protocol. It is here for information only.
Basic Call Progress Tones Generator with Directionality(see ITU-T Recommendation Q.1950 [13])	bcbg, (0x0023)	1	If CS type Services provided by network
Call Progress Tones Generator (see ITU-T Recommendation H.248.1 [3])	cg, (0x0007)	1	If CS type Services provided by network
Basic Services Tones Generator (see ITU-T Recommendation Q.1950 [13])	srvtg, (0x0025)	1	If CS type Services provided by network
Expanded Call Progress Tones Generator (see ITU-T Recommendation Q.1950 [13])	xcbg, (0x0024)	1	If CS type Services provided by network
Basic Announcement Syntax (see ITU-T Recommendation H.248.9 [6])	bannsyx, (0x0047)	1	Support is optional if playing announcement is supported.
Voice Variable Syntax (see ITU-T Recommendation H.248.9 [6])	vsyx, (0x0048)	1	Support is optional if playing announcement is supported.
Announcement Set Syntax (see ITU-T Recommendation H.248.9 [6])	setsyx, (0x0049)	2	Support is optional if playing announcement is supported.
General text Variable type (see ITU-T Recommendation H.248.9 [6])	phrsyx, (0x004a)	2	Support is optional if playing announcement is supported.
Advanced Audio Server Base (see ITU-T Recommendation H.248.9 a1 [26])	aasb, (0x0033)	2	Support is optional if playing announcement is supported.
AAS Recording package (see ITU-T Recommendation H.248.9 [6])	aasrec, (0x0035)	1	Support is optional if Audio Record is supported.
AAS segment management (see ITU-T Recommendation H.248.9 [6])	aassm, (0x0036)	1	



Generic Announcement (see ITU-T Recommendation H.248.7 [5])	an, (0x001d)	2	Support is mandatory if playing announcement is supported.
Intrusion Tones Generation (see ITU-T Recommendation Q.1950 [13])	int, (0x0027)	1	If CS type Services provided by network
Business Tones Generation (see ITU-T Recommendation Q.1950 [13])	biztn, (0x0028)	1	If CS type Services provided by network
Conferencing Tones Generation (see ITU-T Recommendation H.248.27 [12])	confnt, (0x0038)	1	Support is optional and may be used if Audio Conference is supported.
Inactivity Timer (see ITU-T Recommendation H.248.14 [9])	it, (0x0045)	1	Support is mandatory if UDP transport is enabled for H.248 messages.
MGC Information Package (see ITU-T Recommendation H.248.45,	mgcinfo, (0x00a0)	1	This package may be supported as an operator option. For this profile the information string shall be limited to 32 octets in length.
Advanced audio server base package for TTS enhancement (see ITU-T Recommendation H.248.9 a1 [26])	aastts, (0x00a8)	1	Support is mandatory if Text to Speech is supported.
ASR package (see ITU-T Recommendation H.248.9 a1 [26])	asr, (0x00a6)	1	Support is mandatory if Automatic Speech Recognition is supported.
Multimedia Recording Package (see ITU-T Recommendation H.248.9 a1 [26])	mrp, (0x00b3)	1	Support is mandatory if Multimedia recording is supported.
Multimedia play package (see ITU-T Recommendation H.248.9 a1 [26])	mpp, (0x00a9)	1	Support is mandatory if Multimedia announcement file is supported.
Overload Control Package (see ITU-T Recommendation H.248.11 [7])	ocp, (0x0051)	1	
RTP Package (see ITU-T Recommendation H.248.1 [3])	rtp, (0x000c)	1	
MSRP Statistics Package (see ITU-T Recommendation H.248.69 [35])	msrpstat, (0x00ea)	1	Support is mandatory if Message conference is supported.
Play Message Package (see ITU-T Recommendation H.248.69 [35])	mess, (0x00ec)	1	Support is mandatory if Message conference is supported.
Message Filtering Package (see ITU-T Recommendation H.248.69 [35])	mf, (0x00ef)	1	Support is mandatory if Message conference is supported.
Record Message Package (see ITU-T Recommendation H.248.69 [35])	recmess, (0x00f1)	1	Support is mandatory if Message conference is supported.
Floor Control Package (see ITU-T Recommendation H.248.19a2 [33])	fcp, (0x006e)	2	Support is mandatory if Floor control is supported.

Floor Control Policy Package (see ITU-T Recommendation H.248.19a2 [33])	fcpoli, (0x00ab)	1	Support is mandatory if Floor control is supported.
Floor Status Change Handling Package (see ITU-T Recommendation H.248.19a2 [33])	fschp, (0x00aa)	1	Support is mandatory if Floor control is supported.
Floor Control Signalling Package (see ITU-T Recommendation H.248.19a2 [33])	fcsig, (0x00e5)	1	Support is mandatory if Floor control is supported.
Explicit Congestion Notification for RTP-over-UDP Support (see 3GPP TS 29.238 Annex B) [38])	ecnrous (0x010b)	1	Support of ECN feature

### 5.14.3 Package Usage Information

#### 5.14.3.1 Generic Package

**Table 5.14.3.1.1: Package Usage Information for Generic Package**

Properties	Mandatory/Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
Signals	Mandatory/Optional	Used in command:		Duration Provisioned Value:
None	-	-	-	-
	Signal Parameters	Mandatory/Optional	Supported Values:	Duration Provisioned Value:
	-	-	-	-
Events	Mandatory/Optional	Used in command:		
Cause (g/cause, 0x0001/0x0001)	M	ADD, MOD, NOTIFY		
	Event Parameters	Mandatory/Optional	Supported Values:	Provisioned Value:
	None	-	-	-
	ObservedEvent Parameters	Mandatory/Optional	Supported Values:	Provisioned Value:
	General Cause (Generalcause, 0X0001)	M	"NR" Normal Release (0x0001) "UR" Unavailable Resources (0x0002) "FT" Failure, Temporary (0x0003) "FP" Failure, Permanent (0x0004) "IW" Interworking Error (0x0005) "UN" Unsupported (0x0006)	-
Failure Cause (FailureCause, 0x0002)	O	Octet String	-	
Signal Completion. (g/sc, 0x0001/0x0002)	M	ADD, MOD, MOVE, NOTIFY		
	Event Parameters	Mandatory/Optional	Supported Values:	Provisioned Value:
	None	-	-	-

	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	Signal Identity (SigID, 0x0001)	M	pkgdName syntax	-
	Termination Method (Meth, 0x0002)	M	"TO" (0x0001) Signal timed out or otherwise completed on its own "EV" (0x0002) Interrupted by event "SD" (0x0003) Halted by new Signals descriptor "NC" (0x0004) Not completed, other cause	-
	Signal List Id (SLID, 0x0003)	O	Integer	Not Applicable
	Request ID (RID, 0x0004)	O	String indicating the Request ID	-
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Supported Values:</b>
None	-	-		-
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.2 Base Root Package

Table 5.14.3.2.1: Package Usage Information for Base Root Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
MaxNrOfContexts (root/maxNumberOfContexts, 0x0002/0x0001)	M	AuditValue	1 and up	Implementation Specific
MaxTerminationsPerContext (root/maxTerminationsPerContext, 0x0002/0x0002)	O	AuditValue	See 5.4	Implementation Specific
normalMGExecutionTime (root/normalMGExecutionTime, 0x0002/0x0003)	O	AuditValue	Integer	Operator Defined
normalMGCEExecutionTime (root/normalMGCEExecutionTime, 0x0002/0x0004)	O	AuditValue	Integer	Operator Defined
MGProvisionalResponseTimerValue (root/ MGProvisionalResponseTimerValue, 0x0002/0x0005)	O	AuditValue	Integer(NormalMGExecutionTime + networkdelay)	Operator Defined
MGCProvisionalResponseTimerValue (root/ MGCProvisionalResponseTimerValue, 0x0002/0x0006)	O	AuditValue	Integer (initially NormalMGCEExecutionTime + networkdelay)	Operator Defined
MGCOriginatedPendingLimit (root/ MGCOriginatedPendingLimit, 0x0002/0x0007)	O	AuditValue	Integer	Operator Defined
MGOOriginatedPendingLimit (root/ MGOOriginatedPendingLimit, 0x0002/0x0008)	O	AuditValue	Integer	Operator Defined
<b>Signals</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
<b>None</b>	-	-		< -
	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	-	-	-	-
<b>Events</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		
None	-	-		
	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	
None	-	-	-	
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.3 Overload Control Package

Table 5.14.3.3.1: Package Usage Information for Overload Control Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
Signals	Mandatory/ Optional	Used in command:		Duration Provisioned Value:
None	-	-		-
	Signal Parameters	Mandatory/ Optional	Supported Values:	Duration Provisioned Value:
	-	-	-	-
Events	Mandatory/ Optional	Used in command:		
MG_Overload. (ocp/ mg_overload, 0x0051/0x0001)	M	ADD, MOD, NOTIFY		
	Event Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	-	-	-	-
	ObservedEvent Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	-	-	-	-
Statistics	Mandatory/ Optional	Used in command:	Supported Values:	
None	-	-	-	
Error Codes	Mandatory/ Optional			
None	-			

## 5.14.3.4 Network Package

Table 5.14.3.4.1: Package Usage Information for Network Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
Maximum Jitter Buffer (nt /jit, 0x000b/0x0007)	M	ADD, MOD, MOVE	ALL	-
Signals	Mandatory/ Optional	Used in command:		Duration Provisioned Value:
None	-	-		-
	Signal Parameters	Mandatory/ Optional	Supported Values:	Duration Provisioned Value:
	-	-	-	-
Events	Mandatory/ Optional	Used in command:		
network failure(nt / netfail, 0x000b/0x0005)	M	ADD, MOD, MOVE, NOTIFY		
	Event Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	none	-	-	-
	ObservedEvent Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	cause(cs,0x0001)	M	ALL	-
quality alert (nt / qualert, 0x000b/0x0006)	M	ADD, MOD, MOVE, NOTIFY		
	Event Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	Threshold(th,0x0001)	M	0 to 99	-
	ObservedEvent Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	Threshold(th,0x0001)	M	0 to 99	-

Statistics	Mandatory/ Optional	Used in command:	Supported Values:
Duration(nt / dur, 0x000b/0x0001)	M	AUDITVALUE	ALL
Octets Sent (nt / os, 0x000b/0x0002)	M	AUDITVALUE	ALL
Octets Received(nt / or, 0x000b/0x0003)	M	AUDITVALUE	ALL
<b>Error Codes</b>	<b>Mandatory/ Optional</b>		
-	-		

## 5.14.3.5 RTP Package

Table 5.14.3.5.1: Package Usage Information for RTP Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
None	-	-		-
	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	-	-	-	-
<b>Events</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		
Payload Transition, (rtp/pltrans, 0x000C/0x0001)	M	ADD, MOD, MOVE, NOTIFY		
	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	None	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	rtppayload (rtppltype, 0x0001)	M	A valid encoding name	-
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Supported Values:</b>
Packets Sent, (rtp/ps, 0x000C/0x0004)	O	AUDITVALUE, SUBTRACT REPLY		ALL
Packets Received, (rtp/pr, 0x000C/0x0005)	O	AUDITVALUE , SUBTRACT REPLY		ALL
Packet Loss, (rtp/pl, 0x000C/0x0006)	O	AUDITVALUE , SUBTRACT REPLY		ALL
Jitter, (rtp/jit, 0x000C/0x0007)	O	AUDITVALUE , SUBTRACT REPLY		ALL
Delay, (rtp/delay, 0x000C/0x0008)	O	AUDITVALUE , SUBTRACT REPLY		ALL
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.6 DTMF Detection Package

Table 5.14.3.6.1: Package Usage Information for DTMF Detection Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
Signals	Mandatory/ Optional	Used in command:		Duration Provisioned Value:
None	-	-		-
	Signal Parameters	Mandatory/ Optional	Supported Values:	Duration Provisioned Value:
	-	-	-	-
Events	Mandatory/ Optional	Used in command:		
DTMF character 0 (dd/d0,0x0006/0x0010)	M	ADD, MOD, NOTIFY		
DTMF character 1 (dd/d1,0x0006/0x0011)	Event Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
DTMF character 2 (dd/d2,0x0006/0x0012)	-	-	-	-
DTMF character 3 (dd/d3,0x0006/0x0013)	ObservedEvent Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
DTMF character 4 (dd/d4,0x0006/0x0014)	-	-	-	-
DTMF character 5 (dd/d5,0x0006/0x0015)				
DTMF character 6 (dd/d6,0x0006/0x0016)				
DTMF character 7 (dd/d7,0x0006/0x0017)				
DTMF character 8 (dd/d8,0x0006/0x0018)				
DTMF character 9 (dd/d9,0x0006/0x0019)				
DTMF character * (dd/ds,0x0006/0x0020)				
DTMF character # (dd/do,0x0006/0x0021)				
DTMF character A (dd/da,0x0006/0x001a)				
DTMF character B (dd/db,0x0006/0x001b)				
DTMF character C (dd/dc,0x0006/0x001c)				
DTMF character D (dd/dd,0x0006/0x001d)				
Statistics	Mandatory/ Optional	Used in command:	Supported Values:	
None	-	-	-	
Error Codes	Mandatory/ Optional			
None	-			

## 5.14.3.7 Call Progress Tones Generator Package

Table 5.14.3.7.1: Package Usage Information for Call Progress Tones Generator Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
Signals	Mandatory/ Optional	Used in command:		Duration Provisioned Value:
Dial Tone, (cg/dt, 0x0007/0x030)	M	ADD, MOD, MOVE		Value
	Signal Parameters	Mandatory/ Optional	Supported Values:	Duration Provisioned Value:

Ringing Tone, (cg/rt, 0x0007/0x031) Busy Tone, (cg/bt, 0x0007/0x032) Congestion Tone, (cg/ct, 0x0007/0x033) Special Information Tone, (cg/sit, 0x0007/0x034) Warning Tone, (cg/wt, 0x0007/0x035) Payphone Recognition Tone, (cg/pt, 0x0007/0x036) Call Waiting Tone, (cg/cw, 0x0007/0x037) Caller Waiting Tone, (cg/cr, 0x0007/0x038)	-	-	-	-
<b>Events</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		
None	-	-		
	<b>Event Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Statistics</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Supported Values:</b>
None	-	-		-
<b>Error Codes</b>	<b>Mandatory/Optional</b>			
None	-			

5.14.3.8 Basic Services Tones Generator Package

Table 5.14.3.8.1: Package Usage Information for Basic Services Tones Generator Package

Properties	Mandatory/Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
Recall Dial Tone (srvtn/rdt,0x0025/0x004f)	<b>O</b>	<b>ADD, MOD, MOVE</b>		<b>Value</b>
Confirmation Tone (srvtn/conf,0x0025/0x0050) Held Tone (srvtn/ht,0x0025/0x0051) Message Waiting Tone (srvtn/mwt,0x0025/0x0052)	<b>Signal Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	Tone Direction (btd, 0x0001)	M	Internal / External	Default=External
<b>Events</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		



None	-	-		
	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
-	-	-	-	
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	
None	-	-	-	
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

5.14.3.9 Expanded Call Progress Tones Generator Package

Table 5.14.3.9.1: Package Usage Information for Expanded Call Progress Tones Generator Package

<b>Properties</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
Comfort Tone (xcg/cmft, 0x0024/0x004a)	O	ADD, MOD, MOVE		Value
Off-hook warning Tone (xcg/roh, 0x0024/0x004b)	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
Negative Acknowledgement (xcg/nack, 0x0024/0x004c)	Tone Direction (btd, 0x0001)	M	Internal / External	Default=External
Vacant Number Tone (xcg/vac, 0x0024/0x004d)				
Special Conditions Dial Tone (xcg/spec, 0x0024/0x004e)				
<b>Events</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		
None	-	-		
None	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	
None	-	-	-	
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

5.14.3.10 Basic Announcement Syntax Package

Table 5.14.3.10.1: Package Usage Information for Basic Announcement Syntax Package

<b>Properties</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
None	-	-		-
None	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>

	-	-	-	-
<b>Events</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		
None	-	-		
	<b>Event Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Statistics</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Supported Values:</b>
None	-	-		-
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.11 Voice Variable Syntax Package

Table 5.14.3.11.1: Package Usage Information for Voice Variable Syntax Package

<b>Properties</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
None	-	-		-
	<b>Signal Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	-	-	-	-
<b>Events</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		
None	-	-		
	<b>Event Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Statistics</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Supported Values:</b>
None	-	-		-
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.12 Announcement Set Syntax Package

Table 5.14.3.12.1: Package Usage Information for Announcement Set Syntax Package

<b>Properties</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
None	-	-		-
	<b>Signal Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	-	-	-	-
<b>Events</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		
None	-	-		
	<b>Event Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-

	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Supported Values:</b>
None	-	-		-
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.13 General Text Variable Type Package

Table 5.14.3.13.1: Package Usage Information for General Text Variable Type Package

<b>Properties</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
None	-	-		-
	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	-	-	-	-
<b>Events</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		
None	-	-		
	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	
None	-	-	-	
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.14 Advanced Audio Server Base Package

Table 5.14.3.14.1: Package Usage Information for Advanced Audio Server Base Package

<b>Properties</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
	M	ADD, MOD, MOVE, AUDITVALUE,		-
	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
Play (aasb/play, 0x0033/0x0001)	Announcement (an, 0x0001)	M	Any String	-
	Iterations (it,0x0002)	O	Any Integer	1
	Interval(iv,0x0003)	O	0 upwords	-
	Announcement Direction(di,0x0006)	M	Ext (0x01) Int (0x02)	Default=External
<b>Events</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		
	M	NOTIFY		
	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
Audio operation failure (aasb/audfail, 0x0033 /0x0001)	-	-	-	-

	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	Return Code(rc, 0x0001)	M	FFS	-
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Supported Values:</b>
None	-	-		-
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

### 5.14.3.15 Basic Call Progress Tones Generator with Directionality

**Table 5.14.3.15.1: Package Usage Information For Basic Call Progress Tones Generator with Directionality Package**

<b>Properties</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
Dial Tone (bcg/bdt, 0x0023/0x0040)	O	ADD, MOD, MOVE		Value
Ringing Tone (bcg/brt, 0x0023/0x0041)	<b>Signal Parameters</b> Tone Direction (btd, 0x0001)	<b>Mandatory/ Optional</b> M	<b>Supported Values:</b> Internal / External	<b>Duration Provisioned Value:</b> Default=External
Busy Tone (bcg/bbt, 0x0023/0x0042)				
Congestion Tone (bcg/bct, 0x0023/0x0043)				
Special Information Tone (bcg/bsit, 0x0023/0x0044)				
Warning Tone (bcg/bwt, 0x0023/0x0045)				
Payphone Recognition Tone (bcg/bpt, 0x0023/0x0046)				
Call Waiting Tone (bcg/bcw, 0x0023/0x0047)				
Caller Waiting Tone (bcg/bcr, 0x0023/0x0048)				
Pay Tone (bcg/bpy, 0x0023/0x0049)				
<b>Events</b>				
None	-	-		
	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Supported Values:</b>
None	-	-		-
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.16 AAS Recording Package

Table 5.14.3.16.1: Package Usage Information for AAS Recording Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
Maximum temporary record life (aasrec/maxtrl 0x0035/0x0003)	M	ADD, MOD, MOVE	ALL	-
<b>Signals</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
PlayRecord (aasrec/playrec, 0x0035/0x0002)	M	ADD, MOD, MOVE		-
	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	Record Length Timer(rlt, 0x0008)	O	ALL	-
	Recording Identifier (rid, 0x0009)	M	ALL	-
	EndInputKey(eik, 0x0010)	O	ALL	
record direction (rd,0x0011)	O		Ext (0x01), Int(0x02)	Ext (0x01)
Make persistent (aasrec/makepers, 0x0035/0x0003)	Not Used	-		
	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	
<b>Events</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		
Audio operation failure (aasrec/audfail, 0x0035/0x0001)	M	NOTIFY		
	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	None	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	Return Code(rc, 0x0001)	M	ALL	-
PlayRecord success(aasrec/precsucc, 0x0035/0x0002)	M	NOTIFY		
	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	None	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	Recording result (res,0x0003)	M	ALL	-
	Recording id (ri, 0x0004)	M	ALL	-
Record duration (rdur,0x0005)	M	ALL	-	
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	
None	-	-	-	
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.17 Multimedia Play Package

Table 5.14.3.17.1: Package Usage Information for Multimedia Play Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
Signals	Mandatory/ Optional	Used in command:		Duration Provisioned Value:
Play (mpp/play, 0x00a9/0x0001)	M	ADD, MOD, MOVE		-
	Signal Parameters	Mandatory/ Optional	Supported Values:	Duration Provisioned Value:
	Announcement (an,0x0001)	M	ALL	-
	Iterations (it,0x0002)	O	Any Integer	1
	Interval  (iv,0x0003)	O	0 upwards	-
	Announcement Direction (di, 0x0006)	O	Ext (0x01) Int (0x02)	Default=External
Events	Mandatory/ Optional	Used in command:		
None	-	-		
	Event Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	-	-	-	-
	ObservedEvent Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
-	-	-	-	
Statistics	Mandatory/ Optional	Used in command:	Supported Values:	
None	-	-	-	
Error Codes	Mandatory/ Optional			
None	-			

## 5.14.3.18 Generic Announcement Package

Table 5.14.3.18.1: Package Usage Information for Generic Announcement Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
Signals	Mandatory/ Optional	Used in command:		Duration Provisioned Value:
Fixed: Announcement play (an/apf, x001d/0x0001)	M	ADD, MOD, MOVE		-
	Signal Parameters	Mandatory/ Optional	Supported Values:	Duration Provisioned Value:
	Announcement name (an ,0x0001)	M	ALL	-
	Number of cycles (noc ,0x0002)	O	Any Integer	-
	Announcement Variant (av ,0x0003)	O	ALL	-
	Announcement Direction (di ,0x0004)	O	Ext (0x01) Int (0x02)	Default=External

Events	Mandatory/ Optional	Used in command:		
None	-	-		
	Event Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	-	-	-	-
	ObservedEvent Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
-	-	-	-	-
Statistics	Mandatory/ Optional	Used in command:		Supported Values:
None	-	-		-
Error Codes	Mandatory/ Optional			
None	-			

### 5.14.3.19 Intrusion Tones Generator Package

Table 5.14.3.19.1: Package Usage Information for Intrusion Tones Generator Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
Signals	Mandatory/ Optional	Used in command:		Duration Provisioned Value:
Intrusion Pending Tone (int/pend,0x0027/0x0057)	O	ADD, MOD, MOVE		-
Intrusion Tone (int/int,0x0027/0x0058)	Signal Parameters Tone Direction (btd, 0x0001)	M	Supported Values: Internal / External	Duration Provisioned Value: Default=External
Intrusion Reminder Tone (int/rem,0x0027/0x0059)				
Toll Break-In Tone (int/tbi,0x0027/0x005a)				
Intrusion Queue Tone (int/intque,0x0027/0x005b)				
Busy Verification Tone (int/bv,0x0027/0x005c)				
Events	Mandatory/ Optional	Used in command:		
None	-	-		
	Event Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	-	-	-	-
	ObservedEvent Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
-	-	-	-	-
Statistics	Mandatory/ Optional	Used in command:		Supported Values:
None	-	-		-
Error Codes	Mandatory/ Optional			
None	-			

## 5.14.3.20 Business Tones Generation Package

Table 5.14.3.20.1: Package Usage Information for Business Tones Generation Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
Signals	Mandatory/ Optional	Used in command:		Duration Provisioned Value:
Off-Hook Queuing Tone (biztn/ofque,0x0028/0x005d)	O	ADD, MOD, MOVE		-
Expensive Route Warning Tone (biztn/erwt,0x0028/0x005e)	Signal Parameters	Mandatory/ Optional	Supported Values:	Duration Provisioned Value:
Distinctive Dial Tone (biztn/ddt,0x0028/0x005f)	Tone Direction (btd, 0x0001)	M	Internal / External	Default=External
Internal Dial Tone (biztn/idt,0x0028/0x0060)				
Events	Mandatory/ Optional	Used in command:		
None	-	-		
	Event Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	-	-	-	-
	ObservedEvent Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	-	-	-	-
Statistics	Mandatory/ Optional	Used in command:	Supported Values:	
None	-	-	-	
Error Codes	Mandatory/ Optional			
None	-			

## 5.14.3.21 Conferencing Tones Generation Package

Table 5.14.3.21.1: Package Usage Information for Conferencing Tones Generation Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
Signals	Mandatory/ Optional	Used in command:		Duration Provisioned Value:
Conf. Entrance Tone (confn/enter, 0x0038/0x0061)	O	ADD, MOD, MOVE		-
Conf. Exit Tone (confn/exit, 0x0038/0x0062)	Signal Parameters	Mandatory/ Optional	Supported Values:	Duration Provisioned Value:
Conf. Lock Tone (confn/lock, 0x0038/0x0063)	Tone Direction (btd, 0x0001)	M	Internal / External	Default=External
Conf. Unlock Tone (confn/unlock, 0x0038/0x0064)				
Time Limit Warning Tone (confn/timelim, 0x0038/0x0065)				
Events	Mandatory/ Optional	Used in command:		
None	-	-		
	Event Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	-	-	-	-



	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Statistics</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	
None	-	-	-	
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.22 Inactivity Timer Package

Table 5.14.3.22.1: Package Usage Information for Inactivity Timer Package

<b>Properties</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
None	-	-		-
	<b>Signal Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	-	-	-	-
<b>Events</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		
Inactivity Timeout(it/ito, 0x0045/0x0001)	M	MOD, NOTIFY		
	<b>Event Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	Maximum Inactivity Time(mit, 0x0001)	M	Any integer	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	None	-	-	-
<b>Statistics</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	
None	-	-	-	
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.23 MGC Information Package

Table 5.14.3.23.1: Package Usage Information for MGC Information Package

<b>Properties</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
Data Block(MGCInfo/db, 0x00a0/0x0001)	M	ADD, MOD, AUDITVALUE	A range of 0 to 32 octets	An empty string
<b>Signals</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
None	-	-		-
	<b>Signal Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	-	-	-	-
<b>Events</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		
None	-	-		
	<b>Event Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-

	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Supported Values:</b>
None	-	-		-
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.24 Advanced audio server base package for TTS enhancement

Table 5.14.3.24.1: Package Usage Information for TTS enhancement package

<b>Properties</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
Play Segment Identifier (aastts/playsid, 0x00a8/0x0001)	M	ADD, MOD, MOVE		-
	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	Announcement (an,0x0001)	M	ALL	-
	Iterations (it, 0x0003)	O	0 upwards	1
	Interval (iv,0x0004)	O	0 upwards	-
	Direction (di,0x0005)	O	Ext (0x01) Int(0x02)	Default=External
Play script (aastts/playscript, 0x00a8/0x0002)	M	ADD, MOD, MOVE		-
	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	Script (script,0x0001)	M	(NOTE 1)	-
	Iterations (it,0x0003)	O	0 upwards	1
	Interval (iv, 0x0004)	O	ALL	-
	Direction (di,0x0005)		Ext (0x01) Int(0x02)	Default=External
<b>Events</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		
TTS operation failure(aastts/ttsfail, 0x00a8/0x0001)	M	ADD, MOD, NOTIFY		
	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	None	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	Return Code (rc ,0x0001)	M	ALL	-
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Supported Values:</b>
None	-	-		-
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			
NOTE 1: The value shall comply with the Annex A : "The W3C SSML Profile for TTS function".				

## 5.14.3.25 ASR Package

Table 5.14.3.25.1: Package Usage Information for ASR Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
ASR recognition with grammar script(asr/asrws, 0x00a6/0x0001)	M	ADD, MOD, MOVE		-
	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	grammar file (rgs, 0x0002)	M	(NOTE 1)	-
	Recognition grammar script format (rgsf, 0x0004)	O	ABNF (0x0001) <input type="checkbox"/> XML (0x0002)	ABNF (0x0001)
	recognition mode (rm, 0x0005)	O	Normal (0x0001) <input type="checkbox"/> Hotword (0x0002)	Normal(0x0001)
	End Input Key (eik, 0x0006)	O	ALL	-
ASR recognition with grammar identifier(asr/asrid, 0x00a6/0x0002)	M	ADD, MOD, MOVE		-
	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	Recognition grammar identifier (rgid, 0x0002)	M	ALL	-
	Recognition grammar script type (rgst, 0x0003)	Not Used		
	Recognition grammar script format (rgsf, 0x0004)	O	ABNF (0x0001) <input type="checkbox"/> XML (0x0002)	ABNF (0x0001)
	recognition mode (rm, 0x0005)	O	Normal (0x0001) <input type="checkbox"/> Hotword (0x0002)	Normal(0x0001)
End Input Key (eik, 0x0006)	O	ALL	-	
<b>Events</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		
ASR failure (asr/asrfail, 0x00a6/0x0001)	M	ADD, MOD, NOTIFY		
	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	None	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
Return Code (rc, 0x0001)	M	ALL	-	
ASR success(asr/asrsucc, 0x00a6/0x0002)	M	ADD, MOD, NOTIFY		
	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	None	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
ASR result (asrr, 0x0001)	M	ALL	-	
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	
None	-	-	-	
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			
NOTE 1: The value shall comply with Annex B. "the W3C SRGS Profile for ASR function".				

5.14.3.26 Multimedia Recording Package

Table 5.14.3.26.1: Package Usage Information for Multimedia Recording Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
PlayRecord (mrp/playrec, 0x00b3/0x0002)	M	ADD, MOD, MOVE		-
	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	Record Length Timer(rlt, 0x0008)	M	ALL	-
	Recording Identifier (rid, 0x0009)	M	ALL	-
	EndInputKey(eik, 0x0010)	O	ALL	-
	record direction (rd,0x0011)	O	Ext 0x01, Int(0x02)	Ext (0x01)
<b>Events</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		
none	-	-		
	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	
None	-	-	-	
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

5.14.3.27 Tone Generator Package

Table 5.14.3.27.1: Package Usage Information for Tone Generator Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
Play Tone (tonegen/pt,0x0003/0x0001)	Not Used	-		-
	<b>Signal Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	-	-	-	-
<b>Events</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>		
None	-	-		
	<b>Event Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/ Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Statistics</b>	<b>Mandatory/ Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	
None	-	-	-	
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.28 Hanging Termination Detection Package

Table 5.14.3.28.1: Package Usage Information for Hanging Termination Detection Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None				
Signals	Mandatory/ Optional	Used in command:		Duration Provisioned Value:
None				
	Signal Parameters	Mandatory/ Optional	Supported Values:	Duration Provisioned Value:
Events	Mandatory/ Optional	Used in command:		
Termination Heartbeat (hangterm/ thb, (0x0098/0x0001)	M	ADD, MOD, MOVE, AUDITVALUE, NOTIFY		
	Event Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	Timer X	M	ALL	0 (no heartbeat message)
	ObservedEvent Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
Statistics	Mandatory/ Optional	Used in command:	Supported Values:	
None				
Error Codes	Mandatory/ Optional			

## 5.14.3.29 MSRP Statistics Package

Table 5.14.3.29.1: Package Usage Information for MSRP Statistics Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
Signals	Mandatory/ Optional	Used in command:		Duration Provisioned Value:
None	-	-		-
	Signal Parameters	Mandatory/ Optional	Supported Values:	Duration Provisioned Value:
	-	-	-	-
Events	Mandatory/ Optional	Used in command:		
Messaging Quota (msrpstat/mquota, 0x00ea/0x0001)	M	ADD, MOD, NOTIFY		
	Event Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	Number of Messages Sent Quota(msq, 0x0001)	0	0 and up	0
	Number of Messages Received Quota(mrq, 0x0002)	0	0 and up	0
	Messages Sent Volume Quota(msv, 0x0003)	0	0 and up	0
	Messages Received Volume Quota (mrv, 0x0004)	0	0 and up	0
	Time Quota (tm, 0x0005)	0	Any Integer	0
	ObservedEvent Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:

	Quota Reached (qreach, 0x0001)	M	0x0001 - 0x0005	-
	Number of Messages Sent (nms, 0x0002)	O	0 and up	-
	Number of Messages Received (nmr, 0x0003)	O	0 and up	-
	Volume of Messages Sent (vms, 0x0004)	O	0 and up	-
	Volume of Messages Received (vmr, 0x0005)	O	0 and up	-
<b>Events</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		
<b>Individual Message Information (msrpstat/imi, 0x00ea/0x0002)</b>	Not Used	-		
	<b>Event Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
-	-	-	-	
<b>Statistics</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Supported Values:</b>
Number of Messages Sent (msrpstat/nms, 0x00ea/0x0001)	O	AUDITVALUE		0 and up
Number of Messages Received (msrpstat/nmr, 0x00ea/0x0002)	O	AUDITVALUE		0 and up
Volume of Messages Sent (msrpstat/vms, 0x00ea/0x0003)	O	AUDITVALUE		0 and up
Volume of Messages Received (msrpstat/vmr, 0x00ea/0x0004)	O	AUDITVALUE		0 and up
<b>Error Codes</b>	<b>Mandatory/ Optional</b>			
None	-			

## 5.14.3.30 Play Message Package

Table 5.14.3.30.1: Package Usage Information for Play Message Package

<b>Properties</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
None	-	-	-	-
<b>Signals</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
Send Message (mess/sm, 0x00ec/0x0001)	M	ADD, MOD, MOVE		-
	<b>Signal Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	Message Identity (mi, 0x0001)	M	Any String	-
Message Contents by reference (mcr, 0x0002)	M	Any String	-	

	Failure Report (fr, 0x0003)	O	yes/no	yes
	Success Report (sr, 0x0004)	O	yes/no	no
<b>Events</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		
Message Sending Response Status (mess/msrs, 0x00ec/0x0001)	M	ADD, MOD, NOTIFY		
	<b>Event Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	Message Identity (mi, 0x0001)	M	Any String	-
	Status Code (sc, 0x0002)	M	Any String	-
<b>Statistics</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Supported Values:</b>
None	-	-		-
<b>Error Codes</b>	<b>Mandatory/Optional</b>			
None	-			

### 5.14.3.31 Message Filtering Package

**Table 5.14.3.31.1: Package Usage Information for Message Filtering Package**

<b>Properties</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
Incoming Message Filters (mf/imf, 0x00ef/0x0001)	O	ADD, MOD	(NOTE 1)	-
Incoming Message Filters by Reference (mf/imfr, 0x00ef/0x0002)	Not Used	-	-	-
Outgoing Message Filters (mf/omf, 0x00ef/0x0003)	O	ADD, MOD	(NOTE 1)	-
Outgoing Message Filters by Reference (mf/omfr, 0x00ef/0x0004)	Not Used	-	-	-
<b>Signals</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
None	-	-		-
	<b>Signal Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	-	-	-	-
<b>Events</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		
Filed Message (mf/fm, 0x00ef/0x0001)	Not Used	-		
	<b>Event Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Events</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		
Filtering Runtime Error (mf/fre, 0x00??/0x0002)	FFS	-		
	<b>Event Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-

	ObservedEvent Parameters	Mandatory/Optional	Supported Values:	Provisioned Value:
	-	-	-	-
Statistics	Mandatory/Optional	Used in command:	Supported Values:	
None	-	-	-	-
Error Codes	Mandatory/ Optional			
Sieve Script Syntax Error (700)	FFS			
Unsupported Sieve Require Error (701)	FFS			
Sieve Actions Exceeded Error (702)	FFS			
NOTE 1: The value shall comply with Sieve [IETF RFC5228] with the exceptions described in H.248.69 [35] Clause 13.6. Filtering rules and Message treatment for Filtered message are included in the parameter.				

### 5.14.3.32 Record Message Package

**Table 5.14.3.32.1: Package Usage Information for Record Message Package**

Properties	Mandatory/Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
Signals	Mandatory/Optional	Used in command:	Supported Values:	Duration Provisioned Value:
Record Message (recmess/rm, 0x00f1/0x0001)	M	ADD, MOD, MOVE		-
	Signal Parameters	Mandatory/Optional	Supported Values:	Duration Provisioned Value:
	Storage Location (sl, 0x0001)	M	Any String	-
	Append (app, 0x0002)	Not Used	-	-
	Direction (dir, 0x0003)	O	EXT/INT	EXT
	Maximum Record Size (mrs, 0x0004)	Not Used		
Events	Mandatory/Optional	Used in command:		
Record Operation Failure (recmess/messfail, 0x00f1/0x001 )	Not Used	-		
	Event Parameters	Mandatory/Optional	Supported Values:	Provisioned Value:
	-	-	-	-
	ObservedEvent Parameters	Mandatory/Optional	Supported Values:	Provisioned Value:
	-	-	-	-
Statistics	Mandatory/Optional	Used in command:	Supported Values:	
None	-	-	-	-
Error Codes	Mandatory/ Optional			
None	-			



5.14.3.33 Floor Control Package

Table 5.14.3.33.1: Package Usage Information for Floor Control Package

Properties	Mandatory/Optional	Used in command:	Supported Values:	Provisioned Value:
Controller's Floor Identity (fcp/cfi, 0x006e/0x0002)	M	ADD, MOD	Sub-list of Integer	-
<b>Signals</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
None	-	-		-
	<b>Signal Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	-	-	-	-
<b>Events</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		
None	-	-		
	<b>Event Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
<b>Statistics</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>	<b>Supported Values:</b>	
None	-	-	-	
<b>Error Codes</b>	<b>Mandatory/Optional</b>			
None	-			

5.14.3.34 Floor Control Policy Package

Table 5.14.3.34.1: Package Usage Information for Floor Control Policy Package

Properties	Mandatory/Optional	Used in command:	Supported Values:	Provisioned Value:
Floor Control Algorithm (fcpoli/fca, 0x00ab/0x0001)	M	ADD, MOD	Sub-list of String with (FloorID COLON Algorithm)	-
Max Floor Users (fcpoli/mfu, 0x00ab/0x0002)	M	ADD, MOD	Sub-list of String with (FloorID COLON NumUsers)	-
<b>Signals</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		<b>Duration Provisioned Value:</b>
None	-	-		-
	<b>Signal Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Duration Provisioned Value:</b>
	-	-	-	-
<b>Events</b>	<b>Mandatory/Optional</b>	<b>Used in command:</b>		
None	-	-		
	<b>Event Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-
	<b>ObservedEvent Parameters</b>	<b>Mandatory/Optional</b>	<b>Supported Values:</b>	<b>Provisioned Value:</b>
	-	-	-	-

Statistics	Mandatory/ Optional	Used in command:	Supported Values:
None	-	-	-
Error Codes	Mandatory/ Optional		
None	-		

## 5.14.3.35 Floor Status Change Handling Package

Table 5.14.3.35.1: Package Usage Information for Floor Status Change Handling Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
None	-	-	-	-
Signals	Mandatory/ Optional	Used in command:		Duration Provisioned Value:
Confirm Media Update (fschp/cmu, 0x00aa/0x0001)	M	MOD		-
	Signal Parameters	Mandatory/ Optional	Supported Values:	Duration Provisioned Value:
	Floor Status(fs, 0x0001)	M	Sub-list of String with (FloorID COLON Status)	-
	Result(res, 0x0002)	M	Success/Fail	Success
Events	Mandatory/ Optional	Used in command:		
Floor Status Detection and Reporting (fschp/fsdr, 0x00aa/0x0001)	M	ADD, MOD, NOTIFY		
	Event Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	-	-	-	-
	ObservedEvent Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	Floor Status(fs, 0x0001)	M	Sub-list of String with (FloorID COLON Status)	-
Statistics	Mandatory/ Optional	Used in command:	Supported Values:	
None	-	-	-	
Error Codes	Mandatory/ Optional			
None	-			

## 5.14.3.36 Floor Control Signalling Package

Table 5.14.3.xx.1: Package Usage Information for Floor Control Signalling Package

Properties	Mandatory/ Optional	Used in command:	Supported Values:	Provisioned Value:
Floor Control Conference Identity (fcsig/fconfid, 0x00??/0x0001)	M	ADD, MOD	Sub-list of Integer	-
Floor and Stream Association (fcsig/fsa, 0x00??/0x0002)	M	ADD, MOD	Sub-list of Stringr	-
Signals	Mandatory/ Optional	Used in command:		Duration Provisioned Value:
None	-	-		-
	Signal Parameters	Mandatory/ Optional	Supported Values:	Duration Provisioned Value:
	-	-	-	-
Events	Mandatory/ Optional	Used in command:		
None	-	-		
	Event Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	-	-	-	-
	ObservedEvent Parameters	Mandatory/ Optional	Supported Values:	Provisioned Value:
	-	-	-	-
Statistics	Mandatory/ Optional	Used in command:	Supported Values:	
None	-	-	-	
Error Codes	Mandatory/ Optional			
None	-			

## 5.14.3.37 Explicit Congestion Notification for RTP-over-UDP Support (ecnrous)

Table 5.14.3.37.1: Explicit Congestion Notification for RTP-over-UDP Support package

Properties	Mandatory/Optional	Used in command	Supported Values	Provisioned Value
ECN Enabled (ecnrous/ecnen, 0x010b/0x0001)	M	ADD, MODIFY	True, False	-
Congestion Response Method (ecnrous/crm, 0x010b/0x0002)	Not Signalled	-	-	"RDCC"(0x0002) NOTE
Initiation Method (ecnrous/initmethod, 0x010b/0x0003)	M	ADD, MODIFY	"leap", "inactive"	"leap"
ECN Mode (ecnrous/mode, 0x010b/0x0004)	Not Signalled	-	-	"setread" (0x0002)
ECT Marking (ecnrous/ectmark, 0x010b /0x0005)	Not Signalled	-	-	"0" (0x0002)
ECN Congestion Marking (ecnrous/congestmark, 0x010b/0x0006)	Not Signalled	-	-	"nomark" (0x0003)
ECN SDP Usage (ecnrous/ecnsdp, 0x010b/0x0007)	Not Signalled	-	-	"P" (0x0001)
Signals	Mandatory/Optional	Used in command		Duration Provisioned Value
None	-	-		-
	Signal Parameters	Mandatory/Optional	Supported Values	Duration Provisioned Value
	-	-	-	-
Events	Mandatory/Optional	Used in command		
ECN Failure (ecnrous/fail, 0x010b/0x0001)	M	ADD, MODIFY, NOTIFY		
	Event Parameters	Mandatory/Optional	Supported Values	Provisioned Value
	-	-	-	-
	-	-	-	-
	ObservedEvent Parameters	Mandatory/Optional	Supported Values	Provisioned Value
	Failure Type (type,0x0001)	Mandatory	INIT, USE	-
	Media Sender SSRC (ssrc, 0x0002)	Not Supported	-	-
Statistics	Mandatory/Optional	Used in command	Supported Values	
Source (ecnrous/ssrc, 0x010b/0x0001)	Not Supported	-	-	
CE Counter (ecnrous/cecount, 0x010b/0x0002)	Not Supported	-	-	
ECT0 Counter (ecnrous/ectzero, 0x010b/0x0003)	Not Supported	-	-	
ECT1 Counter (ecnrous/ectone, 0x010b/0x0004)	Not Supported	-	-	
Not-ECT Counter (ecnrous/notect, 0x010b/0x0005)	Not Supported	-	-	
Lost Packets Counter (ecnrous/lost 0x010b/0x0006)	Not Supported	-	-	
Extended Highest Sequence number (ecnrous/ehsn, 0x010b/0x0007)	Not Supported	-	-	
Error Codes	Mandatory/Optional			
None	-			
NOTE:	Application Specific Rate Adaptation shall be applied in accordance with 3GPP TS 26.114 [41]. For speech this requires support of CMR and TMMBR for video.			

## 5.15 Mandatory Support of SDP and Annex C Information Elements

The v=, o=, s=, m=, c=, t=, a= and b= lines of the SDP [20] syntax shall be supported. All other lines should be ignored if received.

**Table 5.15.1: Supported Annex C and SDP information elements**

Supported Annex C and SDP information elements:		
Information Element	Annex C Support	SDP Support

Protocol version (v=)	"SDP_V "	<p>The protocol version (v=) line contains a single field: v= &lt;version&gt;</p> <p>and shall be used in accordance with RFC 2327 [20] (i.e. v=0).</p>
Origin (o=)	"SDP_O "	<p>The origin line consists of 6 fields: o= &lt;user name&gt; &lt;session ID&gt; &lt;version&gt; &lt;network type&gt; &lt;address type&gt; &lt;address&gt;.</p> <p>The MRFC is not required to supply this line but shall accept it.</p> <p>The MRFP should populate this line as follows or use the value received from the MRFC:</p> <ul style="list-style-type: none"> <li>- &lt;user name&gt; should contain an hyphen</li> <li>- &lt;session ID&gt; and &lt;version&gt; should contain one or more digits as described in RFC 2327 [20]</li> <li>- &lt;network type&gt; shall be set to IN</li> <li>- &lt;address type&gt; shall be set to IP4 or IP6 The Address Type shall be set to "IP4" or "IP6" depending on the addressing scheme used by the network to which the MRFP is connected.</li> <li>- &lt;address&gt; should contain the fully qualified domain name of the gateway.</li> </ul>
Session Name (s=)	"SDP_S"	<p>The session name (s=) line contains a single field: s= &lt;session-name&gt;.</p> <p>The MRFC is not required to supply a session name but shall accept one. This line may be used to convey correlation information for use in CDRs.</p> <p>The MRFP shall use an hyphen "-" as a session name or the value received from the MRFC.</p>
Connection data (c=)	"SDP_C "	<p>The connection data line consists of 3 fields: c= &lt;network-type&gt; &lt;address-type&gt; &lt;connection-address&gt;</p> <ul style="list-style-type: none"> <li>- The &lt;network-type&gt; shall be set to "IN".</li> <li>- The &lt;address-type&gt; shall be set to "IP4" or "IP6" depending on the addressing scheme used by the network to which the MRFP is connected.</li> <li>- The &lt;connection-address&gt; sent by the MRFC in the remote descriptor is the address to which the MRFP shall send the media flows.</li> <li>- The &lt;connection-address&gt; sent by the MRFC in local descriptors may be a unicast IPv4 or IPv6 address or it may be wildcarded to allow the MRFP to choose an address. In the second case, MGs shall fill this field with a unicast IP address at which they will receive the media stream. Thus a TTL value shall not be present and a "number of addresses" value shall not be present. The field shall not be filled with a fully-qualified domain name instead of an IP address.</li> </ul> <p>When the &lt;connection address&gt; is wildcarded (i.e. choose wildcard) by the MRFC, the MRFP allocates an IP address based on the address type. The addressing space for which this address is taken may depend on the termination ID supplied by the MRFC.</p>
Media announcements (m=)	"SDP_M "	<p>Media Announcements (m=) lines consist of 3 fields: m= &lt;media&gt; &lt;port&gt; &lt;transport&gt; &lt;format&gt;</p> <ul style="list-style-type: none"> <li>- The &lt;media&gt; field shall be set to "audio" or "video" or "message" or "application" (NOTE1).</li> <li>- The &lt;port&gt; field in remote descriptors is provided by the MRFC and represents the port to which the MRFP shall send the media flows.</li> <li>- The &lt;port&gt; field in local descriptors may be provided by the MRFC or wildcarded (i.e. choose wildcard) to allow the MRFP</li> </ul>

		<p>to choose a value for the port on which it wishes to receive the media stream</p> <ul style="list-style-type: none"> <li>- The &lt;transport&gt; field shall be according to table 5.15.2</li> <li>- The &lt;format&gt; field may be explicitly supplied by the MRFC, wildcarded or overspecified. If the MRFC wishes to request the MRFP to choose which media formats it wishes to use for the call then the MRFC shall provide a "\$" wildcard. If the MRFC wishes to suggest that the MRFP selects a media format from a list of possible media formats then it shall provide a list of appropriate media types in accordance with SDP. All conforming gateways shall support at least the default narrowband AMR codec as defined in 3GPP TS 26.235 [31]. Optionally, other codecs defined in 3GPP TS 26.235 [31] and format "8" for RTP/AVP (i.e. G.711 A-Law).</li> </ul> <p>Dynamic payloads shall not be used when a static RTP/AVP payload value is defined in RFC 3551[21].</p>
Bandwidth (b=)	"SDP_B "	<p>The Bandwidth (b=) line consists of 2 fields:  <i>b= &lt;modifier&gt;: &lt;bandwidth-value&gt;</i></p> <p>Bandwidth information shall be supplied by the MRFC if the required bandwidth cannot be immediately derived from the information contained in the m= line. If absent, the MRFP shall assume a reasonable default bandwidth value for well-known codecs and shall provide this value in the response sent to the MRFC. The Modifier field shall be set to "AS".</p> <p>The Bandwidth Value field shall be set to the maximum bandwidth requirement of the media stream in kbit/s. The bandwidth value shall take into account all headers down to the IP layer, including a 5% bandwidth for RTCP packets.</p>
Time (t=)	"SDP_T "	<p>The time (t=) line consists of two fields:  <i>t= &lt;start-time&gt; &lt;stop-time&gt;</i>.</p> <p>This line is ignored by both the MRFC and the MRFP if received in local and remote descriptors.</p> <p>The MRFC is not required to supply a time description but shall accept one.</p> <p>When supplied, this line shall be set to 0 0.</p>
Attributes (a=)	"SDP_A "	<p>Attributes (a=) lines consist of two fields:  <i>a= &lt;attribute&gt;: &lt;value&gt;</i></p> <p>One or more of the "a" attribute lines specified below may be included, depending on the payload type.</p> <p>An attribute line not specified below should not be used. Only the following attributes are understood by the MRFP. Other attributes are ignored.</p> <p><i>a= rtpmap: &lt;payload type&gt; &lt;encoding name&gt;/&lt;clock rate&gt; [/&lt;encoding parameters&gt;]</i>  <i>a= fmtp:&lt;format&gt; &lt;format specific parameters&gt;</i>  <i>a=ptime: &lt;time&gt;</i>  <i>a=userid: &lt;token of user identifier&gt; (NOTE3)</i>  <i>a=floorid: &lt;token of Floor identifier&gt; (NOTE3)</i>  <i>a=path:MSRP-URI (NOTE4)</i>  <i>a=rtcp-fb: ... (NOTE 5)</i></p> <p>For AVPF transport, the "rtcp-fb" SDP attribute defined in IETF RFC 4585 [39] may be used to provide the feedback message types the MRFP is allowed to send and to indicate RTCP timing information.</p>

NOTE1:	The "application" media is used to describe a BFCP stream. The way to generate a 'm' line for a BFCP stream follows the format specified in RFC 4583[32], where the port is always a TCP port, the transport field is TCP/BFCP, the fmt (format) list is ignored.
NOTE2:	Void
NOTE3:	The "userid" and "floorid" are SDP media-level attributes. They are used in BFCP 'm' lines. The "floorid" defines a list of Floor identifiers, indicating the available Floor(s) for the user represented by the termination. The token representing the Floor identifier is the integer representation of the Floor ID. The "userid" attributes carry the integer representation of a user ID.
NOTE4:	An MSRP-URI is an "msrp" or "msrps" URI defined as "MSRP-URI = msrp-scheme "://" authority [ "/" session-id ] ";" transport *(";" URI-parameter)". The authority component contains a numeric IP address and port. The session-id part identifies a particular session of the participant allowing multiple sessions to share the same TCP connection.
NOTE 5:	The support is optional

**Table 5.15.2: Transport Protocol**

<b>Transport Protocol &lt;proto&gt; in m-line:</b>	If the MG does not support the requested transport protocol, it shall reject the command with error code 449.
TCP/MSRP	Message service using IETF RFC 4975 [34]. (NOTE 1)
RTP/AVP	RTP profile according IETF RFC 3551 [21]. For voice and video services
RTP/AVPF	Extended RTP profile for RTCP-based Feedback (RTP/AVPF) according IETF RFC 4585 [40]. For voice and video services (NOTE 1).
TCP/BFCP	for BFCP, see IETF RFC 4583 [32] (NOTE 1)
NOTE 1: support optional.	
NOTE 2: Upper case TCP is defined by IETF RFC 4145 [39] and registered by IANA. .	

## 5.16 Optional support of SDP and Annex C information elements

*Specifies what SDP attributes and Annex C information elements may be supported.*

**Table 5.16.1:**

<b>Optional Annex C and SDP information elements:</b>			
<b>Information Element</b>	<b>Annex C Support</b>	<b>SDP Support</b>	<b>Support Dependent on:</b>
<name>	<Annex C property>	<Describe>	<Describe>

## 5.17 Procedures

### 5.17.1 Formats and Codes

Table 5.17.1.1 shows the parameters which are required for the procedures defined in the following clauses.

The coding rules applied in ITU-T Recommendation H.248.1 [3] for the applicable coding technique shall be followed for the UMTS capability set.

The binary encoding rules which are applicable to the defined Abstract Syntaxes are the Basic Encoding Rules for Abstract Syntax Notation One, defined in ITU-T Recommendation X.690 [41]. Specifically in accordance with ITU-T Recommendation X.690 [41] section 7.3, alternative encodings based on the definite and indefinite form of length are permitted by the basic encoding rules as a sender's option. Receivers shall support both alternatives.

Unsupported values of parameters or properties may be reported by the MGW and shall be supported by the MSC as such by using H.248.1 error code #449 "Unsupported or Unknown Parameter or Property Value ". **Error Text in the error Descriptor:** The unsupported or unknown value is included in the error text in the error descriptor.



Table 5.17.1.1: Information Elements Used in Procedures

Signalling Object	H.248 Descriptor	Coding
Announcement Cause	Events ObservedEvents	The "Meth" parameter in g/sc event per ITU-T Recommendation H.248.1 [3] Annex E.1.2
Announcement Completed	Events ObservedEvents	The g/sc event per ITU-T Recommendation H.248.1 [3] Annex E.1.2
Announcement Cycles	Signal	The "noc" parameter as per ITU-T Recommendation H.248.7 [5], Clause 4.3.1
Announcement Direction	Signal	The "di" parameter as per ITU-T Recommendation H.248.7 [5], Clause 4.3.1
Announcement Variant	Signal	The "av" parameter as per ITU-T Recommendation H.248.7 [5], Clause 4.3.1
ASR Cause	Events ObservedEvents	The "rc" parameter in asr/asrfail event as per ITU-T Recommendation H.248.9a1 [26] Clause 12.2.1.
Cause	Events ObservedEvents	Encoded as "Meth" parameter in g/sc event per ITU-T Recommendation H.248.1 [3] Annex E.1.2
Codec List	Local Descriptor or Remote Descriptor	<fmt list> in a single SDP m-line. For a static RTP payload type, the codec type should be implied by the RTP payload type, if not then each codec type shall be provided in a separate SDP "a=rtpmap"-line and possibly additional SDP "a=fmtp"-line(s). For a dynamic RTP payload type, for each codec information on the codec type shall be provided in a separate SDP "a=rtpmap"-line and possibly additional SDP "a=fmtp"-line(s).
ConfID	ContextAttribute Descriptor	The "fconfid" parameter as per ITU-T Recommendation H.248.19a2 [33], Clause 10.6.1.1. It is defined as type integer as used over BFCP.
Context ID	NA	Binary Encoding: As per ITU-T Recommendation H.248.1 [3] Annex A. Textual Encoding: As per ITU-T Recommendation H.248.1 [3] Annex B.
ControlledByChair	TerminationState Descriptor	List of Floor Ids controlled by this termination as a chair, specified by "cfi" as defined in Clause 10.1.1.2 of H.248.19a2 [33].
Digit	Observed Events	Encoding as per ITU-T Recommendation H.248.1 Annex E.6.2. Digits are reported individually by the MRFP.
DTMFTrigger	Signal Descriptor	"endinputkey, eik" see H.248.9a1 [26] Clause 16.3.1.1.16.
ECN Enabled	Local Descriptor or Remote Descriptor	Defined according to the "ECN Enabled" property in 3GPP TS 29.238 Annex B [38].
ECN Failure	Events, Observed Events	Defined according to the "ECN Failure" Event in 3GPP TS 29.238 Annex B [38].
ECN Failure Type	ObservedEvents Descriptor	As for the ObservedEventsDescriptor Parameter "Failure Type" in 3GPP TS 29.238 Annex B [38].
ECN Initiation Method	Local Descriptor or Remote Descriptor	Defined according to "Initiation Method" property in 3GPP TS 29.238 Annex B [38].
End of Recording Notification	Events ObservedEvents	Enables the MRFC to be informed of the end of a recording. Corresponds to aasrec/audfail (mrp/audfail) and aasrec/precsucc, (mrp/precsucc) events see ITU-T Recommendation H.248.9a1 [26] 12.2.
FloorControlAlgorithm	Context Attribute (NOTE1)	Sub-list of (Floorid, Algorithm). "fca" as defined in Clause 10.4.1.2 of H.248.19a2 [33].
FloorID	Local Descriptor	"a= floorid" SDP line as specified in Table 5.15.1.
FloorRequestResult	Signal Descriptor	The "res" parameter as per ITU-T Recommendation H.248.19a2 [33], Clause 10.5.3.1.1.2. It is defined as Boolean (success or fail)
FloorResAssociations	Context Attribute (NOTE1)	The "fsa" parameter as per ITU-T Recommendation H.248.19a2 [33], Clause 10.6.1.2. It is defined as sub-list of (Floorid, StreamID).
FloorStatus	Observed Events	"Floor Status, fs" as defined in H.248.19 a2 [33]. This is a list of FloorIds and status (e.g. granted, revoked)
IncMessageFilters	LocalControl Descriptor	"Incoming Message Filters, imf" parameter in H.248.69 [35] Clause 13.1.1, which is defined as string and complies with Sieve [IETF RFC5228] with the exceptions described in H.248.69 [35] Clause 13.6.
IP Address	Local Descriptor or Remote Descriptor	<connection address> in SDP "c-line"
Iterations	Signal	" Iterations, it" parameter in H.248.9a1 [26] Clause 13.3.1.1.3 or Clause 13.3.2.1.3

MaxFloorHolder	Context Attribute (NOTE1)	Sub-list of (FloorID, Number). "mfu" as defined in Clause 10.4.1.2 of H.248.19a2 [33]
Maximum Record Time	Signal	"Record Length Timer, rlt" parameter in H.248.9a1 [26] Clause 16.3.1.1.8 for multimedia recording or Clause 10.3.1.1.8 for audio recording
Media Identifier	Signal	TBD
Mediatype	Local Descriptor or Remote Descriptor	<media> in sdp m-line "audio" for voice service, and "image" for T.38 service.
MessageContentType		TBD as enumeration to indicate the content type of message. (e.g. video, audio)
MessageContentFmt		TBD as enumeration to indicate the content format (e.g. mpeg, jpeg for picture)
MessageIdentifier	Signal	"mcr" parameter in the mess/sm signal in H.248.69 [35] Clause 10.3.1.1.2, which is defined as URI that points to the message data that shall be sent.
MessagePlayResultReport	Signal	"fr" or 'sr' parameter in the mess/sm signal in H.248.69 [35], which is defined as Enumeration to indicate the request of report result of message play (Success Report, Failure Report, Both or None)
MessagePlayCause	ObservedEvents	"sc" parameter in the mess/msrs event in H.248.69 [35] Clause 10.2.1.2.2, which is defined as Enumeration to notify the result of the message play.
MessageRecordFileIdentifier	Signal	"sl" parameter in the recmess/rm signal in H.248.69 [35] Clause 15.3.1.1.1, which is defined as a URI where the messages are to be stored.
MessagesReceivedNumQuota	Events	"mrq" parameter in the msrpstat/mquota event in H.248.69 [35] Clause 8.2.1.1.2, which is defined as integer to define the quota for number of messages that may be received on the termination for the messaging Stream.
MessagesReceivedVolQuota	Events	"mrv" parameter in the msrpstat/mquota event in H.248.69 [35] Clause 8.2.1.1.4, which is defined as integer to define the quota for cumulative total size of messages that may be received on the Termination for the messaging Stream.
MessagesreceivedNum	ObservedEvents Statistics	"nmr" parameter in the msrpstat/mquota event or statistics in H.248.69 [35], which is defined as integer to define the number of messages that have been received on the termination for the messaging Stream.
MessagesReceivedVol	ObservedEvents Statistics	"vmr" parameter in the msrpstat/mquota event or statistics in H.248.69 [35], which is defined as integer to define the cumulative total size of messages that have been received on the Termination for the messaging Stream.
MessagesSentNumQuota	Events	"msq" parameter in the msrpstat/mquota event in H.248.69 [35] Clause 8.2.1.1.1, which is defined as integer to define the quota for number of messages that may be sent from the termination for the messaging Stream.
MessagesSentVolQuota	Events	"msv" parameter in the msrpstat/mquota event in H.248.69 [35] Clause 8.2.1.1.3, which is defined as integer to define the quota for cumulative total size of messages that may be sent from the Termination for the messaging Stream.
MessagesSentNum	ObservedEvents Statistics	"nms" parameter in the msrpstat/mquota event or or statistics in H.248.69 [35], which is defined as integer to define the number of messages that have been sent from the termination for the messaging Stream.
MessagesSentVol	ObservedEvents Statistics	"vms" parameter in the msrpstat/mquota event or statistics in H.248.69 [35], which is defined as integer to define the cumulative total size of messages that may be sent from the Termination for the messaging Stream.
MSRP session identity	Local Descriptor or Remote Descriptor	<session-id> in SDP 'a= path:MSRP-URI'-line.
OutMessageFilters	LocalControl Descriptor	"Outgoing Message Filters, omf" parameter in H.248.69 [35] Clause 13.1.3, which is defined as string and complies with Sieve [IETF RFC5228] with the exceptions described in H.248.69 [35] Clause 13.6.
Port	Local Descriptor or Remote Descriptor	<port> in SDP m-line.
Recognition Result	ObservedEvents	"asrr" parameter to "asrsucc" event in H.248.9a1 [26] Clause

		12.2.2.2.1. Each result may be able to be structured by multiple parts in time sequence with the input time, may be able to include the text token that the value will correspond to tokens as defined by the SRGS grammar, may be able to include the interpretation of application specific markup, may be able to include the confidence score that represents the recognition quality.
Record File Format	Signal	To Be Defined
Record File Identifier	Signal	"rid" parameter in playrec signal H.248.9a1 [26] Clause 16.3.1.1.9 for multimedia recording or Clause 10.3.1.1.9 for audio recording
Reserve_Value	Local Control	ITU-T Recommendation H.248.1 [3] Mode property. Binary Encoding: Encoding as per ITU-T Recommendation H.248.1 Annex A "reserveValue" Textual Encoding: Encoding as per ITU-T Recommendation H.248.1 Annex B "reservedValueMode".
RtcpbwRS	Local Descriptor or Remote Descriptor	<bandwidth> in SDP "b:RS"-line.
RtcpbwRR	Local Descriptor or Remote Descriptor	<bandwidth> in SDP "b:RR"-line.
RTPpayload	Local Descriptor or Remote Descriptor	<fmt list> in SDP m-line
SenderAddr		TBD
SRGS Grammar	Signal	"grammar file, gf" parameter in asr/asr signal in H.248.9a1 [26] Clause 12.3.1.1.2
SRGS grammar URI	Signal	" Recognition grammar identifier, rgid" parameter in asr/ asrid signal in H.248.9a1 [26] Clause 12.3.2.1.2
SSML	Signal	"an" parameter in the aastts/play signal in H.248.9a1 [26] Clause 14.3.1.1.1
StatRepReason	ObservedEvents	"qreach" parameter in the msrstat/mquota event in H.248.69 [35] Clause 8.2.1.2.1, which is defined as enumeration to indicate the quota that has triggered the reporting of the event.
StatValTime	Events	"tm" parameter in the msrstat/mquota event in H.248.69 [35] Clause 8.2.1.1.5, which is defined as integer to define how long for the quotas associated are active for.
Stream Number	Stream	Encoding as per ITU-T Recommendation H.248.1 Annex B "Stream"/"ST". For a single stream, this may be omitted by the MRFC.
Termination heartbeat	Events ObservedEvents	The hangterm/thb event as per ITU-T Recommendation H.248.36 [30] Clause 5.2.1.
Termination ID	NA	Binary Encoding: As per ITU-T Recommendation H.248.1 [3] Annex A. Textual Encoding: As per ITU-T Recommendation H.248.1 [3] Annex B.
Timing	Events	As in dd package H.248.1 [3] Annex E.6.2, (end tone detected shall be used)
Tone Completed	Events ObservedEvents	"g/sc" see H.248.1 [3] Annex E.1.2
Tone Duration	Signal	As in the respective tone package
Tone Identity	Signal	Encoding as per ITU-T Recommendation H.248.1 Annex B and the package which defines the tone (Tone Signal Ids only).
Transaction ID	NA	Binary Encoding: As per ITU-T Recommendation H.248.1 [3] Annex A. Textual Encoding: As per ITU-T Recommendation H.248.1 [3] Annex B.
TTS Completed	Events ObservedEvents	"g/sc" see H.248.1 [3] Annex E.1.2 if successful, aastts/ttsfail H.248.9a1 [26] Clause 14.2.1 if not successful.
Transport	Local Descriptor or Remote Descriptor	<transport> in SDP m-line, see 5.15
UserID	Local Descriptor	"a= userid" SDP line as specified in Table 5.15.1.

NOTE1: H.248.1 version 3 required.

## 5.17.2 Call Related Procedures

### 5.17.2.1 General

This section describes the various call related procedures performed by the MRFP, which are listed in table 15.17.2.1.

Table 5.17.2.1.1: MRFP Call Related Procedures

Transaction defined in 3GPP TS 23.333 [25]	Transaction used from TS 29.163 [27]	Supported	Comment
Reserve IMS Resources	Reserve IMS Connection point	Mandatory	See 5.17.2.2
Configure IMS Resources	Configure IMS Resources	Mandatory	See 5.17.2.3
Reserve and Configure IMS Resources	Reserve IMS Connection Point and configure remote resources	Mandatory	See 5.17.2.4
Release IMS termination	Release IMS termination	Mandatory	See 5.17.2.5
Detect DTMF	Detect IMS RTP Tel Event	Optional	See 5.17.2.18
Stop DTMF Detection	End IMS RTP Tel Event	Optional	See 5.17.2.20
Report DTMF	Notify IMS RTP Tel Event	Optional	See 5.17.2.19
Start Playing Multimedia	n.a for re-use	Optional	See 5.17.2.24
Stop Playing Multimedia	n.a for re-use	Optional	See 5.17.2.25
Playing Multimedia Completed	n.a for re-use	Optional	See 5.17.2.26
Send Tone	n.a for re-use	Optional	See 5.17.2.6
Stop Tone	IMS Stop Tone	Optional	See 5.17.2.7
Tone Completed	IMS Tone Completed	Optional	See 5.17.2.8
Start Announcement	n.a for re-use	Optional	See 5.17.2.9
Stop Announcement	Stop Announcement	Optional	See 5.17.2.10
Announcement Completed	Announcement Completed	Optional	See 5.17.2.11
Start Audio Record	n.a for re-use	Optional	See 5.17.2.15
Stop Audio Record	n.a for re-use	Optional	See 5.17.2.16
Audio Record Complete	n.a for re-use	Optional	See 5.17.2.17
Start Multimedia Record	n.a for re-use	Optional	See 5.17.2.27
Stop Multimedia Record	n.a for re-use	Optional	See 5.17.2.28
Multimedia Record Completed	n.a for re-use	Optional	See 5.17.2.29
Start TTS	n.a for re-use	Optional	See 5.17.2.12
Stop TTS	n.a for re-use	Optional	See 5.17.2.13
TTS Completed	n.a for re-use	Optional	See 5.17.2.14
Start ASR	n.a for re-use	Optional	See 5.17.2.21
Stop ASR	n.a for re-use	Optional	See 5.17.2.23
ASR Completed	n.a for re-use	Optional	See 5.17.2.22

Adhoc Audio Conference	n.a for re-use	Optional	See 5.17.2.30
Multi-Media Conferencing	n.a for re-use	Optional	See 5.17.2.31
Termination heartbeat Indication	Termination heartbeat Indication	Mandatory	See 5.17.2.32
Configure BFCP Termination	n.a for re-use	Optional	See 5.17.2.33
Configure Conference For Floor Control	n.a for re-use	Optional	See 5.17.2.34
Designate Floor Chair	n.a for re-use	Optional	See 5.17.2.35
Floor Request Decision	n.a for re-use	Optional	See 5.17.2.36
Report Floor Request Decision	n.a for re-use	Optional	See 5.17.2.37
Modify Media	n.a for re-use	Optional	See 5.17.2.38
Confirm Media Update	n.a for re-use	Optional	See 5.17.2.39
Start Playing Message	n.a for re-use	Optional	See 5.17.2.40
Stop Playing Message	n.a for re-use	Optional	See 5.17.2.41
Playing Message Completed	n.a for re-use	Optional	See 5.17.2.42
Start Message Record	n.a for re-use	Optional	See 5.17.2.43
Stop Message Record	n.a for re-use	Optional	See 5.17.2.44
Message Record Completed	n.a for re-use	Optional	See 5.17.2.45
Configure Granted Quota	n.a for re-use	Optional	See 5.17.2.46
Report Message Statistics	n.a for re-use	Optional	See 5.17.2.47
Configure Filtering Rules	n.a for re-use	Optional	See 5.17.2.48
ECN Failure Indication	n.a for re-use	Optional	See 5.17.2.49
NOTE 1: A procedure defined in this table can be combined with another procedure in the table. This means that they can share the same contextID and termination ID(s) and that they can be combined in the same H.248 command.			

### 5.17.2.2 Reserve IMS Resources

The MRFC sends an ADD request command as in Table 5.17.2.2.1.

**Table 5.17.2.2.1: Reserve IMS Resources Request**

Address Information	Control information	Bearer information
Local Descriptor { Port = \$ IP Address = \$ If media is "message": MSRP session identity = \$ }	Transaction ID = x Context ID= \$ Termination ID = \$ If Stream Number specified:- Stream Number If Resources for multiple Codecs required: Reserve_Value NotificationRequested (Event ID = x, "termination heartbeat") If ECN transparent support required: ECN Enable = "True" Initiation Method = "inactive"  If ECN Endpoint support required ECN Enable = "True" Initiation Method = "ECN Initiation Method" NOTE  If notification of ECN Failure Report: NotificationRequested (Event ID = x, "ECN Failure")	Local Descriptor { If media is "audio" or "video": Codec List = Codec List RTP Payloads = RTP Payload If media is "message": Transport = TCP/MSRP } or Local Descriptor { RTP Payloads = \$ }
NOTE: This shall be set to a value other than "inactive"		

On reserving the IMS termination, the MRFP responds as in Table 5.17.2.2.2.

**Table 5.17.2.2.2: Reserve IMS Resources Request Acknowledge**

Address Information	Control information	Bearer information
Local Descriptor { Port IP Address If media is "message": MSRP session identity }	Transaction ID = x Context ID = C1 Termination ID = T1 Stream Number	Local Descriptor { If media is "audio" or "video":  Codec List RTP Payloads If media is "message": Transport = TCP/MSRP }

### 5.17.2.3 Configure IMS Resources

The MRFC sends a MODIFY request command as in Table 5.17.2.3.1.

**Table 5.17.2.3.1: Configure IMS Resources Request**

Address Information	Control information	Bearer information
If local resources are modified: Local Descriptor { Port IP Address If media is "message": MSRP session identity } If remote resources are modified: Remote Descriptor { Port IP Address If media is "message": MSRP session identity }	Transaction ID = x Context ID = C1 Termination ID = T1  If Stream Number specified: Stream Number  If Resources for multiple Codecs required: Reserve_Value  If detection of hanging termination is requested: (NOTE1) NotificationRequested (Event ID = x, "termination heartbeat") If ECN transparent support required: ECN Enable = "True" Initiation Method = "inactive"  If ECN Endpoint support required ECN Enable = "True" Initiation Method = "ECN Initiation Method" NOTE2  If notification of ECN Failure Report: NotificationRequested (Event ID = x, "ECN failure")	If local resources are modified: Local Descriptor { If media is "audio" or "video": Codec List RTP Payloads If media is "message": Transport = TCP/MSRP } If remote resources are modified: Remote Descriptor { If media is "audio" or "video": Codec List RTP Payloads If media is "message": Transport = TCP/MSRP }
NOTE1: It is highly recommended to request termination heartbeat notification to detect hanging context and termination in the MRFP that may result e.g. from a loss of communication between the MRFC and the MRFP.		
NOTE 2: This shall be set to a value other than "inactive"		

The MRFP responds as in 5.17.2.3.2.

**Table 5.17.2.3.2: Configure IMS Resources Request Acknowledge**

Address Information	Control information	Bearer information
If local resources were provided in request: Local Descriptor { Port IP Address If media is "message": MSRP session identity } If remote resources are provided in request: Remote Descriptor { Port IP Address If media is "message": MSRP session identity }	Transaction ID = x Context ID = C1 Termination ID = T1  If Stream Number Specified: Stream Number	If local resources were provided in request: Local Descriptor { If media is "audio" or "video": Codec List RTP Payloads If media is "message": Transport = TCP/MSRP } If remote resources are provided in request: Remote Descriptor { If media is "audio" or "video": Codec List RTP Payloads If media is "message": Transport = TCP/MSRP }

**5.17.2.4 Reserve and Configure IMS Resources**

The MRFC sends an ADD request command as in Table 5.17.2.4.1.



**Table 5.17.2.4.1: Reserve and Configure IMSresources Request**

Address Information	Control information	Bearer information
Local Descriptor { Port = \$ IP Address = \$ If media is "message": MSRP session identity = \$ } Remote Descriptor { Port IP Address If media is "message": MSRP session identity }	Transaction ID = x Context ID = \$ Termination ID = \$  If Stream Number Specified: Stream Number If Resources for multiple Codecs shall be reserved: Reserve_Value  If detection of hanging termination is requested: (NOTE1) NotificationRequested (Event ID = x, "termination heartbeat")  If ECN transparent support required: ECN Enable = "True" Initiation Method = "inactive"  If ECN Endpoint support required ECN Enable = "True" Initiation Method = "ECN Initiation Method" NOTE2  If notification of ECN Failure Report: NotificationRequested (Event ID = x, "ECN Failure")	Local Descriptor { If media is "audio" or "video": Codec List RTP Payloads If media is "message": Transport = TCP/MSRP } Remote Descriptor { If media is "audio" or "video": Codec List RTP Payloads If media is "message": Transport = TCP/MSRP }
NOTE1: It is highly recommended to request termination heartbeat notification to detect hanging context and termination in the MRFP that may result e.g. from a loss of communication between the MRFC and the MRFP.		
NOTE 2: This shall be set to a value other than "inactive"		

The MRFP responds as in Table 5.17.2.4.2.

**Table 5.17.2.4.2: Reserve and Configure IMS Resources Request Acknowledge**

Address Information	Control information	Bearer information
Local Descriptor { Port IP Address If media is "message": MSRP session identity } Remote Descriptor { Port IP Address If media is "message": MSRP session identity }	Transaction ID = x Context ID = C1 Termination ID = T1 Stream Number	Local Descriptor { If media is "audio" or "video": Codec List RTP Payloads If media is "message": Transport = TCP/MSRP } Remote Descriptor { If media is "audio" or "video": Codec List RTP Payloads If media is "message": Transport = TCP/MSRP }

**5.17.2.5 Release IMS Termination**

The MRFC sends a SUBTRACT command as in Table 5.17.2.5.1.

**Table 5.17.2.5.1: Release IMS Termination Request**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID= C1 Termination ID = T1	

On releasing the IMS termination, the MRFP responds as in Table 5.17.2.5.2

**Table 5.17.2.5.2: Release IMS Termination Request Acknowledge**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.6 Send Tone

This procedure is used to play a tone.

The MRFC sends an ADD or MODIFY command as in table 5.17.2.6.1.

**Table 5.17.2.6.1: Send Tone**

Address information	Control information	Bearer information
	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$ If Termination exists: Termination ID = T1 Else Termination ID = \$  If Stream Number specified: Stream Number  Signal ID = Tone Identity If override Signal Direction Direction = Signal Direction  If DTMF override Override = DTMFTrigger  If MRFC wishes to override the default tone duration: Tone Duration  If MRFC requires to be informed of the end of the tone :- Request End Of Signal Notification If detection of hanging termination is requested: (NOTE3) NotificationRequested (Event ID = x, "termination heartbeat")	

NOTE1: Signal Direction shall be either "internal" or "external".  
 NOTE2: Only the Tone Signal Ids shall be used, not the Tone Ids within the PlayTone Signal Id.  
 NOTE3: The termination heartbeat event shall be configured when requesting a new bearer termination.

The MRFP responds as shown in Table 5.17.2.6.2.

**Table 5.17.2.6.2: SendTone Acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 If local resources were provided in request: Stream Number	

### 5.17.2.7 Stop Tone

This procedure is used to stop a tone. This procedure is the same as the procedure Start Tone however the signal descriptor shall not include the started tone signal. Note that a tone may also be stopped by releasing the IMS termination.

### 5.17.2.8 Tone Completed

This procedure is used to report that a tone has ended.

The MRFP sends a NOTIFY to the MRFC as shown in table 5.17.2.q.1.

**Table 5.17.2.8.1: Tone Completed**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 End Of Signal Notification = Tone Completed Cause	

The MRFC responds as shown in Table 5.17.2.8.2.

**Table 5.17.2.8.2: Tone Completed Ack**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.9 Start Announcement

This procedure is used to play an announcement, which may be fixed or variable.

The MRFC sends an ADD or MODIFY command as in Table 5.17.2.9.1.

**Table 5.17.2.9.1: Start Announcement**

Address information	Control information	Bearer information
	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$ If Termination exists: Termination ID = T1 Else Termination ID = \$  If Stream number specified: Stream Number  Announcement Identity If override Signal Direction Direction = Announcement Direction  If DTMF override Override = DTMFTrigger  If MRFC wishes to override the default number of cycles: Announcement Cycles  If MRFC wishes to override the default announcement variant: Announcement Variant  If MRFC requires to be informed of the end of the fixed announcement :- Request End Of Signal Notification  If detection of hanging termination is requested: (NOTE4) NotificationRequested (Event ID = x, "termination heartbeat")	
NOTE1: Signal Direction shall be either "internal" or "external". NOTE2: Stream mode may be maintained as for the ongoing call or may be restricted to "send only". NOTE3: Signal Lists shall be supported. NOTE4: The termination heartbeat event shall be configured when requesting a new bearer termination.		

The MRFP responds as shown in Table 5.17.2.9.2.

**Table 5.17.2.9.2: Start Announcement Acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  If local resources were provided in request: Stream Number	

### 5.17.2.10 Stop Announcement

This procedure is used to stop an announcement. This procedure is the same as the procedure Start Announcement however the signal descriptor shall not include the started announcement signal. Note that an announcement may also be stopped by releasing the IMS termination.

### 5.17.2.11 Announcement Completed

This procedure is used to report that an announcement has ended.

The MRFP sends a NOTIFY to the MRFC as shown in table 5.17.2.11.1.

**Table 5.17.2.11.1: Announcement Completed**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 End Of Signal Notification = Announcement Completed Cause = Announcement Cause	

The MRFC responds as shown in Table 5.17.2.11.2.

**Table 5.17.2.11.2: Announcement Completed Ack**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.12 Start TTS

This procedure is used to play out a text file as speech.

The MRFC sends an ADD or MODIFY command as in Table 5.17.2.12.1.

**Table 5.17.2.12.1: Start TTS request**

Address information	Control information	Bearer information
	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$ If Termination exists: Termination ID = T1 Else Termination ID = \$  If Stream number specified: Stream Number If override Direction TTS Direction = Signal Direction  If DTMF override DTMF Stop TTS =DTMFTrigger  Text Block = SSML  If MRFC wishes to override the default number of cycles: number of cycles = Iterations  If MRFC requires to be informed of the end of TTS:- Request End Of Signal Notification  If detection of hanging termination is requested: (NOTE1) NotificationRequested (Event ID = x, "termination heartbeat")	
NOTE1: The termination heartbeat event shall be configured when requesting a new bearer termination.		

The MRFP responds as shown in Table 5.17.2.12.2.

**Table 5.17.2.12.2: Start TTS Acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  If local resources were provided in request: Stream Number	

### 5.17.2.13 Stop TTS

This procedure is used to stop TTS play. This procedure is the same as the procedure Start TTS however the signal descriptor shall not include the started TTS signal. Note that an TTS play may also be stopped by releasing the IMS termination.

### 5.17.2.14 TTS Completed

This procedure is used to report that an TTS play has ended.

The MRFP sends a NOTIFY to the MRFC as shown in table 5.17.2.14.1.

**Table 5.17.2.14.1: TTS Completed**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 End Of Signal Notification = TTS Completed Cause	

The MRFC responds as shown in Table 5.17.2.14.2.

**Table 5.17.2.14.2: TTS Completed Ack**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.15 Start Audio Record

This procedure enables a caller to leave/record a voice message (e.g. in a voice mail application).

The MRFC sends an ADD or MODIFY command as in table 5.17.2.15.1.

**Table 5.17.2.15.1: Start Audio Record**

Address information	Control information	Bearer information
	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$ If Termination exists: Termination ID = T1 Else Termination ID = \$  If Stream Number specified: Stream Number  If specific record file Recording File Identity = Record File Identifier  If request record file Identity Recording File Identity = ?  If maximum record time Maximum Recording Length = Maximum Record Time If MRFC requires to be informed of the end of the recording :- End Of Recording Notification  If override Signal Direction Direction = Signal Direction  If detection of hanging termination	

Address information	Control information	Bearer information
	is requested: (NOTE1) NotificationRequested (Event ID = x, "termination heartbeat")	
NOTE1: The termination heartbeat event shall be configured when requesting a new bearer termination. NOTE2: Signal Direction shall be either "internal" or "external". NOTE3: Multiple signals shall be supported.		

The MRFP responds as shown in table 5.17.2.15.2.

**Table 5.17.2.15.2: Start Audio Record acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 If local resources were provided in request: Stream Number If requested record file identity Recording File Identity = Record File Identifier	

### 5.17.2.16 Stop Audio Record

This procedure is used to stop recording of audio. Note that Audio Record may also be stopped by releasing the IMS termination.

**Table 5.17.2.16.1: Stop Audio Record**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  Stop Audio Record Indication  If End of Audio Record Notification previously requested : Stop End of Record Notification	

The MRFP responds as shown in Table 5.17.2.16.2.

**Table 5.17.2.16.2: Stop Audio Record Response**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.17 Audio Record Complete

This procedure enables the MRFP to inform the MRFC when an audio recording is complete.



The MRFP sends a NOTIFY command as in table 5.17.2.17.1.

**Table 5.17.2.17.1: Audio Record Complete**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  End Of Recording Notification	

The MRFC responds as shown in table 5.17.2.17.2.

**Table 5.17.2.17.2: Audio Record Complete Acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.18 Detect DTMF

This procedure is used to collect DTMF digits.

The MRFP applies the procedures defined in RFC 4733 [22] to receive DTMF digits at the user plane, however only complete single digits shall be reported, i.e. the MRFP shall wait until E-bit is set to 1 before reporting the digit to the MRFC.

The MRFC sends an ADD or MODIFY command as in Table 5.17.2.18.1.

**Table 5.17.2.18.1: Detect DTMF**

Address information	Control information	Bearer information
	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$ If Termination exists: Termination ID = T1 Else Termination ID = \$  If Stream Number specified: Stream Number  NotificationRequested (Event ID = x, "Report_DTMF (Digit,Timing)")	
NOTE1: Only "end tone detected" shall be requested by the MRFC. NOTE2: All digits shall be requested i.e. Toneld shall be wildcarded.		

The MRFP responds as shown in Table 5.17.2.18.2.

**Table 5.17.2.18.2: Detect DTMF acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 If local resources were provided in request: Stream Number	

### 5.17.2.19 Report DTMF

This procedure is used to notify the MRFC of detected DTMF digits.

The MRFP sends a NOTIFY command as in Table 5.17.2.19.1.

**Table 5.17.2.19.1: Report DTMF**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 Digit Notification = digit	

The MRFC responds as shown in Table 5.17.2.19.2.

**Table 5.17.2.19.2: Report DTMF Digit Acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.20 Stop DTMF Detection

This procedure is used to stop DTMF digit detection.

The MRFC sends a MODIFY command as in Table 5.17.2.20.1.

**Table 5.17.2.20.1: Stop DTMF Detection**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  Stop DTMF Digit Collection	

The MRFP responds as shown in Table 5.17.2.20.2.

**Table 5.17.2.20.2: Stop DTMF Digit Detection acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.21 ASR Request

This procedure enables the MRFC to request the MRFP to perform automatic speech recognition; an advanced interaction with the user involving guidance announcements and collection of user input via speech and also possibly DTMF. In turn, the MRFP attempts to recognize and match the detected speech to the specified grammar file and report this to the MRFC.

The MRFC sends an ADD or MODIFY command as in table 5.17.2.21.1.

**Table 5.17.2.21.1: ASR request**

Address information	Control information	Bearer information
	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$ If Termination exists: Termination ID = T1 Else Termination ID = \$  If Stream Number specified: Stream Number  If recognition with grammar script ASR Grammar = SRGS grammar Else recognition with grammar identifier ASR Grammar = SRGS grammar URI  If MRFC requires to be informed of the end of the ASR :- NotificationRequested (Event ID = x, "Notify ASR Completion (recognition result)")  If detection of hanging termination is requested: (NOTE1) NotificationRequested (Event ID = x, "termination heartbeat")	
NOTE1: The termination heartbeat event shall be configured when requesting a new bearer termination.		

The MRFP responds as shown in table 5.17.2.21.2.

**Table 5.17.2.21.2: ASR request acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1	

	Termination ID = T1 If local resources were provided in request: Stream Number	
--	--------------------------------------------------------------------------------------	--

### 5.17.2.22 ASR Completed

This procedure enables the MRFP to inform the MRFC of the result of an ASR request.

The MRFP sends a NOTIFY command as in table 5.17.2.22.1.

**Table 5.17.2.22.1: ASR Completed**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  If ASR fails: ASR Cause Else recognition result	

The MRFP responds as shown in table 5.17.2.22.2.

**Table 5.17.2.22.2: ASR Completed acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.23 Stop ASR

This procedure is used to stop the ASR procedure.

The MRFC sends a MODIFY command as in Table 5.17.2.23.1.

**Table 5.17.2.23.1: Stop ASR**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  Stop ASR	

The MRFP responds as shown in Table 5.17.2.23.2.

**Table 5.17.2.23.2: Stop ASR acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

**5.17.2.24 Start Playing Multimedia**

This procedure enables a caller to be connected to a playback of previously recorded multimedia segments. This procedure is similar to that of 5.17.2.9 with the difference that multiple H.248 streams will be used to reflect the multimedia content to be played out.

The MRFC sends an ADD or MODIFY command as in Table 5.17.2.24.1.

**Table 5.17.2.24.1: Start Playing Multimedia**

Address information	Control information	Bearer information
	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$ If Termination exists: Termination ID = T1 Else Termination ID = \$  If multiple media sources Stream NumberX: Media IdentifierX Stream numberY: Media IdentifierY Else Stream NumberX, Stream NumberY: Media Identifier  If override multimedia format Format = Multimedia File Format  If override Signal Direction Direction = Signal Direction  If DTMF override Multimedia Override = DTMFTrigger  If MRFC wishes to override the default number of cycles: play Cycles= iteration  If MRFC wishes to override the default announcement variant: Announcement Variant  If MRFC requires to be informed of the end of the multimedia play Request End Of Signal Notification  If detection of hanging termination is requested: (NOTE4)	

	NotificationRequested (Event ID = x, "termination heartbeat")	
<p>NOTE1: Signal Direction shall be either "internal" or "external".</p> <p>NOTE2: Stream mode may be maintained as for the ongoing call or may be changed be restricted to "send only".</p> <p>NOTE3: Signal Lists shall be supported</p> <p>NOTE4: The termination heartbeat event shall be configured when requesting a new bearer termination.</p>		

The MRFP responds as shown in Table 5.17.2.24.2.

**Table 5.17.2.24.2: Start Playing Multimedia Acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  If local resources were provided in request: Stream Number	

### 5.17.2.25 Stop Playing Multimedia

This procedure is used to stop an announcement. This procedure is the same as the procedure Start Playing Multimedia however the signal descriptor shall not include the started multimedia signal. Note that playing multimedia may also be stopped by releasing the IMS termination.

### 5.17.2.26 Playing Multimedia Completed

This procedure is used to report that a playing multimedia has ended.

The MRFP sends a NOTIFY to the MRFC as shown in table 5.17.2.26.1.

**Table 5.17.2.26.1: Playing Multimedia Completed**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 End Of Signal Notification = Playing Multimedia Completed Cause = Announcement Cause	

The MRFC responds as shown in Table 5.17.2.26.2.

**Table 5.17.2.26.2: Playing Multimedia Completed Ack**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.27 Start Multimedia Record

This procedure enables a caller to leave/record a multimedia message. This procedure is similar to that of Audio Record (5.17.2.15) with the difference that multiple H.248 streams will be used and both audio and video codecs are specified

for each participant in the conference. Any prompting "announcements" are played out in the appropriate format by the MRFP based on the fact that multimedia codecs are specified by the MRFC in the Remote Descriptor. Similarly, the MRFP records all received media streams that are consistent with the Local Descriptor of the termination.

The MRFC sends an ADD or MODIFY command as in table 5.17.2.27.1.

**Table 5.17.2.27.1 – Start Multimedia Record**

Address information	Control information	Bearer information
	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$ If Termination exists: Termination ID = T1 Else Termination ID = \$  If Stream Number specified: Stream Number  If specific record file Recording File Identity = Record File Identifier  If override multimedia format Format = Multimedia File Format  If maximum record time Maximum Recording Length = Maximum Record Time  If MRFC requires to be informed of the end of the recording :- End Of Recording Notification  If request record file identity Recording File Identity = ?  If DTMF override Override = DTMFTrigger  If detection of hanging termination is requested: (NOTE1) NotificationRequested (Event ID = x, "termination heartbeat")	
NOTE1: The termination heartbeat event shall be configured when requesting a new bearer termination.		
NOTE2: Multiple signals shall be supported.		

The MRFP responds as shown in table 5.17.2.27.2.

**Table 5.17.2.27.2: Start Multimedia Record acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1	

	Termination ID = T1 If local resources were provided in request: Stream Number  If requested record file identity Recording File Identity = Record File Identifier	
--	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

### 5.17.2.28 Stop Multimedia Record

This procedure is used to stop recording of multimedia. Note that Audio Record may also be stopped by releasing the IMS termination.

**Table 5.17.2.28.1: Stop Multimedia Record**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  Stop Multimedia Record Indication  If End of Multimedia Record Notification previously requested : Stop End of Record Notification	

The MRFP responds as shown in Table 5.17.2.28.2.

**Table 5.17.2.28.2: Stop Multimedia Record Response**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.29 Multimedia Record Completed

This procedure enables the MRFP to inform the MRFC when multimedia recording is complete.

The MRFP sends a NOTIFY command as in table 5.17.2.29.1.

**Table 5.17.2.29.1: Multimedia Record Completed**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  End Of Recording Notification	

The MRFC responds as shown in table 5.17.2.29.2.



**Table 5.17.2.29.2: Multimedia Record Completed Acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.30 Adhoc Audio Conference

This includes support for N-party conferences plus the support of audio transcoding. In this case, up to N ephemeral terminations may be placed in a context and appropriate audio transcoding performed by the MRFP between any codec differences between the terminations. In terms of the media mixing, the MRFP mixes audio from terminations N-1, N-2 etc plays to termination N and so forth.

This procedure consists of the creation of the first ephemeral termination of a conference within a context using procedure "Reserve and Configure IMS Resources" and then subsequent parties are added using procedures "Reserve IMS Resources" and "Configure IMS Resources".

### 5.17.2.31 Multi-Media Conferencing

This is similar to audio conferencing (5.17.2.y) with the difference that multiple H.248 streams will be used and both audio and video codecs are specified for each participant in the conference. The MRFP shall only transcode and mix between streams of the same media type.

### 5.17.2.32 Termination heartbeat indication

When the procedure "Termination heartbeat indication" is required the following procedure is initiated: the MRFP sends a NOT.req command with the following information.

#### 5.17.2.32.1 NOT.req (Termination heartbeat) MRFP to MRFC

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  Event_ID (Event ID = x, "termination heartbeat")	

When the processing of command is complete, the MRFC initiates the following procedure.

#### 5.17.2.32.2 NOT.resp (Termination heartbeat) MRFC to MRFP

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

The heartbeat timer shall be configured to a value much greater than the mean call holding time.

The MRFC is in charge of correcting any detected mismatch, by subtracting hanging terminations or clearing hanging contexts.

### 5.17.2.33 Configure BFCP Termination

This procedure configures a termination to support Binary Floor Control Protocol.

The MRFC sends an ADD or MODIFY command as in Table 5.17.2.33.1.

**Table 5.17.2.33.1: Configure BFCP Termination MRFC to MRFP**

Address Information	Control information	Bearer information
Local Descriptor { Port = \$ IP Address = \$ } Remote Descriptor { Port IP Address }	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$ If Termination exists: Termination ID = T1 Else Termination ID = \$  If Stream Number Specified: Stream Number  If detection of hanging termination is requested: (NOTE1) NotificationRequested (Event ID = x, "termination heartbeat")	Local Descriptor { Transport = TCP/BFCP User Identifier = UserID Available Floors = FloorID-x, FloorID-y...(NOTE2) }  Remote Descriptor { Transport = TCP/ BFCP }
NOTE1: It is highly recommended to request termination heartbeat notification to detect hanging context and termination in the MRFP that may result e.g. from a loss of communication between the MRFC and the MRFP. NOTE2: Properties are configured against the local stream descriptor for BFCP but infact applies to the whole termination (user), i.e. all streams.		

The MRFP responds as in Table 5.17.2.33.2.

**Table 5.17.2.33.2: Configure BFCP Termination Acknowledge MRFP to MRFC**

Address Information	Control information	Bearer information
Local Descriptor { Port IP Address } Remote Descriptor { Port IP Address }	Transaction ID = x Context ID = C1 Termination ID = T1 Stream Number	Local Descriptor { Transport = TCP/ BFCP } Remote Descriptor { Transport = TCP/ BFCP }

### 5.17.2.34 Configure Conference

This procedure configures or modifies Context properties required to support a MRFP based Floor Control Server.

The MRFC sends an ADD or MODIFY command as in Table 5.17.2.34.1.

**Table 5.17.2.34.1: Configure Conference MRFC to MRFP**

Address Information	Control information	Bearer information
	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$  ContextAttribute Descriptor { Conference Identifier = ConfID  Floor Control Algorithm = FloorControlAlgorithm  MaxNumber of Floor Holders = MaxFloorHolder  Floor Resource Associations = FloorResAssociations }	

The MRFP responds as in Table 5.17.2.34.2.

**Table 5.17.2.34.2: Configure Conference Acknowledge MRFP to MRFC**

Address Information	Control information	Bearer information
	Context ID = C1	

### 5.17.2.35 Designate Floor Chair

This procedure configures a termination to be Floor Chair support Binary Floor Control Protocol.

Pre-requisites:

- This procedure is dependent on "Configure Conference" procedure having been successfully completed or it may be combined in the same ADD command.
- This procedure is dependent on "Configure BFCP Termination" procedure having been successfully completed or it may be combined in the same command.

The MRFC sends an ADD or MODIFY command as in Table 5.17.2.35.1.

**Table 5.17.2.35.1: Designate Floor Chair MRFC to MRFP**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 If Termination exists: Termination ID = T1 Else Termination ID = \$ If Stream Number Specified: Stream Number Floors Controlled by Chair = ControlledByChair If detection of hanging termination is requested: (NOTE1) NotificationRequested (Event ID = x, "termination heartbeat")	
NOTE1: It is highly recommended to request termination heartbeat notification to detect hanging context and termination in the MRFP that may result e.g. from a loss of communication between the MRFC and the MRFP.		

The MRFP responds as in Table 5.17.2.35.2.

**Table 5.17.2.35.2: Designate Floor Chair Acknowledge MRFP to MRFC**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 Stream Number	

### 5.17.2.36 Floor Request Decision

This procedure requests the MRFP to notify the MRFC when a decision has been made by the FCS in response to a BFCP Floor Request.

The MRFC sends an ADD or MODIFY command as in Table 5.17.2.yx.1.

**Table 5.17.2.36.1: Floor Request Decision MRFC to MRFP**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 NotificationRequested (Event ID = x, "FloorRequestDecision" )	

The MRFP responds as in Table 5.17.2.36.2.

**Table 5.17.2.36.2: Floor Request Decision Acknowledge MRFP to MRFC**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.37 Report Floor Request Decision

This procedure indicates the decision made by the FCS in response to a BFCP Floor Request. The MRFP indicates the agreed Floor Permissions so that any required changes to the streams can be managed by the MRFC.

The MGW sends a NOT.req command with the following information.

**Table 5.17.2.37.1: NOT.req (FloorRequestDecision) MRFP to MRFC**

Address Information	Control information	Bearer information
	Transaction ID = z Context ID = c1 Termination ID = bearer1  Event_ID (Event ID = x, " FloorRequestDecision ( Floor ID1 + FloorStatus1, Floor ID2 + FloorStatus2) ")	

When the processing of command (1) is complete, the MGC initiates the following procedure.

**Table 5.17.2.37.2: NOT.resp (FloorRequestDecision) MRFC to MRFP**

Address Information	Control information	Bearer information
	Transaction ID = z Context ID = c1 Termination ID = bearer1	

### 5.17.2.38 Modify Media

This procedure modifies the termination(s) in accordance with the agreed Floor Permissions granted by the FCS in response to a BFCP Floor Request (notified to the MRFC via the "Report Floor Request Decision" procedure).

The MRFC sends a MODIFY command as in Table 5.17.2.38.1.

**Table 5.17.2.38.1: Modify Media MRFC to MRFP**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID	Local Descriptor { If stream modified Stream Mode = mode. If attributes modified [SDP...] }  Remote Descriptor { If stream modified Stream Mode = mode. If attributes modified [SDP...] }

The MRFP responds as in Table 5.17.2.38.2.

**Table 5.17.2.38.2: Modify Media Acknowledge MRFP to MRFC**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 Stream Number	

### 5.17.2.39 Confirm Media Update

This procedure indicates to the MRFP when the media modification for a given Floor Request (notified to the MRFC via the "Report Floor Request Decision" procedure) has been performed.

The MRFC sends a MODIFY command as in Table 5.17.2.39.1.

**Table 5.17.2.39.1: Confirm Media Update MRFC to MRFP**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID If Stream Number Specified: Stream Number  Floor Request Status = FloorStatus Result = FloorRequestResult	

The MRFP responds as in Table 5.17.2.39.2.

**Table 5.17.2.39.2: Confirm Media Update Acknowledge MRFP to MRFC**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 Stream Number	

### 5.17.2.40 Start Playing Message

This procedure enables a caller to be connected to a playback of previously recorded message segments. This procedure is similar to that of 5.17.2.24 with the difference that message streams will be used to reflect the message content to be played out.

The MRFC sends an ADD or MODIFY command as in Table 5.17.2.40.1.

**Table 5.17.2.40.1: Start Playing Message**

Address information	Control information	Bearer information
	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$ If Termination exists: Termination ID = T1 Else Termination ID = \$	

	If Stream Number specified: Stream Number  Message identifier = MessageIdentifier  If override Signal Direction Direction = Signal Direction  If MRFC requires to be informed of the end of the message play: Result of message play = MessagePlayResultReport  If detection of hanging termination is requested: (NOTE4) NotificationRequested (Event ID = x, "termination heartbeat")	
NOTE1: Signal Direction shall be either "internal" or "external". NOTE2: Stream mode may be maintained as for the ongoing call or may be changed be restricted to "send only". NOTE3: Signal Lists shall be supported NOTE4: The termination heartbeat event shall be configured when requesting a new bearer termination.		

The MRFP responds as shown in Table 5.17.2.40.2.

**Table 5.17.2.40.2: Start Playing Message Acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  If local resources were provided in request: Stream Number	

**5.17.2.41 Stop Playing Message**

This procedure is used to stop an announcement. This procedure is the same as the procedure Start Playing Message however the signal descriptor shall not include the started message signal. Note that playing message may also be stopped by releasing the IMS termination.

**5.17.2.42 Playing Message Completed**

This procedure is used to report that a playing message has ended.

The MRFP sends a NOTIFY to the MRFC as shown in table 5.17.2.aa+3.1.

**Table 5.17.2.42.1: Playing Message Completed**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 End Of Signal Notification = Playing Message Completed Cause = MessagePlayCause	

The MRFC responds as shown in Table 5.17.2.42.2.

**Table 5.17.2.42.2: Playing Message Completed Ack**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.43 Start Message Record

This procedure enables a caller to leave/record a messaging message. This procedure is similar to that of Multimedia Record (5.17.2.27) with the difference that messaging H.248 stream will be used. Similarly, the MRFP records all received media streams that are consistent with the Local Descriptor of the termination.

The MRFC sends an ADD or MODIFY command as in table 5.17.2.43.1.

**Table 5.17.2.43.1 – Start Message Record**

Address information	Control information	Bearer information
	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$ If Termination exists: Termination ID = T1 Else Termination ID = \$  If Stream Number specified: Stream Number  If specific record file Recording File Identity = MessageRecordFileIdentifier Else Recording File Identity = ?  If maximum record time Maximum Recording Length = Maximum Record Time  If override Signal Direction Direction = Signal Direction  If MRFC requires to be informed of the end of the recording :- End Of Recording Notification	

The MRFP responds as shown in table 5.17.2.43.2.

**Table 5.17.2.43.2: Start Message Record acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 If local resources were provided in request: Stream Number	



	If requested record file identity Recording File Identity = MessageRecordFileIdentifier	
--	-----------------------------------------------------------------------------------------------	--

### 5.17.2.44 Stop Message Record

This procedure is used to stop recording of message. Note that Message Record may also be stopped by releasing the IMS termination.

**Table 5.17.2.44.1: Stop Message Record**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  Stop Multimedia Record Indication  If End of Multimedia Record Notification previously requested: Stop End of Record Notification	

The MRFP responds as shown in Table 5.17.2.44.2.

**Table 5.17.2.44.2: Stop Message Record Response**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.45 Message Record Completed

This procedure enables the MRFP to inform the MRFC when message recording is complete.

The MRFP sends a NOTIFY command as in table 5.17.2.bb+3.1.

**Table 5.17.2.45.1: Message Record Completed**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  End Of Recording Notification	

The MRFC responds as shown in table 5.17.2.45.2.

**Table 5.17.2.45.2: Message Record Completed Acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.46 Configure Granted Quota

This procedure configures a termination of the granted quota to support message statistics.

The MRFC sends an ADD or MODIFY command as in Table 5.17.2.46.1.

**Table 5.17.2.46.1: Configure Granted Quota MRFC to MRFP**

Address Information	Control information	Bearer information
	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$ If Termination exists: Termination ID = T1 Else Termination ID = \$  If Stream Number Specified: Stream Number  If report of message statistics on quota is requested: NotificationRequested (Event ID = x, "Messaging Quota" ( If Quota for number of messages sent specified: Number of Messages Sent Quota = MessagesSentNumQuota  If Quota for number of messages received specified: Number of Messages received Quota = MessagesreceivedNumQuota  If Quota for volume of messages sent specified: Volume of Messages Sent Quota = MessagesSentVolQuota  If Quota for volume of messages received specified: Volume of Messages Received Quota = MessagesReceivedVolQuota  If Valid Time specified: Valid Time = StatValTime ))	

The MRFP responds as in Table 5.17.2.46.2.

**Table 5.17.2.46.2: Configure Granted Quota Acknowledge MRFP to MRFC**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 Stream Number	

### 5.17.2.47 Report Message Statistics

This procedure is used to notify the MRFC of message statistics.

The MRFP sends a NOTIFY command as in Table 5.17.2.47.1.

**Table 5.17.2.47.1: Report Message Statistics**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  Reason For Report = StatRepReason  If number of messages sent requested: Number of Messages Sent = MessagesSentNum  If number of messages received requested: Number of Messages received = MessagesreceivedNum  If volume of messages sent requested: Volume of Messages Sent = MessagesSentVol  If volume of messages received requested: Volume of Messages Received = MessagesReceivedVol	

The MRFC responds as shown in Table 5.17.2.47.2.

**Table 5.17.2.47.2: Report Message Statistics Acknowledge**

Address information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

### 5.17.2.48 Configure Filtering Rules

This procedure configures a termination of the filtering rules to support message filtering.

The MRFC sends an ADD or MODIFY command as in Table 5.17.2.48.1.

**Table 5.17.2.48.1: Configure Filtering Rules MRFC to MRFP**

Address Information	Control information	Bearer information
	Transaction ID = x If context already exists: Context ID = C1 Else Context = \$ If Termination exists: Termination ID = T1 Else Termination ID = \$  If Stream Number Specified: Stream Number  If requested message filtering on incoming messages: Incoming Message Filters = IncMessageFilters (NOTE)  If requested message filtering on outgoing messages: Outgoing Message Filters = OutMessageFilters (NOTE)	
NOTE: The value shall comply with Sieve [IETF RFC5228] with the exceptions described in H.248.69 [35] Clause 13.6. Filtering rules and Message treatment for Filtered message are included in the parameter. The filtering rules include Sender address, Message size, Message content type, Message content format and Message subject, and the filtering rules can be applied in different combination. The Message treatment for Filtered message include Block the delivery of the message, Store the message content and Redirect the message to another address. If the message treatment is "Store the message content" the Store URL should be specified, if the message treatment is "Redirect the message" the Redirect URL should be specified.		

The MRFP responds as in Table 5.17.2.48.2.

**Table 5.17.2.48.2: Configure Filtering Rules Acknowledge MRFP to MRFC**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1 Stream Number	

**5.17.2.49 ECN Failure Indication**

The MRFP sends a NOTIFY request command as in Table 5.17.2.49.1.

**Table 5.17.2.49.1: ECN Failure Indication**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1  Event_ID (Event ID = x, "ECN Failure (ECN Failure Type)")	

The MRFC responds as in Table 5.17.2.49.2

**Table 5.17.2.49.2: ECN Failure Indication Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = C1 Termination ID = T1	

## 5.17.3 Non-Call Related Procedures

### 5.17.3.1 General

This section describes the various non-call related procedures which are listed in table 5.17.3.1.1

**Table 5.17.3.1.1: MRFP Non-Call Related Procedures**

Transaction defined in 3GPP TS 23.333 [25]	Support	Comment
MRFP Out of service	Mandatory	5.17.3.2
MRFP Communication Up	Mandatory	5.17.3.3
MRFP Register	Mandatory	5.17.3.4
MRFP Re-register	Mandatory	5.17.3.5
MRFC Ordered Re-register	Mandatory	5.17.3.6
MRFC Restoration	Optional	5.17.3.7
MRFC Out of Service	Optional	5.17.3.8
Audit Value	Mandatory	5.17.3.9
Audit Capability	Optional	5.17.3.10
Capability Update	Optional	5.17.3.11
MRFP Resource Congestion Handling – Activate	Mandatory	5.17.3.12
MRFP Resource Congestion Handling – Indication	Mandatory	5.17.3.13
Command Rejected	Mandatory	5.17.3.14  The "Command Rejected" procedure may be used in response both to call-related and non-call-related ITU-T Recommendation H.248 Commands
MRFP Restoration	Mandatory	5.17.3.15

### 5.17.3.2 MRFP Out Of Service

The MRFP sends a SERVICE CHANGE request command as in Table 5.17.3.2.1.

**Table 5.17.3.2.1: MRFP Out Of Service Request**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID= - Termination ID = ROOT SC Method = FORCED or GRACEFUL SC Reason = 905 Termination Taken OOS or 908, MG Impending Failure	

The MRFC responds as in table 5.17.3.2.2.

**Table 5.17.3.2.2: MRFP Out Of Service Request Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT	

### 5.17.3.3 MRFP Communication Up

The MRFP sends a SERVICE CHANGE request command as in Table 5.17.3.3.1 to the MRFC address to which the control link association was previously established.

**Table 5.17.3.3.1: MRFP Communication Up**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT SC Method = DISCONNECTED SC Reason = 900 , Service Restored	

The MRFC may respond as in table 5.17.3.3.2. If a response is received, the control link association is re-established and the inactivity timer would be restarted.

**Table 5.17.3.3.2: MRFP Communication Up Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT	

### 5.17.3.4 MRFP Register

The MRFP sends a SERVICE CHANGE request command as in Table 5.17.3.4.1.

**Table 5.17.3.4.1: MRFP Register**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT SC Method = RESTART SC Reason = 901 Cold Boot or 902, Warm Boot H248 Profile Identity H248 Protocol Version	

The MRFC responds as in table 5.17.3.4.2.

**Table 5.17.3.4.2: MRFP Register Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT H248 Protocol Version If applicable:- H248 Profile Identity	

### 5.17.3.5 MRFC Restoration

When the MRFC has recovered, the MRFC sends a SERVICE CHANGE as in Table 5.17.3.5.1,

The MRFP may respond as in Table 5.17.3.5.2.

The MRFC sends a SERVICE CHANGE as in Table 5.17.3.5.1

**Table 5.17.3.5.1: MRFC Restoration**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID= - Termination ID = ROOT SC Method = RESTART SC Reason = 901, Cold Boot OR 902, Warm Boot	

The MRFP responds as in table 5.17.3.5.2.

**Table 5.17.3.5.2: MRFC Restoration Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT	

### 5.17.3.6 MRFP Re-Register

The MRFP sends a SERVICE CHANGE request command as in Table 5.17.3.6.1.

**Table 5.17.3.6.1: Re-Registration**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID= - Termination ID = ROOT SC Method = Handoff SC Reason = 903, MGC Directed Change H248 Profile Identity H248 Protocol Version	

The MRFC responds as in table 5.17.3.6.2.

**Table 5.17.3.6.2: Re-Registration Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT H248 Protocol Version If applicable:- H248 Profile Identity	

### 5.17.3.7 MRFC Ordered Re-register

The MRFC sends a SERVICE CHANGE request command as in Table 5.17.3.7.1.

**Table 5.17.3.7.1: MRFC Ordered Re-Register**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID= - Termination ID = ROOT SC Method = HANDOFF SC Reason = 903, MGC Directed Change	

The MRFP responds as in table 5.17.3.7.2.

**Table 5.17.3.7.2: MRFC Ordered Re-Register Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT	

The MRFP then performs an MRFP Re-Register procedure according to Clause 5.17.3.6.

### 5.17.3.8 Audit Value

The MRFC sends an AUDIT VALUE request command as in Table 5.17.3.8.1.

**Table 5.17.3.8.1: Audit Value**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID= -/ALL Termination ID = ROOT/ALL/T1 Audit Packages (NOTE1) Audit Descriptor = Empty/IndAuditParameter:= IndAudMediaDescriptor:= streams { IndAudStreamParms:= { Stream Number, IndAudStreamParms:= IndAudLocalControlDescriptor:= IndAudPropertyParm:= mgcinfo } }	
NOTE 1: Packages is for Null/Root Combina.		

The MRFP responds as in table 5.17.3.8.2.

**Table 5.17.3.8.2: Audit Value Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = -/Context ID Termination ID = ROOT/T1 Packages List mgcinfo	

Upon reception of the command in the MRFP:

- The Service State returns the current Service State



- When Packages are requested, the Package Names and Versions are returned

The following table illustrates the allowed combinations that can be obtained with the AuditValue Command:

**Table 15.17.3.8.3: Combinations of AuditValue Command**

ContextID	TerminationID	Information Obtained
Specific	Wildcard	Audit of matching Terminations in a Context
Specific	Specific	Audit of a single Termination in a Context
Null	Root	Audit of Media Gateway state and events
All	Specific	(Non-null) ContextID in which the Termination currently exists

### 5.17.3.9 Audit Capabilities

The MRFC sends an AUDIT CAPABILITY request command as in Table 5.17.3.9.1.

**Table 5.17.3.9.1: Audit Capability Request**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID= - Termination ID = ROOT Audited Capabilities	

The MRFP responds as in table 5.17.3.9.2.

**Table 5.17.3.8.2.2: Audit Capability Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT Capabilities	

### 5.17.3.10 Capability Update

The MRFP sends a SERVICE CHANGE request command as in Table 5.17.3.10.1.

**Table 5.17.3.10.1: Capability Update**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID= - Termination ID = ROOT SC Method = RESTART SC Reason = 917, Capability Change H248 Profile Identity H248 Protocol Version	

The MRFC responds as in table 5.17.3.10.2.

**Table 5.17.3.10.2 Capability Update Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT	

### 5.17.3.11 MRFC Out of Service

The MRFC sends a SERVICE CHANGE request command as in Table 5.17.3.11.1.

**Table 5.17.3.11.1: MRFC Out Of Service**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT SC Method = FORCED or GRACEFUL SC Reason = 905, Termination Taken OOS	

The MRFP responds as in table 5.17.3.11.2.

**Table 5.17.3.11.2: MRFC Out Of Service Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT	

### 5.17.3.12 MRFP Resource Congestion Handling – Activate

The MRFC sends a MODIFY request command as in Table 5.17.3.12.1.

**Table 5.17.3.12.1: MRFP Resource Congestion Handling – Activate**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT If required : Set Inactivity Timer Request Overload Notification	

The MRFP responds as in table 5.17.3.12.2.

**Table 5.17.3.12.2: MRFP Resource Congestion Handling – Activate Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT	

### 5.17.3.13 MRFP Resource Congestion Handling – Indication

The MRFP sends a NOTIFY request command as in Table 5.17.3.13.1.

**Table 5.17.3.13.1: MRFP Resource Congestion Handling – Indication**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID= - Termination ID = ROOT Overload Notification	

The MRFC responds as in table 5.17.3.13.2.

**Table 5.17.3.13.2: MRFP Resource Congestion Handling – Indication Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT	

### 5.17.3.14 Command Rejected

When the procedure "Command Reject" is required the following procedure is initiated:

The MGW/MGC sends .resp to any command.req with the following information.

**Table 5.17.3.14.1: NYcommand.resp (command reject ) MRFP/MRFC to MRFC/MRFP**

Address Information	Control information	Bearer information
	Transaction ID = z Context ID = c1 or no context  Reason=Error	

### 5.17.3.15 MRFP Restoration

When the MRFP has recovered, the MRFP sends a SERVICE CHANGE as in Table 5.17.3.15.1,

The MRFC may respond as in Table 5.17.3.15.2.

The MRFP sends a SERVICE CHANGE as in Table 5.17.3.15.1

**Table 5.17.3.15.1: MRFC Restoration**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID= - Termination ID = ROOT SC Method = RESTART SC Reason = 900, Service Restored	

The MRFC responds as in table 5.17.3.15.2.

**Table 5.17.3.15.2: MRFC Restoration Ack**

Address Information	Control information	Bearer information
	Transaction ID = x Context ID = - Termination ID = ROOT	

# Annex A (normative): The W3C SSML Profile for TTS function

## A.1 Introduction

This annex contains a profile to the W3C Speech Synthesis Markup Language (SSML) specification [28]. The SSML specification is a W3C Recommendation, and is designed to provide a rich, XML-based markup language for assisting the generation of synthetic speech in Web and other applications. The essential role of the markup language is to provide authors of synthesizable content a standard way to control aspects of speech such as pronunciation, volume, pitch, rate, etc. across different synthesis-capable platforms.

This annex provides a profile for SSML according to the stage 2 specification of the Mp interface. This profile is referenced by the advanced audio server base package for TTS enhancement.

## A.2 TTS Profile

Table A.2.1: The profile of SSML

Element or attribute	Description	Support
<b>speak</b>	This is the root element that can contain text to be rendered and the following elements: <b>audio, break, emphasis, lexicon, mark, meta, metadata, p, phoneme, say-as, sub, s, voice</b>	Mandatory.
<b>xml:lang</b>	This attribute defines the language that applied to the element, subelements and its attributes. The <b>phoneme, emphasis, break, p,</b> and <b>s</b> elements are language specific dependent	Mandatory
<b>xml:base</b>	This attribute defines the base URI for resolving relative URI that may be used for the following elements: - The optional <b>src</b> attribute of <b>audio</b> element - The <b>uri</b> attribute of <b>lexicon</b> element	Optional
<b>lexicon</b>	An SSML document may reference one or more external pronunciation documents, the <b>lexicon</b> element is used to identified the URI of this external document. A lexicon document contains pronunciation for tokens that can appear in a text to be spoken. A <b>lexicon</b> element shall contain an uri.	Mandatory
<b>meta and metadata</b>	The <b>metadata</b> and <b>meta</b> elements are containers in which information about the document can be placed	Optional

<b>p and s</b>	<p>A <b>p</b> element represents a paragraph and <b>s</b> element represents a sentence.</p> <p>The use of <b>p</b> and <b>s</b> elements is optional. Where text occurs without an enclosing <b>p</b> or <b>s</b> element the <a href="#">synthesis processor</a> should attempt to determine the structure using language-specific knowledge of the format of plain text.</p> <p>The <b>p</b> element can only contain text to be rendered and the following elements: <a href="#">audio</a>, <a href="#">break</a>, <a href="#">emphasis</a>, <a href="#">mark</a>, <a href="#">phoneme</a>, <a href="#">prosody</a>, <a href="#">say-as</a>, <a href="#">sub</a>, <a href="#">s</a>, <a href="#">voice</a>.</p> <p>The <b>s</b> element can only contain text to be rendered and the following elements: <a href="#">audio</a>, <a href="#">break</a>, <a href="#">emphasis</a>, <a href="#">mark</a>, <a href="#">phoneme</a>, <a href="#">prosody</a>, <a href="#">say-as</a>, <a href="#">sub</a>, <a href="#">voice</a>.</p>	Optional
<b>say-as</b>	<p>The <a href="#">say-as</a> element allows the author to indicate information on the type of text construct contained within the element and to help specify the level of detail for rendering the contained text. For example for English when "\$200" appears in a document it may be spoken as "two hundred dollars", similarly, "1/2" may be spoken as "half", "one of two".</p> <p>Defining a comprehensive set of text format types is difficult because of the variety of languages that have to be considered and because of the innate flexibility of written languages. SSML only specifies the <a href="#">say-as</a> element, its attributes, and their purpose. It does not enumerate the possible values for the attributes. The Working Group expects to produce a separate document that will define standard values and associated normative behavior for these values.</p> <p>The <b>say-as</b> element has three attributes: interpret-as, format and detail</p> <p>The <b>say-as</b> element can only contains text to be rendered</p>	Optional
<b>phoneme</b>	<p>The <a href="#">phoneme</a> element provides a phonemic/phonetic pronunciation for the contained text.</p> <p>The <b>ph</b> attribute is a required attribute that specifies the phoneme/phone string.</p> <p>The <b>alphabet</b> attribute is an optional attribute that specifies the phonemic/phonetic alphabet. An alphabet in this context refers to a collection of symbols to represent the sounds of one or more human languages. The only valid values for this attribute are "<b>ipa</b>" (see the next paragraph) and vendor-defined strings of the form "<b>x-organization</b>" or "<b>x-organization-alphabet</b>".</p> <p>Example:</p> <pre>&lt;phoneme                                alphabet="ipa" ph="t&amp;#x259;mei&amp;#x325;&amp;#x27E;ou&amp;#x325;"&gt;      tomato &lt;/phoneme&gt;</pre>	Optional

<b>sub</b>	<p>The <a href="#">sub</a> element is employed to indicate that the text in the alias attribute value replaces the contained text for pronunciation. The required alias attribute specifies the string to be spoken instead of the enclosed string. The <a href="#">sub</a> element can only contain text (no elements).</p> <p>Example:  <code>&lt;sub alias="World Wide Web Consortium"&gt;W3C&lt;/sub&gt;</code></p>	Optional
<b>Voice</b>	<p>The <b>voice</b> element indicates the characteristics of the voice rendering.</p> <p>The <b>voice</b> element is commonly used to change the language</p> <p>The following attributes are used:</p> <ul style="list-style-type: none"> <li>- gender: male, female or neutral</li> <li>- age</li> <li>- variant: indicates a preferred variant of the other voice characteristics</li> <li>- name indicates the processor-specific voice name</li> </ul>	Optional
<b>emphasis</b>	<p>The <a href="#">emphasis</a> element requests that the contained text be spoken with emphasis (also referred to as prominence or stress).</p> <p>the optional level attribute indicates the strength of emphasis to be applied. Defined values are "strong", "moderate", "none" and "reduced".</p> <p>The <a href="#">emphasis</a> element can only contain text to be rendered and the following elements: <a href="#">audio</a>, <a href="#">break</a>, <a href="#">emphasis</a>, <a href="#">mark</a>, <a href="#">phoneme</a>, <a href="#">prosody</a>, <a href="#">say-as</a>, <a href="#">sub</a>, <a href="#">voice</a>.</p>	Optional
<b>break</b>	<p>The <a href="#">break</a> element is an empty element that controls the pausing or other prosodic boundaries between words.</p> <p>The <b>break</b> element is most often used to override the typical automatic behaviour of a synthesis processor.</p> <p>The following attributes are used on the break element:</p> <ul style="list-style-type: none"> <li>- <b>strength: "none", "x-weak", "weak" "medium", "strong", or "x-strong"</b>. It indicates the strength of the prosodic break in the speech output. For example, the breaks between paragraphs are typically much stronger than the breaks between words within a sentence.</li> <li>- <b>Time:</b> the time attribute is an option attribute indicating the duration of a pause to be inserted in the output in seconds or milliseconds e.g. "250ms", "3s"</li> </ul>	Optional

<b>prosody</b>	<p>The <b>prosody</b> element permits control of the pitch, speaking rate and volume of the speech output, the optional attributes are:</p> <ul style="list-style-type: none"> <li>- <b>pith</b>: this attribute indicates the baseline pitch. legal value are: a number followed by "Hz", a relative change (+10Hz or +5st, a semitone is half of a tone on the standard diatonic scale), or a "x-low", "low", "medium", "high", "x-high", or "default". The exact meaning of baseline pitch may vary across synthesis processors</li> <li>- <b>pitch contour</b>: the pitch contour is a set of the form (time position,target), the first value is a percentage of the period of the contained text (a <a href="#">number</a> followed by "%") and the second value is the value of the pitch attribute. e.g. (20%,"+10Hz) (40%, "+20Hz) means increase the pitch of 10Hz at 20% of the period of the contained text and 20Hz at 40% of the text duration.</li> <li>- <b>Range</b>: the pitch range although the exact meaning may vary across synthesis processor. The same value as for pitch are legal value from SSML.</li> <li>- <b>Rate</b>: change the speaking rate. Legal values are: a relative change or "x-slow", "slow", "medium", "fast", "x-fast" or "default".</li> <li>- <b>Duration</b>: a value in seconds or milliseconds for the desired time to take to read the element contents.</li> <li>- <b>Volume</b>: the volume for the contained text in the range 0.0 to 100.0. Legal values are: a number, a relative change or "silent", "x-soft", "soft", "medium", "loud", "x-loud", or "default".</li> </ul>	Optional
<b>audio</b>	The <b>audio</b> element supports the insertion of recorded audio files.	Optional
<b>Mark</b>	The <b>mark</b> element is an empty element that places a marker into the text/tag sequence that the environment will be informed to detect the corresponding position within the rendered output and may report an event when encountered. This element has a <b>name</b> attribute.	Optional
<b>Desc</b>	The <b>desc</b> element can only occur within the content of the audio element. It describes the textual content of the audio source that may be used when text-only output is being produced by the synthesis processor.	Optional

---

## Annex B (normative): The W3C SRGS Profile for ASR function

### B.1 Introduction

This annex contains a profile to the W3C Speech Recognition Grammar Specification (SRGS) [29]. The SRGS are intended for use by speech recognizers and other grammar processors so that developers can specify the words and patterns of words to be listened for by a speech recognizer.

This annex provides a profile for SRGS according to the stage 2 specification of the Mp interface. This profile is referenced by the ASR Package.

---

### B.2 SRGS Profile

Table B.2.1: The profile of SRGS

Declaration Item	Description	Support or not
Language	The <b>language</b> declaration of a grammar provides the <a href="#">language identifier</a> that indicates the primary language contained by the document and optionally indicates a country or other variation. Additionally, any legal rule expansion may be <a href="#">labeled with a language identifier</a> . The language declaration is required for all speech recognition grammars.	Mandatory
Mode	The mode of a grammar indicates the type of input that the user agent should be detecting. The default mode is " <b>voice</b> " for speech recognition grammars. An alternative input mode is " <b>dtmf</b> " input.  For the Mp interface, only voice mode is supported.	Mandatory
Root rule	Both the XML Form and ABNF Form permit the grammar header to optionally declare a single rule to be the root rule of the grammar. The rule declared as the root rule must be defined within the scope of the grammar. The rule declared as the root rule may be <a href="#">scoped</a> as either <b>public</b> or <b>private</b> .	Mandatory



Tag format	<p>The <b>tag-format</b> declaration is an optional declaration of a tag-format identifier that indicates the content type of all <a href="#">rule tags</a> and <a href="#">header tags</a> contained within a grammar. The tag-format identifier is a <a href="#">URI</a>. It is recommended that the tag format identifier indicate both the content type and a version. Tags typically contain content for a <a href="#">semantic interpretation</a> processor and in such cases the identifier, if present, should indicate the semantic processor to use. Tag-format identifier values beginning with the string "semantics/x.y" (where x and y are digits) are reserved for use by the W3C Semantic Interpretation for Speech Recognition specification <a href="#">[SEM]</a> or future versions of the specification.</p>	Mandatory
Base URI	<p>Relative URIs are resolved according to a base URI, which may come from a variety of sources. The base URI declaration allows authors to specify a document's base URI explicitly. The path information specified by the base URI declaration only affects URIs in the document where the element appears. The base URI declaration is permitted but optional in both the XML Form and the ABNF Form.</p>	Optional
Pronunciation lexicon	<p>A grammar may optionally reference one or more external pronunciation lexicon documents. A lexicon document is identified by a <a href="#">URI</a> with an optional <a href="#">media type</a>. The pronunciation information contained within a lexicon document is used only for tokens defined within the enclosing grammar. The W3C Voice Browser Working Group is developing the Pronunciation Lexicon Markup Language <a href="#">[LEX]</a>. The specification will address the matching process between tokens and lexicon entries and the mechanism by which a speech recognizer handles multiple pronunciations from internal and grammar-specified lexicons. Pronunciation handling with proprietary lexicon formats will necessarily be specific to the speech recognizer. Pronunciation lexicons are necessarily language-specific. Pronunciation lookup in a lexicon and pronunciation inference for any token may use an algorithm that is language-specific. (See <a href="#">Section 2.1</a> for additional information on token handling and pronunciations.)</p>	Mandatory
Metadata	<p>Grammar documents let authors specify metadata — information about a document rather than document content — in a number of ways. A <a href="#">meta declaration</a> in either the ABNF Form or XML Form may be used to express metadata information in both XML</p>	Not Applicable

	<p>Form and ABNF Form grammars or to reference metadata available in an external resource. The XML Form also supports a <a href="#">metadata element</a> that provides a more general and powerful treatment of metadata information than <b>meta</b>. Since <b>metadata</b> requires an XML metadata schema which cannot be expressed in ABNF, there is no equivalent of <b>metadata</b> in the ABNF Form of grammars.</p>	
Tag	<p>A grammar may optionally specify one or more <b>tag</b> declarations in the header. The content of a <b>tag</b> in the header, just like a <a href="#">tag in rule expansions</a>, is an arbitrary string which may be used for <a href="#">semantic interpretation</a>.</p>	Mandatory

## Annex C (informative): Change history

Change history							
Date	TSG #	TSG Doc.	CR	Rev	Subject/Comment	Old	New
06-2007	CT#36	CP-070336			V7.0.0 approved in CT#36	1.0.0	7.0.0
09-2007	CT#37	CP-070539	0001	2	Alignment of stage 3 to proposed stage 2 changes for Audio Record and Multimedia Record	7.0.0	7.1.0
09-2007	CT#37	CP-070539	0002	1	Completion of formats and codes	7.0.0	7.1.0
09-2007	CT#37	CP-070539	0003	1	Corrections to Stage 3 Profile	7.0.0	7.1.0
09-2007	CT#37	CP-070539	0004	1	Editorial corrections	7.0.0	7.1.0
12-2007	CT#38	CP-070745	0005	1	Properties returned in commands	7.1.0	7.2.0
12-2007	CT#38	CP-070745	0007		Add the tone generator package	7.1.0	7.2.0
12-2007	CT#38	CP-070745	0008	1	Align parameters for configure remote IMS resources	7.1.0	7.2.0
12-2007	CT#38	CP-070745	0009	1	Amend iterations parameter in start TTS procedure	7.1.0	7.2.0
12-2007	CT#38	CP-070745	0010	1	Amendment of the ASR procedure	7.1.0	7.2.0
12-2007	CT#38	CP-070745	0011	1	Clean-up of hanging contexts and terminations	7.1.0	7.2.0
12-2007	CT#38	CP-070745	0012	1	Correct the usage information of the recording package	7.1.0	7.2.0
12-2007	CT#38	CP-070745	0014	1	Implementation of multiple signals played simultaneously	7.1.0	7.2.0
12-2007	CT#38	CP-070745	0015	1	Align the profile with stage 2	7.1.0	7.2.0
03-2008	CT#39	CP-080017	0016		Alignment of IMS resources procedures" title	7.2.0	7.3.0
03-2008	CT#39	CP-080017	0018	1	Amend the notify completion table	7.2.0	7.3.0
03-2008	CT#39	CP-080021	0017	1	Mandatory use termination heartbeat	7.3.0	8.0.0
06-2008	CT#40	CP-080263	0019		Usage of H.248.45 MGC Information Package	8.0.0	8.1.0
06-2008	CT#40	CP-080263	0022	1	Alignment of 3GPP Mp Codec Requirements	8.0.0	8.1.0
06-2008	CT#40	CP-080263	0023	2	Introduction of stage 3 procedure for Messaging Conference	8.0.0	8.1.0
06-2008	CT#40	CP-080273	0021	1	Alignment of SDP usage	8.0.0	8.1.0
09-2008	CT#41	CP-080465	0025	1	Alignment of Supported Transports	8.1.0	8.2.0
09-2008	CT#41	CP-080465	0026	2	Floor Control Procedures, Stage 3	8.1.0	8.2.0
09-2008	CT#41	CP-080465	0027		Message Conference Procedure for Stage 3	8.1.0	8.2.0
12-2008	CT#42	CP-080694	0028	3	Update stage 3 profile for Message conference	8.2.0	8.3.0
			0029	1	Update stage 3 profile for Floor control		
			0030	1	Alignment of Audit Value Procedure		
			0032		Remove Editor's Note on MSRP Session Identity		
			0033		Remove Editor's Note on Draft Version Indication		
03-2009	CT#43	CP-090040	0034	2	Alignment of Audit Value Procedure	8.3.0	8.4.0
			0035	1	Modification of Reference for eMp		
03-2009					CR 0034 was removed since it was Rel-7 only	8.4.0	8.4.1
2009-12	-	-	-	-	Update to Rel-9 version (MCC)	8.4.1	9.0.0
2011-03	CT#51	CP-110275	0040	10	ECN Support in Mp Interface	9.0.0	10.0.0
		CP-110058	0041	1	Handling of rtcp-fb SDP attribute and SDP attribute for RTCP APP feedback messages		
2011-06	CT#52	CP-110368	0042	1	ECN Failure improvements	10.0.0	10.1.0

		CP-110368	0044	1	Alignment of 3GPP profiles with SG16 ECN package definition		
2011-12	Ct#54	CP-110776	0048		Missing ASN.1 encoding of H.248.69 packages	10.1.0	10.2.0
		CP-110798	0045		Explicit Congestion Notification		
		CP-110796	0049		Missing ASN.1 encoding of mandatory and optional package tables		
		CP-110789	0050	1	ECN Improvements		

---

## History

<b>Document history</b>		
V10.0.0	May 2011	Publication
V10.1.0	June 2011	Publication
V10.2.0	January 2012	Publication