ETSI TS 138 306 V15.18.0 (2022-10)



5G; NR; User Equipment (UE) radio access capabilities (3GPP TS 38.306 version 15.18.0 Release 15)



Reference RTS/TSGR-0238306vfi0

Keywords

5G

ETSI

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from: <u>http://www.etsi.org/standards-search</u>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at <u>https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx</u>

If you find errors in the present document, please send your comment to one of the following services: <u>https://portal.etsi.org/People/CommiteeSupportStaff.aspx</u>

If you find a security vulnerability in the present document, please report it through our Coordinated Vulnerability Disclosure Program: https://www.etsi.org/standards/coordinated-vulnerability-disclosure

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI. The copyright and the foregoing restriction extend to reproduction in all media.

> © ETSI 2022. All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (https://ipr.etsi.org/).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECTTM, **PLUGTESTSTM**, **UMTSTM** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPPTM** and **LTETM** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2MTM** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM**[®] and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under http://webapp.etsi.org/key/queryform.asp.

Modal verbs terminology

In the present document "shall", "shall not", "should", "should not", "may", "need not", "will", "will not", "can" and "cannot" are to be interpreted as described in clause 3.2 of the <u>ETSI Drafting Rules</u> (Verbal forms for the expression of provisions).

"must" and "must not" are NOT allowed in ETSI deliverables except when used in direct citation.

Contents

Intelle	ectual Property Rights	2
Legal	Notice	2
Moda	l verbs terminology	2
Forew	/ord	5
1	Scope	6
2	References	6
3	Definitions, symbols and abbreviations	7
3.1	Definitions	7
3.2	Symbols	
3.3	Abbreviations	7
4	UE radio access capability parameters	8
4.1	Supported max data rate	8
4.1.1	General	
4.1.2	Supported max data rate	
4.1.3	Void	
4.1.4	Total layer 2 buffer size	9
4.2	UE Capability Parameters	10
4.2.1	Introduction	10
4.2.2	General parameters	12
4.2.3	SDAP Parameters	12
4.2.4	PDCP Parameters	13
4.2.5	RLC parameters	13
4.2.6	MAC parameters	14
4.2.7	Physical layer parameters	
4.2.7.1		
4.2.7.2		
4.2.7.3	•	
4.2.7.4		
4.2.7.5		
4.2.7.6	1	
4.2.7.7		
4.2.7.8		
4.2.7.9		
4.2.7.1		
4.2.7.1		
4.2.7.1	1	
4.2.7.1		
4.2.8	Void	
4.2.9	Vola MeasAndMobParameters	
4.2.10		
4.2.10	1 I	
4.2.10		
4.2.10	Void	
4.2.11		
4.2.12		
4.2.15		
5	Optional features without UE radio access capability parameters	
5.1	PWS features	64
5.2	UE receiver features	
5.3	RRC connection	64
6	Conditionally mandatory features without UE radio access capability parameters	
7	Void	65

8	UE Capability Constrai	nts	65
Anne	x A (normative):	Differentiation of capabilities	66
A.1:	TDD/FDD differentiati	on of capabilities in TDD-FDD CA	66
A.2:	FR1/FR2 differentiation	n of capabilities in FR1-FR2 CA	67
A.3:	Void		68
A.4:	Void		68
A.5:	General differentiation	of capabilities in Cross-Carrier operation	68
Anne	x B (informative):	UE capability indication for UE capabilities with both FDD/TDD and FR1/FR2 differentiations	70
Anne	x C (informative):	Change history	72
Histor	ry		76

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

1 Scope

The present document defines the NR UE Radio Access Capability Parameters.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.
- [1] 3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
- [2] 3GPP TS 38.101-1: "NR; User Equipment (UE) radio transmission and reception Part 1: Range 1 Standalone".
- [3] 3GPP TS 38.101-2: "NR; User Equipment (UE) radio transmission and reception Part 2: Range 2 Standalone".
- [4] 3GPP TS 38.101-3: "NR; User Equipment (UE) radio transmission and reception Part 3: Range 1 and Range 2 Interworking operation with other radios".
- [5] 3GPP TS 38.133: "NR; Requirements for support of radio resource management".
- [6] 3GPP TS 38.211: "NR; Physical channels and modulation".
- [7] 3GPP TS 37.340: "Evolved Universal Terrestrial Radio Access (E-UTRA) and NR Multiconnectivity".
- [8] 3GPP TS 38.321: "NR; Medium Access Control (MAC) protocol specification".
- [9] 3GPP TS 38.331: "NR; Radio Resource Control (RRC) protocol specification".
- [10] 3GPP TS 38.212: "NR; Multiplexing and channel coding".
- [11] 3GPP TS 38.213: "NR; Physical layer procedures for control".
- [12] 3GPP TS 38.214: "NR; Physical layer procedures for data".
- [13] 3GPP TS 38.215: "NR; Physical layer measurements".
- [14] 3GPP TS 36.101: "Evolved Universal Terrestrial Radio Access (E-UTRA) radio transmission and reception".
- [15] 3GPP TS 36.306: "Evolved Universal Terrestrial Radio Access (E-UTRA) User Equipment (UE) radio access capabilities".
- [16] 3GPP TS 38.323: "NR; Packet Data Convergence Protocol (PDCP) specification".
- [17] 3GPP TS 36.331: "Evolved Universal Terrestrial Radio Access (E-UTRA) Radio Resource Control (RRC); Protocol Specification".
- [18] 3GPP TS 38.101-4: "NR; User Equipment (UE) radio transmission and reception Part 4: Performance requirements".
- [19] 3GPP TS 36.213: "Evolved Universal Terrestrial Radio Access (E-UTRA); Physical layer procedures".

[20]

3GPP TS 38.304: "User Equipment (UE) procedures in Idle mode and RRC Inactive state".

3 Definitions, symbols and abbreviations

3.1 Definitions

For the purposes of the present document, the terms and definitions given in TR 21.905 [1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in TR 21.905 [1].

Fallback band combination: A band combination that would result from another band combination (parent band combination) by releasing at least one SCell or uplink configuration of SCell, or SCG, or SUL. An intra-band non-contiguous band combination is not considered to be a fallback band combination of an intra-band contiguous band combination. A fallback band combination supports the same channel bandwidth(s) for each carrier as its parent band combination(s).

Fallback per band feature set: A feature set per band that has same or lower capabilities than the reported capabilities from the reported feature set per band for a given band.

Fallback per CC feature set: A feature set per CC that has same or lower capabilities than the capabilities of UE (e.g. supported MIMO layers, BW, modulation order) while keeping the numerology the same from the reported feature set per CC for a given carrier per band.

3.2 Symbols

For the purposes of the present document, the following symbols apply:

MaxDLDataRate:	Maximum DL data rate
MaxDLDataRate_MN:	Maximum DL data rate in the MN
MaxDLDataRate_SN:	Maximum DL data rate in the SN
MaxULDataRate:	Maximum UL data rate

3.3 Abbreviations

For the purposes of the present document, the abbreviations given in TR 21.905 [1] and the following apply. An abbreviation defined in the present document takes precedence over the definition of the same abbreviation, if any, in TR 21.905 [1].

DL Downlink	r
ES Estatura Sat	r
FS Feature Set	r
FSPC Feature Set Per Component-carrie	
MAC Medium Access Control	
MCG Master Cell Group	
MN Master Node	
MR-DC Multi-RAT Dual Connectivity	
PDCP Packet Data Convergence Protoco	1
RLC Radio Link Control	
RTT Round Trip Time	
SCG Secondary Cell Group	
SDAP Service Data Adaptation Protocol	
SN Secondary Node	
UL Uplink	

4 UE radio access capability parameters

4.1 Supported max data rate

4.1.1 General

The DL and UL max data rate supported by the UE is calculated by band or band combinations supported by the UE. A UE supporting NR (NR SA, MR-DC) shall support the calculated DL and UL max data rate defined in 4.1.2.

4.1.2 Supported max data rate

For NR, the approximate data rate for a given number of aggregated carriers in a band or band combination is computed as follows.

data rate (in Mbps) =
$$10^{-6} \cdot \sum_{j=1}^{J} \left(v_{Layers}^{(j)} \cdot Q_m^{(j)} \cdot f^{(j)} \cdot R_{max} \cdot \frac{N_{PRB}^{BW(j),\mu} \cdot 12}{T_s^{\mu}} \cdot \left(1 - OH^{(j)}\right) \right)$$

wherein

J is the number of aggregated component carriers in a band or band combination $R_{\text{max}}=948/1024$

For the j-th CC,

 $v_{layers}^{(j)}$ is the maximum number of supported layers given by higher layer parameter maxNumberMIMO-

LayersPDSCH for downlink and maximum of higher layer parameters *maxNumberMIMO-LayersCB-PUSCH* and *maxNumberMIMO-LayersNonCB-PUSCH* for uplink.

 $Q_m^{(j)}$ is the maximum supported modulation order given by higher layer parameter *supportedModulationOrderDL* for downlink and higher layer parameter *supportedModulationOrderUL* for uplink.

 $f^{(j)}$ is the scaling factor given by higher layer parameter *scalingFactor* and can take the values 1, 0.8, 0.75, and 0.4.

 μ is the numerology (as defined in TS 38.211 [6])

 T_s^{μ} is the average OFDM symbol duration in a subframe for numerology μ , i.e. $T_s^{\mu} = \frac{10^{-3}}{14 \cdot 2^{\mu}}$. Note that normal cyclic prefix is assumed.

 $N_{PRB}^{BW(j),\mu}$ is the maximum RB allocation in bandwidth $BW^{(j)}$ with numerology μ , as defined in 5.3 TS 38.101-1 [2] and 5.3 TS 38.101-2 [3], where $BW^{(j)}$ is the UE supported maximum bandwidth in the given band or band combination.

 $OH^{(j)}$ is the overhead and takes the following values

0.14, for frequency range FR1 for DL 0.18, for frequency range FR2 for DL 0.08, for frequency range FR1 for UL 0.10, for frequency range FR2 for UL

NOTE: Only one of the UL or SUL carriers (the one with the higher data rate) is counted for a cell operating SUL.

The approximate maximum data rate can be computed as the maximum of the approximate data rates computed using the above formula for each of the supported band or band combinations.

For single carrier NR SA operation, the UE shall support a data rate for the carrier that is no smaller than the data rate computed using the above formula, with $J = 1 \ CC$ and component $v_{Layers}^{(j)} \cdot Q_m^{(j)} \cdot f^{(j)}$ is no smaller than 4.

NOTE: As an example, the value 4 in the component above can correspond to $v_{Layers}^{(j)} = 1$, $Q_m^{(j)} = 4$ and $f^{(j)} = 1$.

For EUTRA in case of MR-DC, the approximate data rate for a given number of aggregated carriers in a band or band combination is computed as follows.

Data rate (in Mbps) =
$$10^{-3} \cdot \sum_{j=1}^{J} TBS_j$$

wherein

J is the number of aggregated EUTRA component carriers in MR-DC band combination

 TBS_j is the total maximum number of DL-SCH transport block bits received or the total maximum number of UL-SCH transport block bits transmitted, within a 1ms TTI for j-th CC, as derived from TS36.213 [19] based on the UE supported maximum MIMO layers for the j-th CC, and based on the maximum modulation order for the j-th CC and number of PRBs based on the bandwidth of the j-th CC according to indicated UE capabilities.

The approximate maximum data rate can be computed as the maximum of the approximate data rates computed using the above formula for each of the supported band or band combinations.

For MR-DC, the approximate maximum data rate is computed as the sum of the approximate maximum data rates from NR and EUTRA.

4.1.3 Void

4.1.4 Total layer 2 buffer size

The total layer 2 buffer size is defined as the sum of the number of bytes that the UE is capable of storing in the RLC transmission windows and RLC reception and reassembly windows and also in PDCP reordering windows for all radio bearers.

The required total layer 2 buffer size in MR-DC and NR-DC is the maximum value of the calculated values based on the following equations:

- MaxULDataRate_MN * RLCRTT_MN + MaxULDataRate_SN * RLCRTT_SN + MaxDLDataRate_SN * RLCRTT_SN + MaxDLDataRate_MN * (RLCRTT_SN + X2/Xn delay + Queuing in SN)
- MaxULDataRate_MN * RLCRTT_MN + MaxULDataRate_SN * RLCRTT_SN + MaxDLDataRate_MN * RLCRTT_MN + MaxDLDataRate_SN * (RLCRTT_MN + X2/Xn delay + Queuing in MN)

Otherwise it is calculated by MaxDLDataRate * RLC RTT + MaxULDataRate * RLC RTT.

NOTE: Additional L2 buffer required for preprocessing of data is not taken into account in above formula.

The required total layer 2 buffer size is determined as the maximum total layer 2 buffer size of all the calculated ones for each band combination and the applicable Feature Set combination in the supported MR-DC or NR band combinations. The RLC RTT for NR cell group corresponds to the smallest SCS numerology supported in the band combination and the applicable Feature Set combination.

wherein

X2/Xn delay + Queuing in SN = 25ms if SCG is NR, and 55ms if SCG is EUTRA

X2/Xn delay + Queuing in MN = 25ms if MCG is NR, and 55ms if MCG is EUTRA

RLC RTT for EUTRA cell group = 75ms

RLC RTT for NR cell group is defined in Table 4.1.4-1

SCS (KHz)	RLC RTT (ms)
15KHz	50
30KHz	40
60KHz	30
120KHz	20

Table 4.1.4-1: RLC RTT for NR cell group per SCS

4.2 UE Capability Parameters

4.2.1 Introduction

The following clauses define the UE radio access capability parameters. Only parameters for which there is the possibility for UEs to signal different values are considered as UE radio access capability parameters. Therefore, mandatory features without capability parameters that are the same for all UEs are not listed here.

The network needs to respect the signalled UE radio access capability parameters when configuring the UE and when scheduling the UE.

The UE may support different functionalities between FDD and TDD, and/or between FR1 and FR2. The UE shall indicate the UE capabilities as follows. In the table of UE capability parameter in subsequent clauses, "Yes" in the column by "FDD-TDD DIFF" and "FR1-FR2 DIFF" indicates the UE capability field can have a different value for between FDD and TDD or between FR1 and FR2 and "No" indicates if it cannot. Regarding to the per UE capabilities that are FDD/TDD differentiated (i.e. capabilities indicated as "Yes" in the column by "FDD-TDD DIFF"), the corresponding capabilities indicated by the FDD capability is applied to SUL if SUL band is supported by the UE. "FD" in the column indicates to refer the associated field description. "FR1 only" or "FR2 only" in the column indicates the associated feature is only supported in FR1 or FR2 and "TDD only" indicates it is not applicable to the feature (e,g. the signalling supports the UE to have different values between FDD and TDD or between FR1 and FR2).

- 1> set all fields of UE-NR/MRDC-Capability except fdd-Add-UE-NR/MRDC-Capabilities, tdd-Add-UE-NR/MRDC-Capabilities, fr1-Add-UE-NR/MRDC-Capabilities and fr2-Add-UE-NR/MRDC-Capabilities, to include the values applicable for all duplex mode(s) and frequency range(s) that the UE supports;
- 1> if UE supports both FDD (or SUL) and TDD and if (some of) the UE capability fields have a different value for FDD (or SUL) and TDD
 - 2> if for FDD (and, if the UE supports SUL, for SUL), the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:
 - 3> include field fdd-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for FDD;
 - 2> if for TDD, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:
 - 3> include field tdd-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for TDD;
- 1> if UE supports both FR1 and FR2 and if (some of) the UE capability fields have a different value for FR1 and FR2:
 - 2> if for FR1, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:
 - 3> include field fr1-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for FR1;
 - 2> if for FR2, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:

- 3> include field fr2-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for FR2;
- NOTE 1: The fields which indicate "shall be set to 1" or "shall be set to *supported*" in the following tables means these features are purely mandatory and are assumed they are the same as mandatory without capability signalling.
- NOTE 2: For the case where the UE is allowed to support different functionality between FDD and TDD and between FR1 and FR2 according to the specification, the UE capability indication is clarified in Annex B.

For optional features, the UE radio access capability parameter indicates whether the feature has been implemented and successfully tested. For mandatory features with the UE radio access capability parameter, the parameter indicates whether the feature has been successfully tested. In the table of UE capability parameter in subsequent clauses, "Yes" in the column by "M" indicates the associated feature is mandatory and "No" indicates the associated feature is optional. "CY" in the column indicates the associated feature is conditional mandatory and the condition is described in the field description and the associated feature is considered mandatory with capability parameter, when the described condition is satisfied. "FD" in the column indicates to refer the associated field description. Some parameters in subsequent clauses are not related to UE features and in the case, "N/A" is indicated in the column.

UE capability parameters have hierarchical structure. In the table of UE capability parameter in subsequent clauses, "Per" indicates the level the associated parameter is included. "UE" in the column indicates the associated parameter is signalled per UE, "Band" indicates it is signalled per band, "BC" indicates it is signalled per band combination, "FS" indicates it is signalled per feature set (per band per band combination), "FSPC" indicates it is signalled per feature set per component carrier (per CC per band per band combination), and "FD" in the column indicates to refer the associated field description.

4.2.2 General parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
<i>accessStratumRelease</i> Indicates the access stratum release the UE supports as specified in TS 38.331 [9].	UE	Yes	No	No
<i>delayBudgetReporting</i> Indicates whether the UE supports delay budget reporting as specified in TS 38.331 [9].	UE	No	No	No
<i>inactiveState</i> Indicates whether the UE supports RRC_INACTIVE as specified in TS 38.331 [9].	UE	Yes	No	No
overheatingInd Indicates whether the UE supports overheating assistance information.	UE	No	No	No
partialFR2-FallbackRX-Req Indicates whether the UE meets only a partial set of the UE minimum receiver requirements for the eligible FR2 fallback band combinations as defined in Clause 4.2 of TS 38.101-2 [3] and Clause 4.2 of TS 38.101-3 [4]. If not indicated, the UE shall meet all the UE minimum receiver requirements for all the FR2 fallback combinations in TS 38.101-2 [3] and TS 38.101-3 [4]. The UE shall support configuration of any of the FR2 fallback band combinations regardless of the presence or the absence of this field.	UE	No	No	No
<i>reducedCP-Latency</i> Indicates whether the UE supports reduced control plane latency as defined in TS 38.331 [9]	UE	No	No	No
<i>splitSRB-WithOneUL-Path</i> Indicates whether the UE supports UL transmission via MCG path and DL reception via either MCG path or SCG path, as specified for the split SRB in TS 37.340 [7]. The UE shall not set the FDD/TDD specific fields for this capability (i.e. it shall not include this field in UE-MRDC-CapabilityAddXDD-Mode).	UE	No	No	No
<i>splitDRB-withUL-Both-MCG-SCG</i> Indicates whether the UE supports UL transmission via both MCG path and SCG path for the split DRB as specified in TS 37.340 [7]. The UE shall not set the FDD/TDD specific fields for this capability (i.e. it shall not include this field in UE-MRDC-CapabilityAddXDD-Mode).	UE	Yes	No	No
<i>srb3</i> Indicates whether the UE supports direct SRB between the SN and the UE as specified in TS 37.340 [7]. The UE shall not set the FDD/TDD specific fields for this capability (i.e. it shall not include this field in <i>UE-MRDC-CapabilityAddXDD-Mode</i>). This field is not applied to NE-DC.	UE	Yes	No	No

4.2.3 SDAP Parameters

Definitions for parameters	Per	М	FDD- TDD DIFF
as-ReflectiveQoS	UE	No	No
Indicates whether the UE supports AS reflective QoS.			

4.2.4 PDCP Parameters

Definitions for parameters	Per	M	FDD- TDD DIFF
<i>continueROHC-Context</i> Defines whether the UE supports ROHC context continuation operation where the UE does not reset the current ROHC context upon PDCP re-establishment, as specified in TS 38.323 [16].	UE	No	No
<i>maxNumberROHC-ContextSessions</i> Defines the maximum number of header compression context sessions supported by the UE, excluding context sessions that leave all headers uncompressed.	UE	No	No
outOfOrderDelivery Indicates whether UE supports out of order delivery of data to upper layers by PDCP.	UE	No	No
<i>pdcp-DuplicationMCG-OrSCG-DRB</i> Indicates whether the UE supports CA-based PDCP duplication over MCG or SCG DRB as specified in TS 38.323 [16].	UE	No	No
<i>pdcp-DuplicationSplitDRB</i> Indicates whether the UE supports PDCP duplication over split DRB as specified in TS 38.323 [16].	UE	No	No
<i>pdcp-DuplicationSplitSRB</i> Indicates whether the UE supports PDCP duplication over split SRB1/2 as specified in TS 38.323 [16].	UE	No	No
<i>pdcp-DuplicationSRB</i> Indicates whether the UE supports CA-based PDCP duplication over SRB1/2 and/or, if (NG)EN-DC is supported, SRB3 as specified in TS 38.323 [16].	UE	No	No
shortSN Indicates whether the UE supports 12 bit length of PDCP sequence number.	UE	Yes	No
 supportedROHC-Profiles Defines which ROHC profiles from the list below are supported by the UE: 0x0000 ROHC No compression (RFC 5795) 0x0001 ROHC RTP/UDP/IP (RFC 3095, RFC 4815) 0x0002 ROHC UDP/IP (RFC 3095, RFC 4815) 0x0003 ROHC ESP/IP (RFC 3095, RFC 4815) 0x0004 ROHC IP (RFC 3843, RFC 4815) 0x0006 ROHC TCP/IP (RFC 6846) 0x0101 ROHC RTP/UDP/IP (RFC 5225) 0x0102 ROHC UDP/IP (RFC 5225) 0x0103 ROHC ESP/IP (RFC 5225) 0x0104 ROHC IP (RFC 5225) 0x0104 ROHC IP (RFC 5225) A UE that supports one or more of the listed ROHC profiles shall support ROHC profile 0x0000 ROHC uncompressed (RFC 5795). An IMS voice capable UE shall indicate support of ROHC profiles 0x0000, 0x0001, 0x0002 and be able to compress and decompress headers of PDCP SDUs at a PDCP SDU rate corresponding to supported IMS voice codecs. 	UE	No	No
uplinkOnlyROHC-Profiles Indicates the ROHC profile(s) that are supported in uplink-only ROHC operation by the UE. - 0x0006 ROHC TCP (RFC 6846)	UE	No	No
A UE that supports uplink-only ROHC profile(s) shall support ROHC profile 0x0000 ROHC uncompressed (RFC 5795).			

4.2.5 RLC parameters

Definitions for parameters	Per	М	FDD- TDD DIFF
am-WithShortSN	UE	Yes	No
Indicates whether the UE supports AM DRB with 12 bit length of RLC sequence number.			
um-WithLongSN	UE	Yes	No
Indicates whether the UE supports UM DRB with 12 bit length of RLC sequence number.			
um-WithShortSN	UE	Yes	No
Indicates whether the UE supports UM DRB with 6 bit length of RLC sequence number.			

4.2.6 MAC parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
Ich-ToSCellRestriction Indicates whether the UE supports restricting data transmission from a given LCH to a configured (sub-) set of serving cells (see <i>allowedServingCells</i> in <i>LogicalChannelConfig</i>). A UE supporting <i>pdcp-DuplicationMCG-OrSCG-DRB</i> or <i>pdcp- DuplicationSRB</i> (see <i>PDCP-Config</i>) shall also support <i>Ich-ToSCellRestriction</i> .	UE	No	No	No
<i>Icp-Restriction</i> Indicates whether UE supports the selection of logical channels for each UL grant based on RRC configured restriction using RRC parameters <i>allowedSCS-List</i> , <i>maxPUSCH-Duration</i> , and <i>configuredGrantType1Allowed</i> as specified in TS 38.321 [8].	UE	No	No	No
logicalChannelSR-DelayTimer Indicates whether the UE supports the <i>logicalChannelSR-DelayTimer</i> as specified in TS 38.321 [8].	UE	No	Yes	No
<i>longDRX-Cycle</i> Indicates whether UE supports long DRX cycle as specified in TS 38.321 [8].	UE	Yes	Yes	No
<i>multipleConfiguredGrants</i> Indicates whether UE supports more than one configured grant configurations (including both Type 1 and Type 2) in a cell group. For each cell, the UE supports at most one configured grant per BWP and the maximum number of configured grant configurations per cell group is 2. If absent, for each configured cell group, the UE only supports one configured grant configuration on one serving cell.	UE	No	Yes	No
<i>multipleSR-Configurations</i> Indicates whether the UE supports 8 SR configurations per PUCCH cell group as specified in TS 38.321 [8].	UE	No	Yes	No
<i>recommendedBitRate</i> Indicates whether the UE supports the bit rate recommendation message from the gNB to the UE as specified in TS 38.321 [8].	UE	No	No	No
recommendedBitRateQuery Indicates whether the UE supports the bit rate recommendation query message from the UE to the gNB as specified in TS 38.321 [8]. This field is only applicable if the UE supports <i>recommendedBitRate</i> .	UE	No	No	No
shortDRX-Cycle Indicates whether UE supports short DRX cycle as specified in TS 38.321 [8].	UE	Yes	Yes	No
<i>skipUplinkTxDynamic</i> Indicates whether the UE supports skipping of UL transmission for an uplink grant indicated on PDCCH if no data is available for transmission as specified in TS 38.321 [8].	UE	No	Yes	No

4.2.7 Physical layer parameters

4.2.7.1 *BandCombinationList* parameters

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
<i>bandEUTRA</i> Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
<i>bandList</i> Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
<i>bandNR</i> Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
<i>ca-BandwidthClassDL-EUTRA</i> Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
<i>ca-BandwidthClassDL-NR</i> Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
<i>ca-BandwidthClassUL-NR</i> Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
<i>ca-ParametersEUTRA</i> Contains the EUTRA part of band combination parameters for a given (NG)EN- DC/NE-DC band combination.	BC	No	N/A	N/A
<i>ca-ParametersNR</i> Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
<i>ca-ParametersNRDC</i> Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. In this version of the standard, a UE indicating support for NR-DC supports only configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
<i>mrdc-Parameters</i> Contains the band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
<i>ne-DC-BC</i> Indicates whether the UE supports NE-DC for the band combination.	BC	No	N/A	N/A
powerClass Indicates power class the UE supports when operating according to this band combination. If the field is absent, the UE supports the default power class. If this power class is higher than the power class that the UE supports on the individual bands of this band combination (<i>ue-PowerClass</i> in <i>BandNR</i>), the latter determines maximum TX power available in each band. The UE sets the power class parameter only in band combinations that are applicable as specified in TS 38.101- 1 [2] and TS 38.101-3 [4].	BC	No	N/A	FR1 only

SRS-SwitchingTimeNR Indicates the interruption time on DL/UL reception within a NR band pair during the RF retuning for switching between a carrier on one band and another (PUSCH-less) carrier on the other band to transmit SRS. <i>switchingTimeDL/ switchingTimeUL</i> : n0us represents 0 us, n30us represents 30us, and so on. <i>switchingTimeDL/ switchingTimeUL</i> is mandatory present if switching between the NR band pair is supported, otherwise the field is absent. It is signalled per pair of bands per band combination.	FD	No	N/A	N/A
SRS-SwitchingTimeEUTRA Indicates the interruption time on DL/UL reception within a EUTRA band pair during the RF retuning for switching between a carrier on one band and another (PUSCH- less) carrier on the other band to transmit SRS. <i>switchingTimeDL/</i> <i>switchingTimeUL</i> : n0 represents 0 OFDM symbols, n0dot5 represents 0.5 OFDM symbols, n1 represents 1 OFDM symbol and so on. <i>switchingTimeDL/</i> <i>switchingTimeUL</i> is mandatory present if switching between the EUTRA band pair is supported, otherwise the field is absent. It is signalled per pair of bands per band combination.	FD	No	N/A	N/A
 srs-TxSwitch Defines whether UE supports SRS for DL CSI acquisition as defined in clause 6.2.1.2 of TS 38.214 [12]. The capability signalling comprises of the following parameters: supportedSRS-TxPortSwitch indicates SRS Tx port switching pattern supported by the UE. The indicated UE antenna switching capability of 'xTyR' corresponds to a UE, capable of SRS transmission on 'x' antenna ports over total of 'y' antennas, where 'y' corresponds to all or subset of UE receive antennas, where 2T4R is two pairs of antennas; txSwitchImpactToRx indicates the entry number of the first-listed band with UL (see NOTE) in the band combination that affects this DL; txSwitchImpactToRx and txSwitchWithAnotherBand, value 1 means first entry, value 2 means second entry and so on. All DL and UL that switch together indicate the same entry number. For txSwitchImpactToRx and txSwitchWithAnotherBand, value 1 means first entry, value 2 means second entry and so on. All DL and UL that switch together indicate the same entry number. The entry number is the band combinations for the purpose of indicating different SRS antenna switching capabilities. NOTE: The first-listed band with UL includes a band associated with FeatureSetUplinkId set to 0 corresponding to the support of SRS-	BC	Yes	N/A	N/A
SwitchingTimeNR. supportedBandwidthCombinationSet Defines the supported bandwidth combination set for a band combination as defined in TS 38.101-1 [2], TS 38.101-2 [3] and TS 38.101-3 [4]. For NR SA CA, NR-DC, inter-band (NG)EN-DC without intra-band (NG)EN-DC component, inter- band NE-DC without intra-band NE-DC component and intra-band (NG)EN-DC/NE- DC with additional inter-band NR CA component, the field defines the bandwidth combinations for the NR part of the band combination. For intra-band (NG)EN- DC/NE-DC without additional inter-band NR and LTE CA component, the field indicates the supported bandwidth combination set applicable to intra-band (NG)EN-DC/NE-DC band combination. Field encoded as a bit map, where bit N is set to "1" if UE support Bandwidth Combination Set N for this band combination as defined in the TS 38.101-1 [2], TS 38.101-2 [3] and TS 38.101-3 [4]. The leading / leftmost bit (bit 0) corresponds to the Bandwidth Combination Set 0, the next bit corresponds to the Bandwidth Combination Set 1 and so on. It is mandatory if - the band combination has more than one NR carrier (at least one SCell in an NR cell group); - or is an intra-band (NG)EN-DC/NE-DC combination without additional inter- band NR and LTE CA component; -	BC	CY	N/A	N/A

	50	01		
supportedBandwidthCombinationSetIntraENDC	BC	CY	N/A	N/A
Defines the supported bandwidth combination set for a band combination that				
allows configuration of at least one EUTRA serving cell and at least one NR serving				
cell in the same band, as defined in the TS 38.101-3 [4], table 5.3B.1.2-1 and table				
5.3B.1.3-1.				
 For intra-band (NG)EN-DC with additional inter-band CA component(s) of 				
LTE and/or NR, the field defines the bandwidth combinations for the intra-				
band (NG)EN-DC component.				
- For intra-band NE-DC with additional inter-band CA component(s) of LTE				
and/or NR, the field defines the bandwidth combinations for the intra-band				
NE-DC component.				
Field encoded as a bit map, where bit N is set to "1" if UE support Bandwidth				
Combination Set N for this band combination as defined in the TS 38.101-3 [4]. The				
leading / leftmost bit (bit 0) corresponds to the Bandwidth Combination Set 0, the				
next bit corresponds to the Bandwidth Combination Set 1 and so on.				
- It is mandatory if the band combination is an intra-band (NG)EN-DC/NE-DC				
combination supporting both UL and DL intra-band (NG)EN-DC/NE-DC parts				
with additional inter-band NR/LTE CA component.				
- It is optional if the band combination is an intra-band (NG)EN-DC/NE-DC				
combination without supporting UL in both the bands of the intra-band				
(NG)EN-DC/NE-DC UL part. If not included, the network assumes the UE				
supports BCS0 as defined in TS 38.101-3 [4], table 5.3B.1.2-1 and table				
5.3B.1.3-1 for the intra-band (NG)EN-DC/NE-DC.				

4.2.7.2 BandNR parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
additionalActiveTCI-StatePDCCH Indicates whether the UE supports one additional active TCI-State for control in addition to the supported number of active TCI-States for PDSCH. The UE can include this field only if maxNumberActiveTCI-PerBWP in tci-StatePDSCH is set to n1. Otherwise, the UE does not include this field.	Band	No	N/A	N/A
<i>aperiodicBeamReport</i> Indicates whether the UE supports aperiodic 'CRI/RSRP' or 'SSBRI/RSRP' reporting on PUSCH. The UE provides the capability for the band number for which the report is provided (where the measurement is performed).	Band	Yes	N/A	N/A
<i>aperiodicTRS</i> Indicates whether the UE supports DCI triggering aperiodic TRS associated with periodic TRS.	Band	No	N/A	N/A
asymmetricBandwidthCombinationSet Defines the supported asymmetric channel bandwidth combination for the band as defined in the TS 38.101-1 [2]. Field encoded as a bit map, where bit N is set to "1" if UE support asymmetric channel bandwidth combination set N for this band as defined in the TS 38.101-1 [2]. The leading / leftmost bit (bit 0) corresponds to the asymmetric channel bandwidth combination set 1, the next bit corresponds to the asymmetric channel bandwidth combination set 2 and so on. UE shall support asymmetric channel bandwidth combination set 0. If the field is absent, the UE supports asymmetric channel bandwidth combination set 0.	Band	No	No	No
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
beamCorrespondenceWithoutUL-BeamSweeping Indicates how UE supports FR2 beam correspondence as specified in TS 38.101-2 [3], clause 6.6. The UE that fulfils the beam correspondence requirement without the uplink beam sweeping (as specified in TS 38.101-2 [3], clause 6.6) shall set the field to <i>supported</i> . The UE that fulfils the beam correspondence requirement with the uplink beam sweeping (as specified in TS 38.101-2 [3], clause 6.6) shall not report this field.	Band	Yes	N/A	FR2 only

<i>beamManagementSSB-CSI-RS</i> Defines support of SS/PBCH and CSI-RS based RSRP measurements. The	Band	Yes	N/A	FD
capability comprises signalling of				
- maxNumberSSB-CSI-RS-ResourceOneTx indicates maximum total number				
of configured one port NZP CSI-RS resources and SS/PBCH blocks that are				
supported by the UE to measure L1-RSRP as specified in TS 38.215 [13]				
within a slot and across all serving cells (see NOTE). On FR2, it is				
mandatory to report $>=8$; On FR1, it is mandatory with capability signalling to				
report $>=8$.				
- maxNumberCSI-RS-Resource indicates maximum total number of				
configured NZP-CSI-RS resources that are supported by the UE to measure				
L1-RSRP as specified in TS 38.215 [13] across all serving cells (see NOTE).				
It is mandated to report at least n8 for FR1.				
- maxNumberCSI-RS-ResourceTwoTx indicates maximum total number of two				
ports NZP CSI-RS resources that are supported by the UE to measure L1-				
RSRP as specified in TS 38.215 [13] within a slot and across all serving cells				
(see NOTE).				
(
- supportedCSI-RS-Density indicates density of one RE per PRB for one port				
NZP CSI-RS resource for RSRP reporting, if supported. On FR2, it is				
mandatory to report either "three" or "oneAndThree"; On FR1, it is				
mandatory with capability signalling to report either "three" or				
"oneAndThree".				
- maxNumberAperiodicCSI-RS-Resource indicates maximum number of				
configured aperiodic CSI-RS resources across all serving cells (see NOTE).				
For FR1 and FR2, the UE is mandated to report at least n4.				
NOTE: If the UE sets a value other than <i>n0</i> in an FR1 band, it shall set that same				
value in all FR1 bands. If the UE sets a value other than <i>n0</i> in an FR2				
band, it shall set that same value in all FR2 bands. The UE supports a				
total number of resources equal to the maximum of the FR1 and FR2				
value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells.				
beamReportTiming	Band	Yes	N/A	N/A
Indicates the number of OFDM symbols between the end of the last symbol of	Dana	103	1 1/7 1	1 1/7 1
SSB/CSI-RS and the start of the first symbol of the transmission channel containing				
beam report. The UE provides the capability for the band number for which the				
report is provided (where the measurement is performed). The UE includes this field				
for each supported sub-carrier spacing.				
beamSwitchTiming	Band	No	N/A	FR2
ndicates the minimum number of OFDM symbols between the DCI triggering of				only
aperiodic CSI-RS and aperiodic CSI-RS transmission. The number of OFDM				
symbols is measured from the end of the last symbol containing the indication to the				
start of the first symbol of CSI-RS. The UE includes this field for each supported				
sub-carrier spacing.				
NOTE: beamSwitchTiming of value (sym224 or sym336) will be used to				
determine UE expectation/behaviour for aperiodic CSI-RS for tracking				
and latency requirements for L1-RSRP reporting as described in clause				
5.1.6.1.1 of TS 38.214 [12], while UE behaviour/assumption regarding				
before or ofter been quited timing is upon colfied for measuring AD 001				
before or after beam switch timing is unspecified for measuring AP CSI-				
RS for CSI acquisition (without trs-Info and without repetition) and for				
RS for CSI acquisition (without trs-Info and without repetition) and for beam management (with repetition 'off').	Band	No	N/A	N/A
RS for CSI acquisition (without trs-Info and without repetition) and for beam management (with repetition 'off'). bwp-DiffNumerology	Band	No	N/A	N/A
RS for CSI acquisition (without trs-Info and without repetition) and for beam management (with repetition 'off'). bwp-DiffNumerology Indicates whether the UE supports BWP adaptation up to 4 BWPs with the different	Band	No	N/A	N/A
RS for CSI acquisition (without trs-Info and without repetition) and for beam management (with repetition 'off'). bwp-DiffNumerology Indicates whether the UE supports BWP adaptation up to 4 BWPs with the different numerologies, via DCI and timer. Except for SUL, the UE only supports the same	Band	No	N/A	N/A
RS for CSI acquisition (without trs-Info and without repetition) and for beam management (with repetition 'off'). bwp-DiffNumerology ndicates whether the UE supports BWP adaptation up to 4 BWPs with the different numerologies, via DCI and timer. Except for SUL, the UE only supports the same numerology for the active UL and DL BWP. For the UE capable of this feature, the	Band	No	N/A	N/A
RS for CSI acquisition (without trs-Info and without repetition) and for beam management (with repetition 'off'). bwp-DiffNumerology Indicates whether the UE supports BWP adaptation up to 4 BWPs with the different numerologies, via DCI and timer. Except for SUL, the UE only supports the same numerology for the active UL and DL BWP. For the UE capable of this feature, the bandwidth of a UE-specific RRC configured DL BWP includes the bandwidth of the	Band	No	N/A	N/A
RS for CSI acquisition (without trs-Info and without repetition) and for	Band	No	N/A	N/A

bwp-SameNumerology		Band	No	N/A	N/A
	rts BWP adaptation (up to 2/4 BWPs) with the same			1 1// 1	
	er. Except for SUL, the UE only supports the same				
	and DL BWP. For the UE capable of this feature, the				
	RC configured DL BWP includes the bandwidth of the				
	to is present) and SSB for PCell and PSCell (if				
configured). For SCell(s), the	e bandwidth of the UE-specific RRC configured DL				
BWP includes SSB, if there i	s SSB on SCell(s).				
bwp-WithoutRestriction		Band	No	N/A	N/A
	eration without bandwidth restriction. The Bandwidth				
	'P for PCell and PSCell means that the bandwidth of a				
	DL BWP may not include the bandwidth of CORESET				
#0 (if configured) and SSB. F	For SCell(s), it means that the bandwidth of DL BWP				
may not include SSB.					
channelBWs-DL	· · · · · ·	Band	Yes	N/A	N/A
	spacing the UE supported channel bandwidths.				
	-DL (without suffix) for a band or absence of specific				
	rted subcarrier spacing means that the UE supports the				
	[5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100,				
	use 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS				
	or the given band or the specific SCS entry.				
	BWs-DL (without suffix) starting from the leading /				
	5, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in				
	fix) starting from the leading / leftmost bit indicate 50,				
	rightmost bit (for 200MHz) shall be set to 1. t bit in <i>channelBWs-DL-v1590</i> indicates 70MHz, the				
	45MHz, the third leftmost bit indicates 35MHz, the				
	00MHz and all the remaining bits in <i>channelBWs-DL</i> -				
	fourth leftmost bit (for 100MHz) is not applicable for				
	79 and n90 as defined in TS 38.101-1 [2].				
NOTE: To determine whe	ther the UE supports a specific SCS for a given band,				
	ates the supportedSubCarrierSpacingDL and the scs-				
60kHz.	tes the supported subcarrier spacing DE and the scs-				
	ther the UE supports a channel bandwidth of 90 MHz,				
	gnore this capability and validate instead the				
	iz, the supportedBandwidthCombinationSet and the				
	dthCombinationSetIntraENDC. For serving cell(s) with				
	idwidths the network validates the <i>channelBWs-DL</i> , the				
	dthCombinationSet, the				
	dthCombinationSetIntraENDC, the				
	<i>vidthCombinationSet</i> (for a band supporting asymmetric				
	h as defined in clause 5.3.6 of TS 38.101-1 [2]) and				
supportedBandwi		1	1		

channelE	BWs-UL	Band	Yes	N/A	N/A
Indicates	for each subcarrier spacing the UE supported channel bandwidths.				
	of the channelBWs-UL (without suffix) for a band or absence of specific				
	Iz entry for a supported subcarrier spacing means that the UE supports the				
	andwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100,				
	were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS				
	version 15.7.0 [3] for the given band or the specific SCS entry.				
	the bits in <i>channelBWs-UL</i> (without suffix) starting from the leading /				
	it indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in				
	<i>Ws-UL</i> (without suffix) starting from the leading / leftmost bit indicate 50,				
	200MHz. The third / rightmost bit (for 200MHz) shall be set to 1.				
	the leading/leftmost bit in channelBWs-UL-v1590 indicates 70 MHz, the				
	ftmost bit indicates 45MHz, the third leftmost bit indicates 35MHz, the				
fourth left	most bit indicates 100MHz and all the remaining bits in <i>channelBWs-UL-</i>				
v1590 sha	all be set to 0. The fourth leftmost bit (for 100MHz) is not applicable for				
bands n4	1, n48, n77, n78, n79 and n90 as defined in TS 38.101-1 [2].				
NOTE:	To determine whether the UE supports a specific SCS for a given band,				
	the network validates the supportedSubCarrierSpacingUL and the scs-				
	60kHz.				
	To determine whether the UE supports a channel bandwidth of 90 MHz				
	the network may ignore this capability and validate instead the				
	channelBW-90mhz, the supportedBandwidthCombinationSet and the				
	supportedBandwidthCombinationSetIntraENDC. For serving cell(s) with				
	other channel bandwidths the network validates the channelBWs-UL, the				
	supportedBandwidthCombinationSet, the				
	supportedBandwidthCombinationSetIntraENDC, the				
	asymmetricBandwidthCombinationSet (for a band supporting asymmetric				
	channel bandwidth as defined in clause 5.3.6 of TS 38.101-1 [2]) and				
	supportedBandwidthUL.				

codebookParameters	Band	FD	N/A	N/A
Indicates the codebooks and the corresponding parameters supported by the UE.				
Parameters for type I single panel codebook (type1 singlePanel) supported by the UE, which are mandatory to report:				
- supportedCSI-RS-ResourceList,				
- a UE shall support a <i>maxNumberTxPortsPerResource</i> minimum value of				
4 for codebook type I single panel in FR1 in the case of a single active CSI-resource across all bands in a band combination, regardless of what				
it reports in supportedCSI-RS-ResourceList with				
maxNumberTxPortsPerResource;				
- a UE shall support a <i>maxNumberTxPortsPerResource</i> minimum value of				
8 when configured with wideband CSI report for codebook type I single				
panel in FR1 in the case of a single active CSI-resource across all bands in a band combination, regardless of what it reports in <i>supportedCSI-RS</i> -				
ResourceList with maxNumberTxPortsPerResource;				
- a UE shall support a maxNumberTxPortsPerResource minimum value of				
2 for codebook type I single panel in FR2 in the case of a single active				
CSI-resource across all bands in a band combination, regardless of what				
it reports in supportedCSI-RS-ResourceList with maxNumberTxPortsPerResource.				
- modes indicates supported codebook modes (mode 1, both mode 1 and				
mode 2);				
 maxNumberCSI-RS-PerResourceSet indicates the maximum number of CSI- RS resource in a resource set. 				
Parameters for type I multi-panel codebook (type1 multiPanel) supported by the UE, which are optional:				
- supportedCSI-RS-ResourceList,				
- modes indicates supported codebook modes (mode 1, mode 2, or both				
mode 1 and mode 2);				
 maxNumberCSI-RS-PerResourceSet indicates the maximum number of CSI- RS resource in a resource set; 				
 nrofPanels indicates supported number of panels. 				
Parameters for type II codebook (type2) supported by the UE, which are optional:				
 supportedCSI-RS-ResourceList, parameterLx indicates the parameter "Lx" in codebook generation where x is 				
an index of Tx ports indicated by maxNumberTxPortsPerResource;				
- amplitudeScalingType indicates the amplitude scaling type supported by the				
UE (wideband or both wideband and sub-band);				
 amplitudeSubsetRestriction indicates whether amplitude subset restriction is supported for the UE. 				
Parameters for type II codebook with port selection (type2-PortSelection) supported by the UE, which are optional:				
- supportedCSI-RS-ResourceList;				
- parameterLx indicates the parameter "Lx" in codebook generation where x is				
 an index of Tx ports indicated by maxNumberTxPortsPerResource; amplitudeScalingType indicates the amplitude scaling type supported by the 				
UE (wideband or both wideband and sub-band).				
supportedCSI-RS-ResourceList includes list of the following parameters:				
- maxNumberTxPortsPerResource indicates the maximum number of Tx ports				
in a resource;				
 maxNumberResourcesPerBand indicates the maximum number of resources across all CCs within a band simultaneously; 				
 totalNumberTxPortsPerBand indicates the total number of Tx ports across all 				
CCs within a band simultaneously.				
crossCarrierScheduling-SameSCS	Band	No	N/A	N/A
ndicates whether the UE supports cross carrier scheduling for the same				
numerology with carrier indicator field (CIF) in carrier aggregation where				
umerologies for the scheduling cell and scheduled cell are same.				

csi-ReportFramework	Band	Yes	N/A	N/A
Indicates whether the UE supports CSI report framework. This capability signalling				
 comprises the following parameters: maxNumberPeriodicCSI-PerBWP-ForCSI-Report indicates the maximum number of periodic CSI report setting per BWP for CSI report; 				
 maxNumberPeriodicCSI-PerBWP-ForBeamReport indicates the maximum number of periodic CSI report setting per BWP for beam report. 				
 maxNumberAperiodicCSI-PerBWP-ForCSI-Report indicates the maximum number of aperiodic CSI report setting per BWP for CSI report; 				
 maxNumberAperiodicCSI-PerBWP-ForBeamReport indicates the maximum number of aperiodic CSI report setting per BWP for beam report; 				
 maxNumberAperiodicCSI-triggeringStatePerCC indicates the maximum number of aperiodic CSI triggering states in CSI-AperiodicTriggerStateList per CC; 				
 maxNumberSemiPersistentCSI-PerBWP-ForCSI-Report indicates the maximum number of semi-persistent CSI report setting per BWP for CSI report; 				
 maxNumberSemiPersistentCSI-PerBWP-ForBeamReport indicates the maximum number of semi-persistent CSI report setting per BWP for beam report; 				
 simultaneousCSI-ReportsPerCC indicates the number of CSI report(s) for which the UE can measure and process reference signals simultaneously in a CC of the band for which this capability is provided. The CSI report comprises periodic, semi-persistent and aperiodic CSI and any latency classes and codebook types. The CSI report in simultaneousCSI- ReportsPerCC includes the beam report and CSI report. 				
The UE is mandated to report csi-ReportFramework.				
 csi-RS-ForTracking Indicates support of CSI-RS for tracking (i.e. TRS). This capability signalling comprises the following parameters: maxBurstLength indicates the TRS burst length. Value 1 indicates 1 slot and value 2 indicates both of 1 slot and 2 slots. In this release UE is mandated to report value 2; 	Band	Yes	N/A	N/A
 maxSimultaneousResourceSetsPerCC indicates the maximum number of TRS resource sets per CC which the UE can track simultaneously; 				
 maxConfiguredResourceSetsPerCC indicates the maximum number of TRS resource sets configured to UE per CC. It is mandated to report at least 8 for FR1 and 16 for FR2; 				
- maxConfiguredResourceSetsAllCC indicates the maximum number of TRS resource sets configured to UE across CCs. If the UE includes the field in an FR1 band, it shall set the same value in all FR1 bands. If the UE includes the field in an FR2 band, it shall set the same value in all FR1 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells. The UE is mandated to report at least 16 for FR1 and 32 for FR2.				
The UE is mandated to report csi-RS-ForTracking.				

csi-RS-IM-ReceptionForFeedback	Band	Yes	N/A	N/A
Indicates support of CSI-RS and CSI-IM reception for CSI feedback. This capability				
signalling comprises the following parameters: - maxConfigNumberNZP-CSI-RS-PerCC indicates the maximum number of				
 maxConfiguration/2P-CSI-RS-PERCE indicates the maximum number of configured NZP-CSI-RS resources per CC; 				
 maxConfigNumberPortsAcrossNZP-CSI-RS-PerCC indicates the maximum number of ports across all configured NZP-CSI-RS resources per CC; 				
 maxConfigNumberCSI-IM-PerCC indicates the maximum number of configured CSI-IM resources per CC; 				
 maxNumberSimultaneousNZP-CSI-RS-PerCC indicates the maximum number of simultaneous CSI-RS-resources per CC; 				
 totalNumberPortsSimultaneousNZP-CSI-RS-PerCC indicates the total number of CSI-RS ports in simultaneous CSI-RS resources per CC. 				
The UE is mandated to report csi-RS-IM-ReceptionForFeedback.				
csi-RS-ProcFrameworkForSRS	Band	No	N/A	N/A
Indicates support of CSI-RS processing framework for SRS. This capability signalling comprises the following parameters:				
- maxNumberPeriodicSRS-AssocCSI-RS-PerBWP indicates the maximum				
number of periodic SRS resources associated with CSI-RS per BWP;				
 maxNumberAperiodicSRS-AssocCSI-RS-PerBWP indicates the maximum number of aperiodic SRS resources associated with CSI-RS per BWP; 				
 maxNumberSP-SRS-AssocCSI-RS-PerBWP indicates the maximum number of semi-persistent SRS resources associated with CSI-RS per BWP; 				
 simultaneousSRS-AssocCSI-RS-PerCC indicates the number of SRS resources that the UE can process simultaneously in a CC, including periodic, aperiodic and semi-persistent SRS. 				
extendedCP Indicates whether the UE supports 60 kHz subcarrier spacing with extended CP	Band	No	N/A	N/A
length for reception of PDCCH, and PDSCH, and transmission of PUCCH, PUSCH, and SRS.				
groupBeamReporting Indicates whether UE supports RSRP reporting for the group of two reference	Band	No	N/A	N/A
signals. maxNumberCSI-RS-BFD	Band	CY	N/A	N/A
Indicates maximal number of CSI-RS resources across all CCs, and across MCG	Dana		1 1/7 1	1 1/7 1
and SCG in case of NR-DC, for UE to monitor PDCCH quality. In this release, the				
maximum value that can be signalled is 16. If the UE includes the field in an FR1				
band, it shall set the same value in all FR1 bands. If the UE includes the field in an				
FR2 band, it shall set the same value in all FR2 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more				
than the FR1 value across all FR1 serving cells and no more than the FR2 value				
across all FR2 serving cells. It is mandatory with capability signalling for FR2 and				
optional for FR1.				
maxNumberCSI-RS-SSB-CBD	Band	CY	N/A	N/A
Defines maximal number of different CSI-RS [and/or SSB] resources across all CCs, and across MCG and SCG in case of NR-DC, for new beam identifications. In				
this release, the maximum value that can be signalled is 128. If the UE includes the				
field in an FR1 band, it shall set the same value in all FR1 bands. If the UE includes				
the field in an FR2 band, it shall set the same value in all FR2 bands. The UE				
supports a total number of resources equal to the maximum of the FR1 and FR2				
value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells. It is mandatory with capability				
signalling for FR2 and optional for FR1. The UE is mandated to report at least 32 for				
FR2.				
<i>maxNumberNonGroupBeamReporting</i> Defines support of non-group based RSRP reporting using N_max RSRP values	Band	Yes	N/A	N/A
reported.				

maxNumberRxBeam	Band	CY	N/A	N/A
Defines whether UE supports receive beamforming switching using NZP CSI-RS				
resource. UE shall indicate a single value for the preferred number of NZP CSI-RS				
resource repetitions per CSI-RS resource set. Support of Rx beam switching is				
mandatory for FR2.				
maxNumberRxTxBeamSwitchDL	Band	No	N/A	FR2
Defines the number of Tx and Rx beam changes UE can perform on this band				only
within a slot. UE shall report one value per each subcarrier spacing supported by				
the UE. In this release, the number of Tx and Rx beam changes for scs-15kHz and				
scs-30kHz are not included.				
maxNumberSSB-BFD	Band	CY	N/A	N/A
Defines maximal number of different SSBs across all CCs, and across MCG and				
SCG in case of NR-DC, for UE to monitor PDCCH quality. In this release, the				
maximum value that can be signalled is 16. If the UE includes the field in an FR1				
band, it shall set the same value in all FR1 bands. If the UE includes the field in an				
FR2 band, it shall set the same value in all FR2 bands. The UE supports a total				
number of resources equal to the maximum of the FR1 and FR2 value, but no more				
than the FR1 value across all FR1 serving cells and no more than the FR2 value				
across all FR2 serving cells. It is mandatory with capability signalling for FR2 and				
optional for FR1.				
maxUplinkDutyCycle-PC2-FR1	Band	No	N/A	FR1
Indicates the maximum percentage of symbols during a certain evaluation period				only
that can be scheduled for uplink transmission so as to ensure compliance with				,
applicable electromagnetic energy absorption requirements provided by regulatory				
bodies. This field is only applicable for FR1 power class 2 UE as specified in clause				
6.2.1 of TS 38.101-1 [2]. If the field is absent, 50% shall be applied. Value n60				
corresponds to 60%, value n70 corresponds to 70% and so on.				
maxUplinkDutyCycle-FR2	Band	No	N/A	FR2
Indicates the maximum percentage of symbols during 1s that can be scheduled for	Danu			only
uplink transmission at the UE maximum transmission power, so as to ensure				
compliance with applicable electromagnetic power density exposure requirements				
provided by regulatory bodies. This field is applicable for all power classes UE in				
FR2 as specified in TS 38.101-2 [3]. Value n15 corresponds to 15%, value n20				
corresponds to 20% and so on. If the field is absent or the percentage of uplink				
symbols transmitted within any 1s evaluation period is larger than				
maxUplinkDutyCycle-FR2, the UE behaviour is specified in TS 38.101-2 [3].				
modifiedMPR-Behaviour	Band	No	N/A	N/A
Indicates whether UE supports modified MPR behaviour defined in TS 38.101-1 [2]	Danu			
and TS 38.101-2 [3].				
multipleTCI	Band	Yes	N/A	N/A
Indicates whether UE supports more than one TCI state configurations per	Danu	105	IN/A	
CORESET. UE is only required to track one active TCI state per CORESET. UE is				
required to support minimum between 64 and number of configured TCI states indicated by <i>tci-StatePDSCH</i> . This field shall be set to <i>supported</i> .				
pdsch-256QAM-FR2	Pand	No	NI/A	EDC
	Band	No	N/A	FR2
Indicates whether the UE supports 256QAM modulation scheme for PDSCH for				only
FR2 as defined in 7.3.1.2 of TS 38.211 [6].	Dend	No -	N1/A	N1/A
periodicBeamReport	Band	Yes	N/A	N/A
Indicates whether UE supports periodic 'CRI/RSRP' or 'SSBRI/RSRP' reporting				
using PUCCH formats 2, 3 and 4 in one slot.			TDD	
powerBoosting-pi2BPSK	Band	No	TDD	FR1
Indicates whether UE supports power boosting for pi/2 BPSK, when applicable as			only	only
defined in 6.2 of TS 38.101-1 [2].				
ptrs-DensityRecommendationSetDL	Band	CY	N/A	N/A
For each supported sub-corrier encourse indicates preferred threshold eats for				
determining DL PTRS density. It is mandated for FR2. For each supported sub-				
determining DL PTRS density. It is mandated for FR2. For each supported sub- carrier spacing, this field comprises:				
For each supported sub-carrier spacing, indicates preferred threshold sets for determining DL PTRS density. It is mandated for FR2. For each supported sub-carrier spacing, this field comprises: - two values of <i>frequencyDensity</i> ;				
determining DL PTRS density. It is mandated for FR2. For each supported sub- carrier spacing, this field comprises:				

ptrs-DensityRecommendationSetUL	Band	No	N/A	N/A
For each supported sub-carrier spacing, indicates preferred threshold sets for determining UL PTRS density. For each supported sub-carrier spacing, this field comprises:				
- two values of <i>frequencyDensity</i> ;				
- three values of <i>timeDensity</i> ;				
- five values of sampleDensity.				
<i>pucch-SpatialRelInfoMAC-CE</i> Indicates whether the UE supports indication of <i>PUCCH-spatialrelationinfo</i> by a	Band	CY	N/A	N/A
MAC CE per PUCCH resource. It is mandatory for FR2 and optional for FR1. pusch-256QAM	Band	No	N/A	N/A
Indicates whether the UE supports 256QAM modulation scheme for PUSCH as defined in 6.3.1.2 of TS 38.211 [6].	Danu	NO		11/7
pusch-TransCoherence	Band	No	N/A	N/A
Defines support of the uplink codebook subset by the UE for UL precoding for PUSCH transmission as described in clause 6.1.1.1 of TS 38.214 [12]. UE indicated support of partial coherent codebook subset shall also support non-coherent codebook subset. UE indicated support of full coherent codebook subset shall also support partial and non-coherent codebook subset.	Dana		N/A	
rateMatchingLTE-CRS Indicates whether the UE supports receiving PDSCH with resource mapping that excludes the REs determined by the higher layer configuration LTE-carrier	Band	Yes	N/A	N/A
configuring common RS, as specified in TS 38.214 [12].				
 spatialRelations Indicates whether the UE supports spatial relations. The capability signalling comprises the following parameters. maxNumberConfiguredSpatialRelations indicates the maximum number of configured spatial relations per CC for PUCCH and SRS. It is not applicable to FR1 and applicable to FR2 only. The UE is mandated to report 16 or higher values; 	Band	FD	N/A	FD
 maxNumberActiveSpatialRelations indicates the maximum number of active spatial relations with regarding to PUCCH and SRS for PUSCH, per BWP per CC. It is not applicable to FR1 and applicable and mandatory to report one or higher value for FR2 only; 				
 additionalActiveSpatialRelationPUCCH indicates support of one additional active spatial relation for PUCCH. It is mandatory with capability signalling if maxNumberActiveSpatialRelations is set to n1; 				
 maxNumberDL-RS-QCL-TypeD indicates the maximum number of downlink RS resources used for QCL type D in the active TCI states and active spatial relation information, which is optional. 				
The UE is mandated to report spatialRelations for FR2.				
sp-BeamReportPUCCH Indicates support of semi-persistent 'CRI/RSRP' or 'SSBRI/RSRP' reporting using	Band	No	N/A	N/A
PUCCH formats 2, 3 and 4 in one slot. sp-BeamReportPUSCH Indicates support of semi-persistent 'CRI/RSRP' or 'SSBRI/RSRP' reporting on	Band	No	N/A	N/A
PUSCH.		N 1	N1/A	
 srs-AssocCSI-RS Parameters for the calculation of the precoder for SRS transmission based on channel measurements using associated NZP CSI-RS resource (srs-AssocCSI-RS) as described in clause 6.1.1.2 of TS 38.214 [12]. UE supporting this feature shall also indicate support of non-codebook based PUSCH transmission. This capability signalling includes list of the following parameters: maxNumberTxPortsPerResource indicates the maximum number of Tx ports in a resource; 	Band	No	N/A	N/A
- <i>maxNumberResourcesPerBand</i> indicates the maximum number of resources across all CCs within a band simultaneously;				
 totalNumberTxPortsPerBand indicates the total number of Tx ports across all CCs within a band simultaneously. 				

tci-StatePDSCH		Band	Yes	N/A	N/A
	CH. The capability signalling comprises the				
following parameters:					
	esPerCC indicates the maximum number of				
	or PDSCH. For FR2, the UE is mandated to				
	value 128 is an optional value). For FR1, the				
	alues at least to the maximum number of				
allowed SSBs in the supported					
TCI-states per BWP per CC, in active TCI state(s), it is not exp assumption(s) for any PDSCH	P indicates the maximum number of activated cluding control and data. If a UE reports X ected that more than X active QCL type D and any CORESETs for a given BWP of a he UE. The UE shall include this field.				
Note the UE is required to track only t	ne active TCI states.				
The UE is mandated to report tci-State	PDSCH.				
twoPortsPTRS-UL		Band	No	N/A	N/A
	vith 2 antenna ports for UL transmission.				
ue-PowerClass		Band	Yes	N/A	N/A
	nt UE power class than the default UE power	Bunu		1 1// 1	14/71
class as defined in clause 6.2 of TS 3	3.101-1 [2], the UE shall report the supported				
	UE shall report the supported UE power class				
as defined in clause 6 and 7 of TS 38.					
		Pond	Na	NI/A	EDO
uplinkBeamManagement	for LIL. This conchility signalling comprises	Band	No	N/A	FR2
	t for UL. This capability signalling comprises				only
the following parameters:					
	Set-BM indicates the maximum number of				
	rce set configurable for beam management,				
supported by the UE.					
	indicates the maximum number of SRS beam management, supported by the UE.				
-					
	ndenceWithoutUL-BeamSweeping to bability. This feature is optional for the UE that ut uplink beam sweeping as defined in clause				
	berSRS-ResourceSet to determine the				
	esource sets that can be configured to the UE /aperiodic configurations as below:				
ior periodic/semi-persistent					
	Additional constraint on the maximum				
Maximum number of SRS	Additional constraint on the maximum				
Maximum number of SRS resource sets across all time	number of SRS resource sets				
Maximum number of SRS resource sets across all time domain behaviour	number of SRS resource sets configured to the UE for each				
Maximum number of SRS resource sets across all time domain behaviour (periodic/semi-	number of SRS resource sets configured to the UE for each supported time domain behaviour				
Maximum number of SRS resource sets across all time domain behaviour (periodic/semi- persistent/aperiodic) reported in	number of SRS resource sets configured to the UE for each				
Maximum number of SRS resource sets across all time domain behaviour (periodic/semi-	number of SRS resource sets configured to the UE for each supported time domain behaviour				
Maximum number of SRS resource sets across all time domain behaviour (periodic/semi- persistent/aperiodic) reported in <i>maxNumberSRS-ResourceSet</i> 1	number of SRS resource sets configured to the UE for each supported time domain behaviour (periodic/semi-persistent/aperiodic)				
Maximum number of SRS resource sets across all time domain behaviour (periodic/semi- persistent/aperiodic) reported in maxNumberSRS-ResourceSet 1 2	number of SRS resource sets configured to the UE for each supported time domain behaviour (periodic/semi-persistent/aperiodic)				
Maximum number of SRS resource sets across all time domain behaviour (periodic/semi- persistent/aperiodic) reported in maxNumberSRS-ResourceSet 1 2 3	number of SRS resource sets configured to the UE for each supported time domain behaviour (periodic/semi-persistent/aperiodic) 1 1 1				
Maximum number of SRS resource sets across all time domain behaviour (periodic/semi- persistent/aperiodic) reported in maxNumberSRS-ResourceSet 1 2	number of SRS resource sets configured to the UE for each supported time domain behaviour (periodic/semi-persistent/aperiodic)				
Maximum number of SRS resource sets across all time domain behaviour (periodic/semi- persistent/aperiodic) reported in maxNumberSRS-ResourceSet 1 2 3	number of SRS resource sets configured to the UE for each supported time domain behaviour (periodic/semi-persistent/aperiodic) 1 1 1				
Maximum number of SRS resource sets across all time domain behaviour (periodic/semi- persistent/aperiodic) reported in maxNumberSRS-ResourceSet 1 2 3 4	number of SRS resource sets configured to the UE for each supported time domain behaviour (periodic/semi-persistent/aperiodic)				
Maximum number of SRS resource sets across all time domain behaviour (periodic/semi- persistent/aperiodic) reported in maxNumberSRS-ResourceSet 1 2 3 4 5	number of SRS resource sets configured to the UE for each supported time domain behaviour (periodic/semi-persistent/aperiodic) 1 1 1 2 2 2				

4.2.7.3 CA-ParametersEUTRA

Definitions for parameters	Per	м	FDD- TDD DIFF	FR1- FR2 DIFF
additionalRx-Tx-PerformanceReq	BC	No	N/A	N/A
additionalRx-Tx-PerformanceReq defined in 4.3.5.22, TS 36.306 [15].				
<i>dl-1024QAM-TotalWeightedLayers</i> Indicates total number of weighted layers for the LTE part of the concerned (NG)EN-DC/NE-DC band combination the UE can process for 1024QAM, as described in TS 36.306 [15] equation 4.3.5.31-1. Actual value = (10 + indicated value x 2), i.e. value 0 indicates 10 layers, value 1 indicates 12 layers and so on. For an (NG)EN-DC/NE-DC band combination for which this field is not included, <i>dl</i> - <i>1024QAM-TotalWeightedLayers-r15</i> as described in TS 36.331 [17] applies, if	BC	No	N/A	N/A
included.				
multipleTimingAdvance	BC	No	N/A	N/A
multipleTimingAdvance defined in 4.3.5.3, TS 36.306 [15].				
simultaneousRx-Tx	BC	No	N/A	N/A
simultaneousRx-Tx defined in 4.3.5.4, TS 36.306 [15]. supportedBandwidthCombinationSetEUTRA	BC	CY	N/A	N/A
Indicates the set of supported bandwidth combinations for the LTE part for inter- band (NG)EN-DC without intra-band (NG)EN-DC component, inter-band NE-DC without intra-band NE-DC component and intra-band (NG)EN-DC/NE-DC with additional inter-band LTE CA component. The field is encoded as a bit map, where bit N is set to "1" if UE support Bandwidth Combination Set N for this band combination. The leading / leftmost bit (bit 0) corresponds to the Bandwidth Combination Set 0, the next bit corresponds to the Bandwidth Combination Set 1 and so on. The UE shall neither include the field for a (NG)EN-DC/NE-DC combination which has only one LTE carrier, nor for a (NG)EN-DC/NE-DC combination which has more than one LTE carrier for which the UE only supports Bandwidth Combination Set 0 for the LTE part. If the inter-band (NG)EN-DC/NE-DC has more than one LTE carrier, the UE shall support at least one bandwidth combination for the supported LTE part.				
supportedNAICS-2CRS-AP supportedNAICS-2CRS-AP defined in 4.3.5.8, TS 36.306 [15].	BC	No	N/A	N/A
<i>fd-MIMO-TotalWeightedLayers</i> Indicates total number of weighted layers for the LTE part of the concerned (NG)EN-DC/NE-DC band combination the UE can process for FD-MIMO, as described in TS 36.306 [15] equation 4.3.28.13-1 and TS 36.331 [17] clause 6.3.6, NOTE 8 in <i>UE-EUTRA-Capability</i> field descriptions. For an (NG)EN-DC/NE-DC band combination for which this field is not included, <i>totalWeightedLayers-r13</i> as described in TS 36.331 [17] applies, if included.	BC	No	N/A	N/A
ue-CA-PowerClass-N defined in 4.3.5.1.3, TS 36.306 [15].	BC	No	N/A	N/A

4.2.7.4 CA-ParametersNR

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
 csi-RS-IM-ReceptionForFeedbackPerBandComb Indicates support of CSI-RS and CSI-IM reception for CSI feedback. This capability signalling comprises the following parameters: maxNumberSimultaneousNZP-CSI-RS-ActBWP-AllCC indicates the maximum number of simultaneous CSI-RS resources (irrespective of the associated codebook type) in active BWPs across all CCs, and across MCG and SCG in case of NR-DC. The network applies this limit in addition to the limits signalled in MIMO-ParametersPerBand->	BC	Yes	N/A	N/A
total number of CSI-RS ports in simultaneous CSI-RS resources (irrespective of the associated codebook type) in active BWPs across all CCs, and across MCG and SCG in case of NR-DC. The network applies this limit in addition to the limits signalled in <i>MIMO-ParametersPerBand-></i> <i>totalNumberPortsSimultaneousNZP-CSI-RS-PerCC</i> and in <i>Phy-</i> <i>ParametersFRX-Diff-> totalNumberPortsSimultaneousNZP-CSI-RS-PerCC</i> .				
The UE is mandated to report <i>csi-RS-IM-ReceptionForFeedbackPerBandComb</i> . <i>diffNumerologyAcrossPUCCH-Group</i> Indicates whether different numerology across two NR PUCCH groups for data and control channel at a given time in NR CA and (NG)EN-DC/NE-DC is supported by	BC	No	N/A	N/A
the UE. <i>diffNumerologyWithinPUCCH-GroupLargerSCS</i> Indicates whether UE supports different numerology across carriers within a PUCCH group and a same numerology between DL and UL per carrier for data/control channel at a given time in NR CA, (NG)EN-DC/NE-DC and NR-DC. In case of NR CA and (NG)EN-DC/NE-DC with one NR PUCCH group and in case of NR CA with two NR PUCCH groups, it also indicates whether the UE supports different numerologies across NR carriers within the same NR PUCCH group up to two different numerologies within the same NR PUCCH group, wherein NR PUCCH is sent on the carrier with larger SCS for data and control channel at a given time. In case of (NG)EN-DC/NE-DC with two NR PUCCH groups, it indicates whether the UE supports different numerologies across NR carriers up to two different numerologies within an NR PUCCH group in FR1, wherein NR PUCCH is sent on the carrier with larger SCS, and same numerology across NR carriers within another NR PUCCH group in FR2 for data and control channel at a given time. In case of NR-DC, it indicates whether the UE supports different numerologies across NR carriers within the same NR PUCCH group in MCG (in FR1) up to two different numerologies within the same NR PUCCH group wherein NR PUCCH is sent on the carrier with larger SCS for data/control channel at a given time. In case of NR-DC, it indicates whether the UE supports different numerologies across NR carriers within the same NR PUCCH group in MCG (in FR1) up to two different numerologies within the same NR PUCCH group wherein NR PUCCH is sent on the carrier with larger SCS for data/control channel at a given time; and same numerology across NR carriers in SCG (in FR2).	BC	No	N/A	N/A
<i>diffNumerologyWithinPUCCH-GroupSmallerSCS</i> Indicates whether UE supports different numerology across carriers within a PUCCH group and a same numerology between DL and UL per carrier for data/control channel at a given time in NR CA, (NG)EN-DC/NE-DC and NR-DC. In case of NR CA and (NG)EN-DC/NE-DC with one NR PUCCH group and in case of NR CA with two NR PUCCH groups, it also indicates whether the UE supports different numerologies across NR carriers within the same NR PUCCH group up to two different numerologies within the same NR PUCCH group, wherein NR PUCCH is sent on the carrier with smaller SCS for data and control channel at a given time. In case of (NG)EN-DC/NE-DC with two NR PUCCH groups, it indicates whether the UE supports different numerologies across NR carriers up to two different numerologies within an NR PUCCH group in FR1, wherein NR PUCCH is sent on the carrier with smaller SCS, and same numerology across NR carriers within another NR PUCCH group in FR2 for data and control channel at a given time. In case of NR-DC, it indicates whether the UE supports different numerologies across NR carriers within the same NR PUCCH group in MCG (in FR1) up to two different numerologies within the same NR PUCCH group wherein NR PUCCH is sent on the carrier with smaller SCS for data/control channel at a given time.	BC	No	N/A	N/A

	50		N1/A	N1/A
<i>JualPA-Architecture</i> For band combinations with single-band with UL CA, this field indicates the support	BC	No	N/A	N/A
of dual PA. If absent in such band combinations, the UE supports single PA for all				
he ULs. For other band combinations, this field is not applicable.				
parallelTxSRS-PUCCH-PUSCH	BC	No	N/A	N/A
ndicates whether the UE supports parallel transmission of SRS and PUCCH/				
PUSCH across CCs in an inter-band CA band combination.				
parallelTxPRACH-SRS-PUCCH-PUSCH	BC	No	N/A	N/A
ndicates whether the UE supports parallel transmission of PRACH and				
SRS/PUCCH/PUSCH across CCs in an inter-band CA band combination.				
simultaneousCSI-ReportsAllCC	BC	Yes	N/A	N/A
ndicates whether the UE supports CSI report framework and the number of CSI				
eport(s) which the UE can simultaneously process across all CCs, and across				
MCG and SCG in case of NR-DC. The CSI report comprises periodic, semi- persistent and aperiodic CSI and any latency classes and codebook types. The CSI				
eport in <i>simultaneousCSI-ReportsAllCC</i> includes the beam report and CSI report.				
This parameter may further limit simultaneousCSI-ReportsPerCC in MIMO-				
ParametersPerBand and Phy-ParametersFRX-Diff for each band in a given band				
combination.				
simultaneousRxTxInterBandCA	BC	CY	N/A	N/A
ndicates whether the UE supports simultaneous transmission and reception in				
DD-TDD and TDD-FDD inter-band NR CA. If this field is included in ca-				
ParametersNR-ForDC, it indicates the UE supports simultaneous transmission and				
eception between any UL/DL band pair within a cell group and across MCG and				
SCG in TDD-TDD and TDD-FDD inter-band NR-DC. It is mandatory for certain				
[DD-FDD and TDD-TDD band combinations defined in TS 38.101-1 [2], TS 38.101-				
2 [3] and TS 38.101-3 [4].				
simultaneousRxTxInterBandCAPerBandPair	BC	CY	N/A	N/A
ndicates whether the UE supports simultaneous transmission and reception in				
DD-TDD and TDD-FDD inter-band NR CA for each band pair in the band combination.				
Encoded as a bitmap with size L * $(L - 1) / 2$, and bit N (leftmost bit is indexed as bit				
)) is set to "1" if the UE supports simultaneous transmission and reception for band				
bair (x, y), where L is the number of band entries in the band combination, x and y				
are the indices of the band entry in the band combination (the first band entry is				
ndexed as 0), x < y, and N = x*(2*L − x − 1)/2 + y − x − 1.				
f this field is included in ca-ParametersNR-ForDC, each bit of this field indicates				
vhether the UE supports simultaneous transmission and reception between each				
band pair, within a cell group and across MCG and SCG in TDD-TDD and TDD-				
DD inter-band NR-DC.				
The UE does not include this field if the UE supports simultaneous transmission and				
eception for all applicable band pairs in the band combination (in which case				
simultaneousRxTxInterBandCA is included) or does not support for any band pair in				
he band combination. It is mandatory for certain band pairs as specified in TS				
38.101-1 [2], TS 38.101-2 [3] and TS 38.101-3 [4]. The UE shall consistently set the bits which correspond to the same band pair.				
simultaneousRxTxSUL	BC	CY	N/A	N/A
ndicates whether the UE supports simultaneous reception and transmission for a			ר <i>יו</i> אי ד	11//
NR band combination including SUL. Mandatory/Optional support depends on band				
combination and captured in TS 38.101-1 [2].				
simultaneousRxTxSULPerBandPair	BC	CY	N/A	N/A
ndicates whether the UE supports simultaneous reception and transmission for a				
NR band combination including SUL for each band pair in the band combination.				
Encoded in the same manner as simultaneousRxTxInterBandCAPerBandPair.				
The UE does not include this field if the UE supports simultaneous transmission and				
eception for all applicable band pairs in the band combination (in which case				
simultaneousRxTxSUL is included) or does not support for any band pair in the				
band combination. It is mandatory for certain band pairs as specified in TS 38.101-1				
2]. The UE shall consistently set the bits which correspond to the same band pair. simultaneousSRS-AssocCSI-RS-AIICC		NI-	N1/A	N1/A
	BC	No	N/A	N/A
		1		
ndicates support of CSI-RS processing framework for SRS and the number of SRS				
ndicates support of CSI-RS processing framework for SRS and the number of SRS esources that the UE can process simultaneously across all CCs, and across MCG				
ndicates support of CSI-RS processing framework for SRS and the number of SRS esources that the UE can process simultaneously across all CCs, and across MCG and SCG in case of NR-DC, including periodic, aperiodic and semi-persistent SRS.				
ndicates support of CSI-RS processing framework for SRS and the number of SRS esources that the UE can process simultaneously across all CCs, and across MCG				
		1		

supportedNumberTAG Defines the number of timing advance groups supported by the UE. It is applied to NR CA, NR-DC and (NG)EN-DC/NE-DC. For (NG)EN-DC/NE-DC, it indicates number of TAGs only for NR CG. The number of TAGs for the LTE MCG is signalled by existing LTE TAG capability signalling. For NR CA/NR-DC band combination, if the band combination comprised of more than one band entry (i.e., inter-band or intra-band non-contiguous band combination), it indicates that different timing advances on different band entries are supported. If absent, the UE supports only one TAG for the NR part. It is mandatory for the UE to support more than one TAG for NR-DC. For the mixed inter-band and intra-band NR CA/NR-DC band combination, if the network configures more non-contiguous UL serving cells than the number of supported TAG, the UE only supports the configuration where all UL CCs of the same frequency band are configured with the same Timing Advance Group ID.	BC	CY	N/A	N/A	
---	----	----	-----	-----	--

4.2.7.5 *FeatureSetDownlink* parameters

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
additionalDMRS-DL-Alt Indicates whether the UE supports the alternative additional DMRS position for co- existence with LTE CRS. It is applied to 15kHz SCS and one additional DMRS case only.	FS	No	N/A	FR1 only
<i>csi-RS-MeasSCellWithoutSSB</i> Defines whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured for a cell that does not transmit SS/PBCH block. A UE that supports this feature shall also support scellWithoutSSB.	FS	No	N/A	N/A
<i>dl-MCS-TableAlt-DynamicIndication</i> Indicates whether the UE supports dynamic indication of MCS table for PDSCH.	FS	No	N/A	N/A
featureSetListPerDownlinkCC Indicates which features the UE supports on the individual DL carriers of the feature set (and hence of a band entry that refer to the feature set) by <i>FeatureSetDownlinkPerCC-Id.</i> The order of the elements in this list is not relevant, i.e., the network may configure any of the carriers in accordance with any of the <i>FeatureSetDownlinkPerCC-Id</i> in this list. A fallback per CC feature set resulting from the reported feature set per DL CC is not signalled but the UE shall support it.	FS	N/A	N/A	N/A
<i>intraBandFreqSeparationDL</i> Indicates DL frequency separation class the UE supports, which indicates a maximum frequency separation between lower edge of lowest CC and upper edge of highest CC in a frequency band, for intra-band non-contiguous CA. The UE sets the same value in the FeatureSetDownlink of each band entry within a band. The values c1, c2 and c3 correspond to the values defined in TS 38.101-2 [3]. It is mandatory to report for UE which supports DL intra-band non-contiguous CA in FR2.	FS	CY	N/A	FR2 only
oneFL-DMRS-ThreeAdditionalDMRS-DL Defines whether the UE supports DM-RS pattern for DL transmission with 1 symbol front-loaded DM-RS with three additional DM-RS symbols.	FS	No	N/A	N/A
oneFL-DMRS-TwoAdditionalDMRS-DL Defines support of DM-RS pattern for DL transmission with 1 symbol front-loaded DM-RS with 2 additional DM-RS symbols and more than 1 antenna ports.	FS	Yes	N/A	N/A
pdcch-MonitoringAnyOccasions Defines the supported PDCCH search space monitoring occasions. withoutDCI-gap indicates whether the UE supports PDCCH search space monitoring occasions in any symbol of the slot for Type 1-PDCCH common search space configured by dedicated RRC signalling, for a Type 3-PDCCH common search space, or for a UE-specific search space with the capability of supporting at least 44, 36, 22, and 20 blind decodes in a slot for 15 kHz, 30 kHz, 60kHz, and 120 kHz subcarrier spacing values respectively. withDCI-gap indicates whether the UE supports PDCCH search space monitoring occasions in any symbol of the slot with minimum time separation of two OFDM symbols for 15 kHz, four OFDM symbols for 30 kHz, seven OFDM symbols for 60 kHz with NCP, and 140FDM symbols for 120kHz between two consecutive transmissions of PDCCH scarambled with C-RNTI, MCS-C-RNTI, or CS-RNTI for Type 1-PDCCH common search space, or for a UE-specific search space, with the capability of supporting at least 44, 36, 22, and 20 blind decodes in a slot for 15 kHz, 30 kHz, 60kHz, and 120 kHz subcarrier spacing space.	FS	No	N/A	N/A
<i>pdcch-MonitoringAnyOccasionsWithSpanGap</i> Indicates whether the UE supports PDCCH search space monitoring occasions in any symbol of the slot with minimum time separation between two consecutive transmissions of PDCCH with span up to two OFDM symbols for two OFDM symbols or span up to three OFDM symbols for four and seven OFDM symbols. Value set1 indicates the supported value set (X,Y) is (7,3), value set2 indicates the supported value set (X,Y) is (4,3) and (7,3) and value set 3 indicates the supported value set (X,Y) is (2,2), (4,3) and (7,3).	FS	No	N/A	N/A
<i>pdsch-ProcessingType1-DifferentTB-PerSlot</i> Defines whether the UE capable of processing time capability 1 supports reception of up to two, four or seven unicast PDSCHs for several transport blocks with PDSCH scrambled using C-RNTI, TC-RNTI, MCS-C-RNTI or CS-RNTI in one serving cell within the same slot per CC that are multiplexed in time domain only. Note PDSCH(s) for Msg.4 is included.	FS	No	N/A	N/A

pdsch-ProcessingType2	FS	No	N/A	FR1
Indicates whether the UE supports PDSCH processing capability 2. The UE				only
supports it only if all serving cells are self-scheduled and if all serving cells in one				
band on which the network configured processingType2 use the same subcarrier				
spacing. This capability signalling comprises the following parameters for each sub-				
carrier spacing supported by the UE.				
 fallback indicates whether the UE supports PDSCH processing capability 2 				
when the number of configured carriers is larger than numberOfCarriers for a				
reported value of <i>differentTB-PerSlot</i> . If <i>fallback</i> = 'sc', UE supports				
capability 2 processing time on lowest cell index among the configured				
carriers in the band where the value is reported, if <i>fallback</i> = 'cap1-only', UE				
supports only capability 1, in the band where the value is reported;				
- differentTB-PerSlot indicates whether the UE supports processing type 2 for				
1, 2, 4 and/or 7 unicast PDSCHs for different transport blocks per slot per				
CC; and if so, it indicates up to which number of CA serving cells the UE				
supports that number of unicast PDSCHs for different TBs. The UE shall				
include at least one of numberOfCarriers for 1, 2, 4 or 7 transport blocks per				
slot in this field if <i>pdsch-ProcessingType2</i> is indicated.				
pdsch-ProcessingType2-Limited	FS	No	N/A	FR1
Indicates whether the UE supports PDSCH processing capability 2 with scheduling				only
limitation for SCS 30kHz. This capability signalling comprises the following				
parameter.				
 differentTB-PerSlot-SCS-30kHz indicates the number of different TBs per 				
slot.				
The UE supports this limited processing capability 2 only if:				
 One carrier is configured in the band, independent of the number of carriers 				
configured in the other bands;				
2) The maximum bandwidth of PDSCH is 136 PRBs;				
3) N1 based on Table 5.3-2 of TS 38.214 [12] for SCS 30 kHz.				
pdsch-SeparationWithGap	FS	No	N/A	N/A
Indicates whether the UE supports separation of two unicast PDSCHs with a gap,				
applicable to Sub-carrier spacings of 30 kHz and 60 kHz only. For any two				
consecutive slots n and n+1, if there are more than 1 unicast PDSCH in either slot,				
the minimum time separation between starting time of any two unicast PDSCHs				
within the duration of these slots is 4 OFDM symbols for 30kHz and 7 OFDM				
symbols for 60kHz.				
scalingFactor	FS	No	N/A	N/A
Indicates the scaling factor to be applied to the band in the max data rate				
calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75				
indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the				
max data rate calculation.				
scellWithoutSSB	FS	CY	N/A	N/A
Defines whether the UE supports configuration of SCell that does not transmit				
SS/PBCH block. This is conditionally mandatory with capability signalling for intra-				
band CA but not supported for inter-band CA.				
searchSpaceSharingCA-DL	FS	No	N/A	N/A
Defines whether the UE supports DL PDCCH search space sharing for carrier				
	1	1		1

<i>supportedSRS-Resources</i> Defines support of SRS resources for SRS carrier switching for a band without associated FeatureSetuplink. The capability signalling comprising indication of:	FS	FD	N/A	N/A
 maxNumberAperiodicSRS-PerBWP indicates supported maximum number of aperiodic SRS resources that can be configured for the UE per each BWP 				
 maxNumberAperiodicSRS-PerBWP-PerSlot indicates supported maximum number of aperiodic SRS resources per slot in the BWP 				
 maxNumberPeriodicSRS-PerBWP indicates supported maximum number of periodic SRS resources per BWP 				
 maxNumberPeriodicSRS-PerBWP-PerSlot indicates supported maximum number of periodic SRS resources per slot in the BWP 				
 maxNumberSemiPersistentSRS-PerBWP indicate supported maximum number of semi-persistent SRS resources that can be configured for the UE per each BWP 				
 maxNumberSemiPersistentSRS-PerBWP-PerSlot indicates supported maximum number of semi-persistent SRS resources per slot in the BWP 				
 maxNumberSRS-Ports-PerResource indicates supported maximum number of SRS antenna port per each SRS resource 				
If the UE indicates the support of srs-CarrierSwitch for this band and this field is absent, the UE suports one periodic, one aperiodic, no semi-persistent SRS resources per BWP per slot and one SRS antenna port per SRS resource.				
timeDurationForQCL	FS	Yes	N/A	FR2
Defines minimum number of OFDM symbols required by the UE to perform PDCCH				only
reception and applying spatial QCL information received in DCI for PDSCH				
processing as described in TS 38.214 [12] clause 5.1.5. The number of OFDM symbols is measured from the end of the last symbol of the PDCCH reception to the				
start of the first symbol of the PDSCH reception. UE shall indicate one value of the				
minimum number of OFDM symbols per each subcarrier spacing of 60kHz and				
120kHz.				
twoFL-DMRS-TwoAdditionalDMRS-DL	FS	No	N/A	N/A
Defines whether the UE supports DM-RS pattern for DL transmission with 2				
symbols front-loaded DM-RS with one additional 2 symbols DM-RS. type1-3-CSS	ES	Vaa	NI/A	FR2
<i>type1-3-CSS</i> Defines whether the UE is able to receive PDCCH in FR2 in a Type1-PDCCH	FS	Yes	N/A	only
common search space configured by dedicated RRC signalling, in a Type3-PDCCH				Uniy
common search space or a UE-specific search space if those are associated with a				
CORESET with a duration of 3 symbols.				
ue-SpecificUL-DL-Assignment	FS	No	N/A	N/A
Indicates whether the UE supports dynamic determination of UL and DL link				
direction and slot format based on Layer 1 scheduling DCI and higher layer				
configured parameter TDD-UL-DL-ConfigDedicated as specified in TS 38.213 [11].				

4.2.7.6 *FeatureSetDownlinkPerCC* parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
<i>channelBW-90mhz</i> Indicates whether the UE supports the channel bandwidth of 90 MHz.	FSPC	No	N/A	FR1 only
<i>maxNumberMIMO-LayersPDSCH</i> Defines the maximum number of spatial multiplexing layer(s) supported by the UE for DL reception. For single CC standalone NR, it is mandatory with capability signalling to support at least 4 MIMO layers in the bands where 4Rx is specified as mandatory for the given UE and at least 2 MIMO layers in FR2. If absent, the UE does not support MIMO on this carrier.	FSPC	CY	N/A	N/A
 SupportedBandwidthDL Indicates maximum DL channel bandwidth supported for a given SCS that UE supports within a single CC, which is defined in Table 5.3.5-1 in TS 38.101-1 [2] for FR1 and Table 5.3.5-1 in TS 38.101-2 [3] for FR2. For FR1, all the bandwidths listed in TS38.101-1 Table 5.3.5-1 for each band shall be mandatory with a single CC unless indicated optional. For FR2, the set of mandatory CBW is 50, 100, 200 MHz. When this field is included in a band combination with a single band entry and a single CC entry (i.e. non-CA band combination), the UE shall indicate the maximum channel bandwidth for the band according to TS 38.101-1 [2] and TS 38.101-2 [3]. The UE may report a supportedBandwidthDL wider than the channelBWs-DL; this supportedBandwidthDL may not be included in the Table 5.3.5-1 of TS 38.101-1 [2]/TS 38.101-2[3] for the case that the UE is unable to report the actual supported bandwidth according to the Table 5.3.5-1 of TS 38.101-2[3]. NOTE: To determine whether the UE supports a channel bandwidth of 90 MHz, the network may ignore this capability and validate instead the channelBW-90mhz, the supportedBandwidthCombinationSetIntraENDC. For serving cell(s) with other channel bandwidth CombinationSetIntraENDC, the asymmetricBandwidthCombinationSet(for a band supporting asymmetric channel bandwidthDL. 	FSPC	CY	N/A	N/A
 supportedModulationOrderDL Indicates the maximum supported modulation order to be applied for downlink in the carrier in the max data rate calculation as defined in 4.1.2. If included, the network may use a modulation order on this serving cell which is higher than the value indicated in this field as long as UE supports the modulation of higher value for downlink. If not included: for FR1, the network uses the modulation order signalled in <i>pdsch-256QAM-FR1</i>. for FR2, the network uses the modulation order signalled per band i.e. <i>pdsch-256QAM-FR2</i> if signalled. If not signalled in a given band, the network shall use the modulation order 64QAM. In all the cases, it shall be ensured that the data rate does not exceed the max data rate (<i>DataRate</i>) and max data rate per CC (<i>DataRateCC</i>) according to TS 38.214 [12]. 	FSPC	No	N/A	N/A
supportedSubCarrierSpacingDL Defines the supported sub-carrier spacing for DL by the UE, as defined in clause 4.2-1 of TS 38.211 [6], indicating the UE supports simultaneous reception with same or different numerologies in CA. Support of simultaneous reception with same numerology for intra-band NR CA including both contiguous and non-contiguous is mandatory with capability in both FR1 and FR2. Support of simultaneous reception with two different numerologies between FR1 band(s) and FR2 band(s) in DL is mandatory with capability if UE supports inter-band NR CA including both FR1 band(s) and FR2 band(s). Optional for other cases. Support of simultaneous reception of with different numerologies in CA for other cases is optional.	FSPC	CY	N/A	N/A

4.2.7.7 *FeatureSetUplink* parameters

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.	FS	No	N/A	N/A
<i>dynamicSwitchSUL</i> Indicates whether the UE supports supplemental uplink with dynamic switch (DCI based selection of PUSCH carrier). The UE supports this among a carrier on a band X and a band Y if it sets this capability parameter for both band X and band Y.	FS	No	N/A	N/A
featureSetListPerUplinkCC Indicates which features the UE supports on the individual UL carriers of the feature set (and hence of a band entry that refer to the feature set) by <i>FeatureSetUplinkPerCC-Id</i> . The order of the elements in this list is not relevant, i.e., the network may configure any of the carriers in accordance with any of the <i>FeatureSetUplinkPerCC-Id</i> in this list. A fallback per CC feature set resulting from the reported feature set per UL CC is not signalled but the UE shall support it.	FS	N/A	N/A	N/A
<i>intraBandFreqSeparationUL</i> Indicates UL frequency separation class the UE supports, which indicates a maximum frequency separation between lower edge of lowest CC and upper edge of highest CC in a frequency band, for intra-band non-contiguous CA. The UE sets the same value in the FeatureSetUplink of each band entry within a band. The values c1, c2 and c3 corresponds to the values defined in TS 38.101-2 [3]. It is mandatory to report for UE which supports UL non-contiguous CA in FR2.	FS	CY	N/A	FR2 only
pa-PhaseDiscontinuityImpacts Indicates incapability motivated by impacts of PA phase discontinuity with overlapping transmissions with non-aligned starting or ending times or hop boundaries across carriers for intra-band (NG)EN-DC/NE-DC, intra-band CA and FDM based ULSUP. This capability applies to: - Intra-band (NG)EN-DC/NE-DC combination without additional inter-band NR	FS	No	N/A	N/A
 and LTE CA component; Intra-band (NG)EN-DC/NE-DC combination supporting both UL and DL intra- band (NG)EN-DC/NE-DC parts with additional inter-band NR/LTE CA component; Inter-band (NG)EN-DC/NE-DC combination, where the frequency range of the E-UTRA band is a subset of the frequency range of the NR band (as specified in Table 5.5B.4.1-1 of TS 38.101-3 [4]). 				
If this capability is included in an "Intra-band (NG)EN-DC/NE-DC combination supporting both UL and DL intra-band (NG)EN-DC/NE-DC parts with additional inter-band NR/LTE CA component", this capability applies to the intra-band (NG)EN-DC/NE-DC BC part.				
pusch-ProcessingType1-DifferentTB-PerSlot Indicates whether the UE capable of processing time capability 1 supports transmission of up to two, four or seven unicast PUSCHs for several transport blocks in one serving cell within the same slot per CC that are multiplexed in time domain only.	FS	No	N/A	N/A

	50			
 pusch-ProcessingType2 Indicates whether the UE supports PUSCH processing capability 2. The UE supports it only if all serving cells are self-scheduled and if all serving cells in one band on which the network configured processingType2 use the same subcarrier spacing. This capability signalling comprises the following parameters for each subcarrier spacing supported by the UE. fallback indicates whether the UE supports PUSCH processing capability 2 when the number of configured carriers is larger than numberOfCarriers for a reported value of differentTB-PerSlot. If fallback = 'sc', UE supports capability 2 processing time on lowest cell index among the configured carriers in the band where the value is reported, if fallback = 'cap1-only', UE supports only capability 1, in the band where the value is reported; 	FS	No	N/A	FR1 only
 differentTB-PerSlot indicates whether the UE supports processing type 2 for 1, 2, 4 and/or 7 unicast PUSCHs for different transport blocks per slot per CC; and if so, it indicates up to which number of CA serving cells the UE supports that number of unicast PUSCHs for different TBs. The UE shall include at least one of numberOfCarriers for 1, 2, 4 or 7 transport blocks per slot in this field if pusch-ProcessingType2 is indicated. 				
pusch-SeparationWithGap Indicates whether the UE supports separation of two unicast PUSCHs with a gap, applicable to Sub-carrier spacings of 15 kHz, 30 kHz and 60 kHz only. For any two consecutive slots n and n+1, if there are more than 1 unicast PUSCH in either slot, the minimum time separation between starting time of any two unicast PUSCHs within the duration of these slots is 2 OFDM symbols for 15kHz, 4 OFDM symbols for 30kHz and 7 OFDM symbols for 60kHz.	FS	No	N/A	N/A
searchSpaceSharingCA-UL Defines whether the UE supports UL PDCCH search space sharing for carrier	FS	No	N/A	N/A
aggregation operation. simultaneous TxSUL-NonSUL Indicates whether the UE supports simultaneous transmission of SRS on an SUL/non-SUL carrier and PUSCH/PUCCH/SRS on the other UL carrier in the same cell. The UE supports simultaneous transmission on an SUL band X and a Non- SUL band Y if it sets this capability parameter for both band X and band Y.	FS	No	N/A	N/A
supportedSRS-Resources Defines support of SRS resources. The capability signalling comprising indication of:	FS	FD	N/A	N/A
 maxNumberAperiodicSRS-PerBWP indicates supported maximum number of aperiodic SRS resources that can be configured for the UE per each BWP 				
 maxNumberAperiodicSRS-PerBWP-PerSlot indicates supported maximum number of aperiodic SRS resources per slot in the BWP 				
 maxNumberPeriodicSRS-PerBWP indicates supported maximum number of periodic SRS resources per BWP 				
 maxNumberPeriodicSRS-PerBWP-PerSlot indicates supported maximum number of periodic SRS resources per slot in the BWP 				
 maxNumberSemiPersistentSRS-PerBWP indicate supported maximum number of semi-persistent SRS resources that can be configured for the UE per each BWP 				
 maxNumberSemiPersistentSRS-PerBWP-PerSlot indicates supported maximum number of semi-persistent SRS resources per slot in the BWP 				
 maxNumberSRS-Ports-PerResource indicates supported maximum number of SRS antenna port per each SRS resource 				
If this field is not included, the UE suports one periodic, one aperiodic, no semi- persistent SRS resources per BWP and one periodic, one aperiodic, no semi- persistent SRS resources per BWP per slot and one SRS antenna port per SRS resource.				

twoPUCCH-Group Indicates whether two PUCCH group in CA with a same numerology across CCs for data and control channel [at a given time] is supported by the UE. For NR CA, two PUCCH group is supported with the same numerology across NR carriers for data and control channel at a given time. For (NG)EN-DC/NE-DC, two PUCCH group is supported with the same numerology across NR carriers for data and control channel at a given time. For (NG)EN-DC/NE-DC, two PUCCH group is supported with the same numerology across NR carriers for data and control channel at a given time, wherein an NR PUCCH group is configured in FR1 and another NR PUCCH group is configured in FR2. The UE supports two PUCCH groups with PUCCH on a band X and a band Y if it sets this capability parameter for both band X and band Y.	FS	No	N/A	N/A
<i>ul-MCS-TableAlt-DynamicIndication</i> Indicates whether the UE supports dynamic indication of MCS table using MCS-C-RNTI for PUSCH.	FS	No	N/A	N/A
zeroSlotOffsetAperiodicSRS Indicates whether the UE supports 0 slot offset between aperiodic SRS triggering and transmission, for SRS for CB PUSCH and antenna switching on FR1.	FS	No	N/A	N/A

4.2.7.8 *FeatureSetUplinkPerCC* parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
<i>channelBW-90mhz</i> Indicates whether the UE supports the channel bandwidth of 90 MHz.	FSPC	No	N/A	FR1 only
<i>maxNumberMIMO-LayersCB-PUSCH</i> Defines supported maximum number of MIMO layers at the UE for PUSCH transmission with codebook precoding. UE indicating support of this feature shall also indicate support of PUSCH codebook coherency subset. This feature is not supported for SUL.	FSPC	No	N/A	N/A
<i>maxNumberMIMO-LayersNonCB-PUSCH</i> Defines supported maximum number of MIMO layers at the UE for PUSCH transmission using non-codebook precoding. This feature is not supported for SUL. UE supporting non-codebook based PUSCH transmission shall indicate support of <i>maxNumberMIMO-LayersNonCB-PUSCH, maxNumberSRS-ResourcePerSet</i> and <i>maxNumberSimultaneousSRS-ResourceTx</i> together.	FSPC	No	N/A	N/A
maxNumberSimultaneousSRS-ResourceTx Defines the maximum number of simultaneous transmitted SRS resources at one symbol for non-codebook based transmission to the UE. This feature is not supported for SUL.	FSPC	No	N/A	N/A
<i>maxNumberSRS-ResourcePerSet</i> Defines the maximum number of SRS resources per SRS resource set configured for codebook or non-codebook based transmission to the UE. This feature is not supported for SUL.	FSPC	No	N/A	N/A
 supportedBandwidthUL Indicates maximum UL channel bandwidth supported for a given SCS that UE supports within a single CC, which is defined in Table 5.3.5-1 in TS38.101-1 [2] for FR1 and Table 5.3.5-1 in TS 38.101-2 [3] for FR2. For FR1, all the bandwidths listed in TS38.101-1 Table 5.3.5-1 for each band shall be mandatory with a single CC unless indicated optional. For FR2, the set of mandatory CBW is 50, 100, 200 MHz. When this field is included in a band combination with a single band entry and a single CC entry (i.e. non-CA band combination), the UE shall indicate the maximum channel bandwidth for the band according to TS 38.101-1 [2] and TS 38.101-2 [3]. The UE may report a supportedBandwidthUL wider than the channelBWs-UL; this supportedBandwidthUL may not be included in the Table 5.3.5-1 of TS 38.101-1 [2]/TS 38.101-2[3] for the case that the UE is unable to report the actual supported bandwidth according to the Table 5.3.5-1 of TS 38.101-2[3]. NOTE: To determine whether the UE supports a channel bandwidth of 90 MHz the network may ignore this capability and validate instead the channelBW-90mhz, the supportedBandwidthCombinationSet and the supportedBandwidthCombinationSet intraENDC. For serving cell(s) with other channel bandwidth combinationSet, the supportedBandwidthCombinationSet (for a band supporting asymmetric channel bandwidth as defined in clause 5.3.6 of TS 38.101-1 [2] and supportedBandwidthUL 	FSPC	CY	N/A	N/A
 supportedModulationOrderUL Indicates the maximum supported modulation order to be applied for uplink in the carrier in the max data rate calculation as defined in 4.1.2. If included, the network may use a modulation order on this serving cell which is higher than the value indicated in this field as long as UE supports the modulation of higher value for uplink. If not included, for FR1 and FR2, the network uses the modulation order signalled per band i.e. <i>pusch-256QAM</i> if signalled. If not signalled in a given band, the network shall use the modulation order 64QAM. In all the cases, it shall be ensured that the data rate does not exceed the max data rate (<i>DataRate</i>) and max data rate per CC (<i>DataRateCC</i>) according to TS 38.214 [12]. 	FSPC	No	N/A	N/A

supportedSubCarrierSpacingUL	FSPC	CY	N/A	N/A
Defines the supported sub-carrier spacing for UL by the UE, as defined in 4.2-1 of				
TS 38.211 [6], indicating the UE supports simultaneous transmission with same or				
different numerologies in CA, or indicating the UE supports different numerologies				
on NR UL and SUL within one cell. Support of simultaneous transmissions with				
same numerology for intra-band NR CA including both contiguous and non-				
contiguous is mandatory with capability in both FR1 and FR2. Support of				
simultaneous transmission with two different numerologies between FR1 band(s)				
and FR2 band(s) in UL is mandatory with capability if UE supports inter-band NR				
CA including both FR1 band(s) and FR2 band(s). Support of simultaneous				
transmission with different numerologies in CA for other cases is optional.				

4.2.7.9 *MRDC-Parameters*

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
asyncIntraBandENDC Indicates whether the UE supports asynchronous FDD-FDD intra-band (NG)EN-DC with MRTD and MTTD as specified in clause 7.5 and 7.6 of TS 38.133 [5]. If asynchronous FDD-FDD intra-band (NG)EN-DC is not supported, the UE supports only synchronous FDD-FDD intra-band (NG)EN-DC.	BC	No	FDD only	FR1 only
 This capability applies to: Intra-band (NG)EN-DC combination without additional inter-band NR and LTE CA component; Intra-band (NG)EN-DC combination supporting both UL and DL intra-band (NG)EN-DC parts with additional inter-band NR/LTE CA component; Intra-band (NG)EN-DC combination without supporting UL in both the bands of the intra-band (NG)EN-DC UL part; Inter-band (NG)EN-DC combination, where the frequency range of the E-UTRA band is a subset of the frequency range of the NR band (as specified in Table 5.5B.4.1-1 of TS 38.101-3 [4]). 				
If this capability is included in an "Intra-band (NG)EN-DC combination supporting both UL and DL intra-band (NG)EN-DC parts with additional inter-band NR/LTE CA component" or in an "Intra-band (NG)EN-DC combination without supporting UL in both the bands of the intra-band (NG)EN-DC UL part", this capability applies to the intra-band (NG)EN-DC BC part.				
<i>dualPA-Architecture</i> For an intra-band band combination, this field indicates the support of dual PAs. If absent in an intra-band band combination, the UE supports single PA for all the ULs in the intra-band band combination. For other band combinations, this field is not applicable.	BC	No	N/A	N/A
 This capability applies to: Intra-band (NG)EN-DC/NE-DC combination without additional inter-band NR and LTE CA component; Intra-band (NG)EN-DC/NE-DC combination supporting both UL and DL intraband (NG)EN-DC/NE-DC parts with additional inter-band NR/LTE CA component; Inter-band (NG)EN-DC/NE-DC combination, where the frequency range of the E-UTRA band is a subset of the frequency range of the NR band (as specified in Table 5.5B.4.1-1 of TS 38.101-3 [4]). 				
If this capability is included in an "Intra-band (NG)EN-DC/NE-DC combination supporting both UL and DL intra-band (NG)EN-DC/NE-DC parts with additional inter-band NR/LTE CA component", this capability applies to the intra-band (NG)EN-DC/NE-DC BC part.				
<i>dynamicPowerSharingENDC</i> Indicates whether the UE supports dynamic (NG)EN-DC power sharing between NR FR1 carriers and the LTE carriers. If the UE supports this capability the UE supports the dynamic power sharing behaviour as specified in clause 7 of TS 38.213 [11].	BC	Yes	N/A	FR1 only
<i>dynamicPowerSharingNEDC</i> Indicates whether the UE supports dynamic NE-DC power sharing between NR FR1 carriers and the LTE carriers. If the UE supports this capability, the UE supports the dynamic power sharing behavior as specified in clause 7 of TS 38.213 [11].	BC	Yes	N/A	FR1 only
<i>intraBandENDC-Support</i> Indicates whether the UE supports intra-band (NG)EN-DC with only non-contiguous spectrum, or with both contiguous and non-contiguous spectrum for the (NG)EN-DC combination as specified in TS 38.101-3 [4]. If the UE does not include this field for an intra-band (NG)EN-DC combination the UE only supports the contiguous spectrum for the intra-band (NG)EN-DC combination.	BC	No	N/A	N/A

interBandContiguousMRDC	BC	CY	N/A	N/A
Indicates for an inter-band (NG)EN-DC/NE-DC combination, where the frequency				
range of the E-UTRA band is a subset of the frequency range of the NR band (as				
specified in Table 5.5B.4.1-1 of TS 38.101-3 [4]), that the UE supports intra-band				
contiguous (NG)EN-DC/NE-DC requirements (see TS 38.101-3 [4]). If the field is				
absent for such an inter-band (NG)EN-DC/NE-DC combination, the UE supports				
intra-band non-contiguous (NG)EN-DC/NE-DC requirements.				
simultaneousRxTxInterBandENDC	BC	CY	N/A	N/A
Indicates whether the UE supports simultaneous transmission and reception in				
TDD-TDD and TDD-FDD inter-band (NG)EN-DC/NE-DC. It is mandatory for certain				
TDD-FDD and TDD-TDD band combinations defined in TS 38.101-3 [4].				
This capability applies to:				
- TDD-TDD and TDD-FDD Intra-band (NG)EN-DC/NE-DC combination				
supporting both UL and DL intra-band (NG)EN-DC/NE-DC parts with				
additional inter-band NR/LTE CA component;				
- TDD-TDD and TDD-FDD Intra-band (NG)EN-DC/NE-DC combination				
without supporting UL in both the bands of the intra-band (NG)EN-DC/NE-				
DC UL part;				
- TDD-TDD and TDD-FDD Inter-band (NG)EN-DC/NE-DC combination				
without Intra-band component.				
This capability is not applicable to the inter-band (NG)EN-DC/NE-DC combination,				
where the frequency range of the E-UTRA band is a subset of the frequency range				
of the NR band (as specified in Table 5.5B.4.1-1 of TS 38.101-3 [4]).				
simultaneousRxTxInterBandENDCPerBandPair	BC	CY	N/A	N/A
Indicates whether the UE supports simultaneous transmission and reception in	ЪС		IN/A	
TDD-TDD and TDD-FDD inter-band (NG)EN-DC/NE-DC for each band pair in the				
band combination.				
Encoded in the same manner as <i>simultaneousRxTxInterBandCAPerBandPair</i> .				
The UE does not include this field if the UE supports simultaneous transmission and				
reception for all applicable band pairs in the band combination (in which case				
simultaneousRxTxInterBandENDC is included) or does not support for any band				
pair in the band combination. It is mandatory for certain band pairs as specified in				
TS 38.101-3 [4]. The UE shall consistently set the bits which correspond to the				
same band pair.				
Each bit of the capability only applies to TDD-TDD and TDD-FDD Inter-band				
(NG)EN-DC/NE-DC band pairs, except for the band pairs where the frequency				
range of the E-UTRA band is a subset of the frequency range of the NR band (as				
specified in Table 5.5B.4.1-1 of TS 38.101-3 [4]).				
singleUL-Transmission	BC	FD	N/A	N/A
Indicates that the UE does not support simultaneous UL transmissions as defined in	50		1 1/77	11/7
TS 38.101-3 [4]. The UE may only include this field for certain band combinations				
defined in TS 38.101-3 [4]. If included for a particular band combination, the field				
applies to all fallback band combinations of this band combination, the field				
in TS 38.101-3 [4] as being allowed to include this field and does not apply to any				
other fallback band combinations defined in TS 38.101-3 [4].				
The UE shall include this field for band combinations containing a band pair for				
which single UL transmission is the only specified operation mode in TS 38.101-3				
[4] and if the UE supports UL on both bands. Otherwise, this feature is optional.				
spCellPlacement	UE	No	N/A	N/A
Indicates whether the UE supports a SpCell on FR1-FDD, FR1-TDD and/or FR2-	UE		IN/A	IN/A
TDD depending on which additional SCells of other frequency range(s) / duplex				
mode(s) are configured. It is applicable to SCG of (NG)EN-DC and MCG of NE-DC,				
where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in				
a cell group. If not included, the UE supports SpCell on any serving cell with UL in				
supported band combinations.	D O		N1/A	
tdm-Pattern	BC	CY	N/A	FR1
Indicates whether the UE supports the <i>tdm-PatternConfig</i> for <i>single UL-transmission</i>				only
associated functionality, as specified in TS 36.331 [17]. Support is conditionally				
mandatory in (NG)EN-DC for UEs that do not support dynamicPowerSharingENDC				
and for UEs that indicate single UL transmission for any (NG)EN-DC BC. Support is				
conditionally mandatory in NE-DC for UEs that do not support				
dynamicPowerSharingNEDC and for UEs that indicate single UL transmission for				
any NE-DC BC. The feature is optional otherwise.				

<i>ul-SharingEUTRA-NR</i> Indicates whether the UE supports (NG)EN-DC/NE-DC with EUTRA-NR coexistence in UL sharing via TDM only, FDM only, or both TDM and FDM from UE perspective as specified in TS 38.101-3 [4].	BC	No	N/A	FR1 only
<i>ul-SwitchingTimeEUTRA-NR</i> Indicates support of switching type between LTE UL and NR UL for (NG)EN- DC/NE-DC with LTE-NR coexistence in UL sharing from UE perspective as defined in clause 6.3B of TS 38.101-3 [4]. It is mandatory to report switching time type 1 or type 2 if UE reports <i>ul-SharingEUTRA-NR</i> is <i>tdm</i> or <i>both</i> .	BC	CY	N/A	FR1 only
 <i>ul-TimingAlignmentEUTRA-NR</i> Indicates whether to apply the same UL timing between NR and LTE for dynamic power sharing capable UE operating in a synchronous intra-band contiguous (NG)EN-DC. If this field is absent, UE shall be capable of handling a timing difference up to applicable MTTD requirements when operating in a synchronous intra-band contiguous (NG)EN-DC network, as specified in TS 38.133 [5]. This capability applies to: Intra-band contiguous (NG)EN-DC combination without additional inter-band NR and LTE CA component; Intra-band contiguous (NG)EN-DC combination supporting both UL and DL intra-band (NG)EN-DC parts with additional inter-band NR/LTE CA component; Inter-band (NG)EN-DC combination, where the frequency range of the E-UTRA band is a subset of the frequency range of the NR band (as specified in Table 5.5B.4.1-1 of TS 38.101-3 [4]). If this capability is included in an "Intra-band contiguous (NG)EN-DC combination NR/LTE CA component", this capability applies to the intra-band (NG)EN-DC parts with additional inter-band NR/LTE CA component; 	BC	No	N/A	N/A

4.2.7.10 Phy-Parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
absoluteTPC-Command Indicates whether the UE supports absolute TPC command mode.	UE	No	No	Yes
almostContiguousCP-OFDM-UL	UE	No	No	Yes
Indicates whether the UE supports almost contiguous UL CP-OFDM transmissions as defined in clause 6.2 of TS 38.101-1 [2].	0-			
bwp-SwitchingDelay	UE	CY	No	No
Defines whether the UE supports DCI and timer based active BWP switching delay type1 or type2 specified in clause 8.6.2 of TS 38.133 [5]. It is mandatory to report type 1 or type 2 when <i>bwp-SameNumerology</i> or <i>bwp-DiffNumerology</i> is supported on at least one band.	_			
<i>cbg-FlushIndication-DL</i> Indicates whether the UE supports CBG-based (re)transmission for DL using CBG flushing out information (CBGFI) as specified in TS 38.214 [12].	UE	No	No	No
<i>cbg-TransIndication-DL</i> Indicates whether the UE supports CBG-based (re)transmission for DL using CBG transmission information (CBGTI) as specified in TS 38.214 [12].	UE	No	No	No
<i>cbg-TransIndication-UL</i> Indicates whether the UE supports CBG-based (re)transmission for UL using CBG transmission information (CBGTI) as specified in TS 38.214 [12].	UE	No	No	No
<i>configuredUL-GrantType1</i> Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.	UE	No	No	No
<i>configuredUL-GrantType2</i> Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.	UE	No	No	No
cqi-TableAlt Indicates whether UE supports the CQI table with target BLER of 10^-5.	UE	No	No	Yes
<i>csi-ReportFramework</i> See <i>csi-ReportFramework</i> in 4.2.7.2. For a band combination comprised of FR1 and FR2 bands, this parameter, if present, limits the corresponding parameter in <i>MIMO</i> -	UE	Yes	No	N/A
ParametersPerBand. csi-ReportWithoutCQI Indicates whether UE supports CSI reporting with report quantity set to 'CRI/RI/i1' as defined in clause 5.2.1.4 of TS 38.214 [12].	UE	No	No	Yes
<i>csi-ReportWithoutPMI</i> Indicates whether UE supports CSI reporting with report quantity set to 'CRI/RI/CQI' as defined in clause 5.2.1.4 of TS 38.214 [12].	UE	No	No	Yes
<i>csi-RS-CFRA-ForHO</i> Indicates whether the UE can perform reconfiguration with sync using a contention free random access on PRACH resources that are associated with CSI-RS resources of the target cell.	UE	No	No	No
<i>csi-RS-IM-ReceptionForFeedback</i> See <i>csi-RS-IM-ReceptionForFeedback</i> in 4.2.7.2. For a band combination comprised of FR1 and FR2 bands, this parameter, if present, limits the corresponding parameter in <i>MIMO-ParametersPerBand</i> .	UE	Yes	No	N/A
<i>csi-RS-ProcFrameworkForSRS</i> See <i>csi-RS-ProcFrameworkForSRS</i> in 4.2.7.2. For a band combination comprised of FR1 and FR2 bands, this parameter, if present, limits the corresponding parameter in <i>MIMO-ParametersPerBand</i> .	UE	No	No	N/A
<i>dl-64QAM-MCS-TableAlt</i> Indicates whether the UE supports the alternative 64QAM MCS table for PDSCH.	UE	No	No	Yes
<i>dl-SchedulingOffset-PDSCH-TypeA</i> Indicates whether the UE supports DL scheduling slot offset (K0) greater than 0 for PDSCH mapping type A.	UE	Yes	Yes	Yes
<i>dl-SchedulingOffset-PDSCH-TypeB</i> Indicates whether the UE supports DL scheduling slot offset (K0) greater than 0 for PDSCH mapping type B.	UE	Yes	Yes	Yes
downlinkSPS Indicates whether the UE supports PDSCH reception based on semi-persistent scheduling.	UE	No	No	No
dynamicBetaOffsetInd-HARQ-ACK-CSI Indicates whether the UE supports indicating beta-offset (UCI repetition factor onto PUSCH) for HARQ-ACK and/or CSI via DCI among the RRC configured beta- offsets.	UE	No	No	No

dynamicHARQ-ACK-Codebook	UE	Yes	No	No
Indicates whether the UE supports HARQ-ACK codebook dynamically constructed				
by DCI(s). This field shall be set to supported. dynamicHARQ-ACK-CodeB-CBG-Retx-DL	UE	No	No	No
Indicates whether the UE supports HARQ-ACK codebook size for CBG-based	UE	INO	INO	INO
(re)transmission based on the DAI-based solution as specified in TS 38.213 [11].				
dynamicPRB-BundlingDL	UE	No	No	No
Indicates whether UE supports DCI-based indication of the PRG size for PDSCH			INU	
reception.				
dynamicSFI	UE	No	Yes	Yes
Indicates whether the UE supports monitoring for DCI format 2_0 and determination			163	103
of slot formats via DCI format 2_0.				
dynamicSwitchRA-Type0-1-PDSCH	UE	No	No	No
Indicates whether the UE supports dynamic switching between resource allocation	0-		110	
Types 0 and 1 for PDSCH as specified in TS 38.212 [10].				
dynamicSwitchRA-Type0-1-PUSCH	UE	No	No	No
Indicates whether the UE supports dynamic switching between resource allocation	0-		110	
Types 0 and 1 for PUSCH as specified in TS 38.212 [10].				
pucch-F0-2WithoutFH	UE	Yes	No	Yes
Indicates whether the UE supports transmission of a PUCCH format 0 or 2 without				
frequency hopping. When included, the UE does not support PUCCH formats 0 and				
2 without frequency hopping. When not included, the UE supports the PUCCH				
formats 0 and 2 without frequency hopping.				
pucch-F1-3-4WithoutFH	UE	Yes	No	Yes
Indicates whether the UE supports transmission of a PUCCH format 1, 3 or 4	_			
without frequency hopping. When included, the UE does not support PUCCH				
formats 1, 3 and 4 without frequency hopping. When not included, the UE supports				
the PUCCH formats 1, 3 and 4 without frequency hopping.				
interleavingVRB-ToPRB-PDSCH	UE	Yes	No	No
Indicates whether the UE supports receiving PDSCH with interleaved VRB-to-PRB				
mapping as specified in TS 38.211 [6].				
interSlotFreqHopping-PUSCH	UE	No	No	No
Indicates whether the UE supports inter-slot frequency hopping for PUSCH				
transmissions.				
intraSlotFreqHopping-PUSCH	UE	Yes	No	Yes
Indicates whether the UE supports intra-slot frequency hopping for PUSCH				
transmission, except for PUSCH scheduled by PDCCH in the Type1-PDCCH				
common search space before RRC connection establishment.				
maxLayersMIMO-Indication	UE	Yes	No	No
Indicates whether the UE supports the network configuration of maxMIMO-Layers				
as specified in TS 38.331 [9].				
maxNumberSearchSpaces	UE	No	No	No
Indicates whether the UE supports up to 10 search spaces in an SCell per BWP.				
multipleCORESET	UE	CY	No	Yes
Indicates whether the UE supports configuration of up to two PDCCH CORESETs				
per BWP in addition to the CORESET with CORESET-ID 0 in the BWP. If this is not				
supported, the UE supports one PDCCH CORESET per BWP in addition to the				
CORESET with CORESET-ID 0 in the BWP. It is mandatory with capability				
signalling for FR2 and optional for FR1.				
mux-HARQ-ACK-PUSCH-DiffSymbol	UE	Yes	No	Yes
Indicates whether the UE supports HARQ-ACK piggyback on a PUSCH with/without				
aperiodic CSI once per slot when the starting OFDM symbol of the PUSCH is				
different from the starting OFDM symbols of the PUCCH resource that HARQ-ACK				
would have been transmitted on.				
mux-MultipleGroupCtrlCH-Overlap	UE	No	No	Yes
Indicates whether the UE supports more than one group of overlapping PUCCHs				
and PUSCHs per slot per PUCCH cell group for control multiplexing.				
mux-SR-HARQ-ACK-CSI-PUCCH-MultiPerSlot	UE	No	No	Yes
Indicates whether the UE supports multiplexing SR, HARQ-ACK and CSI on a				
PUCCH or piggybacking on a PUSCH more than once per slot when SR, HARQ-				
ACK and CSI are supposed to be sent with the same or different starting symbol in				
a slot.	1	1 1		

mux-SR-HARQ-ACK-CSI-PUCCH-OncePerSlot	UE	FD	No	Yes
sameSymbol indicates the UE supports multiplexing SR, HARQ-ACK and CSI on a				
PUCCH or piggybacking on a PUSCH once per slot, when SR, HARQ-ACK and CSI				
are supposed to be sent with the same starting symbols on the PUCCH resources				
in a slot. <i>diffSymbol</i> indicates the UE supports multiplexing SR, HARQ-ACK and				
CSI on a PUCCH or piggybacking on a PUSCH once per slot, when SR, HARQ-				
ACK and CSI are supposed to be sent with the different starting symbols in a slot.				
The UE is mandated to support the multiplexing and piggybacking features indicated by <i>sameSymbol</i> while the UE is optional to support the multiplexing and				
piggybacking features indicated by <i>diffSymbol</i> .				
If the UE indicates sameSymbol in this field and does not support mux-HARQ-ACK-				
PUSCH-DiffSymbol, the UE supports HARQ-ACK/CSI piggyback on PUSCH once				
per slot, when the starting OFDM symbol of the PUSCH is the same as the starting				
OFDM symbols of the PUCCH resource(s) that would have been transmitted on.				
If the UE indicates sameSymbol in this field and supports mux-HARQ-ACK-PUSCH-				
DiffSymbol, the UE supports HARQ-ACK/CSI piggyback on PUSCH once per slot				
for which case the starting OFDM symbol of the PUSCH is the different from the				
starting OFDM symbols of the PUCCH resource(s) that would have been				
transmitted on.				
mux-SR-HARQ-ACK-PUCCH	UE	No	No	Yes
Indicates whether the UE supports multiplexing SR and HARQ-ACK on a PUCCH				
or piggybacking on a PUSCH once per slot, when SR and HARQ-ACK are				
supposed to be sent with the different starting symbols in a slot.			N 1	
nzp-CSI-RS-IntefMgmt	UE	No	No	No
Indicates whether the UE supports interference measurements using NZP CSI-RS.				N N
oneFL-DMRS-ThreeAdditionalDMRS-UL	UE	No	No	Yes
Defines whether the UE supports DM-RS pattern for UL transmission with 1 symbol front-loaded DM-RS with three additional DM-RS symbols.				
oneFL-DMRS-TwoAdditionalDMRS-UL	UE	Yes	No	Yes
Defines support of DM-RS pattern for UL transmission with 1 symbol front-loaded	UE	res	INU	res
DM-RS with 2 additional DM-RS symbols and more than 1 antenna ports.				
onePortsPTRS	UE	CY	No	Yes
Defines whether UE supports PT-RS with 1 antenna port in DL reception and/or UL	02		110	100
transmission. It is mandatory with UE capability signalling for FR2 and optional for				
FR1. The left most in the bitmap corresponds to DL reception and the right most bit				
in the bitmap corresponds to UL transmission.				
onePUCCH-LongAndShortFormat	UE	No	No	Yes
Indicates whether the UE supports transmission of one long PUCCH format and				
one short PUCCH format in TDM in the same slot.				
pCell-FR2	UE	Yes	No	FR2
Indicates whether the UE supports PCell operation on FR2.				only
pdcch-MonitoringSingleOccasion	UE	No	No	FR1
Indicates whether the UE supports receiving PDCCH in a search space configured				only
to be monitored within a single span of any three contiguous OFDM symbols in a				
slot with the capability of supporting at least 44 blind decodes in a slot for 15 kHz				
subcarrier spacing.				
pdcch-BlindDetectionCA	UE	No	No	No
Indicates PDCCH blind decoding capabilities supported by the UE for CA with more than 4 CCs as anaptified in TS 28 212 [11]. The field value is from 4 to 16				
than 4 CCs as specified in TS 38.213 [11]. The field value is from 4 to 16.				
NOTE: FR1-FR2 differentiation is not allowed in this release, although the				
capability signalling is supported for FR1-FR2 differentiation.				
pdcch-BlindDetectionMCG-UE	UE	No	No	Yes
Indicates PDCCH blind decoding capabilities supported for MCG when in NR DC.	02		110	100
The field value is from 1 to 15. The UE sets the value in accordance with the				
constraints specified in TS 38.213 [11].				
Additionally, if the UE does not report <i>pdcch-BlindDetectionCA</i> , and if X is the				
maximum number of CCs supported by the UE across all NR-DC band				
combinations then there is at least one parameter pair (X1, X2) such that X1 + X2 =				
X and the UE supports at least one NR-DC band combination with X1 CCs in MCG				
and X2 CCs in SCG and for which X1 <= pdcch-BlindDetectionMCG-UE and X2 <=				
pdcch-BlindDetectionSCG-UE.				

pdcch-BlindDetectionSCG-UE	UE	No	No	Yes
Indicates PDCCH blind decoding capabilities supported for SCG when in NR DC.				
The field value is from 1 to 15. The UE sets the value in accordance with the				
constraints specified in TS 38.213 [11].				
Additionally, if the UE does not report <i>pdcch-BlindDetectionCA</i> , and if X is the				
maximum number of CCs supported by the UE across all NR-DC band				
combinations then there is at least one parameter pair (X1, X2) such that $X1 + X2 =$				
X and the UE supports at least one NR-DC band combination with X1 CCs in MCG				
and X2 CCs in SCG and for which X1 <= pdcch-BlindDetectionMCG-UE and X2 <=				
pdcch-BlindDetectionSCG-UE.				FD 4
pdsch-256QAM-FR1	UE	Yes	No	FR1
Indicates whether the UE supports 256QAM modulation scheme for PDSCH for				only
FR1 as defined in 7.3.1.2 of TS 38.211 [6].	=			
pdsch-MappingTypeA	UE	Yes	No	No
Indicates whether the UE supports receiving PDSCH using PDSCH mapping type A				
with less than seven symbols. This field shall be set to supported.	=			
pdsch-MappingTypeB	UE	Yes	No	No
Indicates whether the UE supports receiving PDSCH using PDSCH mapping type				
B.	· · -			
pdsch-RepetitionMultiSlots	UE	No	No	No
Indicates whether the UE supports receiving PDSCH scheduled by DCI format 1_1				
when configured with higher layer parameter <i>pdsch-AggregationFactor</i> > 1, as				
defined in 5.1.2.1 of TS 38.214 [12].	, .=			
pdsch-RE-MappingFR1-PerSymbol/pdsch-RE-MappingFR1-PerSlot	UE	Yes	No	FR1
Indicates the maximum number of supported PDSCH Resource Element (RE)				only
mapping patterns for FR1, each described as a resource (including NZP/ZP CSI-				
RS, CRS, CORESET and SSB) or bitmap. The number of patterns coinciding in a				
symbol in a CC and in a slot in a CC are limited by the respective capability				
parameters. Value n10 means 10 RE mapping patterns and n16 means 16 RE				
mapping patterns, and so on. The UE shall set the fields pdsch-RE-MappingFR1-				
PerSymbol and pdsch-RE-MappingFR1-PerSlot to at least n10 and n16,				
respectively. In the exceptional case that the UE does not include the fields, the				
network may anyway assume that the UE supports the required minimum values.				
pdsch-RE-MappingFR2-PerSymbol/pdsch-RE-MappingFR2-PerSlot	UE	Yes	No	FR2
Indicates the maximum number of supported PDSCH Resource Element (RE)				only
mapping patterns for FR2, each described as a resource (including NZP/ZP CSI-				
DS CODESET and SSB) or hitman. The number of patterns coinciding in a symbol				
RS, CORESET and SSB) or bitmap. The number of patterns coinciding in a symbol				
in a CC and in a slot in a CC are limited by the respective capability parameters.				
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns,				
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and				
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlo</i> t to at least n6 and n16, respectively. In the				
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway				
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values.				
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i>	UE	No	No	No
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with	UE	No	No	No
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency	UE	No	No	No
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlo</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6].				
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i>	UE	No	No	No
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH				
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlo</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11].	UE	No	No	No
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i>				No
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM	UE	No	No	No
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM	UE	No	No	No
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported</i> .	UE	No	No	No
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported</i> .	UE	No	No	No Yes
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported.</i> <i>pucch-F3-WithFH</i>	UE	No Yes	No	No Yes
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported</i> . <i>pucch-F3-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 3 (4~14 OFDM	UE	No Yes	No	No Yes
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported</i> . <i>pucch-F3-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 3 (4~14 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to	UE	No Yes	No	No Yes
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported</i> . <i>pucch-F3-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 3 (4~14 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported</i> .	UE UE UE	No Yes Yes	No No No	No Yes Yes
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported</i> . <i>pucch-F3-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 3 (4~14 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported</i> . <i>pucch-F3-4-HalfPi-BPSK</i>	UE	No Yes	No	No Yes Yes
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported.</i> <i>pucch-F3-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 3 (4~14 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported.</i> <i>pucch-F3-4-HalfPi-BPSK</i> Indicates whether the UE supports pi/2-BPSK for PUCCH format 3/4 as defined in	UE UE UE	No Yes Yes	No No No	No Yes Yes
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlo</i> t to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported.</i> <i>pucch-F3-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 3 (4~14 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported.</i> <i>pucch-F3-4-HalfPi-BPSK</i> Indicates whether the UE supports pi/2-BPSK for PUCCH format 3/4 as defined in 6.3.2.6 of TS 38.211 [6]. It is optional for FR1 and mandatory with capability	UE UE UE	No Yes Yes	No No No	No Yes Yes
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlot</i> to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported.</i> <i>pucch-F3-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 3 (4~14 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported.</i> <i>pucch-F3-4-HalfPi-BPSK</i> Indicates whether the UE supports pi/2-BPSK for PUCCH format 3/4 as defined in 6.3.2.6 of TS 38.211 [6]. It is optional for FR1 and mandatory with capability signalling for FR2.	UE UE UE UE	No Yes Yes CY	No No No	No Yes Yes
in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on. The UE shall set the fields <i>pdsch-RE-MappingFR2-PerSymbol</i> and <i>pdsch-RE-MappingFR2-PerSlo</i> t to at least n6 and n16, respectively. In the exceptional case that the UE does not include the fields, the network may anyway assume that the UE supports the required minimum values. <i>precoderGranularityCORESET</i> Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6]. <i>pre-EmptIndication-DL</i> Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11]. <i>pucch-F2-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported.</i> <i>pucch-F3-WithFH</i> Indicates whether the UE supports transmission of a PUCCH format 3 (4~14 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to <i>supported.</i> <i>pucch-F3-4-HalfPi-BPSK</i> Indicates whether the UE supports pi/2-BPSK for PUCCH format 3/4 as defined in 6.3.2.6 of TS 38.211 [6]. It is optional for FR1 and mandatory with capability	UE UE UE	No Yes Yes	No No No	No Yes Yes

<i>pusch-RepetitionMultiSlots</i> Indicates whether the UE supports transmitting PUSCH scheduled by DCI format	UE	Yes	No	No
0_1 when configured with higher layer parameter <i>pusch-AggregationFactor</i> > 1, as defined in clause 6.1.2.1 of TS 38.214 [12].				
pucch-Repetition-F1-3-4	UE	Yes	No	No
Indicates whether the UE supports transmission of a PUCCH format 1 or 3 or 4 over	02			
multiple slots with the repetition factor 2, 4 or 8.				
pusch-HalfPi-BPSK	UE	CY	No	Yes
Indicates whether the UE supports pi/2-BPSK modulation scheme for PUSCH as				
defined in 6.3.1.2 of TS 38.211 [6]. It is optional for FR1 and mandatory with				
capability signalling for FR2.				
pusch-LBRM	UE	No	No	Yes
Indicates whether the UE supports limited buffer rate matching in UL as specified in				
TS 38.212 [10].				
ra-Type0-PUSCH	UE	No	No	No
Indicates whether the UE supports resource allocation Type 0 for PUSCH as				
specified in TS 38.214 [12].				
rateMatchingCtrlResrcSetDynamic	UE	Yes	No	No
Indicates whether the UE supports dynamic rate matching for DL control resource				
set.				
rateMatchingResrcSetDynamic	UE	No	No	No
Indicates whether the UE supports receiving PDSCH with resource mapping that				
excludes the REs corresponding to resource sets configured with RB-symbol level				
granularity indicated by bitmaps (see patternType in RateMatchPattern in TS				
38.331[9]) based on dynamic indication in the scheduling DCI as specified in TS				
38.214 [12].				
rateMatchingResrcSetSemi-Static	UE	Yes	No	No
Indicates whether the UE supports receiving PDSCH with resource mapping that				
excludes the REs corresponding to resource sets configured with RB-symbol level				
granularity indicated by <i>bitmaps</i> and controlResourceSet (see patternType in				
RateMatchPattern in TS 38.331[9]) following the semi-static configuration as				
specified in TS 38.214 [12].				
scs-60kHz	UE	No	No	FR1
Indicates whether the UE supports 60kHz subcarrier spacing for data channel in				only
FR1 as defined in clause 4.2-1 of TS 38.211 [6].				
semiOpenLoopCSI	UE	No	No	Yes
Indicates whether UE supports CSI reporting with report quantity set to				
'CRI/RI/i1/CQI ' as defined in clause 5.2.1.4 of TS 38.214 [12].				
semiStaticHARQ-ACK-Codebook	UE	Yes	No	No
Indicates whether the UE supports HARQ-ACK codebook constructed by semi-				
static configuration.		Yes	Na	Na
spatialBundlingHARQ-ACK	UE	res	No	No
Indicates whether the UE supports spatial bundling of HARQ-ACK bits carried on				
PUCCH or PUSCH per PUCCH group. With spatial bundling, two HARQ-ACK bits				
for a DL MIMO data is bundled into a single bit by logical "AND" operation. spCellPlacement	UE	No	No	No
		No	No	No
Indicates whather the LIE supports a SpCall on ED1 EDD ED1 TDD and/or ED2				
TDD depending on which additional SCells of other frequency range(s) / duplex				
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is				
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group.				
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported				
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations.		No	No	Vec
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations. sp-CSI-IM	UE	No	No	Yes
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations. sp-CSI-IM Indicates whether the UE supports semi-persistent CSI-IM.				
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations. sp-CSI-IM Indicates whether the UE supports semi-persistent CSI-IM. sp-CSI-ReportPUCCH	UE	No	No	
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations. sp-CSI-IM Indicates whether the UE supports semi-persistent CSI-IM. sp-CSI-ReportPUCCH Indicates whether UE supports semi-persistent CSI reporting using PUCCH formats				
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations. sp-CSI-IM Indicates whether the UE supports semi-persistent CSI-IM. sp-CSI-ReportPUCCH Indicates whether UE supports semi-persistent CSI reporting using PUCCH formats 2, 3 and 4.	UE	No	No	No
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations. sp-CSI-IM Indicates whether the UE supports semi-persistent CSI-IM. sp-CSI-ReportPUCCH Indicates whether UE supports semi-persistent CSI reporting using PUCCH formats 2, 3 and 4. sp-CSI-ReportPUSCH				
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations. sp-CSI-IM Indicates whether the UE supports semi-persistent CSI-IM. sp-CSI-ReportPUCCH Indicates whether UE supports semi-persistent CSI reporting using PUCCH formats 2, 3 and 4. sp-CSI-ReportPUSCH Indicates whether UE supports semi-persistent CSI reporting using PUSCH.	UE	No	No	No
Indicates whether the UE supports a SpCell on FR1-FDD, FR1-TDD and/or FR2- TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations. <i>sp-CSI-IM</i> Indicates whether the UE supports semi-persistent CSI-IM. <i>sp-CSI-ReportPUCCH</i> Indicates whether UE supports semi-persistent CSI reporting using PUCCH formats 2, 3 and 4. <i>sp-CSI-ReportPUSCH</i> Indicates whether UE supports semi-persistent CSI reporting using PUSCH. <i>sp-CSI-RS</i> Indicates whether UE supports semi-persistent CSI reporting using PUSCH.	UE	No	No	Yes No No Yes
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations. sp-CSI-IM Indicates whether the UE supports semi-persistent CSI-IM. sp-CSI-ReportPUCCH Indicates whether UE supports semi-persistent CSI reporting using PUCCH formats 2, 3 and 4. sp-CSI-ReportPUSCH Indicates whether UE supports semi-persistent CSI reporting using PUSCH. sp-CSI-REPORTPUSCH Indicates whether UE supports semi-persistent CSI reporting using PUSCH. sp-CSI-RS Indicates whether the UE supports semi-persistent CSI reporting using PUSCH.	UE UE UE	No No Yes	No No No	No No Yes
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations. <i>sp-CSI-IM</i> Indicates whether the UE supports semi-persistent CSI-IM. <i>sp-CSI-ReportPUCCH</i> Indicates whether UE supports semi-persistent CSI reporting using PUCCH formats 2, 3 and 4. <i>sp-CSI-ReportPUSCH</i> Indicates whether UE supports semi-persistent CSI reporting using PUSCH. <i>sp-CSI-RS</i> Indicates whether the UE supports semi-persistent CSI reporting using PUSCH. <i>sp-CSI-RS</i> Indicates whether the UE supports semi-persistent CSI-RS. <i>supportedDMRS-TypeDL</i>	UE	No	No	No
TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations. sp-CSI-IM Indicates whether the UE supports semi-persistent CSI-IM. sp-CSI-ReportPUCCH Indicates whether UE supports semi-persistent CSI reporting using PUCCH formats 2, 3 and 4. sp-CSI-ReportPUSCH Indicates whether UE supports semi-persistent CSI reporting using PUSCH. sp-CSI-ReportPUSCH Indicates whether UE supports semi-persistent CSI reporting using PUSCH. sp-CSI-RS Indicates whether the UE supports semi-persistent CSI reporting using PUSCH.	UE UE UE	No No Yes	No No No	No No Yes

supportedDMRS-TypeUL UE FD No Yes Defines supported DM-RS configuration types at the UE for UL transmission. UE FD No TDD Support of both type 1 and type 2 is mandatory with capability signalling. If this field is on included. Type 1 is supports more than one switch points in a slot for actual DLUL transmission(s). UE No No Yes Indicates whether the UE supports group DCI message based on TPC-PUCCH- RNT for TPC commands for PUSCH. UE No No Yes Indicates whether the UE supports group DCI message based on TPC-PUSCH- RNT for TPC commands for PUSCH. UE No No Yes Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. UE Yes Yes Yes Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. UE Yes Yes Yes Indicates whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols font-loaded DM-RS without additional DM-RS symbols. UE Yes No Yes Indicates whether the UE supports DM-RS pattern for UL transmission with 2 symbols font-loaded DM-RS without additional DM-RS symbols font-loaded DM-RS without additional 2 symbols font-loaded DM-RS without additional DM-RS symbols font-l					
Support of both type 1 is mandatory with capability signalling. If this field Image: Comparison of the component of the component of the comparison of the comparecomparecomparisent of the transport block within each slot, an		UE	FD	No	Yes
is not included, Type 1 is supported. Ide MultiD-LL SwitchPerSiot Indicates whether the UE supports more than one switch points in a slot for actual DULL transmission(s). Tpc-PUCCH-RNTI Indicates whether the UE supports group DCI message based on TPC-PUCCH- RNTI for TPC commands for PUCCH. Indicates whether the UE supports group DCI message based on TPC-PUSCH- RNTI for TPC commands for PUCCH. Tpc-SPSCHRNTI Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI Int TPC-Commands for PUSCH. Tpc-SPSCHRNTI Int Dec SPSCHRNTI Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI Int TPC-Commands for PUSCH. TwoDifferentTPC-Loop-PUSCH Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. Introl Defines whether the UE supports two different TPC loops for PUSCH closed loop power control. Introl-DMRS Defines whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols. The left most in the bitmap corresponds to DL reception and the right most bit in the bitmap corresponds to DL transmission of two PUCCH formats in TDM in Indicates whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols and aner/UCCH-LongAndShortFormat. Indicates whether the UE supports DM-RS pattern for UL transmission with 2 symbols in ont-loaded DM-RS with one additional 2 symbols and aner/UCCH-LongAndShortFormat. Indicates whether the UE supports TDM RS pattern for UL transmission with 2 symbols in ont-loaded DM-RS with one additional 2 symbols and aner/UCCH-LongAndShortFormat. Indicates whether the UE supports TDM RS pattern for UL transmission with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal 0 2.4, or 8 with a single repetition of the transport block within each slot, and redundancy					
idd-MultiDL-UL-SwitchPerSiot UE No TDD Yes Indicates whether the UE supports more than one switch points in a slot for actual UUE No No Yes Indicates whether the UE supports group DCI message based on TPC-PUCCH-RNTI UE No No Yes Indicates whether the UE supports group DCI message based on TPC-PUSCH-RNTI UE No No Yes Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI UE No No Yes Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI UE No No Yes Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI UE Yes Yes Yes Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. UE Yes Yes Yes Yes Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. UE Yes No Yes Yes Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. UE Yes No Yes Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. UE					
Indicates whether the UE supports more than one switch points in a slot for actual DULL transmission(s). Tpc-PUCCH-RNTI Indicates whether the UE supports group DCI message based on TPC-PUCCH- RNTI for TPC commands for PUCCH. Tpc-PUSCH-RNTI Indicates whether the UE supports group DCI message based on TPC-PUSCH- RNTI for TPC commands for PUSCH. Tpc-SRS-RNTI Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. twoDifferentTPC-Loop-PUSCH Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. twoFL-DMRS Defines whether the UE supports two different TPC loops for PUSCH closed loop power control. twoFL-DMRS The left most in the bitmap corresponds to DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols. The left most in the bitmap corresponds to DL reception and the right most bit in the bitmap corresponds to UL transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-Rope-TubARS pattern for UL transmission with 2 symbols fornt-loaded DM-RS with one additional 2 symbols DM-RS. twoFUCCH-RepetitionMultiSlots Indicates whether the UE supports transmission of two PUCCH format 0 or 2 in consecutive symbols in a slot. type2-PUSCH-RepetitionMultiSlots Indicates whether the UE supports transmission with configured grant a specified in TS 38.214 (12) with UL-TWG-rep.A value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configu					
DL/UL transmission(s). UE No Yes Indicates whether the UE supports group DCI message based on TPC-PUCCH-RNTI UE No No Yes Indicates whether the UE supports group DCI message based on TPC-PUSCH-RNTI UE No No Yes Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI UE No No Yes Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI UE No No Yes Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. UE Yes Yes Yes Indicates whether the UE supports DM-RS pattern for DL reception and/or UL UE Yes No Yes Defines whether the UE supports DM-RS pattern for DL reception and/or UL UE Yes No Yes Indicates whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols and none unit 2 symbols front-loaded DM-RS with one additional 2 symbols and none PUCCH-InogAnd/SndF/Brant. UE No Yes Imdicates whether the UE supports transmission of two PUCCH formats in TDM in the same stot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and nonePUCCH-InogAnd/SndF/Brant. UE No No Yes		UE	No		Yes
tpc-PUCCH-RNT1 Indicates whether the UE supports group DCI message based on TPC-PUCCH-RNT1 for TPC commands for PUCCH. UE No No Yes Indicates whether the UE supports group DCI message based on TPC-PUSCH-RNT1 for TPC commands for PUSCH. UE No Yes Indicates whether the UE supports group DCI message based on TPC-SRS-RNT1 Indicates whether the UE supports group DCI message based on TPC-SRS-RNT1 Indicates whether the UE supports wo different TPC loops for PUSCH closed loop power control. UE No Yes Yes Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. UE Yes Yes Yes Yes Yes Indicates whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols. UE Yes No Yes Indicates whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS. UE Yes No Yes Indicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH+F0-2-ConsecSymbols and onePUCCH+ArgentionMult/Stots UE No Yes Indicates whether the UE supports transmission of two PUCCH format 0 or 2 in consecutive symbols in a slot. UE No No				only	
Indicates whether the UE supports group DCI message based on TPC-PUCCH- VE No Yes Indicates whether the UE supports group DCI message based on TPC-PUSCH- VE No No Yes Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI UE No No Yes Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI UE Yes Yes Yes Indicates whether the UE supports two different TPC loops for PUCCH closed loop UE Yes Yes Yes Indicates whether the UE supports DM-RS pattern for DL reception and/or UL UE Yes No Yes Indicates whether the UE supports DM-RS pattern for DL reception and/or UL UE Yes No Yes Defines whether the UE supports DM-RS pattern for DL reception and/or UL UE Yes No Yes Defines whether the UE supports DM-RS pattern for UL transmission with 2 Symbols Yes No Yes Indicates whether the UE supports DM-RS pattern for UL transmission with 2 Yes No Yes Yes Defines whether the UE supports DM-RS pattern for UL transmission with 2 Yes No Yes Yes Yes No Yes </td <td></td> <td></td> <td>- NI</td> <td></td> <td></td>			- NI		
RNTI for TPC commands for PUCCH. UE No Yes Indicates whether the UE supports group DCI message based on TPC-PUSCH- UE No Yes Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI UE No Yes Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI UE No Yes Indicates whether the UE supports two different TPC loops for PUCCH closed loop power control. UE Yes Yes Yes Indicates whether the UE supports bwo different TPC loops for PUSCH closed loop power control. UE Yes Yes Yes Indicates whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols. UE Yes No Yes Versonds to UL transmission. UE Yes No Yes Yes Indicates whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS. UE No Yes VerDifferent the UE supports DM-RS pattern for UL transmission with 2 supports transmission of two PUCCH formats in TDM in the same stoid, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-UMRA-MOVENTSIOI UE No Yes Indicates whether the UE supports transm		UE	NO	No	Yes
tpc-PUSCH-RNT UE No No Yes Indicates whether the UE supports group DCI message based on TPC-PUSCH- UE No No Yes Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI UE No No Yes Indicates whether the UE supports two different TPC loops for PUCCH closed loop power control. UE Yes Yes Yes Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. UE Yes Yes Yes Indicates whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols. UE Yes No Yes TwoPL-DMRS UE Yes No Yes No Yes Defines whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS WE No Yes Indicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, unkin are not covered by twoPUCCH-Fo-2-ConsecSymbols and onePUCCH soft format 0 or 2 in consecutive symbols in a slot. No Yes Indicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in 3 slot.					
Indicates whether the UE supports group DCI message based on TPC-PUSCH- V V RNTI for TPC commands for PUSCH. VE No No Yes Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI VE No No Yes Indicates whether the UE supports two different TPC loops for PUCCH closed loop power control. VE Yes <					
RNTI for TPC commands for PUSCH. UE No No Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI UE No No for TPC commands for SRS. UE No No Yes Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. UE Yes Yes Yes Indicates whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols front-loaded DM-RS without additional DM-RS symbols front-loaded DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS without additional 2 symbols DM-RS. UE Yes No Yes Indicates whether the UE supports IN-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS. UE No No Yes Indicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePU/CCH-Hop2-tonsecSymbols UE No No Yes Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2.4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RepK value equal to 2.4, or 8 w		UE	NO	NO	Yes
tpc-SRS-RNTI UE No No Yes Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI UE No Yes Indicates whether the UE supports two different TPC loops for PUCCH closed loop power control. UE Yes Yes Yes Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. UE Yes Yes Yes Defines whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols. UE Yes No Yes Defines whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS without additional 2 symbols DM-RS. UE Yes No Yes Indicates whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS. UE No Yes Indicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onsecutive symbols in a slot. UE No Yes Indicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot. UE No No Yes Indicates whether the UE s					
Indicates whether the UE supports group DCI message based on TPC-SRS-RNTIUEYestwDifferentTPC-Loop-PUCCHUEYesYesIndicates whether the UE supports two different TPC loops for PUCCH closed loopUEYesYespower control.UEYesYesYestwoDifferentTPC-Loop-PUSCHUEYesYesYesIndicates whether the UE supports two different TPC loops for PUSCH closed loopUEYesNopower control.UEYesNoYestwoFL-DMRSSymbols front-loaded DM-RS without additional DM-RSWesNoYesDefines whether the UE supports DM-RS pattern for DL reception and/or ULtransmission with 2 symbols front-loaded DM-RS without additional DM-RSWesNoYesDefines whether the UE supports DM-RS pattern for UL transmission with 2WesYesNoYesIndicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-LongAndShortFormat.UENoNoYesIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS as 214 [12] with UL-TWG-repK value equal to 2, 4, or 8WesNoNoIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS as 214 [12] with UL-TWG-repK value equal to 2, 4, or 8With a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-ReyEx value equal to 2, 4, or 8NoNoNoIndicates whether the UE s					
for TPC commands for SRS. U Ves twoDifferentTPC-Loop-PUCCH UE Yes Yes Indicates whether the UE supports two different TPC loops for PUCCH closed loop power control. UE Yes Yes twoDifferentTPC-Loop-PUSCH UE Yes Yes Yes Yes Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control. UE Yes Yes Yes twoDifferentTPC-LOMRS UE Symbols The left most in the bitmap corresponds to DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols inchalmed by twoFUCCH-RD-2Consectores provement to additional DM-RS-UL UE Yes No Yes symbols The left most in the bitmap corresponds to DL reception and the right most bit in the bitmap corresponds to UL transmission of two PUCCH formats in TDM in the same sick, which are not covered by twoPUCCH-RD-2-ConsecSymbols and onePUCCH-LongAndShortFormat. UE No No Yes Indicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot. UE No No Yes Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 With a single repetitionMultiSlots UE No		UE	NO	No	Yes
Import Import Indicates whether the UE supports two different TPC loops for PUCCH closed loop power control.UEYesYesYesIndicates whether the UE supports two different TPC loops for PUSCH closed loop power control.UEYesYesYesIndicates whether the UE supports two different TPC loops for PUSCH closed loop power control.UEYesNoYesIndicates whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols.UEYesNoYesDefines whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS util transmission with 2 symbols front-loaded DM-RS but the reception and the right most bit in the bitmap corresponds to UL transmission.UEYesNoYesIndicates whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS.UENoNoYesIndicates whether the UE supports transmission of two PUCCH-for-2-consecSymbols and onnePUCCH-for2-consecSymbolsUENoNoYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in as lot.UENoNoNoIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in					
Indicates whether the ÚE supports two different TPC loops for PUCCH closed loop Ves Ves power control. UE Yes Yes Yes Indicates whether the UE supports two different TPC loops for PUSCH closed loop Ves No Yes power control. UE Yes No Yes twoFL-DMRS Defines whether the UE supports DM-RS pattern for DL reception and/or UL UE Yes No Yes pomer control. UE Yes No Yes Yes No Yes pomer control. UE Yes No Yes No Yes pomer control. UE Yes No Yes No Yes pomer control. UE Yes No Yes Yes No Yes pomer control. UE No No Yes No Yes Yes pomer control. UE No No Yes No Yes Yes Indicates whether the UE supports transmission of two PUCCH-for2-consectrosymbols and onePUCCH-for2-consectrosymbols and sold. UE No No No				X	
power control.UEYesYestwoDifferentTPC-Loop-PUSCHUEYesYesYesIndicates whether the UE supports two different TPC loops for PUSCH closed loopUEYesYespower control.twoFL-DMKSUEYesNoYesTursamsission with 2 symbols front-loaded DM-RS without additional DM-RSUEYesNoYesSymbols.The left most in the bitmap corresponds to DL reception and/or ULUEYesNoYesDefines whether the UE supports DM-RS pattern for UL transmission with 2UEYesNoYesSymbols front-loaded DM-RS with one additional 2 symbols DM-RS.UENoYesYesIndicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-R0-2-ConsecSymbols and onePUCCH-LongAndShortFormat.UENoNoYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoNoNotype1-PUSCH-RepetitionMultiStotsIndicates whether the UE supports type 1 PUSCH transmissions with configured grant as specified in TS 38.214 (12) with UL-TWG-repK value equal to 2.4, or 8With a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 (12) with UL-TWG-repK value equal to 2.4, or 8With a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also suppo		UE	Yes	Yes	Yes
twoDifferentTPC-Loop-PUSCH Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control.UEYesYesYestwoFL-DMRS Defines whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols. The left most in the bitmap corresponds to DL reception and the right most bit in the bitmap corresponds to UL transmission. twoFL-DMRS-TwoAdditionalDMRS-UL Defines whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS. twoPUCCH-AnyOthersinSlot Indicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-CngAdShortFormat.UENoNoYestwoPUCCH-RepetitionMultiSlots Indicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot. type1-PUSCH respectitionMultiSlotsUENoNoNoIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-repK value equal to 2, 4, or 8 with a single repetition MultiSlotsUENoNoNothacase whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block with each slot, and redu					
Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control.UEVestwoFL-DMRS transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols.UEYesNoYesThe left most in the bitmap corresponds to DL reception and the right most bit in the bitmap corresponds to UL transmission.UEYesNoYestwoFL-DMRS-TwoAdditionalDMRS-UL Defines whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS.UEYesNoYesDefines whether the UE supports transmission of two PUCCH-for-2-consecSymbols and onePUCCH-LongAndShortFormat.UENoNoYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoNoYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoNoNoIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoNoNoIndicates whether the UE supports type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as ind				X	
power control.UEYestwoFL-DMRSUEYesNoDefines whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols.UEYesNoYesTwoFL-DMRS-TwoAdditionalDMRS-UL Defines whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS without additional 2 symbols front-loaded DM-RSUEYesNoYesDefines whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS.UENoYestwoFL-DMRS-TwoAdditionalDMRS-UL Defines whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-LongAndShortFormat.UENoNoYestwoFUCCH-Rope-tionadditionalYesIUENoNoYesYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoNoNoIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNoNotype2-PUSCH-RopetitionMultiSlots Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNoNotype2-PUSCH-RopetitionMultiSlots Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2		UE	Yes	Yes	Yes
twoFL-DMRSUEYesNoYesDefines whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols.UEYesNoYesThe left most in the bitmap corresponds to DL reception and the right most bit in the bitmap corresponds to UL transmission.UEYesNoYestwoFL-DMRS-TwoAdditionalDMRS-UL Defines whether the UE supports Transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-LongAndSharfformat.UENoNoYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoNoYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols an a slot.UENoNoNoIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version p					
Defines whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols.Image: Constraint of the symbol symbol symbols to DL reception and the right most bit in the bitmap corresponds to UL transmission.UEYesNoYesTwoFL-DMRS-TwoAdditionalDMRS-UL Defines whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS.UENoNoYestwoPUCCH-AnyOthersInSlot Indicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-LongAndShortFormat.UENoNoYestwoPUCCH-Ro-2-ConsecSymbols Indicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoNoNoNotype1-PUSCH-RepetitionMultiSlots Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TSWeNoNoNothicates whether the UE supports Type 1 PUSCH stransmissions with configured grant as			No.	NI-	
transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols. The left most in the bitmap corresponds to DL reception and the right most bit in the bitmap corresponds to UL transmission. <i>twoFL-DMRS-TwoAdditionalDMRS-UL</i> Defines whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS. <i>twoPUCCH-AnyOthersinSlot</i> Indicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by <i>twoPUCCH-F0-2-ConsecSymbols</i> and <i>onePUCCH-F0-2-ConsecSymbols</i> and <i>onePUCCH-F0-2-ConsecS</i>		UE	res	INO	res
symbols. The left most in the bitmap corresponds to DL reception and the right most bit in the bitmap corresponds to UL transmission.UENoYes <i>twoFL-DMRS-TwoAdditionalDMRS-UL</i> Defines whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS.UEYesNoYes <i>twoPUCCH-AnyOthersInSlot</i> Indicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by <i>twoPUCCH-F0-2-ConsecSymbols</i> and <i>onePUCCH-fo-2-ConsecSymbols</i> and <i>onePUCCH-fo-2-ConsecSymbols</i> and <i>onePUCCH-fo-2-ConsecSymbols</i> of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoYesYes <i>type1-PUSCH-RepetitionMultiSlots</i> Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall 					
The left most in the bitmap corresponds to DL reception and the right most bit in the bitmap corresponds to UL transmission.UEVeswoFL-DMRS-TwoAdditionalDMRS-UL Defines whether the UE supports DM-RS pattern for UL transmission with 2 symbols font-loaded DM-RS with one additional 2 symbols DM-RS.UEYesNoYesIndicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-LongAndShortFormat.UENoNoYestwoPUCCH-F0-2-ConsecSymbols Indicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consective symbols in a slot.UENoNoYestype1-PUSCH-RepetitionMultiSlots Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNoNotype2-PUSCH-RepetitionMultiSlots undicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12].UENoNoNotype2-PUSCH-RepetitionMultiSlots undicates whether the UE supports					
bitmap corresponds to UL transmission.UEVestwoFL-DMRS-TwoAdditionalDMRS-ULUEYesNoYesDefines whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS.UENoNoYestwoPUCCH-AnyOthersInSiotUENoNoYesYesIndicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-LongAndShortFormat.UENoYesYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoYesYesIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-ReV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-ReV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-Rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-Rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-Rep. A UE supporting this feature shall also support					
twoFL-DMRS-TwoAdditionalDMRS-UL Defines whether the UE supports DM-RS pattern for UL transmission with 2 symbols forth-loaded DM-RS with one additional 2 symbols DM-RS.UEYesNoYestwoPUCCH-AnyOthersInSlot the same slot, which are not covered by twoPUCCH-fo-2-ConsecSymbols and onePUCCH-LongAndShortFormat.UENoNoYestwoPUCCH-F0-2-ConsecSymbols Indicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoYesYestype1-PUSCH-RepetitionMultiSlots Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetitionMultiSlots Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetitionMultiSlots Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition MultiSlots Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetitionMultiSlotsUENoNotype2-PUSCH-RepetitionMultiSlots Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RepK value equal to 2, 4, or 8 with a single repetition MultiSlotsUENoNotype2-SP-CSI-Feedback-LongPUCCH 					
Defines whether the UE supports DM-RS pattern for UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS.UENoNoIndicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-LongAndShortFormat.UENoNoYestwoPUCCH-F0-2-ConsecSymbolsUENoVesYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoNoYestype1-PUSCH-RepetitionMultiSlotsUENoNoNoNoIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetitionMultiSlots Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within			Vaa	Na	Vaa
symbols front-loaded DM-RŠ with one additional 2 symbols DM-RS.Image: Content of the symbols of the public of the pub		UE	res	INO	res
twoPUCCH-AnyOthersInSlotUENoNoYesIndicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-LongAndShortFormat.UENoYesYestwoPUCCH-F0-2-ConsecSymbolsUENoYesYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoYesYestype1-PUSCH-RepetitionMultiSlotsUENoNoNoNoNoIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNoNoalso support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNoNoIndicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNoNoIndicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNoNoIndicates whether the UE supports Type 1 CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNoNoIndicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UENoNoYesIndicates whether the UE supports the alternative 64QAM					
Indicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-LongAndShortFormat.UENoYesYestwoPUCCH-F0-2-ConsecSymbolsUENoYesYesYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoNoNotype1-PUSCH-RepetitionMultiSlotsUENoNoNoIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNowith a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-ReV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNoIndicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNoIndicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNoIndicates whether the UE supports Type 1 CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNoIndicates whether the UE supports type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNoIndica			No	No	Vaa
the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-LongAndShortFormat.UENoYestwoPUCCH-F0-2-ConsecSymbolsUENoYesYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoNoNotype1-PUSCH-RepetitionMultiSlotsULUENoNoNoNoIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNoNowith a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-Rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNoNotype2-PUSCH-RepetitionMultiSlots Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-Rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSF-Feedback-LongPUCCH Indicates whether the UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNoulc-6dQBlockSegmentationUEIUENoNoYesIndicates whether the UE		UE	INO	INO	res
onePUCCH-LongAndShortFormat.UENoYestwoPUCCH-F0-2-ConsecSymbolsUENoYesYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoNoNotype1-PUSCH-RepetitionMultiSlotsUENoNoNoNoNoIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSL-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting ov					
twoPUCCH-F0-2-ConsecSymbolsUENoYesYesIndicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoNoNotype1-PUSCH-RepetitionMultiSlotsUENoNoNoNoNoIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNoNowith a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNotype2-PUSCH-RepetitionMultiSlotsUENoNoNoIndicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNowith a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether the UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNouci-CodeBlockSegmentation Indicates whether the UE supports the alternative 64QAM MCS table for PUSCH with and without transform precoding respectively.U					
Indicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.UENoNotype1-PUSCH-RepetitionMultiSlots Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-PUSCH-RepetitionMultiSlots grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UEYesNoNouci-CodeBlockSegmentation Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UEYesNoNoul-64QAM-MCS-TableAlt Indicates whether the UE supports the alternative 64Q		LIE	No	Ves	Vec
consecutive symbols in a slot.UENoNotype1-PUSCH-RepetitionMultiSlotsUENoNoNoIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNowith a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-PUSCH-RepetitionMultiSlots Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12]. uci-CodeBlockSegmentationUEYesNoYesIndicates whether the UE supports the alternative 64QAM MCS table for PUSCH with and without transform precoding respectively.UEYesYesYesul-SchedulingOffsetUEYesYesYesYesYes				163	163
type1-PUSCH-RepetitionMultiSlotsUENoNoIndicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNowith a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-PUSCH-RepetitionMultiSlots Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNouci-CodeBlockSegmentation Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UENoNoYesul-64QAM-MCS-TableAlt Indicates whether the UE supports the alternative 64QAM MCS table for PUSCHUENoNoYesul-SchedulingOffsetUEYesYesYesYes					
Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-PUSCH-RepetitionMultiSlots uncates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether the UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNoNouci-CodeBlockSegmentation Indicates whether the UE supports the alternative 64QAM MCS table for PUSCH with and without transform precoding respectively.UENoNoYesul-SchedulingOffsetUEYesYesYesYesYes			No	No	No
grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNo <i>type2-PUSCH-RepetitionMultiSlots</i> Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RepK-verep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one. <i>type2-SP-CSI-Feedback-LongPUCCH</i> Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNo <i>uci-CodeBlockSegmentation</i> Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UENoNoYes <i>ul-64QAM-MCS-TableAlt</i> with and without transform precoding respectively.UENoNoYes				140	110
with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-PUSCH-RepetitionMultiSlots Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNoNouci-CodeBlockSegmentation Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UENoNoYesul-64QAM-MCS-TableAlt Indicates whether the UE supports the alternative 64QAM MCS table for PUSCHUENoNoYesul-SchedulingOffsetUEYesYesYesYes					
version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-PUSCH-RepetitionMultiSlots Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNoYesuci-CodeBlockSegmentation Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UEVesNoYesul-64QAM-MCS-TableAlt with and without transform precoding respectively.UEYesYesYesYes					
also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-PUSCH-RepetitionMultiSlots Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNoul-CodeBlockSegmentation Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UENoNoYesul-64QAM-MCS-TableAlt with and without transform precoding respectively.UEYesYesYesYesul-SchedulingOffsetUEYesYesYesYes					
38.214 [12] with UL-TWG-repK value of one.UENoNotype2-PUSCH-RepetitionMultiSlotsUENoNoNoIndicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNowith a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNouci-CodeBlockSegmentation Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UENoNoYesul-64QAM-MCS-TableAlt with and without transform precoding respectively.UEYesYesYesYes					
type2-PUSCH-RepetitionMultiSlotsUENoNoIndicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8UENoNowith a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNouci-CodeBlockSegmentation Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UENoNoYesul-64QAM-MCS-TableAlt with and without transform precoding respectively.UEVesYesYesYesul-SchedulingOffsetUEYesYesYesYes					
Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNoNouci-CodeBlockSegmentation Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UEYesNoYesul-64QAM-MCS-TableAlt with and without transform precoding respectively.UEYesYesYesYesul-SchedulingOffsetUEYesYesYesYes		UF	No	No	No
grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNouci-CodeBlockSegmentation Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UEYesNoYesul-64QAM-MCS-TableAlt with and without transform precoding respectively.UEYesYesYesYesul-SchedulingOffsetUEYesYesYesYes					
with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNouci-CodeBlockSegmentation lepending on the payload size.UEYesNoYesul-64QAM-MCS-TableAlt with and without transform precoding respectively.UEVEYesYesul-SchedulingOffsetUEYesYesYes					
version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UENoNouci-CodeBlockSegmentation Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UEYesNoYesul-64QAM-MCS-TableAlt with and without transform precoding respectively.UEVesYesYesYesul-SchedulingOffsetUEYesYesYesYes					
also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.Image: Constraint of the support o					
38.214 [12] with UL-TWG-repK value of one.UENoNotype2-SP-CSI-Feedback-LongPUCCHUENoNoNoIndicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UEVesNouci-CodeBlockSegmentationUEYesNoYesIndicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UEVesNoul-64QAM-MCS-TableAltUENoNoYesIndicates whether the UE supports the alternative 64QAM MCS table for PUSCHUENoNowith and without transform precoding respectively.UEYesYesYes					
type2-SP-CSI-Feedback-LongPUCCHUENoNoNoIndicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UEYesNoYesuci-CodeBlockSegmentationUEYesNoYesYesIndicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UEYesNoYesul-64QAM-MCS-TableAltUENoNoYesYesIndicates whether the UE supports the alternative 64QAM MCS table for PUSCHUENoYeswith and without transform precoding respectively.UEYesYesYesul-SchedulingOffsetUEYesYesYes					
Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].UEYesNoYesuci-CodeBlockSegmentation Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UEYesNoYesul-64QAM-MCS-TableAlt Indicates whether the UE supports the alternative 64QAM MCS table for PUSCH with and without transform precoding respectively.UENoNoYesul-SchedulingOffsetUEYesYesYesYes		UE	No	No	No
PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12]. UE Ves uci-CodeBlockSegmentation UE Yes No Yes Indicates whether the UE supports segmenting UCI into multiple code blocks UE Yes No Yes ul-64QAM-MCS-TableAlt UE No No Yes Indicates whether the UE supports the alternative 64QAM MCS table for PUSCH UE No Yes with and without transform precoding respectively. UE Yes Yes ul-SchedulingOffset UE Yes Yes					
uci-CodeBlockSegmentationUEYesNoYesIndicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UENoYesul-64QAM-MCS-TableAltUENoNoYesIndicates whether the UE supports the alternative 64QAM MCS table for PUSCHUENoYeswith and without transform precoding respectively.UEYesYesul-SchedulingOffsetUEYesYes					
Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.UENoYesul-64QAM-MCS-TableAlt Indicates whether the UE supports the alternative 64QAM MCS table for PUSCH with and without transform precoding respectively.UENoYesul-SchedulingOffsetUEYesYes		UF	Yes	No	Yes
depending on the payload size.UENoYesul-64QAM-MCS-TableAltUENoYesIndicates whether the UE supports the alternative 64QAM MCS table for PUSCHUENoYeswith and without transform precoding respectively.UEYesYesul-SchedulingOffsetUEYesYes					
ul-64QAM-MCS-TableAltUENoYesIndicates whether the UE supports the alternative 64QAM MCS table for PUSCHUENoYeswith and without transform precoding respectively.UEYesYesul-SchedulingOffsetUEYesYes					
Indicates whether the UE supports the alternative 64QAM MCS table for PUSCH Image: Comparison of the support o		UF	No	No	Yes
with and without transform precoding respectively. UE Yes Yes ul-SchedulingOffset UE Yes Yes					
ul-SchedulingOffset UE Yes Yes Yes					
		UE	Yes	Yes	Yes
	Indicates whether the UE supports UL scheduling slot offset (K2) greater than 12.				

4.2.7.11 Other PHY parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
appliedFreqBandListFilter Mirrors the <i>FreqBandList</i> that the NW provided in the capability enquiry, if any. The UE filtered the band combinations in the <i>supportedBandCombinationList</i> in accordance with this <i>appliedFreqBandListFilter</i> .	UE	No	No	No
downlinkSetEUTRA Indicates the features that the UE supports on the DL carriers corresponding to one EUTRA band entry in a band combination by FeatureSetEUTRA-DownlinkId. The FeatureSetEUTRA-DownlinkId = 0 means that the UE does not support a EUTRA DL carrier in this band of a band combination.	Band	N/A	N/A	N/A
downlinkSetNR Indicates the features that the UE supports on the DL carriers corresponding to one NR band entry in a band combination by FeatureSetDownlinkId. The FeatureSetDownlinkId = 0 means that the UE does not support a DL carrier in this band of a band combination. A fallback per band feature set resulting from the reported DL feature set that has fallback per CC feature set is not signalled but the UE shall support it.	Band	N/A	N/A	N/A
<i>featureSetCombinations</i> Pools of feature sets that the UE supports on the NR or MR-DC band combinations.	UE	N/A	No	No
featureSets Pools of downlink and uplink features sets as well as a pool of FeatureSetCombination elements. A FeatureSetCombination refers to the IDs of the feature set(s) that the UE supports in that FeatureSetCombination. The BandCombination entries in the BandCombinationList then indicate the ID of the FeatureSetCombination that the UE supports for that band combination.	UE	N/A	No	No
<i>naics-Capability-List</i> Indicates that UE in MR-DC supports NAICS as defined in TS 36.331 [17].	UE	No	No	No
<i>receivedFilters</i> Contains all filters requested with UE-CapabilityRequestFilterNR from version 15.6.0 onwards.	UE	No	No	No
supportedBandCombinationList Defines the supported NR and/or MR-DC band combinations by the UE. For each band combination the UE identifies the associated feature set combination by featureSetCombinations index referring to featureSetCombination. A fallback band combination resulting from the reported CA and MR-DC band combination is not signalled but the UE shall support it. For intra-band non-contiguous CA band combinations, the UE only includes one band combination, and exclude the others for which the presence of uplink CA bandwidth class in the band combination entry is different. One band combination entry can also indicate support of any other possible permutations in the presence of uplink CA bandwidth class where a paired downlink CA bandwidth class is the same or where the number of UL CCs is smaller than the one of paired DL CCs expressed by the CA bandwidth class, as specified in TS 36.306 [15]. For these band combinations not included in the capability, the supported feature set is the same as the ones for the band combination included in the UE capability.	UE	Yes	No	No
supportedBandCombinationListNEDC-Only Defines the supported NE-DC only type of band combinations by the UE.	UE	No	No	No
supportedBandListNR Includes the supported NR bands as defined in TS 38.101-1 [2] and TS 38.101-2 [3].	UE	Yes	No	No
uplinkSetEUTRA Indicates the features that the UE supports on the UL carriers corresponding to one EUTRA band entry in a band combination by FeatureSetEUTRA-UplinkId. The FeatureSetUplinkId = 0 means that the UE does not support a UL carrier in this band of a band combination.	Band	N/A	N/A	N/A
uplinkSetNR Indicates the features that the UE supports on the UL carriers corresponding to one NR band entry in a band combination by FeatureSetUplinkId. The FeatureSetUplinkId = 0 means that the UE does not support a UL carrier in this band of a band combination. A fallback per band feature set resulting from the reported UL feature set that has fallback per CC feature set is not signalled but the UE shall support it.	Band	N/A	N/A	N/A

4.2.7.12 NRDC-Parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
<i>sfn-SyncNRDC</i> Indicates the UE supports NR-DC only with SFN and frame synchronization between PCell and PSCell. If not included by the UE supporting NR-DC, the UE supports NR-DC with slot-level synchronization without condition on SFN and frame synchronization.	UE	No	No	No

4.2.7.13 CarrierAggregationVariant

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
fr1fdd-FR1TDD-CA-SpCellOnFR1FDD	UE	No	No	No
Indicates whether the UE supports an FR1 FDD SpCell (and possibly SCells) when				
configured with an FR1 TDD SCell.				
fr1fdd-FR1TDD-CA-SpCellOnFR1TDD	UE	No	No	No
Indicates whether the UE supports an FR1 TDD SpCell (and possibly SCells) when				
configured with an FR1 FDD SCell.				
fr1fdd-FR1TDD-FR2TDD-CA-SpCellOnFR1FDD	UE	No	No	No
Indicates whether the UE supports an FR1 FDD SpCell (and possibly SCells) when				
configured with an FR1 TDD SCell and an FR2 TDD SCell.				
fr1fdd-FR1TDD-FR2TDD-CA-SpCellOnFR1TDD	UE	No	No	No
Indicates whether the UE supports an FR1 TDD SpCell (and possibly SCells) when				
configured with an FR1 FDD SCell and an FR2 TDD SCell.				
fr1fdd-FR1TDD-FR2TDD-CA-SpCellOnFR2TDD	UE	No	No	No
Indicates whether the UE supports an FR2 TDD SpCell (and possibly SCells) when				
configured with an FR1 FDD SCell and an FR1 TDD SCell.				
fr1fdd-FR2TDD-CA-SpCellOnFR1FDD	UE	No	No	No
Indicates whether the UE supports an FR1 FDD SpCell (and possibly SCells) when				
configured with an FR2 TDD SCell.				
fr1fdd-FR2TDD-CA-SpCellOnFR2TDD	UE	No	No	No
Indicates whether the UE supports an FR2 TDD SpCell (and possibly SCells) when				
configured with an FR1 FDD SCell.				
fr1tdd-FR2TDD-CA-SpCellOnFR1TDD	UE	No	No	No
Indicates whether the UE supports an FR1 TDD SpCell (and possibly SCells) when				
configured with an FR2 TDD SCell.				
fr1tdd-FR2TDD-CA-SpCellOnFR2TDD	UE	No	No	No
Indicates whether the UE supports an FR2 TDD SpCell (and possibly SCells) when				
configured with an FR1 TDD SCell.				

4.2.8 Void

4.2.9 MeasAndMobParameters

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
csi-RS-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of CSI-RS as specified in TS 38.213 [11] and TS 38.133 [5]. This parameter needs FR1 and FR2 differentiation. If the UE supports this feature, the UE needs to report <i>maxNumberResource-CSI-RS-RLM</i> .	UE	Yes	No	Yes
<i>csi-RSRP-AndRSRQ-MeasWithSSB</i> Indicates whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured with an associated SS/PBCH. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell. If the UE supports this feature, the UE needs to report <i>maxNumberCSI-RS-RRM-RS-SINR</i> .	UE	No	No	Yes
<i>csi-RSRP-AndRSRQ-MeasWithoutSSB</i> Indicates whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured for a cell that transmits SS/PBCH block and without an associated SS/PBCH block. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell. If the UE supports this feature, the UE needs to report <i>maxNumberCSI-RS-RRM-RS-SINR</i> .	UE	No	No	Yes
<i>csi-SINR-Meas</i> Indicates whether the UE can perform CSI-SINR measurements based on configured CSI-RS resources as specified in TS 38.215 [13]. If this parameter is indicated for FR1 and FR2 differently, each indication corresponding to the frequency range of measured target cell. If the UE supports this feature, the UE needs to report <i>maxNumberCSI-RS-RRM-RS-SINR</i> .	UE	No	No	Yes
<i>eutra-CGI-Reporting</i> Defines whether the UE supports acquisition of relevant information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the (NG)EN-DC and NE-DC are not configured or, when consistent DRX is configured in NR-DC. The consistent DRX configuration implies that MN and SN have the same DRX cycle and on-duration configured by MN completely contains on- duration configured by SN. It is mandated if the UE supports EUTRA.	UE	CY	No	No
<i>eutra-CGI-Reporting-NEDC</i> Defines whether the UE supports acquisition of relevant information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the NE-DC is configured.	UE	No	No	No
eutra-CGI-Reporting-NRDC Defines whether the UE supports acquisition of relevant information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the NR- DC is configured wherein MN and SN have different DRX cycles, or on-duration configured by MN does not contain on-duration configured by SN if the DRX cycles are the same.	UE	No	No	No
eventA-MeasAndReport Indicates whether the UE supports NR measurements and events A triggered reporting as specified in TS 38.331 [9]. This field only applies to SN configured measurement when (NG)EN-DC is configured. For NR SA, MN and SN configured measurement when NR-DC is configured, and MN configured measurement when NE-DC is configured, this feature is mandatory supported.	UE	Yes	Yes	No
eventB-MeasAndReport Indicates whether the UE supports EUTRA measurement and event B triggered reporting as specified in TS 38.331 [9]. It is mandated if the UE supports EUTRA.	UE	CY	No	No
<i>handoverLTE-5GC</i> Indicates whether the UE supports HO to EUTRA connected to 5GC. It is mandated if the UE supports EUTRA connected to 5GC.	UE	CY	Yes	Yes
handoverFDD-TDD Indicates whether the UE supports HO between FDD and TDD. It is mandated if the UE supports both FDD and TDD. This field only applies to NR SA/NR-DC/ NE- DC (e.g. PCell handover). For PSCell change when (NG)EN-DC/NR-DC is configured, this feature is mandatory supported. UEs supporting this shall indicate support of <i>handoverInterF</i> for both FDD and TDD.	UE	Yes	No	No

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
handoverFR1-FR2 Indicates whether the UE supports HO between FR1 and FR2. Support is mandatory for the UE supporting both FR1 and FR2. This field only applies to NR SA/NR-DC/NE-DC (e.g. PCell handover). For PSCell change when (NG)EN- DC/NR-DC is configured, this feature is mandatory supported. UEs supporting this shall indicate support of handoverInterF for both FR1 and FR2.	UE	Yes	No	No
handoverInterF Indicates whether the UE supports inter-frequency HO. It indicates the support for inter-frequency HO from the corresponding duplex mode and from frequency range indicated to be supported as described in Annex B. This field only applies to NR SA/NR-DC/NE-DC (e.g. PCell handover). For PSCell change when (NG)EN- DC/NR-DC is configured, this feature is mandatory supported.	UE	Yes	Yes	Yes
handoverLTE-EPC Indicates whether the UE supports HO to EUTRA connected to EPC. It is mandated if the UE supports EUTRA connected to EPC.	UE	CY	Yes	Yes
<i>independentGapConfig</i> This field indicates whether the UE supports two independent measurement gap configurations for FR1 and FR2 specified in clause 9.1.2 of TS 38.133 [5]. The field also indicates whether the UE supports the FR2 inter-RAT measurement without gaps when (NG)EN-DC is not configured.	UE	No	No	No
<i>intraAndInterF-MeasAndReport</i> Indicates whether the UE supports NR intra-frequency and inter-frequency measurements and at least periodical reporting. This field only applies to SN configured measurement when (NG)EN-DC is configured. For NR SA, MN and SN configured measurement when NR-DC is configured, and MN configured measurement when NE-DC is configured, this feature is mandatory supported.	UE	Yes	Yes	No
<i>periodicEUTRA-MeasAndReport</i> Indicates whether the UE supports periodic EUTRA measurement and reporting. It is mandated if the UE supports EUTRA.	UE	CY	No	No
maxNumberCSI-RS-RRM-RS-SINR Defines the maximum number of CSI-RS resources for RRM and RS-SINR measurement across all measurement frequencies per slot. If UE supports any of csi-RSRP-AndRSRQ-MeasWithSSB, csi-RSRP-AndRSRQ-MeasWithoutSSB, and csi-SINR-Meas, UE shall report this capability.	UE	CY	No	No
<i>maxNumberResource-CSI-RS-RLM</i> Defines the maximum number of CSI-RS resources within a slot per spCell for CSI-RS based RLM. If UE supports any of <i>csi-RS-RLM</i> and <i>ssb-AndCSI-RS-RLM</i> , UE shall report this capability.	UE	CY	No	Yes
<i>nr-CGI-Reporting</i> Defines whether the UE supports acquisition of relevant information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when (NG)EN-DC and NE-DC are not configured or, when consistent DRX is configured in NR-DC. The consistent DRX configuration implies that MN and SN have the same DRX cycle and on-duration configured by MN completely contains on-duration configured by SN.	UE	Yes	No	No
<i>nr-CGI-Reporting-ENDC</i> Defines whether the UE supports acquisition of relevant information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the (NG)EN-DC is configured.	UE	Yes	No	No
<i>nr-CGI-Reporting-NEDC</i> Defines whether the UE supports acquisition of relevant information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the NE-DC is configured.	UE	Yes	No	No
<i>nr-CGI-Reporting-NRDC</i> Defines whether the UE supports acquisition of relevant information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the NR-DC is configured wherein MN and SN have different DRX cycles, or on-duration configured by MN does not contain on- duration configured by SN if the DRX cycles are the same.	UE	Yes	No	No

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
simultaneousRxDataSSB-DiffNumerology Indicates whether the UE supports concurrent intra-frequency measurement on serving cell or neighbouring cell and PDCCH or PDSCH reception from the serving cell with a different numerology as defined in clause 8 and 9 of TS 38.133 [5].	UE	No	No	Yes
sftd-MeasPSCell Indicates whether the UE supports SFTD measurements between the PCell and a configured PSCell. If this capability is included in UE-MRDC-Capability, it indicates that the UE supports SFTD measurement between PCell and PSCell in (NG)EN- DC. If this capability is included in UE-NR-Capability, it indicates that the UE supports SFTD measurement between PCell and PSCell in NR-DC.	UE	No	Yes	No
<i>sftd-MeasPSCell-NEDC</i> Indicates whether the UE supports SFTD measurement between the NR PCell and a configured E-UTRA PSCell in NE-DC.	UE	No	Yes	No
sftd-MeasNR-Cell Indicates whether the SFTD measurement with and without measurement gaps between the EUTRA PCell and the NR cells is supported by the UE which is capable of EN-DC/NGEN-DC when EN-DC/NGEN-DC is not configured. The SFTD measurement without gaps can be used when the UE supports at least one EN-DC band combination consisting of the set of the current E-UTRA serving frequencies and the NR frequency where SFTD measurement is configured. In UE-NR-Capability, this field is not used, and UE does not include the field.	UE	No	Yes	No
sftd-MeasNR-Neigh Indicates whether the inter-frequency SFTD measurement with and without measurement gaps between the NR PCell and inter-frequency NR neighbour cells is supported by the UE when MR-DC is not configured. The SFTD measurement without gaps can be used when the UE supports at least one DC or CA band combination consisting of the set of the current NR serving frequencies and the NR frequency where SFTD measurement is configured.	UE	No	Yes	No
<i>sftd-MeasNR-Neigh-DRX</i> Indicates whether the inter-frequency SFTD measurement using DRX off period between the NR PCell and the inter-frequency NR neighbour cells is supported by the UE when MR-DC is not configured.	UE	No	Yes	No
ssb-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of SS/PBCH block as specified in TS 38.213 [11] and TS 38.133 [5]. This field shall be set to <i>supported</i> .	UE	Yes	No	No
ssb-AndCSI-RS-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of SS/PBCH block and CSI-RS as specified in TS 38.213 [11] and TS 38.133 [5]. If the UE supports this feature, the UE needs to report maxNumberResource-CSI-RS-RLM.	UE	No	No	No
ss-SINR-Meas Indicates whether the UE can perform SS-SINR measurement as specified in TS 38.215 [13]. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell.	UE	No	No	Yes
supportedGapPattern Indicates measurement gap pattern(s) optionally supported by the UE for NR SA, for NR-DC, for NE-DC and for independent measurement gap configuration on FR2 in (NG)EN-DC. The leading / leftmost bit (bit 0) corresponds to the gap pattern 2, the next bit corresponds to the gap pattern 3, as specified in TS 38.133 [5] and so on. The UE shall set the bits corresponding to the measurement gap pattern 13 and 14 to 1 if the UE is an NR standalone capable UE that supports a band in FR2 or if the UE is an (NG)EN-DC capable UE that supports <i>independentGapConfig</i> and supports a band in FR2.	UE	CY	No	No

4.2.10 Inter-RAT parameters

Definitions for parameters	Per	М	FDD- TDD DIFF
mfbi-EUTRA	UE	Yes	No
Indicates whether the UE supports the mechanisms defined for cells broadcasting multi band information i.e. comprehending <i>multiBandInfoList</i> defined in TS 36.331 [17].			
modifiedMPR-BehaviorEUTRA	UE	No	No
modifiedMPR-Behavior in 4.3.5.10, TS 36.306 [15].			
multiNS-Pmax-EUTRA	UE	No	No
multiNS-Pmax defined in 4.3.5.16, TS 36.306 [15].			
ne-DC	UE	No	No
Indicates whether the UE supports NE-DC as specified in TS 37.340 [7].			
rs-SINR-MeasEUTRA	UE	No	No
<i>rs-SINR-Meas</i> in 4.3.6.13, TS 36.306 [15].			
rsrgMeasWidebandEUTRA	UE	No	Yes
rsrqMeasWideband in 4.3.6.2, TS 36.306 [15]. If this parameter is indicated for FDD and			
TDD differently, each indication corresponds to the duplex mode of measured target cell.			
supportedBandListEUTRA	UE	No	No
supportedBandListEUTRA defined in 4.3.5.1, TS 36.306 [15].			

- 4.2.10.1 Void
- 4.2.10.2 Void
- 4.2.11 Void
- 4.2.12 Void

4.2.13 IMS Parameters

Definitions for parameters	Per	Μ	FDD- TDD DIFF	FR1- FR2 DIFF
voiceOverEUTRA-5GC Indicates whether the UE supports IMS voice over E-UTRA via 5GC. It is mandated to the UE if the UE is capable of IMS voice over E-UTRA via 5GC. Otherwise, the UE does not include this field. If this field is included and the UE is capable of E-UTRA with EPC, the UE shall support IMS voice over E-UTRA via EPC.	UE	No	No	No
voiceOverNR Indicates whether the UE supports IMS voice over NR. It is mandated to the UE if the UE is capable of IMS voice over NR. Otherwise, the UE does not include this field. If this field is included and the UE is capable of E-UTRA with EPC, the UE shall support IMS voice over E-UTRA via EPC.	UE	No	No	Yes
voiceOverSCG-BearerEUTRA-5GC Indicates whether the UE supports IMS voice over SCG bearer of NE-DC.	UE	No	No	N/A

NOTE: In this release of specification, IMS voice over split bearer is not supported for NR-DC and NE-DC.

4.2.14 RRC buffer size

The RRC buffer size is defined as the maximum overall RRC configuration size that the UE is required to store. The RRC buffer size is 45Kbytes.

5 Optional features without UE radio access capability parameters

5.1 PWS features

Definitions for feature

It is optional for UE to support CMAS reception as specified in TS 38.331 [9]. It is optional for a CMAS-capable UE to support Geofencing information (*warningAreaCoordinates*) as specified in TS 38.331 [9].

ETWS

CMAS

It is optional for UE to support ETWS reception as specified in TS 38.331 [9].

KPAS

It is optional for UE to support Korean Public Alert System (KPAS) reception as specified in TS 38.331 [9]. KPAS uses the same AS mechanisms as defined for CMAS. Therefore a KPAS-capable UE shall support all behaviour that is included in TS 38.331 [9] and TS 38.304 [20] for a CMAS-capable UE.

EU-Alert

It is optional for UE to support EU-Alert reception as specified in TS 38.331 [9]. EU-Alert uses the same AS mechanisms as defined for CMAS. Therefore a EU-Alert-capable UE shall support all behaviour that is included in TS 38.331 [9] and TS 38.304 [20] for a CMAS-capable UE.

5.2 UE receiver features

Definitions for feature

SU-MIMO Interference Mitigation advanced receiver

- R-ML (reduced complexity ML) receivers with enhanced inter-stream interference suppression for SU-MIMO transmissions with rank 2 with 2 RX antennas
- R-ML (reduced complexity ML) receivers with enhanced inter-stream interference suppression for SU-MIMO transmissions with rank 2, 3, and 4 with 4 RX antennas

UE supporting the feature is required to meet the Enhanced Receiver Type requirements in TS 38.101-4 [18]. MMSE-IRC (Minimum Mean Square Error - Interference Rejection Combining) receiver

It is optional for UE to support MMSE-IRC processing for scenarios with inter-cell and intra-cell inter-user interference.

5.3 RRC connection

Definitions for feature

RRC connection release with deprioritisation

It is optional for UE to support RRCRelease with deprioritisationReq as specified in TS 38.331 [9].

RRC connection establishment failure with temporary offset

It is optional for UE to support RRC connection establishment failure with temporary offset (*Qoffsettemp*) as specified in TS 38.331 [9].

6

Conditionally mandatory features without UE radio access capability parameters

Features	Condition
Skipping UL configured grant if no data to transmit.	Either configuredUL-GrantType1 or configuredUL-GrantType2 is supported.
Downlink SDAP header	Either NAS reflective QoS or as-ReflectiveQoS is supported.
IMS emergency call	It is mandatory to support IMS emergency call for UEs which are IMS voice capable in NR.

7 Void

8 UE Capability Constraints

The following table lists constraints indicating the UE capabilities that the UE shall support.

Parameter	Description	Value							
#DRBs	The number of DRBs that a UE shall support.	16 per UE. NOTE1 NOTE3							
#minCellperMeasObj ectNR	The minimum number of neighbour cells (excluding black list cells) that a UE shall be able to store associated with a MeasObjectNR.	32 NOTE 2							
#minBlackCellRange sperMeasObjectNR	The minimum number of blacklist cell PCI ranges that a UE shall be able to store associated with a MeasObjectNR.	8							
#minBlackCellperMe asObjectEUTRA	The minimum number of blacklist cells that a UE shall be able to store associated with a MeasObjectEUTRA.	32							
#minCellperMeasObj ectEUTRA	The minimum number of neighbour cells that a UE shall be able to store associated with a MeasObjectEUTRA.	32 NOTE 2							
#minCellTotal	The minimum number of neighbour cells (excluding black list cells) that UE shall be able to store in total from all measurement objects configured.	256 with counting CSI-RS and SSB as 2.							
#maxDeprioritisation Freq	The UE shall be able to store a depriotisation request for up to 8 frequencies (applicable when receiving another frequency specific deprioritisation request via <i>RRCRelease</i> before T325 expiry).	8							
	NOTE 1: For one MAC entity, the maximum number of DRBs configured with PDCP duplication and with								
 RLC entity(ies) associated with this MAC entity is 8. NOTE 2: In case of CGI reporting, the limit regarding the cells configured includes the cell for which the UE is requested to report CGI i.e. the amount of neighbour cells that can be included is at most (# minCellperMeasObjectRAT - 1), where RAT represents NR and EUTRA. NOTE 3: This requirement is applicable in NR SA, NR-DC and NE-DC. 									

Annex A (normative): Differentiation of capabilities

A.1: TDD/FDD differentiation of capabilities in TDD-FDD CA

Annex A.1 specifies for which TDD and FDD serving cells a UE supporting TDD/FDD CA shall support a feature/capability for which it indicates support within the capability signalling.

A UE that indicates support for TDD/FDD CA (e.g. MCG or SCG):

- For the fields for which the UE is allowed to indicate different support for FDD and TDD, the UE shall support the feature on the PCell and/or SCell(s), as specified in tables A.1-1 in accordance to the following rules:
 - PCell: the UE shall support the feature for the PCell, if the UE indicates support of the feature for the PCell duplex mode;
 - PSCell: the UE shall support the feature for the PSCell, if the UE indicates support of the feature for the PSCell duplex mode;
 - Per serving cell: the UE shall support the feature for a serving cell if the UE indicates support of the feature for the serving cell's duplex mode;
 - All serving cells: UE shall support the feature for all serving cells in a CG if the UE indicates support of the feature for both TDD and FDD duplex modes;
 - Associated serving cells: UE shall support the feature if the UE indicates support of the feature for all associated serving cells's duplex modes;
- For the fields where the UE is not allowed to indicate different support for FDD and TDD, the UE shall support the feature for PCell and SCell(s) if the UE indicates support of the feature via the common capability bit.

UE-NR-Capability or	Classification						
UE-MRDC-Capability	Classification						
eventA-MeasAndReport	PSCell						
dl-SchedulingOffset-PDSCH-TypeA (Note3)	Associated serving cells						
dl-SchedulingOffset-PDSCH-TypeB (Note3)	Associated serving cells						
dynamicSFI (Note3)	Associated serving cells						
handoverInterF	PCell						
handoverLTE-EPC	PCell						
handoverLTE-5GC	PCell						
intraAndInterF-MeasAndReport	PSCell						
logicalChannelSR-DelayTimer(Note2)	Associated serving cells						
longDRX-Cycle	All serving cells						
multipleConfiguredGrants(Note1)	Associated serving cells						
multipleSR-Configurations	Per serving cell						
sftd-MeasNR-Cell	PCell						
sftd-MeasNR-Neigh	PCell						
sftd-MeasNR-Neigh-DRX	PCell						
sftd-MeasPSCell	PCell						
sftd-MeasPSCell-NEDC	PCell						
shortDRX-Cycle	All serving cells						
skipUplinkTxDynamic	Per serving cell						
twoDifferentTPC-Loop-PUCCH (Note3)	Associated serving cells						
twoDifferentTPC-Loop-PUSCH (Note3)	Associated serving cells						
ul-SchedulingOffset (Note3)	Associated serving cells						
NOTE 1: The associated serving cells includin	g the serving cell(s) configured						
with configured grant.							
NOTE 2: For a given logical channel, the asso							
PUCCH cell(s) associated with this logical channel (via							
schedulingRequestID).							
NOTE 3: The associated serving cells includin							
command and the cell applying the c	command.						

Table A.1-1: UE capabilities for which FDD/TDD differentiation is allowed

A.2: FR1/FR2 differentiation of capabilities in FR1-FR2 CA

Annex A.2 specifies for which FR1 and FR2 serving cells a UE supporting FR1/FR2 CA shall support a feature/capability for which it indicates support within the capability signalling.

A UE that indicates support for FR1/FR2 CA (e.g. MCG or SCG):

- For the fields for which the UE is allowed to indicate different support for FR1 and FR2, the UE shall support the feature on the PCell and/or SCell(s), as specified in tables A.2-1 in accordance to the following rules:
 - PCell: the UE shall support the feature for the PCell, if the UE indicates support of the feature for the PCell FR mode;
 - Associated serving cells: UE shall support the feature if the UE indicates support of the feature for associated serving cells's FR modes;
- For the fields where the UE is not allowed to indicate different support for FR1 and FR2, the UE shall support the feature for PCell and SCell(s) if the UE indicates support of the feature via the common capability bit.

UE-NR-Capability	Classification						
absoluteTPC-Command (Note2)	Associated serving cells						
dl-SchedulingOffset-PDSCH-TypeA (Note2)	Associated serving cells						
dl-SchedulingOffset-PDSCH-TypeB (Note2)	Associated serving cells						
dynamicSFI (Note2)	Associated serving cells						
handoverInterF	PCell						
handoverLTE-EPC	PCell						
handoverLTE-5GC	PCell						
tpc-PUCCH-RNTI (Note2)	Associated serving cells						
tpc-PUSCH-RNTI (Note2)	Associated serving cells						
tpc-SRS-RNTI (Note2)	Associated serving cells						
twoDifferentTPC-Loop-PUCCH (Note2)	Associated serving cells						
twoDifferentTPC-Loop-PUSCH (Note2)	Associated serving cells						
ul-SchedulingOffset (Note2)	Associated serving cells						
voiceOverNR (Note1)	Associated serving cells.						
NOTE 1: For a UE that does not support Ich							
associated serving cells includes a							
that supports Ich-ToSCellRestriction capability, the associated							
serving cells includes the serving cells indicated by							
allowedServingCells for the LCH.							
NOTE 2: The associated serving cells include							
command and the cell applying the	e command.						

Table A.2-1: Rel-15 UE capabilities for which FR1/FR2 differentiation is allowed

A.3: Void

A.4: Void

A.5: General differentiation of capabilities in Cross-Carrier operation

Annex A.5 specifies for which multiple serving cells a UE supporting cross-carrier operation shall support a feature/capability for which it indicates support within the capability signalling.

A UE that indicates support for cross-carrier operation in CA (e.g. MCG or SCG):

- For the fields for which the UE is allowed to indicate different support for different bands, the UE shall support the feature on the PCell and/or SCell(s) in cross-carrier operation, as specified in tables A.5-1 in accordance to the following rules:
 - Triggered serving cell: the UE shall support the feature if the UE indicates support of the feature for the band of the scheduled/triggered/indicated serving cell;
 - Triggering&Triggered serving cells: UE shall support the feature if the UE indicates support of the feature for the band of both the scheduling/triggering/indicating serving cell and the scheduled/triggered/indicated serving cell;

UE-NR-Capability	Classification							
aperiodicTRS	Triggered serving cell							
beamSwitchTiming	Triggered serving cell							
bwp-DiffNumerology (NOTE 1)	Triggering&Triggered serving cells							
bwp-SameNumerology (NOTE 1)	Triggering&Triggered serving cells							
crossCarrierScheduling-SameSCS	Triggering&Triggered serving cells							
pdcch-MonitoringAnyOccasionsWithSpanGap	Triggering&Triggered serving cells							
(NOTE 2)								
ue-SpecificUL-DL-Assignment	Triggering&Triggered serving cells							
NOTE 1: For <i>bwp-DiffNumerology</i> and <i>bwp-Sar</i>								
for each band is still based on the indi	cated number for this band regardless of							
whether it is a scheduling cell or sched								
NOTE 2: Applicable for cross carrier scheduling with the same SCS in the scheduling cell and								
the scheduled cell. If the reported value is different between the band of the								
	the band of the scheduling/triggering/indicating							
cell, the value reported for the schedu	ing/triggering/indicating cell is applied.							

 Table A.5-1: General UE capabilities for which differentiation is allowed

Annex B (informative): UE capability indication for UE capabilities with both FDD/TDD and FR1/FR2 differentiations

Annex B clarifies the UE capability indication for the case where the UE is allowed to support different functionality between FDD and TDD, and between FR1 and FR2. Table B-1 clarifies the setting of UE capability fields for cases where the UE supports the corresponding feature in different combinations of duplex mode and frequency range. There are two possible ways of UE capability indication in Case 3 and Case 8.

Supp	port for the feature			Setting of UE	capability fiel	ds	
		Common UE capability (with suffix '- XDD-Diff')	Common UE capability (with suffix '- FRX-diff')	fdd-Add- UE- NR/MRDC- Capabilities	tdd-Add- UE- NR/MRDC- Capabilities	fr1-Add-UE- NR/MRDC- Capabilities	fr2-Add-UE- NR/MRDC- Capabilities
Case 1	FR1 FDD: 'supported' FR1 TDD: 'supported' FR2 TDD: 'supported'	Included	Included	Not included	Not included	Not included	Not included
Case 2	FR1 FDD: 'not supported' FR1 TDD: 'not supported' FR2 TDD: 'not supported'	Not included	Not included	Not included	Not included	Not included	Not included
Case 3	FR1 FDD: 'not supported'	Not included	Included	Not included	Included	Not included	Not included
	FR1 TDD: 'supported' FR2 TDD: 'supported'	Not included	Not included	Not included	Included	Not included	Not included
Case 4	FR1 FDD: 'not supported' FR1 TDD: 'not supported' FR2 TDD: 'supported'	Not included	Not included	Not included	Included	Not included	Included
Case 5	FR1 FDD: 'not supported' FR1 TDD: 'supported' FR2 TDD: 'not supported'	Not included	Not included	Not included	Included	Included	Not included
Case 6	FR1 FDD: 'supported' FR1 TDD: 'not supported' FR2 TDD: 'supported'	The current this case.	UE capability	signalling does	not support the	UE capability ir	ndication for
Case 7	FR1 FDD: 'supported' FR1 TDD: 'not supported' FR2 TDD: 'not supported'	Not included	Not included	Included	Not included	Included	Not included
Case 8	FR1 FDD: 'supported'	Included	Not included	Not included	Not included	Included	Not included
	FR1 TDD: 'supported' FR2 TDD: 'not supported'	Not included	Not included	Not included	Not included	Included	Not included

Table B-1: UE capability indication for UE capabilities with both FDD/TDD and FR1/FR2 differentiations

ETSI TS 138 306 V15.18.0 (2022-10)

Annex C (informative): Change history

	•					Change history	
Date	Meeting	TDoc	CR	Rev	Cat	Subject/Comment	New version
06/2017	RAN2#98	R2- 1704810				First version	0.0.1
06/2017	RAN2#NR2						0.0.2
08/2017	RAN2#99	R2- 1708750					0.0.3
12/2017	RAN2#100	R2- 1712587					0.0.4
12/2017	RAN2#100	R2- 1714141					0.0.5
12/2017	RAN2#100	R2-					0.1.0
12/2017	RP-78	1714271 RP-172521				Submitted to RAN#78 for approval	1.0.0
12/2017	RP-78	111-172521				Upgraded to Rel-15	15.0.0
03/2018	RP-79	RP-180440	0003	3	F	Updates on UE capabilities	15.1.0
06/2018	RP-80	RP-181216		2	B	Introduce ANR in NR	15.2.0
00/2016	RP-80	RP-181216		2	F	Miscellaneous corrections	15.2.0
	RP-80	RP-181216		-	B	Delay budget report and MAC CE adaptation for NR for TS 38.306	15.2.0
09/2018	RP-81	RP-181940		4	F	Correction on total layer2 buffer size	15.2.0
09/2010	RP-81		0008	4	F	Introduction of UE capability constraints	
	RP-81	RP-181942 RP-181942		-	F		15.3.0
12/2018	RP-81 RP-82		0030 0016	4	F	38.306 corrections and cleanup Clarification for Interruption-based and gap-based SFTD	15.3.0 15.4.0
					_	measurement	
	RP-82	RP-182653	0033	1	F	Timer based BWP switching	15.4.0
	RP-82		0035	2	F	Additional UE capabilities for NR standalone	15.4.0
	RP-82	RP-182651	0037	1	F	Clarification to UE capability of independentGapConfig for inter-RAT NR measurement not yet configured with EN-DC	15.4.0
	RP-82	RP-182661	0038	2	F	Update of L2 capability parameters	15.4.0
	RP-82	RP-182660	0047	2	F	Clarification on physical layer parameters of UE capability	15.4.0
	RP-82	RP-182666	0050	3	F	Introduce RRC buffer size in NR	15.4.0
	RP-82	RP-182664	0051	2	F	Clarification of multipleConfiguredGrants	15.4.0
	RP-82	RP-182664	0052	2	F	CR to 38.306 for PDCP CA duplication for SRB	15.4.0
	RP-82	RP-182661	0054	1	F	UE capability handling for FDD/TDD and FR1/FR2	15.4.0
	RP-82	RP-182663	0057	1	F	Clarify for per CC UL/DL modulation order capabilities	15.4.0
	RP-82	RP-182664	0058	1	F	Inter-frequency handover capability	15.4.0
	RP-82	RP-182665	0060	3	F	UE capability on PA architecture	15.4.0
	RP-82	RP-182661	0062	1	F	CR on signaling contiguous and non-contiguous EN-DC capability	15.4.0
	RP-82		0063	6	F	Update of UE capabilities	15.4.0
	RP-82	RP-182662	0065	2	F	Introduction of SRS switching capability	15.4.0
	RP-82	RP-182667	0068	2	В	CR on introduction of UE overheating support in NR SA scenario	15.4.0
	RP-82	RP-182664	0071	-	F	Introduction of SRS switching capability	15.4.0
03/2019	RP-83		0073	1	F	Capability for aperiodic CSI-RS triggering with different numerology between PDCCH and CSI-RS	15.5.0
	RP-83	RP-190542	0074	1	F	Layer-1 capability update	15.5.0
	RP-83	RP-190545		2	F	CR to 38.306 on introducing nr-CGI-Reporting-ENDC	15.5.0
	RP-83	RP-190545		2	F	CR to clarify intra-NR handover capabilities	15.5.0
	RP-83	RP-190546		2	F	Clarification for PDSCHs and PUSCHs per slot for different TBs for	15.5.0
	KF-03	KF-190340	0000	3		UE capable of processing time capability 1	15.5.0
	RP-83	RP-190542	0092	2	F	Correction to mandatory supported capability signaling	15.5.0
	RP-83	RP-190542	0097	2	F	Miscellaneous corrections	15.5.0
	RP-83		0098	2	F	Correction on supportedBandwidthCombinationSetEUTRA-v1530 usage	15.5.0
	RP-83	RP-190543	0099	-	F	Clarification on signaling the bandwidth class	15.5.0
	RP-83	RP-190545		1	F	Clarification on Frequency Separation Class	15.5.0
	RP-83	RP-190544		-	F	CR on Processing delay requirements for RRC Resume procedures in TS 38.306	
06/2019	RP-84	RP-191375	0004	1	F	CR to clarify ul-TimingAlignmentEUTRA-NR	15.6.0
30/2013	RP-84	RP-191373		<u> -</u>	F	Layer-1, RF and RRM capability updates	15.6.0
	RP-84	RP-191373		-	F	Clarification on UE capability of Ich-ToSCellRestriction	15.6.0
	RP-84	RP-191373		2	F	Correction on description of additionalActiveSpatialRelationPUCCH	15.6.0
	RP-84	RP-191378		1	F	Clarification on csi-RS-CFRA-ForHO	15.6.0
	RP-84	RP-191378 RP-191379		2	F	CR on capability of maxUplinkDutyCycle for FR2	15.6.0
					F	38.306 miscellaneous corrections	
	RP-84	RP-191380		2			15.6.0
	RP-84	RP-191378		1	B F	38.306 CR for late drop	15.6.0
	RP-84	RP-191381		4		Clarification on supported modulation order capability	15.6.0
	RP-84	RP-191374		-	F	Correction to PDCP parameters	15.6.0
	RP-84	RP-191381	0121	3	F	Corrections to UE Capability definitions	15.6.0
	RP-84		0122	1	F	38.306 Clarification on multiple TA capabilities	15.6.0
	RP-84	RP-191379	0123	2	F	CR to clarify non-codebook based PUSCH transmission	15.6

	RP-84	RP-191380		3	F	Clarification on pdsch-ProcessingType2	15.6.0
	RP-84	RP-191378		1	F	Clarification on present of tci-StatePDSCH	15.6.0
	RP-84	RP-191378		1	F	Clarification on SA fallback BC support	15.6.0
	RP-84 RP-84	RP-191375		-	F	Correction to Beam Correspondence for CA Correction on the number of DRB in UE Capability Constraints	15.6.0
	RP-64 RP-84	RP-191379 RP-191379	0130	2	F	CR to capture UE supported DL/UL bandwidths	15.6.0 15.6.0
	RP-84	RP-191376	0132	-	F	UE capability signalling for FD-MIMO processing capabilities for EN-	15.6.0
	RP-84	RP-191376	0134	-	F	DC Modified UE capability on different numerologies within the same	15.6.0
	RP-84	RP-191554	0135	-	F	PUCCH group Removal of "Capability for aperiodic CSI-RS triggering with different	15.6.0
					_	numerology between PDCCH and CSI-RS"	
09/2019	RP-85	RP-192196	0136	1	С	Additional capability signalling for 1024QAM support	15.7.0
	RP-85	RP-192191	0142	1	В	Introduction of SFTD measurement to neighbour cells for NR SA	15.7.0
	RP-85 RP-85		0146 0151	1 3	F	MR-DC measurement gap pattern capability Clarifying UE capability freqHoppingPUCCH-F0-2 and	15.7.0 15.7.0
				Ŭ		freqHoppingPUCCH-F1-3-4	
	RP-85	RP-192190	0152	- 2	F	Clarification to dynamic power sharing capability	15.7.0
	RP-85 RP-85	RP-192192 RP-192190		2	F	Miscellaneous corrections Capability of measurement gap patterns	15.7.0 15.7.0
	RP-85		0154	-	F	Correction to IMS capability	15.7.0
	RP-85		0155	2	F	UE Capabilities covering across all serving cells	15.7.0
	RP-85	RP-192194	0167	-	F	Clarification on UE capability on different numerologies within the	15.7.0
						same PUCCH group	
	RP-85	RP-192193	0168	1	F	Correction on CA parameters in NR-DC	15.7.0
	RP-85	RP-192346	0169	-	С	Introduction of UE capability for NR-DC with SFN synchronization between PCell and PSCell	15.7.0
12/2019	RP-86	RP-192934	0185	1	F	Clarification on the restriction of maximum SRS resource sets configuration for uplink beam management.	15.8.0
	RP-86	RP-192936	0186	3	F	Miscellaneous corrections on UE capability fields	15.8.0
	RP-86	RP-192935	0191	1	F	Corrections on PDCCH blind decoding in NR-DC	15.8.0
	RP-86		0200	1	F	Clarification on ne-DC capability	15.8.0
	RP-86		0202	1	F	Correction to channelBWs	15.8.0
	RP-86		0204	1	F	Use of splitSRB-WithOneUL-Path capability (38.306)	15.8.0
	RP-86	RP-192935	0205	-	F	Correction to pdsch-RepetitionMultiSlots and pusch- RepetitionMultiSlots	15.8.0
	RP-86	RP-192937	0215	1	F	Correction on initial BWP bandwidth capabilities	15.8.0
	RP-86		0216	1	F	NE-DC dynamic power sharing capability	15.8.0
	RP-86		0219	-	F	Clarification on crossCarrierScheduling-OtherSCS in R15	15.8.0
03/2020	RP-86 RP-87	RP-192937 RP-200334	0220 0194	- 2	F F	Correction on ambiguity of UE FDD/TDD FR1/FR2 capabilities Correction on parameter description of beamManagementSSB-CSI- RS	15.8.0 15.9.0
	RP-87	RP-200335	0208	3	F	CR on BWCS for inter-ENDC BC with intra-ENDC BC (38.306)	15.9.0
	RP-87	RP-200335	0209	5	F	CR to 38.306 on support of 70MHz channel bandwidth	15.9.0
	RP-87	RP-200334	0236	-	F	Correction on SRB capability in NR-DC	15.9.0
	RP-87	RP-200335	0248	2	F	Data rate for the case of single carrier standalone operation	15.9.0
	RP-87	RP-200334		1	F	CR on the maximum stored number of deprioritisation frequencies	15.9.0
	RP-87	RP-200335		2	F	Miscellaneous Corrections to UE capability parameters	15.9.0
	RP-87	RP-200335		1	F	UE capability of intra-band requirements for inter-band EN-DC/NE-DC	
07/2020	RP-88	RP-201161	0176	/	F	Default values for UE capability	15.10.0
	RP-88	RP-201163		3	F	Corrections on the number of DRBs	15.10.0
	RP-88	RP-201159		1	F	Clarification on supported NR-DC cell grouping	15.10.0
	RP-88 RP-88	RP-201163 RP-201160	0287	2	F	Correction to the serving cell number for ENDC power class SRS Capability report for SRS only Scell	15.10.0
	RP-88 RP-88		0294	<u> '</u>	F	Clarification on L1 feature of NGEN-DC and NE-DC	15.10.0
	RP-88	RP-201159 RP-201162		1	F	Clarification on L2 and RAN4 feature of NGEN-DC and NE-DC	15.10.0
	RP-88	RP-201163		1	F	Correction on UE capabilities with xDD and FRx differentiations	15.10.0
	RP-88		0303	1	F	Invalidating bandwidth class F for FR1	15.10.0
	RP-88	RP-201162		1	F	Missing "Optional features without UE radio access capability parameters"	15.10.0
	RP-88	RP-201163		1	F	Missing UE capability requirements	15.10.0
	RP-88	RP-201164		2	F	Correction on UE capability constraints	15.10.0
			0332	-	F	on the capability of Basic CSI feedback (2-32)	15.10.0
	RP-88				F	Clarification on the support of IMS voice over split bearer for NR-DC	15.10.0
			0338	1	1		
	RP-88		0338 0342	1	F	and NE-DC Clarification on maximum number of supported PDSCH Resource	15.10.0
	RP-88 RP-88 RP-88	RP-201162	0342			and NE-DC Clarification on maximum number of supported PDSCH Resource Element mapping patterns	15.10.0
	RP-88 RP-88	RP-201162 RP-201161 RP-201164		1	F	and NE-DC Clarification on maximum number of supported PDSCH Resource	15.10.0
	RP-88 RP-88 RP-88 RP-88	RP-201162 RP-201161 RP-201164 RP-201161	0342 0345	1 2	F	and NE-DC Clarification on maximum number of supported PDSCH Resource Element mapping patterns Introduction of CGI reporting capabilities	15.10.0 15.10.0 15.10.0 15.10.0

	RP-88	RP-201163	0359	1	F	Correction on UE capability signalling for simultaneous SRS antenna and carrier switching	15.10.0
	RP-88	RP-201187	0361	-	В	CR on introduction of BCS to asymmetric channel bandwidths (38.306)	15.10.0
09/2020	RP-89	RP-201938	0377	1	F	Corrections on UE capability constraints	15.11.0
	RP-89	RP-201937	0386	1	F	Clarification on PDSCH rate-matching capabilities	15.11.0
	RP-89	RP-201937	0388	2	F	Corrections on the capabilities associated with multiple bands/Cells	15.11.0
	RP-89	RP-201938	0403	2	F	Clarification on the extended capability of NGEN-DC	15.11.0
12/2020	RP-90	RP-202790	0418	2	F	CR to clarify UE capability in case of Cross-Carrier operation	15.12.0
	RP-90	RP-202789	0438	1	F	Clarification on the inter-frequency handover capability	15.12.0
	RP-90	RP-202789	0440	-	F	Clarification on NE-DC for bandwidth combination set	15.12.0
	RP-90	RP-202790	0452	1	F	Removing contradiction on number of FSpUCC and FSpDCC	15.12.0
	RP-90	RP-202789	0460	-	F	Clarification on UE capabilities with FDD/TDD differentiation	15.12.0
	RP-90	RP-202790	0475	-	F	Dummify UE capability of crossCarrierScheduling-OtherSCS	15.12.0
	RP-90	RP-202789	0478	1	F	Clarification for multipleCORESET	15.12.0
	RP-90	RP-202881	0480	-	F	CR to 38.306 on handling of fallbacks for FR2 CA	15.12.0
03/2021	RP-91	RP-210697	0488	2	F	Correction on beamSwitchTiming capability	15.13.0
	RP-91	RP-210701	0499	-	F	Dummy the capability bit v2x-EUTRA	15.13.0
	RP-91	RP-210703	0504	2	F	Clarification to LCP restrictions	15.13.0
	RP-91	RP-210748	0511	2	В	Support of 35 MHz and 45 MHz channel bandwidth for FR1	15.13.0
	RP-91	RP-210703	0515	2	F	CR on the SupportedBandwidth and channelBWs(R15)	15.13.0
	RP-91	RP-210702	0519	1	F	CR to clarify the definition of fallback per CC feature set	15.13.0
	RP-91	RP-210702	0522	1	F	Clarfication on FDD-TDD differentiation for SUL band	15.13.0
	RP-91	RP-210702	0524	1	F	Clarification on single uplink operation capability report	15.13.0
	RP-91	RP-210703	0535	-	F	Clarification on the capability of supportedNumberTAG	15.13.0
	RP-91	RP-210701	0536	1	F	Clarification on the supportedBandwidthCombinationSetIntraENDC capability	15.13.0
06/2021	RP-92	RP-211483	0544	2	F	CR on UE capability in case of Cross-Carrier operation	15.14.0
	RP-92	RP-211483	0549	2	F	Correction to BWP capabilities	15.14.0
	RP-92	RP-211482	0565	2	F	CR on the supportedBandwidthCombinationSet-R15	15.14.0
	RP-92	RP-211477	0567	3	В	CR on the 35M45M supporting-R15	15.14.0
	RP-92	RP-211483		-	F	Correction to the use of simultaneous CSI-RS resources	15.14.0
	RP-92		0595	1	F	Clarification on BCS of a fallback band combination	15.14.0
	RP-92	RP-211478	0598	1	F	Further clarification on supportedNumberTAG	15.14.0
	RP-92	RP-211478	0607	1	F	Clarification on maximum number of TCI-state for PDSCH	15.14.0
09/2021	RP-93	RP-212439	0517	4	F	CR on the Intra-band and Inter-band EN-DC Capabilities-R15	15.15.0
	RP-93	RP-212439	0561	3	F	Clarification on the simultaneousRxTxInterBandCA capability in NR-DC	15.15.0
	RP-93	RP-212438	0612	1	F	Correction to the description of additionalActiveTCI-StatePDCCH	15.15.0
	RP-93	RP-212439		1	F	Definition of fallback per CC feature set	15.15.0
	RP-93	RP-212439	0630	1	В	Support of newly introduced 100M bandwidth for band n40	15.15.0
	RP-93	RP-212438	0632	1-	F	Correction on fallback band combination for SUL	15.15.0
12/2021	RP-94	RP-213341	0639	2	F	Simultaneous Rx/Tx UE capability per band pair	15.16.0
	RP-94	RP-213341	0655	1	F	Clarification on intraAndInterF-MeasAndReport capability	15.16.0
	RP-94	RP-213341	0657	-	F	Miscellaneous corrections for Rel-15 UE capabilities	15.16.0
06/2022	RP-96		0708	1	F	Clarification on simultaneous Rx/Tx capability per band pair	15.17.0
	RP-96	RP-221756	0734	1-	F	bwp-SwitchingDelay conditionally mandatory capability	15.17.0
09/2022	RP-97	RP-222516	0775	1	F	CR to TS 38.306 on UE capability of MMSE-IRC receiver	15.18.0

	Document history							
V15.2.0	September 2018	Publication						
V15.3.0	October 2018	Publication						
V15.4.0	April 2019	Publication						
V15.5.0	May 2019	Publication						
V15.6.0	July 2019	Publication						
V15.7.0	October 2019	Publication						
V15.8.0	January 2020	Publication						
V15.9.0	April 2020	Publication						
V15.10.0	July 2020	Publication						
V15.11.0	November 2020	Publication						
V15.12.0	January 2021	Publication						
V15.13.0	April 2021	Publication						
V15.14.0	September 2021	Publication						
V15.15.0	October 2021	Publication						
V15.16.0	January 2022	Publication						
V15.17.0	August 2022	Publication						
V15.18.0	October 2022	Publication						

History