

ETSI TS 138 410 V19.1.0 (2026-02)



TECHNICAL SPECIFICATION

**5G;
NG-RAN;
NG general aspects and principles
(3GPP TS 38.410 version 19.1.0 Release 19)**



Reference

RTS/TSGR-0338410vj10

Keywords

5G

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from the
[ETSI Search & Browse Standards](#) application.

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format on [ETSI deliver](#) repository.

Users should be aware that the present document may be revised or have its status changed,
this information is available in the [Milestones listing](#).

If you find errors in the present document, please send your comments to
the relevant service listed under [Committee Support Staff](#).

If you find a security vulnerability in the present document, please report it through our
[Coordinated Vulnerability Disclosure \(CVD\)](#) program.

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2026.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the [ETSI IPR online database](#).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™**, **LTE™** and **5G™** logo are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found at [3GPP to ETSI numbering cross-referencing](#).

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	5
1 Scope	6
2 References	6
3 Definitions and abbreviations.....	6
3.1 Definitions	6
3.2 Abbreviations	7
4 General aspects.....	7
4.1 NG Architecture	7
4.2 NG interface general principles.....	8
4.3 NG interface specification objectives.....	8
4.4 NG interface capabilities	8
5 Functions of the NG interface	8
5.1 General	8
5.2 Paging function	9
5.3 UE Context Management function.....	9
5.4 Mobility Management function.....	9
5.5 PDU Session Management function.....	9
5.6 NAS Transport function	9
5.7 NAS Node Selection function	9
5.8 NG Interface Management function.....	9
5.9 Warning Message Transmission function	10
5.10 Configuration Transfer function.....	10
5.11 Trace function	10
5.12 AMF Management function	10
5.13 Multiple TNL Associations Support Function	10
5.14 AMF Load Balancing function.....	10
5.15 Location Reporting function.....	10
5.16 AMF Re-allocation function.....	10
5.17 UE Radio Capability Management function.....	10
5.18 NRPPa Signaling Transport function	11
5.19 Overload Control function.....	11
5.20 Report of Secondary RAT data volumes Function.....	11
5.21 RIM Information Transfer function.....	11
5.22 Retrieve UE Information function.....	11
5.23 RAN CP Relocation Indication function	11
5.24 Suspend-Resume function	11
5.25 Connection Establishment Indication Function.....	11
5.26 AMF CP Relocation Indication Function	11
5.27 NR MBS Session Management function.....	11
5.28 Multicast Group Paging Function	12
5.29 QMC support function.....	12
5.30 MT Communication Handling function	12
5.31 Timing Synchronisation Status Reporting function	12
5.32 AIoT Service Management function	12
6 Signalling procedures of the NG interface	12
6.1 PDU Session Management Procedures	12
6.2 UE Context Management Procedures.....	12
6.3 NAS transport procedures	13
6.4 UE Mobility Management Procedures	13

6.5	Paging procedure.....	13
6.6	AMF Management procedures.....	13
6.7	NG Interface Management procedures.....	13
6.8	Warning message transmission procedures.....	14
6.9	Location Reporting procedures.....	14
6.10	UE Radio Capability Management procedures.....	14
6.11	UE Tracing procedures.....	14
6.12	NR Positioning Protocol A (NRPPa) procedures.....	14
6.13	Overload Control procedures.....	15
6.14	Configuration Transfer procedures.....	15
6.15	Secondary RAT Data Usage Report procedure.....	15
6.16	RIM Information Transfer procedures.....	15
6.17	Retrieve UE Information procedures.....	15
6.18	RAN CP Relocation Indication procedures.....	15
6.19	UE Context Suspend procedure.....	15
6.20	Connection Establishment Indication procedure.....	16
6.21	AMF CP Relocation Indication procedure.....	16
6.22	UE Context Resume procedure.....	16
6.23	NR MBS Session Management Procedures.....	16
6.24	Multicast Group Paging Procedures.....	16
6.25	The procedures for supporting QMC.....	17
6.26	MT Communication Handling procedures.....	17
6.27	Timing Synchronisation Status Reporting procedures.....	17
6.28	AIoT procedures.....	17
7	NG interface protocol structure.....	17
7.1	NG Control Plane.....	17
7.2	NG User Plane.....	18
8	Other NG interface specifications.....	18
8.1	NG-RAN NG interface: NG layer 1 (TS 38.411).....	18
8.2	NG-RAN NG interface: NG signalling transport (TS 38.412).....	18
8.3	NG-RAN NG interface: NG application protocol (NGAP) (TS 38.413).....	19
8.4	NG-RAN NG interface: NG data transport (TS 38.414).....	19
8.5	NG-RAN NG interface: NG PDU Session user plane protocol (TS 38.415).....	19
Annex A (informative): Change history.....		20
History.....		22

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

1 Scope

The present document is an introduction to the 3GPP TS 38.41x series of technical specifications that define the NG interface for the interconnection of an NG-RAN node to the 5G (5G Core Network).

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

- [1] 3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
- [2] 3GPP TS 38.411: "NG-RAN; NG layer 1".
- [3] 3GPP TS 38.412: "NG-RAN; NG signalling transport".
- [4] 3GPP TS 38.413: "NG-RAN; NG Application Protocol (NGAP)".
- [5] 3GPP TS 38.414: "NG-RAN; NG data transport".
- [6] 3GPP TS 23.502: "Procedures for the 5G system".
- [7] 3GPP TS 38.300: "NR; Overall Description; Stage 2".
- [8] 3GPP TS 23.501: "System Architecture for the 5G system".
- [9] 3GPP TS 38.415: "PDU Session User Plane Protocol".
- [10] 3GPP TS 38.455: "NR Positioning Protocol A (NRPPa)".
- [11] 3GPP TS 36.300: "E-UTRAN); Overall description; Stage 2".
- [12] 3GPP TS 23.247: "Architectural enhancements for 5G multicast-broadcast services; Stage 2".
- [13] 3GPP TS 23.369: "Architecture support for Ambient power-enabled Internet of Things; Stage 2".

3 Definitions and abbreviations

3.1 Definitions

For the purposes of the present document, the terms and definitions given in TR 21.905 [1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in TR 21.905 [1].

AIOTF: as defined in TS 23.369 [13].

A-IoT CN node: as defined in TS 38.300 [7].

gNB: as defined in TS 38.300 [7].

NB-IoT: as defined in TS36.300 [11].

ng-eNB: as defined in TS 38.300 [7].

NG-RAN node: as defined in TS 38.300 [7].

UPF: as defined in TS 23.501 [8].

3.2 Abbreviations

For the purposes of the present document, the terms and definitions given in TR 21.905 [1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in TR 21.905 [1].

5GC	5G Core Network
A-IoT	Ambient IoT
AIOTF	Ambient IoT Function
AMF	Access and Mobility Management Function
CIoT	Cellular IoT
CN	Core Network
DRX	Discontinuous Reception
GW	Gateway
IoT	Internet of Things
LP-WUS	Low Power Wake Up Signal
MBS	Multicast/Broadcast Service
MT	Mobile Terminated
NB-IoT	Narrow Band Internet of Things
NG-U	NG User plane interface
PEI	Paging Early Indication
PTP	Point to Point
PTM	Point to Multipoint
QMC	QoE Measurement Collection
QoE	Quality of Experience
RAT	Radio Access Technology
RIM	Remote Interference Management
RNL	Radio Network Layer
SMF	Session Management Function
UP	User Plane
UPF	User Plane Function

4 General aspects

4.1 NG Architecture

The NG-RAN is layered into a Radio Network Layer (RNL) and a Transport Network Layer (TNL). The NG-RAN architecture, i.e. the NG-RAN logical nodes and interfaces between them, are defined as part of the RNL.

The NG-RAN architecture consists of a set of gNBs and ng-eNBs which are connected to the 5GC through the NG interface and is specified in TS 38.300 [7].

The NG-RAN may have several NG access points towards the 5GC. As a minimum, each NG access point (in NG-RAN or 5GC) shall independently fulfil the requirements of the relevant NG specifications (3GPP 38.41x series - see clause 7).

NG is a logical interface.

There may be multiple NG-C logical interfaces towards the 5GC from any one NG-RAN node. The selection of the NG-C interface is then determined by the NAS Node Selection function as described in clause 5.

There may be multiple NG-U logical interfaces towards the 5GC from any one NG-RAN node. The selection of the NG-U interface is done within the 5GC and signalled to the NG-RAN node by the AMF.

4.2 NG interface general principles

The general principles for the specification of the NG interface are as follows:

- the NG interface is open;
- the NG interface supports the exchange of signalling information between the NG-RAN and 5GC;
- from a logical standpoint, the NG is a point-to-point interface between an NG-RAN node and a 5GC node. A point-to-point logical interface is feasible even in the absence of a physical direct connection between the NG-RAN and 5GC;
- the NG interface supports control plane and user plane separation;
- the NG interface separates Radio Network Layer and Transport Network Layer;
- the NG interface is future proof to fulfil different new requirements and support of new services and new functions;
- the NG interface is decoupled with the possible NG-RAN deployment variants;
- the NG Application Protocol supports modular procedures design and uses a syntax allowing optimized encoding /decoding efficiency.

4.3 NG interface specification objectives

The NG interface specification facilitates the following:

- inter-connection of NG-RAN nodes with AMFs supplied by different manufacturers;
- inter-connection of NG-RAN nodes with A-IoT CN nodes supplied by different manufacturers;
- separation of NG interface Radio Network functionality and Transport Network functionality to facilitate introduction of future technology.

4.4 NG interface capabilities

The NG interface supports:

- procedures to establish, maintain and release NG-RAN part of PDU sessions;
- procedures to perform intra-RAT handovers and inter-RAT handovers;
- the separation of each UE on the protocol level for user specific signalling management;
- the transfer of NAS signalling messages between a UE and an AMF;
- mechanisms for resource reservation for packet data streams;
- procedures to establish, maintain and release NG-RAN part of MBS sessions;
- the transfer of A-IoT NAS signalling messages between an A-IoT device and an AIOTF;
- procedures to establish, maintain and release NG-RAN part of A-IoT sessions.

5 Functions of the NG interface

5.1 General

The following clauses describe the functions supported over the NG interface to fulfil the NG interface capabilities.

5.2 Paging function

The paging function supports the sending of paging requests to the NG-RAN nodes involved in the paging area e.g. the NG-RAN nodes of the TA(s) the UE is registered.

The function also supports CN controlled paging subgrouping for UE Power Saving for PEI and LP-WUS.

5.3 UE Context Management function

The UE Context management function allows the AMF to establish, modify or release a UE Context in the AMF and the NG-RAN node e.g. to support user individual signalling on NG.

The function also enables the AMF to manage RRC state notifications of a CM-CONNECTED UE.

5.4 Mobility Management function

The mobility function for UEs in CM-CONNECTED includes the intra-system handover function to support mobility within NG-RAN and inter-system handover function to support mobility from/to EPS system. It comprises the preparation, execution and completion of handover via the NG interface.

5.5 PDU Session Management function

The PDU Session function is responsible for establishing, modifying and releasing NG-RAN resources for user data transport of a PDU session once a UE context is available in the NG-RAN node.

NGAP supports transparent relaying of PDU Session related information by the AMF as described in TS 23.502 [6].

5.6 NAS Transport function

The NAS Signalling Transport function provides means to transport or reroute a NAS message (e.g. for NAS mobility management) or report the non-delivery of a NAS message for a specific UE over the NG interface.

5.7 NAS Node Selection function

The interconnection of an NG-RAN node to multiple AMFs is supported in the 5GS architecture.

Therefore, a NAS node selection function is located in the NG-RAN node to determine the AMF association of the UE, based on the UE's temporary identifier, which was assigned to the UE by the AMF. When the UE's temporary identifier has not been yet assigned or is no longer valid the NG-RAN node may instead take into account other information (e.g. slicing information, onboarding indication) to determine the AMF. When the NG-RAN node is configured to ensure that the selected AMF serves the country where the UE is located, as described in TS 23.501 [8], the NG-RAN node takes into account UE location information, if available, when determining the AMF.

This functionality is located in the NG-RAN node and enables proper routing via the NG interface. On the NG interface, no specific procedure corresponds to the NAS Node Selection Function.

When an NR Femto node connects to an NR Femto GW, selection of an AMF at UE attachment is performed by the NR Femto GW.

5.8 NG Interface Management function

The NG-interface management functions provide:

- means to re-initialize an already established NG-interface operation (reset);
- means to handle different versions of application part implementations and protocol errors (error indication);

- means to exchange application level data needed for the NG-RAN and AMF to interoperate correctly on the NG interface (setup or respectively configuration update);
- means to remove the interface between gNB and AMF in a controlled manner (removal).

5.9 Warning Message Transmission function

The warning message transmission function provides means to transfer warning messages via NG interface or cancel ongoing broadcast of warning messages. It also provides the capability for the NG-RAN to inform the AMF that ongoing PWS operation has failed for one or more areas, or that one or more areas may be reloaded by the CBC.

5.10 Configuration Transfer function

The Configuration Transfer function is a generic mechanism that allows the request and transfer of RAN configuration information (e.g. SON information) between two RAN nodes via the core network.

5.11 Trace function

The Trace function provides means to control trace sessions in the NG-RAN node.

5.12 AMF Management function

The AMF management function supports AMF planned removal and AMF auto-recovery as specified in TS 23.501 [8].

5.13 Multiple TNL Associations Support Function

When there are multiple TNL associations between a NG-RAN node and an AMF, the NG-RAN node selects the TNL association for NGAP signalling based on the usage and the weight factor of each TNL association received from the AMF, and uses the TNL association as specified in TS 23.501 [8] and TS 23.502 [6]. If an AMF releases a TNL association or a TNL association has failed, the NG-RAN node selects a new one as specified in TS 23.501 [8] and TS 23.502 [6].

5.14 AMF Load Balancing function

The NG interface supports the indication by the AMF of its relative capacity to the NG-RAN node in order to achieve load-balanced AMFs within the pool area.

5.15 Location Reporting function

This function enables the AMF to request the NG-RAN node to report the UE's current location, or the UE's last known location with timestamp, or the UE's presence in a configured area of interest, or the flight information of an aerial UE.

5.16 AMF Re-allocation function

This function allows to redirect an initial connection request issued by an NG-RAN node from an initial AMF towards a target AMF selected by 5GC. In this case the NG-RAN node initiates an Initial UE Message procedure over one NG interface instance and receives the first downlink message to close the UE-associated logical connection over a different NG interface instance.

5.17 UE Radio Capability Management function

The UE Radio Capability Management function is related to the UE radio capability handling.

5.18 NRPPa Signaling Transport function

The NRPPa (NR Positioning Protocol A) Signalling Transport function provides means to transport an NRPPa (3GPP TS 38.455 [10]) message transparently over the NG interface.

5.19 Overload Control function

The overload function provides means to enable AMF to control the load that the NG-RAN node(s) are generating.

5.20 Report of Secondary RAT data volumes Function

The Report of Secondary RAT data volumes Function enables the NG-RAN node to report Secondary RAT usage data information in case of MR-DC, either with a dedicated procedure or by including Secondary RAT usage data information in other messages.

5.21 RIM Information Transfer function

The RIM Information Transfer function is a generic mechanism that allows the transfer of Remote Interference Management (RIM) information between two RAN nodes via the core network.

5.22 Retrieve UE Information function

The Retrieve UE Information function enables the NG-RAN node to request UE information (e.g. QoS differentiation information) from the AMF before the setup of the NG connection for NB-IoT UE(s) using Control Plane CIoT 5GS Optimization.

5.23 RAN CP Relocation Indication function

The RAN CP Relocation Indication function enables the initiation of the UE-associated logical NG-connection for a NB-IoT UE using Control Plane CIoT 5GS Optimisation following a re-establishment request. It allows to have the re-establishment request authenticated by the AMF.

5.24 Suspend-Resume function

This function enables to suspend the UE-associated logical NG-connection and release the NG-U tunnel while storing the UE context in the NG-RAN for a faster subsequent resume as specified for User Plane CIoT 5GS optimizations in TS 23.501 [8]. In this version of the specification, this function only applies for long eDRX cycles.

5.25 Connection Establishment Indication Function

The connection establishment indication function enables the AMF to complete the establishment of the UE-associated logical NG-connection.

5.26 AMF CP Relocation Indication Function

The AMF CP relocation indication function enables the AMF to inform the previously serving NG-RAN node that the UE's connection is to be relocated to a new NG-RAN node.

5.27 NR MBS Session Management function

The MBS Session Management function is responsible for establishing, modifying and releasing NG-RAN resources for user data transport of the involved NR MBS sessions once an MBS context is available in the NG-RAN node.

NGAP supports transparent relaying of MBS Session related information by the AMF as described in TS 23.247 [12].

5.28 Multicast Group Paging Function

The Multicast group paging function supports the sending of multicast group paging requests to the NG-RAN nodes in order to group-page UEs that have joined the Multicast MBS Session.

5.29 QMC support function

The QMC function provides means to manage the QMC sessions and support the mobility of QMC sessions over the NG interface.

5.30 MT Communication Handling function

The function enables to support MT data and signalling handling within the 5GC for UEs in RRC_INACTIVE state with extended DRX beyond 10.24s as specified in TS 23.501[8].

5.31 Timing Synchronisation Status Reporting function

The Timing Synchronisation Status Reporting function enables the AMF to request the NG-RAN node to report the RAN timing synchronisation status information, and enables the NG-RAN node to provide the RAN timing synchronisation status information to the AMF.

5.32 AIoT Service Management function

The AIoT Service Management function is responsible for handling AIoT services.

6 Signalling procedures of the NG interface

6.1 PDU Session Management Procedures

The following PDU Session management procedures are used to establish, release or modify PDU sessions.

- PDU Session Resource Setup;
- PDU Session Resource Release;
- PDU Session Resource Modify;
- PDU Session Resource Notify;
- PDU Session Resource Modify Indication.

6.2 UE Context Management Procedures

The following UE Context management procedures are used to establish, release or modify the UE context. They may also be used to report RRC state transition from NG-RAN to 5GC.

- Initial Context Setup;
- UE Context Release Request;
- UE Context Release;
- UE Context Modification;

- RRC Inactive Transition Report.

6.3 NAS transport procedures

The NAS transport procedures enable transparent transfer of NAS signalling data between the AMF and the UE. The procedures providing this functionality are:

- Initial UE Message (NG-RAN node initiated);
- Uplink NAS transport (NG-RAN node initiated);
- Downlink NAS transport (AMF initiated);
- NAS non delivery indication (NG-RAN node initiated);
- Reroute NAS Request (AMF initiated).

6.4 UE Mobility Management Procedures

The following UE Mobility management procedures are used to prepare, execute or cancel handovers:

- Handover Preparation;
- Handover Resource Allocation;
- Handover Notification;
- Path Switch Request;
- Uplink RAN Status Transfer;
- Downlink RAN Status Transfer;
- Handover Cancellation;
- Handover Success;
- Uplink RAN Early Status Transfer;
- Downlink RAN Early Status Transfer.

6.5 Paging procedure

The following paging procedure is used to send paging requests to the NG-RAN nodes involved in the paging area:

- Paging.

6.6 AMF Management procedures

The following AMF management procedures are used by the AMF to inform the NG-RAN nodes about an AMF's status, and to release the UE TNLA binding for specific UE(s):

- AMF Status Indication;
- UE TNLA binding release.

6.7 NG Interface Management procedures

The following procedures are used to manage the NG interface:

- NG Setup;

- RAN Configuration Update;
- AMF Configuration Update;
- NG Reset;
- Error Indication;
- NG Removal.

6.8 Warning message transmission procedures

The following procedures are used to manage the broadcasting of warning messages:

- Write-Replace Warning;
- PWS Cancel;
- PWS Restart Indication;
- PWS Failure Indication.

6.9 Location Reporting procedures

The following procedures are used to report the location of the UE, or the flight information of an aerial UE:

- Location Reporting Control;
- Location Report;
- Location Reporting Failure Indication.

6.10 UE Radio Capability Management procedures

The following procedures are related to the UE radio capability handling:

- UE Radio Capability Check;
- UE Radio Capability Info Indication;
- UE Radio Capability ID Mapping.

6.11 UE Tracing procedures

The following procedures are used to trace the UE:

- Trace Start;
- Trace Failure Indication;
- Deactivate Trace;
- Cell Traffic Trace.

6.12 NR Positioning Protocol A (NRPPa) procedures

The following procedures are used for NRPPa signalling:

- Downlink UE Associated NRPPa Transport;
- Uplink UE Associated NRPPa Transport;

- Downlink non-UE Associated NRPPa Transport;
- Uplink non-UE Associated NRPPa Transport.

6.13 Overload Control procedures

The following procedures are used by the AMF to start or stop overload control:

- Overload Start procedure;
- Overload Stop procedure.

6.14 Configuration Transfer procedures

The following procedures are used by the AMF to transfer the RAN configuration information:

- Downlink RAN Configuration Transfer procedure;
- Uplink RAN Configuration Transfer procedure.

6.15 Secondary RAT Data Usage Report procedure

The following procedure is used to provide information on the used resources of the secondary RAT:

- Secondary RAT Data Usage Report procedure.

6.16 RIM Information Transfer procedures

The following procedures are used by the AMF to transfer the Remote Interference Management (RIM) information:

- Downlink RIM Information Transfer procedure;
- Uplink RIM Information Transfer procedure.

6.17 Retrieve UE Information procedures

The following procedures are used by the NG-RAN node to retrieve UE information from the AMF:

- Retrieve UE Information Request procedure;
- UE Information Transfer procedure.

6.18 RAN CP Relocation Indication procedures

The following procedure is used by the NG-RAN node to initiate the UE-associated logical NG-connection for the RAN CP Relocation function:

- RAN CP Relocation Indication procedure.

6.19 UE Context Suspend procedure

The following procedure is to suspend the UE-associated logical NG-connection and release the NG-U tunnel with the 5GC while keeping the UE context in NG-RAN. In this version of the specification, this procedure applies only if the NG-RAN node is an ng-eNB.

- UE Context Suspend procedure.

6.20 Connection Establishment Indication procedure

The following procedure is used to enable the AMF to provide information to the NG-RAN node to complete the establishment of the UE-associated logical NG-connection, for UEs using CIoT 5GS Optimization:

- Connection Establishment Indication.

The UE Radio Capability may be provided from the AMF to the NG-RAN node in this procedure. If the UE Radio Capability is not included, this may trigger the NG-RAN node to request the UE Radio Capability from the UE and to provide it to the AMF in the UE RADIO CAPABILITY INFO INDICATION message.

6.21 AMF CP Relocation Indication procedure

The following procedure is used to inform the previously serving NG-RAN node that the UE's connection is to be relocated to a new NG-RAN node, for UEs using Control Plane CIoT 5GS optimizations:

- AMF CP Relocation Indication.

6.22 UE Context Resume procedure

The following procedure is used to resume the UE context, resume the suspended logical NG-connection and re-establish the related NG-U tunnel in the 5GC for the involved UE. In this version of the specification, this procedure applies only if the NG-RAN node is an ng-eNB.

- UE Context Resume procedure.

6.23 NR MBS Session Management Procedures

The following list of MBS Session management procedures are used to establish, release, or modify NG-RAN resources for a NR MBS session:

- Broadcast Session Resource Setup;
- Broadcast Session Modification;
- Broadcast Session Resource Release;
- Broadcast Session Resource Release Required;
- Broadcast Session Transport;
- Multicast Session Activation;
- Multicast Session Deactivation;
- Multicast Session Update;
- Distribution Setup;
- Distribution Release.

6.24 Multicast Group Paging Procedures

The following Multicast Group Paging procedure is used to send multicast group paging requests to the NG-RAN nodes:

- Multicast Group Paging.

6.25 The procedures for supporting QMC

The following procedures are used to control the QMC sessions in the UE and to transfer QMC session information to the target NG-RAN node during the intra-system intra-RAT or intra-system inter-RAT mobility of a UE:

- Initial Context Setup;
- UE Context Modification;
- Handover Preparation;
- Handover Resource Allocation.

6.26 MT Communication Handling procedures

The following procedures are used by the NG-RAN node to request the AMF to activate or deactivate the CN based MT communication handling for UEs in RRC_INACTIVE state with long extended DRX beyond 10.24 seconds, and by the 5GC to indicate availability of downlink data or downlink signalling to the NG-RAN node.

- MT Communication Handling procedure;
- RAN Paging Request procedure;
- Path Switch Request procedure.

6.27 Timing Synchronisation Status Reporting procedures

The following procedures are used to report the RAN timing synchronisation status information:

- Timing Synchronization Status;
- Timing Synchronization Status Report.

6.28 AIoT procedures

The following procedures are used for AIoT services:

- Inventory Request;
- Inventory Report;
- Command Request;
- A-IoT Session Release (AIoT CN Initiated);
- A-IoT Session Release Request (gNB initiated).

7 NG interface protocol structure

7.1 NG Control Plane

The control plane protocol stack of the NG interface is shown on Figure 7.1-1. The transport network layer is built on IP transport. For the reliable transport of signalling messages, SCTP is added on top of IP. The application layer signalling protocol is referred to as NGAP (NG Application Protocol).




Figure 7.1-1: NG Interface Control Plane

7.2 NG User Plane

The NG user plane (NG-U) interface is defined between a NG-RAN node and a UPF. The NG-U interface provides non guaranteed delivery of PDU Session/MBS session user plane PDUs between the NG-RAN node and the UPF.

The protocol stack for NG-U is shown in Figure 7.2-1.




Figure 7.2-1: NG-U protocol structure for PDU/MBS Session

8 Other NG interface specifications

8.1 NG-RAN NG interface: NG layer 1 (TS 38.411)

TS 38.411 [2] specifies the physical layer technologies that may be used to support the NG interface.

8.2 NG-RAN NG interface: NG signalling transport (TS 38.412)

TS 38.412 [3] specifies how the NGAP signalling messages are transported over NG.

8.3 NG-RAN NG interface: NG application protocol (NGAP) (TS 38.413)

TS 38.413 [4] specifies the radio network layer signalling procedures of the control plane between the NG-RAN node and the AMF, or between the NG-RAN node and the A-IoT CN node.

8.4 NG-RAN NG interface: NG data transport (TS 38.414)

TS 38.414 [5] specifies the standards for user data transport protocols over the NG interface.

8.5 NG-RAN NG interface: NG PDU Session user plane protocol (TS 38.415)

TS 38.415 [9] specifies the PDU Session User Plane protocol procedures, and the PDU Set Information User Plane protocol procedures over the NG interface.

Annex A (informative): Change history

Change history							
Date	Meeting	TDoc	CR	Rev	Cat	Subject/Comment	New version
2017-04	R3#95b	R3-171127				TS skeleton	0.0.0
2017-04	R3#95b	R3-171397				Update including TP from R3-171375 with text reduction from rapporteur	0.0.1
2017-05	R3#96	R3-171218				Update of title page and change history	0.0.2
2017-05	R3#96	R3-171965				Addition of section 4 and 6. Deletion of the content of section 5 with detailed PDU session management procedure. Update of change history	0.1.0
2017-05	R3#96	R3-172019				Integration of R3-171981 with NAS Transport procedures. Update of change history.	0.2.0
2017-07	R3 NR AH# 2	R3-172632				Integration of R3-172597 and R3-172598 respectively adding of a list of functions in section 5 and adding references to other NG specifications in sections 2 and 8.	0.3.0
2017-09	R3#97	R3-173448				Integration of R3-173319 and R3-173325 respectively adding a list of procedures and the AMF transparency for PDU session related information. Integration of R3-173318 for terminology alignment with NG-RAN node.	0.4.0
2017-10	R3#97bis	R3-174238				Integration of R3-174104 modifying the NG architecture section. Integration of 3784 adding a list of procedures. Integration of 4151 adding AMF management function and procedures.	0.5.0
2017-12	R3#98	R3-175055				Integration of R3-174527.	0.6.0
2018-01	R3 NR AH#1801	R3-180648				Integration of R3-180540 removing NG-RAN from the abbreviations. Integration of R3-180095 correcting the description style of some procedures.	0.7.0
2018-03	R3#99	R3-181585				Integration of R3-181486 for stage 2 of PWS support. Integration of R3-181412 on NGAP support of multiple SCTP associations.	0.8.0
2018-04	R3#99bis	R3-182523				Integration of R3-181981 introducing TS 38.415. Integration of R3-182273 introducing explicit per UE TNLA binding release.	0.9.0
2018-05	R3#100	R3-183590				Integration of R3-183343 with location reporting function and procedures. Integration of R3-183479 with AMF re-allocation function. Correction of some editorials according to drafting rules.	0.10.0
2018-06	RAN#80	RP-180739				For approval	1.0.0
2018-06	RAN#80					Specification approved at TSG-RAN and placed under change control	15.0.0
2018-09	RAN#81	RP-181922	0001	4	F	NR Corrections (38.410 Baseline CR covering RAN3#101 agreements)	15.1.0
2018-12	RAN#82	RP-182446	0004	1	F	Rapporteur's CR for TS38.410	15.2.0
2018-12	RAN#82	RP-182447	0005	1	B	Introduction of Data Volume Reporting for MR-DC	15.2.0
2019-12	RP-86	RP-192908	0017	2	B	Remote Interference Management Message Transfer Support	16.0.0
2020-03	RP-87-e	RP-200429	0023	-	F	Rapporteur Correction of TS 38.410	16.1.0
2020-07	RP-88-e	RP-201088	0018	6	B	Introduction of NBIOT dedicated CP functions when connected to 5GC	16.2.0
2020-07	RP-88-e	RP-201086	0019	6	B	Introduction of Suspend-Resume for 5GC	16.2.0
2020-07	RP-88-e	RP-201086	0020	7	B	Introduction of CP ClotT 5GS Optimisation for NB-IoT and MTC connected to 5GC (Stage 2)	16.2.0
2020-07	RP-88-e	RP-201075	0024	2	B	Baseline CR for introducing Rel-16 NR mobility enhancement	16.2.0
2020-07	RP-88-e	RP-201078	0025	2	B	Introducing Radio Capability Optimisation (RACS)	16.2.0
2020-09	RP-89-e	RP-201951	0026	1	F	Rapporteur Correction of TS 38.410	16.3.0
2021-09	RP-93-e	RP-211882	0033	3	F	Correction on NAS non delivery	16.4.0
2022-03	RP-95-e	RP-220225	0029	7	C	Clarification of NAS Node Selection Function for NTN nodes providing access over multiple countries	17.0.0
2022-03	RP-95-e	RP-220224	0030	10	B	MBS BL CR for TS 38.410	17.0.0
2022-03	RP-95-e	RP-220220	0032	7	B	Introduction of support for eNPN	17.0.0
2022-03	RP-95-e	RP-220229	0034	4	B	BLCR to 38.410: Support of QoE Measurement Collection for NR	17.0.0
2022-03	RP-95-e	RP-220235	0037	1	B	Support for UE Power Saving Enhancements	17.0.0
2022-03	RP-95-e	RP-220236	0038		D	Rapporteur Corrections of TS 38.410	17.0.0
2022-06	RP-96	RP-221134	0040	1	F	Correction on NR MBS for 38410	17.1.0
2022-06	RP-96	RP-221143	0042	1	F	QoE Rel-17 Corrections	17.1.0
2023-12	RAN#102	RP-233816	0044	6	B	Introduction of NR Redcap Enhancement	18.0.0
2023-12	RAN#102	RP-233829	0045	3	B	(CR to 38.410) Update of MBS RAN sharing solution	18.0.0
2023-12	RAN#102	RP-233838	0046	3	B	Introduction of 5G Timing Resiliency and URLLC enhancements	18.0.0
2023-12	RAN#102	RP-233833	0047	-	B	Introduction of R18 QoE measurement enhancements	18.0.0
2023-12	RAN#102	RP-233831	0048	-	B	Support for XR UP design using new container	18.0.0
2024-03	RAN#103	RP-240617	0049	-	D	Correction of TS 38.410	18.1.0

Change history							
Date	Meeting	TDoc	CR	Rev	Cat	Subject/Comment	New version
2024-04	RAN#103	-	-	-	-	Fixed font style of clause '6.27': From 'normal' to 'Heading2'	18.1.1
2024-04	RAN#103	-	-	-	-	Updated ToC	18.1.2
2024-06	RAN#104	RP-241100	0050	2	F	Correction on MT Communication Handling Procedures in TS 38.410	18.2.0
2025-06	RAN#108	RP-251156	0055	1	F	Alignment NG interface management function and NG Interface Management procedures	18.3.0
2025-09	RAN#109	RP-252678	0051	7	B	Introduce NG Removal procedure	19.0.0
2025-09	RAN#109	RP-252683	0052	6	B	Introduction of NR Femto in NGAP list of functions	19.0.0
2025-09	RAN#109	RP-252676	0053	6	B	Introduction of Ambient IoT	19.0.0
2025-09	RAN#109	RP-252687	0054	4	B	Support Aerial UE Flight Information Reporting	19.0.0
2025-09	RAN#109	RP-252674	0056	2	B	Introduction of LP-WUS	19.0.0
2025-12	RAN#110	RP-253341	0057	1	F	Rapporteur Correction	19.1.0

History

Version	Date	Status
V19.0.0	January 2026	Publication
V19.1.0	February 2026	Publication