

ETSI TS 125 304 V3.1.0 (2000-01)

Technical Specification

Universal Mobile Telecommunications System (UMTS); UE Procedures in Idle Mode and Procedures for Cell Reselection in Connected Mode (3G TS 25.304 version 3.1.0 Release 1999)



Reference

DTS/TSGR-0225304U

Keywords

UMTS

ETSI

Postal address

F-06921 Sophia Antipolis Cedex - FRANCE

Office address

650 Route des Lucioles - Sophia Antipolis
Valbonne - FRANCE
Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16
Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Internet

secretariat@etsi.fr
Individual copies of this ETSI deliverable
can be downloaded from
<http://www.etsi.org>
If you find errors in the present document, send your
comment to: editor@etsi.fr

Important notice

This ETSI deliverable may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Copyright Notification

No part may be reproduced except as authorized by written permission.
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2000.
All rights reserved.

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<http://www.etsi.org/ipr>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

This Technical Specification (TS) has been produced by the ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables. The mapping of document identities is as follows:

For 3GPP documents:

3G TS | TR nn.nnn "<title>" (with or without the prefix 3G)

is equivalent to

ETSI TS | TR 1nn nnn "[Digital cellular telecommunications system (Phase 2+) (GSM);] Universal Mobile Telecommunications System; <title>

For GSM document identities of type "GSM xx.yy", e.g. GSM 01.04, the corresponding ETSI document identity may be found in the Cross Reference List on www.etsi.org/key

Contents

Foreword	5
1 Scope.....	6
2 References.....	6
3 Definitions, symbols and abbreviations	7
3.1 Definitions	7
3.2 Abbreviations.....	8
4 General description of Idle mode.....	8
4.1 Overview.....	8
4.2 Functional division between AS and NAS in Idle mode	10
4.3 Service type in Idle mode	10
5 Process descriptions	12
5.1 PLMN selection and reselection.....	12
5.2 Cell selection and reselection in idle mode.....	12
5.2.1 General.....	12
5.2.2 UTRA Radio access technology.....	16
5.2.2.1 Cell Selection Procedures	16
5.2.2.1.1 Description.....	16
5.2.2.1.2 Criteria	16
5.2.2.2 Immediate Cell Evaluation Procedure	17
5.2.2.2.1 Description.....	17
5.2.2.2.2 Criteria	17
5.2.2.3 Camped Normally.....	18
5.2.2.4 Cell Reselection Procedure.....	18
5.2.2.4.1 Description.....	18
5.2.2.4.2 Intra-Frequency Cell Reselection Criteria	19
5.2.2.4.3 Inter-Frequency Cell Reselection Criteria	19
5.2.2.4.4 Inter-Radio Access Technology Cell Reselection Criteria.....	19
5.2.2.4.5 Cell reselection parameters in system information broadcasts.....	20
5.2.2.5 Cell Selection when leaving connected mode	21
5.2.2.6 Any Cell Selection.....	21
5.2.2.7 Camped on Any Cell	21
5.2.2.8 Any Cell Reselection.....	21
5.2.2.9 ODMA probing sub-process.....	21
5.2.2.6.1 ODMA probing state machines.....	21
5.2.3 GSM Radio access technology.....	23
5.2.3.1 Cell Selection Procedures.....	23
5.2.3.2 Immediate Cell Evaluation Procedure	23
5.2.3.3 Cell Reselection Procedure.....	23
5.2.3.3.1 Description.....	23
5.2.3.3.2 Cell Reselection Criteria	23
5.2.3.3.3 Inter-Radio Access Technology Cell Reselection Procedure.....	23
5.2.3.3.4 Cell reselection parameters in system information broadcasts.....	24
5.2.3.4 Cell Selection when leaving connected mode	24
5.2.3.5 Any Cell Selection.....	24
5.2.3.6 Camped on Any Cell	24
5.2.3.7 Any Cell Reselection.....	24
5.2.4 Barred Cells and Access Control.....	25
5.2.5 Regional Provision of Service.....	25
5.3 Cell Reselection in Connected Mode.....	25
5.3.1 UTRA Radio Access Technology	25
5.3.1.1 General	25
5.3.1.2 Initial Cell Reselection Procedure	26
5.3.1.2.1 Description.....	26
5.3.1.2.2 Criteria	27

5.3.1.3	Immediate Cell Evaluation Procedure	27
5.3.1.3.1	Description.....	27
5.3.1.3.2	Criteria	28
5.3.1.4	Cell Reselection Procedure.....	28
5.3.1.4.1	Description.....	28
5.3.1.4.2	Intra-Frequency Cell Reselection Criteria	29
5.3.1.4.3	Inter-Frequency Cell Reselection Criteria	29
5.3.1.4.4	Inter Radio Access Technology Cell Reselection Criteria.....	29
5.4	Location Registration.....	30
6	Broadcast information receiving.....	30
6.1	Reception of System Information	30
6.2	Cell Broadcast.....	30
7	Idle mode measurements	31
7.1	Network control of UE measurement activities	31
7.1.1	Intra-frequency cell measurements	31
7.1.2	Inter-frequency cell measurements	31
7.1.3	Inter-Radio Access Technology measurements	31
8	Discontinuous Reception	32
9	Multicast services	32
9.1	State diagram between the multicast service and DSCH	32
9.1.1	MT_Null State.....	33
9.1.2	MT_Monitor State.....	33
9.1.3	MT_Saving State.....	33
9.1.4	MT_Active State	34
10	Examples of Procedures.....	34
10.1	NAS initiated change of system information	34
10.2	System Information Update to NAS	36
10.3	CN originated paging in idle mode	37
10.4	PLMN Selection, automatic mode, normal case.....	38
10.5	PLMN Reselection, automatic mode	39
10.6	PLMN Reselection, manual mode	40
10.7	PLMN Selection, automatic mode, selected PLMN not found.....	41
10.8	NAS Controlled Cell Selection.....	42
10.8.1	Execution in Access Stratum.....	42
10.8.2	Execution in Non-Access Stratum	43
Annex A (informative): Change history.....		44
History.....		45

Foreword

This Technical Specification has been produced by the 3GPP.

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of this TS, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 Indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

1 Scope

The present document shall specify the overall idle mode process for the UE and the functional division between the non-access stratum and access stratum in the UE. The non-access stratum part is specified in [5] and the access stratum part in this document. The UE is in idle mode when there is no RRC connection. In idle mode the UE is identified by non-access stratum identities such as IMSI, TMSI and P-TMSI. In addition, the UTRAN has no own information about the individual idle mode UEs, and can only address e.g. all UEs in a cell or all UEs monitoring a specific paging occasion.

This document applies to UEs that support at least UTRA and possibly also other radio access technologies, for instance GSM.

In addition to the specification of the idle mode process, there is a specification of the cell selection and reselection procedures applicable to UEs in connected mode in some cases, which are specified in [4].

This document presents also examples of inter-layer procedures related to the idle mode processes and describes idle mode functionality of a dual RAT UTRA/GSM UE.

Following items are considered for releases beyond Release '99:

1. State diagram between the multicast service and DSCH (section 9.1)
2. ODMA probing sub-process (section 5.2.2.6)

Support for radio access technology priority list is not included in Release 99.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies.

- | | |
|-----|--------------------------------------------------------------------------------------------------|
| [1] | GSM TS 03.22: "Functions related to Mobile Station in idle mode and group receive mode" |
| [2] | 3G TS 25.301: "Radio Interface Protocol Architecture" |
| [3] | 3G TS 25.303: "Interlayer Procedures in Connected Mode" |
| [4] | 3G TS 25.331: "RRC Protocol Specification" |
| [5] | 3G TS 23.022: "Functions related to MS in idle mode and group receive mode" |
| [6] | 3G TR 25.922: "Radio Resource Management Strategies" |
| [7] | 3G TS 25.211: "Physical channels and mapping of transport channels onto physical channels (FDD)" |
| [8] | 3G TS 25.221: "Physical channels and mapping of transport channels onto physical channels (TDD)" |

3 Definitions, symbols and abbreviations

3.1 Definitions

For the purposes of the present document, the following terms and definitions apply.

Acceptable Cell: This is a cell that the UE may camp on to make emergency calls. It shall satisfy certain conditions.

Allowable PLMN: This is a PLMN, which is not in the list of forbidden PLMNs in the UE.

Available PLMN: This is a PLMN where the UE has found a cell that satisfies certain conditions.

Camped on a cell: The UE is in idle mode and has completed the cell selection/reselection process and has chosen a cell. The UE monitors system information and (in most cases) paging information.

NOTE: The services may be limited, and that the PLMN may not be aware of the existence of the UE within the chosen cell.

DRX cycle: The individual time interval between monitoring Paging Occasion for a specific UE.

Home PLMN: This is a PLMN where the Mobile Country Code (MCC) and Mobile Network Code (MNC) of the PLMN identity are the same as the MCC and MNC of the IMSI.

Location Registration (LR): The UE registers its presence in a registration area, for instance regularly or when entering a new registration area.

LSA: Localised Service Area. A LSA is an operator-defined group of cells for which specific access conditions applies. This may correspond to an area in which the Core Network offers specific services. A LSA may be defined within a PLMN or globally. Therefore, a LSA may offer non-contiguous radio coverage.

LSA exclusive access cell: A UE may only camp on this cell if the cell belongs to the LSAs to which the user has subscribed. Nevertheless, if no other cells are available, the UE of non-LSA users may originate emergency calls from this cell.

LSA ID: Localised Service Area Identity.

LSA only access: When LSA only access applies to the user, the UE can only access cells that belong to the LSAs to which the user has subscribed. Outside the coverage area of the subscribed LSAs, the UE may camp on other cells and limited services apply.

LSA preferential access cell: A LSA preferential access cell is a cell, which is part of the LSA. UEs of users that have subscribed to a LSA of an LSA-preferential-access cell have higher priority to resources than non-LSA users in the same cell. The availability of LSA preferential access cells impacts the radio resource allocation (controlled by UTRAN-Access Stratum). This function is out of the scope of the standards.

Maximum DRX cycle: The time interval for the longest possible DRX cycle in a cell.

Paging Block Periodicity (PBP): The period of the occurrence of Paging Blocks. (For FDD, PBP = 1).

Paging Message Receiving Occasion: The frame where the UE receives actual paging message.

Paging occasion:

(FDD) The frame where the UE monitors the PICH.

(TDD) The paging block, which consists of several frames. The value of Paging Occasion is equal to the first frame of the Paging Block.

Radio Access Mode: Radio access mode of the cell, FDD or TDD

Radio Access Technology: The type of technology used for radio access, for instance UTRA or GSM.

Registered PLMN (RPLMN): This is the PLMN on which the UE has performed a location registration successfully.

Registration Area: A (NAS) registration area is an area in which the UE may roam without a need to perform location registration, which is a NAS procedure.

Selected PLMN: This is the PLMN that has been selected by the non-access stratum, either manually or automatically.

Suitable Cell: This is a cell on which an UE may camp. It shall satisfy certain conditions, see 4.3.

Visited PLMN of home country: This is a PLMN, different from the home PLMN, where the MCC part of the PLMN identity is the same as the MCC of the IMSI.

3.2 Abbreviations

For the purposes of the present document, the following abbreviations apply:

AS	Access Stratum
BCCH	Broadcast Control Channel
CN	Core Network
DRX	Discontinuous Reception
DSCH	Downlink Shared Channel
FDD	Frequency Division Duplex
GC	General Control (SAP)
GPRS	General Packet Radio System
GSM	Global System for Mobile
IMSI	International Mobile Subscriber Identity
MCC	Mobile Country Code
MM	Mobility Management
MNC	Mobile Network Code
NAS	Non-Access Stratum
ODMA	Opportunity Driven Multiple Access
ORACH	ODMA Random Access Channel
PCH	Paging Channel
PI	Page Indicator
PICH	Page Indication Channel
PLMN	Public Land Mobile Network
RAT	Radio Access Technology
RRC	Radio Resource Control
SAP	Service Access Point
TDD	Time Division Duplex
UE	User Equipment
UE _R	User Equipment with ODMA relay operation enabled
UMTS	Universal Mobile Telecommunications System
UTRA	UMTS Terrestrial Radio Access
UTRAN	UMTS Terrestrial Radio Access Network

4 General description of Idle mode

4.1 Overview

When a multi-RAT UE is switched on, it attempts to make contact with a public land mobile network (PLMN) using a certain radio access technology.

The particular PLMN to be contacted may be selected either automatically or manually.

The UE looks for a suitable cell of the chosen PLMN and chooses that cell to provide available services, and tunes to its control channel. This choosing is known as "camping on the cell". The UE will then register its presence, by means of a NAS registration procedure, in the registration area of the chosen cell, if necessary.

If the UE finds a more suitable cell, it reselects onto that alternative cell of the selected PLMN and camps on that cell. If the new cell is in a different registration area, location registration is performed.

If necessary, the UE will look for more suitable cells on other PLMNs at regular time intervals, which is referred to as PLMN-reselection. Particularly, in the home country of the UE, the UE will try to get back to its Home PLMN.

If the UE loses coverage of a PLMN, either a new PLMN is selected automatically (automatic mode), or an indication of which PLMNs are available is given to the user, so that a manual selection can be made (manual mode).

Registration is not performed by UE's only capable of services that need no registration.

The purpose of camping on a cell in idle mode is fourfold:

- a) It enables the UE to receive system information from the PLMN.
- b) When registered and if the UE wishes to initiate a call, it can do this by initially accessing the network on the control channel of the cell on which it is camped.
- c) If the PLMN receives a call for the registered UE, it knows (in most cases) the registration area of the cell in which the UE is camped. It can then send a "paging" message for the UE on control channels of all the cells in the registration area. The UE will then receive the paging message because it is tuned to the control channel of a cell in that registration area and the UE can respond on that control channel.
- d) It enables the UE to receive cell broadcast messages

If the UE is unable to find a suitable cell to camp on, or the USIM is not inserted, or if the location registration failed, it attempts to camp on a cell irrespective of the PLMN identity, and enters a "limited service" state in which it can only attempt to make emergency calls.

The idle mode tasks can be subdivided into three processes:

- PLMN selection and reselection;
- Cell selection and reselection;
- Location registration.

The relationship between these processes is illustrated in Figure 1.




Figure 1: Overall Idle Mode process

NOTE: The impact of NAS defined service areas is FFS.

4.2 Functional division between AS and NAS in Idle mode

Table 1 presents the functional division between UE non-access stratum (NAS) and UE access stratum (AS) in idle mode. The non-access stratum part is specified in [5] and the access stratum part in this document. Examples of different idle mode procedures are presented in Section 10.

Table 1: Functional division between AS and NAS in idle mode

Idle Mode Process	UE Non-Access Stratum	UE Access Stratum
PLMN Selection and Reselection	<p>Maintain a list of PLMNs in priority order. Request AS to select a cell either belonging to the PLMN having the highest priority (in automatic mode) or belonging to the manually selected PLMN.</p> <p>In automatic mode, if a PLMN with higher priority is found, request AS to select a cell belonging to that PLMN.</p>	Report available PLMNs to NAS on request from NAS or autonomously.
Cell Selection	Control cell selection by for example, maintaining lists of forbidden registration areas and a list of NAS defined service areas in priority order.	<p>Perform measurements needed to support cell selection.</p> <p>Detect and synchronise to a broadcast channel. Receive and handle broadcast information. Forward NAS system information to NAS.</p> <p>Search for a suitable cell belonging to the PLMN requested by NAS. The cells are identified with PLMN identity in the system information. Respond to NAS whether such cell is found or not.</p> <p>If such a cell is found, the cell is selected to camp on.</p>
Cell Reselection	Control cell reselection by for example, maintaining lists of forbidden registration areas and a list of NAS defined service areas in priority order.	<p>Perform measurements needed to support cell reselection.</p> <p>Detect and synchronise to a broadcast channel. Receive and handle broadcast information. Forward NAS system information to NAS.</p> <p>Change cell if a more suitable cell is found.</p> <p>Perform ODMA probing in an ODMA Relay Node.</p>
Location registration	<p>Register the UE as active after power on.</p> <p>Register the UE's presence in a registration area, for instance regularly or when entering a new registration area.</p> <p>Deregister UE when shutting down.</p>	Report registration area information to NAS.

4.3 Service type in Idle mode

This chapter defines the level of service that may be provided by the UTRAN to an UE in Idle mode.

The action of camping on a cell is mandatory to receive some service from the cell. Three levels of services are defined for UEs in idle mode:

- Limited service (emergency calls)
- Normal service (for public use)
- Operator related services (for operators only)

Furthermore, the cells are categorised according to which services they offer:

acceptable cell:

An "acceptable cell" is a cell on which the UE may camp to obtain limited service (originate emergency calls). Such a cell shall fulfil the following requirements, which is the minimum set of requirements to initiate an emergency call in a UTRAN network:

The cell selection criteria are fulfilled, see Section 5.2.2.1

- The cell is not reserved for operator use only

suitable cell:

A "suitable cell" is a cell on which the UE may camp on to obtain normal service. Such a cell shall fulfil all the following requirements.

- The cell is part of the selected PLMN.
- The cell is not barred except for [details are FFS]:
 - emergency calls, and/or
 - operator only use, and/or
 - SoLSA exclusive access.
- The cell is not part of a forbidden registration area [details are FFS].
- The cell selection criteria are fulfilled, see 5.2.2.1.
- The SoLSA criteria are fulfilled [FFS].
- The cell is not an operator-only cell, unless the UE has those access rights.

barred cell:

An UE shall not camp on this kind of cell for normal services, but may camp on this cell for limited service if no other suitable cell is available.

Whether or not the cell is barred, is indicated in the system information.

operator-only cell:

The aim of this type of cells is to allow the operator using and test newly deployed cells without being disturbed by normal traffic. A UE shall not camp on this cell for any service, except for some classes of UE as indicated on the USIM.

Whether or not the cell is reserved for operator use only, is indicated in the system information.

Table 2 summarises all the different cases above as well as the level of service provided by UTRAN, as seen from the UE in Idle mode.

Table 2: Summary of service levels provided by UTRAN

	Acceptable cell	Suitable cell	Barred cell	Operator-only cell
Limited service	Y	Y	Y	N
Normal service	N	Y	N	N
Operator-related service	N	Y	N	Y

5 Process descriptions

5.1 PLMN selection and reselection

In the UE, the access stratum shall report available PLMNs to the non-access stratum on request from the non-access stratum or autonomously.

The non-access part of the PLMN selection and reselection process is specified in [5].

5.2 Cell selection and reselection in idle mode

5.2.1 General

As stated in Section 1, this document applies to UEs that support at least UTRA and possibly also other radio access technologies, for instance GSM. The following subsections specify the details for idle mode cell selection and reselection.

- The general part for all radio access technologies, currently UTRA and GSM, this subsection.
- UTRA radio access technologies, see subsection 5.2.2.
- GSM radio access technologies, see subsection 5.2.3.

As an example, consider a UE supporting both UTRA and GSM radio access technologies. It shall follow the specification in this subsection at all times, the specification in 5.2.2 while in UTRA and 5.2.3 while in GSM radio access technology (in addition to the GSM specifications).

The UE shall select a suitable cell and the radio access mode based on idle mode measurements and cell selection criteria. The non-access stratum can control the cell selection, for instance in terms of a list of forbidden registration area(s) and a list of NAS defined service area(s) in priority order.

When camped on a cell, the UE shall regularly search for a better cell according to the cell reselection criteria. If a better cell is found, that cell is selected.

The non-access stratum is informed if the cell selection and reselection results in changes in the received system information.

For normal service, the UE has to camp on a suitable cell, tune to that cell's control channel(s) so that the UE can:

- Receive system information from the PLMN
 - Receive registration area information from the PLMN, e.g., location area and routing area, and,
 - Identify the NAS defined service area(s) to which the serving cell belongs
 - Receive other AS and NAS Information
- If registered,

- receive paging and notification messages from the PLMN, and,
- initiate call setup for outgoing calls or other actions from the UE.

Figure 2 shows the states and procedures in the cell selection and reselection process.




Figure 2: Idle Mode Cell Selection and Reselection
 In any state, a new PLMN selection causes an exit to number 1.

Whenever a PLMN has been selected, the UE shall attempt to find a suitable cell to camp on using one of the two procedures, *Initial cell selection* or *Stored information cell selection*. The *Initial cell selection* procedure requires no knowledge about the selected PLMN, but the *Stored information cell selection* procedure requires information about the selected PLMN previously stored. This information makes the search for a suitable cell faster. The non-access stratum may control the cell selection by for example, maintaining lists of forbidden registration areas and a list of NAS defined service areas in priority order.

In the *Initial cell selection* procedure), the UE shall select one radio access technology and search for a suitable cell. If no suitable cell is found, the UE shall select another radio access technology and search for a suitable cell, and so on. In the *Stored information cell selection* procedure, the UE may use stored information about the selected PLMN. The information may contain information from several radio access technologies.

When a suitable cell has been found, the UE shall perform necessary NAS registration procedures. When the UE has registered successfully (assuming a service that requires registration), the UE shall camp on the cell, state *Camped normally*. In this state, the UE shall monitor paging information, monitor system information and perform radio measurements. The measurements shall be used in evaluation of the cell selection, immediate cell evaluation (UTRA only) and reselection criteria. The network controls what the UE shall measure by sending measurement control information in the system information. The measurement control information may contain intra-frequency, inter-frequency and inter-radio-access- technology measurements.

When a cell reselection is triggered, the UE shall evaluate the cell reselection criteria based on radio measurements, and if a better cell is found that cell is selected, procedure *Cell reselection*. The change of cell may imply a change of radio access technology.

When UE leaves idle mode, state *Camped normally*, in order to enter connected mode, state *Connected mode*, the UE shall use the *Immediate cell evaluation* procedure (UTRA only) in order to select the best cell on the current frequency for the access attempt. This procedure allows the UE to reduce power consumption spent on radio measurements, still enabling the UE to select the best cell for access, thus minimising the interference in the system. If no suitable cell is found, the UE shall use the *Cell reselection* procedure. When returning to idle mode, the UE shall use the procedure *Cell selection when leaving connected mode* in order to find a suitable cell to camp on, state *Camped normally*. If no suitable cell is found, the *Stored information cell selection* procedure shall be used.

If no suitable cell is found, the UE shall attempt to find an acceptable cell of any PLMN, state *Any cell selection*. This state is also entered if a non-access stratum registration procedure is rejected, see [5], or if there is no USIM in the UE. If an acceptable cell is found, the UE shall camp on this cell and obtain limited service, state *Camped on any cell*. In this state, the UE shall behave as specified for state *Camped normally*, but typically with a different PLMN. Additionally, the UE shall regularly attempt to find a suitable cell using stored information, trying all radio access technologies that are supported by the UE. If a suitable cell is found, the PLMN is reselected which causes an exit to number 1.

When a cell reselection is triggered, the UE shall evaluate the cell reselection criteria based on radio measurements, and if a better cell is found that cell is selected, procedure *Any cell reselection*. The change of cell may imply a change of radio access technology.

When UE leaves idle mode, state *Camped on any cell*, in order to make an emergency call in connected mode, state *Connected mode (emergency calls only)*, the UE shall use the *Immediate cell evaluation* procedure (UTRA only) in order to select the best cell on the current frequency for the access attempt. If no suitable cell is found, the UE shall use the *Any cell reselection* procedure. When returning to idle mode, the UE shall use the procedure *Cell selection when leaving connected mode* in order to find a suitable cell to camp on, state *Camped on any cell*.

If no acceptable cell is found, the UE shall continue to search for an acceptable cell of any PLMN in state *Any cell selection*. trying all radio access technologies that are supported by the UE.

NOTE: The 'PLMN selection and reselection' process may select a new PLMN at any time in idle mode, which in Figure 2 causes an exit to number 1.

5.2.2 UTRA Radio access technology

5.2.2.1 Cell Selection Procedures

5.2.2.1.1 Description

Whenever a PLMN is selected, the UE shall attempt to find a suitable cell of that PLMN to camp on according to the following steps.

- 1) Create a candidate list of potential cells to camp on. Two searching procedures are possible.

- a) Initial Cell Selection

This procedure requires no prior knowledge of which RF channels are UTRA carriers. The UE shall scan all RF channels in the UTRA band to find a suitable cell. On each carrier, the UE searches first for the scrambling code of the strongest cell, in order to find out which PLMNs are available. If the selected PLMN is found, the search of the rest of carriers may be stopped. After the UE has found one suitable cell for the selected PLMN, the UE shall create a candidate list consisting of this cell and its neighbouring cells, as received in measurement control information via the selected cell.

- b) Stored Information Cell Selection

This procedure requires stored information of carrier frequencies and optionally also scrambling codes information from previously received measurement control information elements. After the UE has found one suitable cell for a selected PLMN the UE shall create the candidate list consisting of this cell and its neighbouring cells, as received in measurement control information via the selected cell.

NOTE: Setting the priorities of PLMN search and selection are FFS

- 2) For each cell on the candidate list fulfilling all criteria for a suitable cell, see 4.3, except the cell selection criteria,, calculate the cell selection value, S , and the quality value, Q , defined in Section 5.2.2.1.2.
- 3) Among the cells with $S > 0$ choose the cell with the highest Q value to camp on.

If no suitable cells are found and the stored information cell selection procedure was used in step 1, the Initial cell selection procedure shall be started and the steps are repeated. If the UE is unable to find any suitable cell using the Initial cell selection procedure, it shall attempt to camp on any acceptable cell and enter the Camped on any cell state, where it can only obtain limited service.

NOTE: In PLMN selection, automatic mode, this would normally result in a new PLMN selection.

5.2.2.1.2 Criteria

The cell selection value, S , is defined as follows.

$$S = Q - Q_{\min} - P_{\text{compensation}}$$

S	Cell Selection value, (dB)
Cell_selection_and_reselecti on_quality_measure	Choice of measurement (CPICH Rx E_c/N_0 or CPICH Rx SIR) to use as quality measure Q (read in system information). See NOTE 1.
Q	Quality value. The quality of the received signal, CPICH Rx E_c/N_0 or CPICH Rx SIR, (dB). The measurement to use for the quality value is set by the <u>Cell_selection_and_reselection_quality_measure</u> information element.
Qmin	Minimum required quality level in the cell (read in system information and dependent on the quantity to measure), (dB or dBm).
Pcompensation	$\max(\text{UE_TXPWR_MAX_RACH} - P_MAX, 0)$, (dB)
UE_TXPWR_MAX_RACH	Maximum TX power level an UE may use when accessing the cell on RACH (read in system information), (dBm)
P_MAX	Maximum RF output power of the UE, (dBm)

NOTE 1: The work in order to support the CPICH Rx SIR measurement is in progress in TSG-RAN WG4 and may impact the use of that measurement in this document

The cell selection criterion is fulfilled if:

$$S > 0$$

5.2.2.2 Immediate Cell Evaluation Procedure

NOTE: Conditions on the use of the immediate cell evaluation procedure are FFS. Specifically, the time needed to perform the procedure is to be considered.

5.2.2.2.1 Description

The Immediate Cell Evaluation procedure is used by the UE to perform a quick evaluation of the quality of the intra-frequency cells. Based on this information, the UE shall select the best cell among the cells on the same frequency, according to the criteria defined in the next section.

The immediate cell evaluation shall be triggered prior to RACH transmission.

The following steps shall be carried out when an immediate cell evaluation has been triggered.

- 1) The candidate list of potential cells to camp on consists of the cells in the current registration area listed for intra-frequency measurements in system information of the serving cell.
- 2) Calculate the Q value and the S value for each cell on the candidate list.
- 3) Select the neighbouring cell that fulfils the criteria in 5.2.2.2.2. best.

NOTE: Whether the calculation of the Q value should require the immediate decoding (e.g. in case the UL load value is used for the calculation) of a set of neighbouring cell BCHs is FFS.

5.2.2.2.2 Criteria

The UE shall select a new cell if the following criteria are fulfilled.

$$S_n > 0$$

$$Q_n > Q_s + Q_{\text{offset}_{s,n}}$$

S_n	Cell Selection value of the neighbouring cell, (dB)
Cell_selection_and_reselecti on_quality_measure	Choice of measurement (CPICH Rx E_c/N_0 or CPICH Rx SIR) to use as quality measures Q_n and Q_s , (read in system information). See NOTE 1.
Q_n	Quality of the neighbouring cell, CPICH Rx E_c/N_0 or CPICH Rx SIR, (dB). The measurement to use for the quality value is set by the Cell_selection_and_reselection_quality_measure information element.
Q_s	Quality of the serving cell, (dB). The measurement to use for the quality value is set by the Cell_selection_and_reselection_quality_measure information element.
$Q_{\text{offset}_{s,n}}$	Offset between the two cells considered in the evaluation (read in system information), (dB).

NOTE 1: The work in order to support the CPICH Rx SIR measurement is in progress in TSG-RAN WG4 and may impact the use of that measurement in this document

If more than one neighbouring cell fulfils the criteria, the UE shall choose the cell where the difference between Q_n and $(Q_s + Q_{\text{offset}})$ is highest. If no neighbouring cell fulfils the criteria, the UE shall keep the serving cell.

5.2.2.3 Camped Normally

When camped normally, the UE shall perform the following tasks:

- Monitor PICH and PCH of the cell as specified in section 8 according to information sent in system information
- Monitor relevant System Information.
- Prior to RACH transmission, the UE shall perform an immediate cell evaluation, according to 5.2.2.2.

5.2.2.4 Cell Reselection Procedure

5.2.2.4.1 Description

The purpose of the cell reselection is to look for a better cell for the UE to camp on. The serving cell is changed when a better cell is found. The criteria for a better cell are different for intra/inter-frequency and inter-radio access system cell reselections (see below).

The cell reselection procedure shall be triggered in the following cases.

1. Better cell is found
2. $S \leq 0$
3. Downlink signalling failure [details are FFS]
4. Cell has become barred or forbidden [details are FFS]

In case 2), 3) and 4) the parameters Q_{hyst} and $T_{\text{reselection}}$ shall not be considered in the criteria.

The following steps are carried out when evaluating cells for cell reselection.

- 1) The candidate list of potential cells to camp on consists of the cells for intra- and inter-frequency measurements and intra-radio access technology measurements in system information of the serving cell.
- 2) Intra- and inter frequency cells: Calculate the Q value and the S value for each cell on the candidate list.
Inter-radio access technology cells: When $Q_s \leq Q_{\text{search}}$, calculate the Q value of each cell on the candidate list.

- 3) Depending on which type of cells is on the candidate list (intra-frequency, inter-frequency and inter-radio access technology), select the cell that fulfils the corresponding criteria best.

Better cells are prioritised in the following order when several cells fulfil their corresponding criteria:

- 1) Intra-frequency neighbouring cells, see 5.2.2.4.2.
- 2) Inter-frequency neighbouring cells, see 5.2.2.4.3.
- 3) Inter-radio access technology neighbouring cells, see 5.2.2.4.4.

5.2.2.4.2 Intra-Frequency Cell Reselection Criteria

The criteria for a better intra-frequency cell are:

$$S_n > 0$$

$$Q_n > Q_s + Q_{\text{offset}_{s,n}} + Q_{\text{hyst}}$$

S_n	Cell Selection value of the neighbouring cell, (dB)
Cell_selection_and_reselecti on_quality_measure	Choice of measurement (CPICH Rx E_c/N_0 or CPICH Rx SIR) to use as quality measures Q_n and Q_s , (read in system information). See NOTE 1.
Q_n	Quality of the neighbouring cell, CPICH Rx E_c/N_0 or CPICH Rx SIR, (dB). The measurement to use for the quality value is set by the <u>Cell_selection_and_reselection_quality_measure</u> information element.
Q_s	Quality of the serving cell, CPICH Rx E_c/N_0 or CPICH Rx SIR, (dB). The measurement to use for the quality value is set by the <u>Cell_selection_and_reselection_quality_measure</u> information element.
$Q_{\text{offset}_{s,n}}$	Offset between the two cells considered in the evaluation (read in system information), (dB)
Q_{hyst_s}	Hysteresis value of the serving cell, (dB)
$T_{\text{reselection}_s}$	Time-to-trigger for cell reselection, (s) NOTE: Exact unit is FFS

NOTE 1: The work in order to support the CPICH Rx SIR measurement is in progress in RAN WG4 and may impact the use of that measurement in this document

The UE shall reselect the new cell, if the cell reselection criteria are fulfilled during a time interval $T_{\text{reselection}}$. The value of $T_{\text{reselection}}$ is broadcast in system information.

5.2.2.4.3 Inter-Frequency Cell Reselection Criteria

The inter-frequency cell reselection evaluation uses the same criteria as intra-frequency cell reselections.

5.2.2.4.4 Inter-Radio Access Technology Cell Reselection Criteria

The criteria for a better inter-radio-access-technology cell are:

$Q_s < Q_{search_s}$ $Q_n > Q_{accept_{s,n}}$

Q_s	Quality of the serving cell, (dB or dBm) NOTE: Exact unit is FFS
Q_n	Quality of the neighbouring cell, (dB or dBm) NOTE: Exact unit is FFS
Q_{search_s}	Below this limit in the serving cell, the UE shall take measurements of inter-radio access technology cells if such entries exist in the measurement control information elements (dB or dBm). NOTE: Exact unit is FFS
$Q_{accept_{s,n}}$	Minimum quality required for a cell in another radio access technology. (dB or dBm) NOTE: Exact unit is FFS

Measurements on another radio access technology are not carried out unless the quality of the serving cell is lower than a threshold, Q_{search} .

The UE shall select an inter-radio access technology cell that fulfils the criteria $Q_n > Q_{accept_{s,n}}$. If more than one cell fulfils the criteria, the UE shall select the cell with the highest quality Q .

Q_{accept} and Q_{search} are included in the system information of the serving cell.

If no cells of the other radio access technologies fulfil the criteria, the UE shall stay on the current cell and continue to perform measurements as long as $Q_s < Q_{search_s}$.

5.2.2.4.5 Cell reselection parameters in system information broadcasts

The selection of values for network controlled parameters can be optimised by means of different methods. Examples of methods are described in [6]. Cell reselection parameters are broadcast in system information as follows:

$Q_{offset_{s,n}}$

The offset between the two cells considered in the evaluation ($Q_{offset_{s,n}}$ (dB)) can be conveyed in two different ways:

Alternative 1. Offsets can be included for each neighbouring cell in the intra-frequency neighbouring cell list, which is read in system information of the serving cell.

Alternative 2. The offset can be broadcast in each cell, and the UE decodes it from system information broadcasts in the neighbouring cell. In the case, this offset is applied for all cell relations towards that neighbouring cell (i.e. for each value on the subscript s). Decoding is done only when the cell measurement exceeds the neighbour cell decoding range. The offset is broadcast together with an offset expiration timer, which indicates how long the offset value is valid.

NOTE: Whether both 1 and 2 could be used or if only one of these alternatives is used is FFS

Q_{hyst_s}

The hysteresis value (Q_{hyst}) is read in system information of the serving cell.

$T_{reselection_s}$

The cell reselection timer value is read in system information of the serving cell.

Decoding range

The decoding range is read in system information of the serving cell.

NOTE: This parameter is only applicable for Alternative 2, see above.

OffsetExp

The offset expiration timer is read in system information of the neighbouring cell.

NOTE: This parameter is only applicable for Alternative 2, see above.

Qaccept_{s,n}

Minimum quality required for selecting a cell in other radio access technology. The value is read in system information of the serving cell.

Qsearch_s

Below this limit in the serving UTRA cell, the UE shall take measurements of inter-radio access technology cells. The value is read in system information of the serving cell.

5.2.2.5 Cell Selection when leaving connected mode

When returning to idle mode from connected mode, the UE shall select a suitable cell to camp on. Candidate cells for this selection are the cell(s) used immediately before leaving connected mode. If no suitable cell is found, the UE shall use the Stored information cell selection procedure in order to find a suitable cell to camp on.

When returning to idle mode after an emergency call on any PLMN, the UE shall select an acceptable cell to camp on. Candidate cells for this selection are the cell(s) used immediately before leaving connected mode. If no acceptable cell is found, the UE shall continue to search for an acceptable cell of any PLMN in state Any cell selection.

5.2.2.6 Any Cell Selection

In this state, the UE shall attempt to find an acceptable cell to camp on, trying all radio access technologies that are supported by the UE.

If no acceptable cell is found, the UE shall continue to search for an acceptable cell in this state.

5.2.2.7 Camped on Any Cell

If an acceptable cell is found, the UE shall camp on this cell and obtain limited service, state Camped on any cell. In this state, the UE shall behave as specified for state Camped normally, but typically with a different PLMN. Additionally, the UE shall regularly attempt to find a suitable cell trying all radio access technologies that are supported by the UE. If a suitable cell is found, this causes an exit to number 1 in Figure 2.

5.2.2.8 Any Cell Reselection

The Any cell reselection procedure is identical to the cell reselection procedure. However, the requirement of selecting a suitable cell is relaxed to selecting an acceptable cell.

5.2.2.9 ODMA probing sub-process

In addition to UE cell selection process the UE_R will initiate or continue to evaluate the relay link via probing. The ODMA probing process state machine controls the rate of ODMA relay node probing. The ODMA probing state machines and mechanisms for controlling the rate of ODMA probing are discussed in the following section.

5.2.2.6.1 ODMA probing state machines

Probing is a mechanism used by the ODMA relay node to build a neighbour list which should contain at least a predefined minimum number of neighbours. The probing activity levels of an ODMA relay node may also be influenced by a number of key system parameters such as

- Number of neighbours
- Gradient information
- Path loss to neighbours

- Speed of the terminal
- Battery power level

The probing state machines are characterised by the level of probing opportunities. The objective of the probing state machines is to optimise ORACH activity to provide reduced interference and regulate power consumption. The difference between these state machines can generally be characterised by the number of ORACH channels that may be used for probing. Thus the probing opportunities within one N multiframe may vary depending upon the active state machine. Additionally, the ratio of probe transmission to reception is controlled by a probing activity parameter K . The state machines are full probing, duty maintained probing, and relay prohibited. The function of each of these state machines is described below:

Full probing


Full probing is the case where probing is allowed on every ORACH timeslot within a N multiframe. The UE_R will probe on the ORACH at a rate defined by the probing activity parameter K .

Duty Maintained probing

The duty maintained probing is the case where probing is allowed on M slots of an N multiframe. The UE_R will probe on the M ORACH slots in an N multiframe at a rate defined by the probing activity parameter K .

Relay Prohibited

In this mode the UE_R would cease all of its ODMA probing activities and will fall into standard TDD or FDD operation.




The probing activity levels for given state machines are illustrated in Figure 3 for a system with an ORACH for M slots per $N \times 16$ multiframe.

Figure 3: Probing state machines and mechanism

NOTE: The distribution of probing opportunities within a multiframe may not necessarily be consecutive and located at the beginning of a multiframe.

A practical illustration of these probing state machines within the ODMA system is shown in Figure 4.

**Figure 4: Illustration of probing process assignment**

5.2.3 GSM Radio access technology

5.2.3.1 Cell Selection Procedures

The cell selection procedures in GSM are specified in [1].

5.2.3.2 Immediate Cell Evaluation Procedure

Immediate Cell Evaluation procedure is not applicable for GSM.

5.2.3.3 Cell Reselection Procedure

5.2.3.3.1 Description

The cell reselection procedure in GSM is specified in [1].

5.2.3.3.2 Cell Reselection Criteria

The cell reselection criteria in GSM are specified in [1].

5.2.3.3.3 Inter-Radio Access Technology Cell Reselection Procedure

The criteria for a better UTRA cell are:

$$Q_s < Q_{\text{search}_s}$$

$$Q_n > Q_{\text{accept}_{s,n}}$$

Q_s	Quality of the serving cell, (dB or dBm) NOTE: Exact unit is FFS
Q_n	Quality of the neighbouring cell, (dB or dBm) NOTE: Exact unit is FFS
Q_{search_s}	Below this limit in the serving cell, the UE shall take measurements of UTRA cells if such entries exist in the measurement control information elements (dB or dBm). NOTE: Exact unit is FFS
$Q_{\text{accept}_{s,n}}$	Minimum quality required for a UTRA cell. (dB or dBm) NOTE: Exact unit is FFS

Measurements on UTRA cells are not carried out unless the quality of the serving cell is lower than a threshold, Q_{search} .

The UE shall select a UTRA cell that fulfils the criteria $Q_n > Q_{\text{accept}_{s,n}}$. If more than one cell fulfils the criteria, the UE shall select the cell with the highest quality Q .

Q_{accept} and Q_{search} are included in the system information of the serving cell.

If no cells of the other technologies fulfil the criteria, the UE shall stay on the current cell and continue to perform measurements as long as $Q_s < Q_{\text{search}_s}$.

5.2.3.3.4 Cell reselection parameters in system information broadcasts

The selection of values for network controlled parameters can be optimised by means of different methods. Examples of methods are described in [6]. Inter-radio access technology cell reselection parameters are broadcast in GSM system information as follows:

Q_{search_s}

When the Q value of the serving GSM cell is below this value, the UE shall perform measurements of UTRA cells.

$Q_{\text{accept}_{s,n}}$

Minimum quality of the UTRA cell required for selecting the UTRA cell.

5.2.3.4 Cell Selection when leaving connected mode

Cell selection when leaving connected mode in GSM is specified in [1].

5.2.3.5 Any Cell Selection

The any cell selection state in GSM is specified in [1].

5.2.3.6 Camped on Any Cell

The camped on any cell state in GSM is specified in [1].

5.2.3.7 Any Cell Reselection

The any cell reselection procedure in GSM is specified in [1].

5.2.4 Barred Cells and Access Control

The barred case of cell status is used to bar completely a cell against access by all normal subscribers. This barred status is indicated in the information broadcast by the cell, in the Cell Access Restriction information element, which has 4 cases:

1. Cell not Barred,
2. Cell Barred for normal users - allows Operator access,
3. Cell Barred for normal users – allows Emergency access,
4. Cell Barred for normal users – allows SoLSA access.

Additionally, combinations of cases 2, 3, and 4 are allowed in one cell.

NOTE: Access Control is FFS

FFS

5.2.5 Regional Provision of Service

FFS

5.3 Cell Reselection in Connected Mode

5.3.1 UTRA Radio Access Technology

5.3.1.1 General

This section specifies cell reselection procedures in UTRAN connected mode.

The UE shall select a suitable cell and radio access technology based on connected mode radio measurements and cell reselection criteria.

Figure 5 shows the states and procedures in the cell reselection process in connected mode.




Figure 5: UTRAN Connected mode cell reselection

Transition from idle mode to connected mode is described in Section 5.2.

For UTRAN connected mode, RRC connection mobility tasks are specified in [25.331]. In some states the UE shall perform cell reselection procedures.

When a cell reselection is triggered, the UE shall evaluate the cell reselection criteria based on radio measurements, and if a better cell is found that cell is selected, procedure *Cell reselection* (see Section 5.3.1.4). If the change of cell implies a change of radio access technology, the RRC connection is released, and the UE enters idle mode. If no suitable cell is found in the cell reselection procedure, the RRC connection is released, and the UE enters idle mode.

When the UE has data to transmit, and there is no restriction for the UE to reselect cell (see [25.331]), the UE shall use the *Immediate cell evaluation* procedure (see Section 5.3.1.3) to select the best suitable cell prior to the access attempt, according to the immediate cell evaluation criteria. Constraints on the use of this procedure are specified in [25.331].

When an immediate cell reselection is triggered, the UE shall use the *Initial cell reselection* procedure (see Section 5.3.1.2) to find a suitable cell. The cases where this may be triggered are specified in [25.331]. One example where this procedure is triggered is at radio link failure, where the UE may trigger an initial cell reselection in order to request re-establishment of the RRC connection. If the UE is unable to find a suitable cell, the UE shall release the RRC connection and enter idle mode.

5.3.1.2 Initial Cell Reselection Procedure

5.3.1.2.1 Description

Triggers for the Initial cell re-selection procedure are specified in [25.331].

When the Initial cell reselection procedure is triggered, the UE shall attempt to find a suitable cell belonging to the selected PLMN according to the following steps:

1. The UE shall scan all RF channels of the UTRA band to find a suitable cell. The UE may optimise this search by using stored information of carrier frequencies and optionally also scrambling code information from previously received measurement control information elements.

2. After the UE has found one suitable cell for the selected PLMN, the UE shall create a candidate list consisting of this cell and its neighbouring UTRA cells, as received in measurement control information via the selected cell.
3. For each cell on the candidate list fulfilling all criteria for a suitable cell, see Section 5.2.2.1, except the cell selection criteria, calculate the cell selection value, S , and the quality value, Q , defined in Section 5.3.1.2.2.
4. Among the cells with $S > 0$ select the cell with the highest Q value.

If the UE is unable to find any suitable cell, the UE shall release the RRC connection and enter idle mode.

5.3.1.2.2 Criteria

The cell selection value, S , is defined as follows.

$$S = Q - Q_{\min} - P_{\text{compensation}}$$

S	Cell Selection value, (dB)
Cell_selection_and_reselection_quality_measure	Choice of measurement (CPICH Rx Ec/N0 or CPICH Rx SIR) to use as quality measures Q (read in system information). See NOTE 1.
Q	Quality value. The quality of the received signal, (CPICH Rx Ec/N0 or CPICH Rx SIR) (dB)
Q_{\min}	Minimum required quality level in the cell (read in system information and dependent on the quantity to measure), (dB)
$P_{\text{compensation}}$	$\max(\text{UE_TXPWR_MAX_RACH} - P_{\text{MAX}}, 0)$, (dB)
UE_TXPWR_MAX_RACH	Maximum TX power level an UE may use when accessing the cell on RACH (read in system information), (dBm)
P_{MAX}	Maximum RF output power of the UE, (dBm)

NOTE 1: The work in order to support the CPICH Rx SIR measurement is in progress in TSG-RAN WG4 and may impact the use of that measurement in this document

The initial cell re-selection criterion is fulfilled if:

$$S > 0$$

5.3.1.3 Immediate Cell Evaluation Procedure

5.3.1.3.1 Description

The Immediate Cell Evaluation procedure is used by the UE to perform a quick evaluation of the quality of the intra-frequency cells. Based on this information, the UE shall select the best cell among the cells on the same frequency, according to the criteria defined in the next section.

The immediate cell evaluation procedure shall be triggered prior to RACH and CPCH (FFS) transmission, if not restrictions specified in [4] inhibits use of the procedure.

The following steps shall be carried out when an immediate cell evaluation has been triggered:

1. The candidate list of potential cells consists of the cells for intra-frequency measurements in system information of the serving cell. However, if UE dedicated measurements control information has been assigned to the UE in

the serving cell, the candidate list consists of the cells for intra-frequency measurements included in this UE dedicated measurement control information.

2. Calculate the Q value and the S value for each cell on the candidate list.
3. Select the neighbouring cell that fulfils the criteria in Section 5.3.1.3.2 best.

5.3.1.3.2 Criteria

The UE shall select a new cell if the following criteria are fulfilled.

$$S_n > 0$$

$$Q_n > Q_s + Q_{\text{offset}_{s,n}}$$

S_n	Cell Selection value of the neighbouring cell, (dB)
Cell_selection_and_reselection_quality_measure	Choice of measurement (CPICH Rx Ec/N0 or CPICH Rx SIR) to use as quality measures Q_n and Q_s (read in system information). See NOTE 1.
Q_n	Quality of the neighbouring cell, (CPICH Rx Ec/N0 or CPICH Rx SIR), (dB)
Q_s	Quality of the serving cell, (CPICH Rx Ec/N0 or CPICH Rx SIR), (dB)
$Q_{\text{offset}_{s,n}}$	Offset between the two cells considered in the evaluation (read in system information), (dB).

NOTE 1: The work in order to support the CPICH Rx SIR measurement is in progress in RAN WG4 and may impact the use of that measurement in this document

If more than one neighbouring cell fulfils the criteria, the UE shall choose the cell where the difference between Q_n and $(Q_s + Q_{\text{offset}})$ is highest. If no neighbouring cell fulfils the criteria, the UE shall keep the serving cell.

5.3.1.4 Cell Reselection Procedure

5.3.1.4.1 Description

The purpose of the cell reselection is to look for a better cell for the UE to camp on. The serving cell is changed when a better cell is found.

The cell reselection procedure shall be triggered in the following cases.

- 1) Better cell is found
- 2) $S \leq 0$
- 3) Downlink signalling failure [details are FFS]
- 4) Cell has become barred or forbidden [details are FFS]

In case 2), 3) and 4), the parameters Q_{hyst} and $T_{\text{reselction}}$ shall not be considered in the criteria.

The following steps are carried out when evaluating cells for cell reselection.

1. The candidate list of potential cells consists of the cells for intra- and inter-frequency and inter-radio access technology measurements in system information of the serving cell. However, if UE dedicated measurements control information has been assigned to the UE in the serving cell, the candidate list consists of the cells for intra- and inter-frequency and inter-radio access technology measurements included in this UE dedicated measurement control information.

2. Intra- and inter frequency cells : Calculate the Q value and the S value for each cell on the candidate list.
Inter-radio-access-technology cells: When $Q_s \leq Q_{search}$, calculate the Q value of each cell on the candidate list.
3. Depending on which types of cells are on the candidate list (intra-frequency, inter-frequency and inter-radio-access technology), select the cell that fulfils the corresponding criteria best.

Better cells are prioritised in the following order when several cells fulfil their corresponding criteria:

- 1) Intra-frequency neighbouring cells, see 5.3.1.4.2.
- 2) Inter-frequency neighbouring cells, see 5.3.1.4.3.
- 3) Inter-radio-access-technology neighbouring cells, see 5.3.1.4.4.

5.3.1.4.2 Intra-Frequency Cell Reselection Criteria

The criteria for a better intra-frequency cell are:

$$S_n > 0$$

$$Q_n > Q_s + Q_{offset_{s,n}} + Q_{hyst_s}$$

S_n	Cell Selection value of the neighbouring cell, (dB)
Cell_selection_and_reselection_quality_measure	Choice of measurement (CPICH Rx Ec/N0 or CPICH Rx SIR) to use as quality measures Q_n and Q_s (read in system information). See NOTE 1.
Q_n	Quality of the neighbouring cell, (CPICH Rx Ec/N0 or CPICH Rx SIR), (dB)
Q_s	Quality of the serving cell, (CPICH Rx Ec/N0 or CPICH Rx SIR), (dB)
$Q_{offset_{s,n}}$	Offset between the two cells considered in the evaluation (read in system information), (dB)
Q_{hyst_s}	Hysteresis value of the serving cell, (dB)
$T_{reselection_s}$	Time-to-trigger criteria for cell reselection, (s) [Note: Exact unit is FFS]

NOTE 1: The work in order to support the CPICH Rx SIR measurement is in progress in RAN WG4 and may impact the use of that measurement in this document

The UE shall reselect the new cell, if the cell reselection criteria are fulfilled during a time interval $T_{reselection}$. The value of $T_{reselection}$ is broadcast in system information.

5.3.1.4.3 Inter-Frequency Cell Reselection Criteria

The inter-frequency cell reselection evaluation uses the same criteria as intra-frequency cell reselections.

5.3.1.4.4 Inter Radio Access Technology Cell Reselection Criteria

The criteria for a better inter-radio-access-technology cell are:

$$Q_s < Q_{search_s}$$

$$Q_n > Q_{accept_{s,n}}$$

Q_s	Quality of the serving cell, (dB or dBm) NOTE: Exact unit is FFS
Q_n	Quality of the neighbouring cell, (dB or dBm) NOTE: Exact unit is FFS
$Q_{search_{s,n}}$	Below this limit in the serving cell, the UE shall take measurements of inter-radio-access-technology cells if such entries exist in the measurement control information elements. (dB or dBm) NOTE: Exact unit is FFS
$Q_{accept_{s,n}}$	Minimum quality required for a cell in another radio access technology. (dB or dBm) NOTE: Exact unit is FFS

Measurements on another radio access are not carried out unless the quality of the serving cell is lower than a threshold, Q_{search} .

The UE shall select an inter-radio-access-technology cell that fulfils the criteria $Q_n > Q_{accept_{s,n}}$. If more than one cell fulfils the criteria, the UE shall select the cell with the highest quality Q .

Q_{accept} and Q_{search} are included in the system information of the serving cell.

If no cells of the other systems fulfil the criteria, the UE shall stay on the current cell and continue to perform measurements as long as $Q_s < Q_{search_s}$.

5.4 Location Registration

In the UE, the access stratum shall report registration area information to the non-access stratum.

The non-access part of the location registration process is specified in [5].

6 Broadcast information receiving

6.1 Reception of System Information

The UE shall read the BCCH to acquire valid system information. For each acquisition, the UE will need different combinations of system information blocks broadcast on BCCH. Thus, the scheduling of the broadcast channel is done in such way that the UE knows exactly when the needed information can be found.

When any of the system information blocks are modified, the corresponding scheduling information is updated to reflect the changes in system information transmitted on BCCH. Further, a message is sent to all UEs on PCCH to indicate that a new master information block is available in the cell. Then the UE shall read the updated master information block on BCCH and if the changes are applicable for the UE, the modified system information block(s) are read as well.

6.2 Cell Broadcast

A UE supporting Cell Broadcast Service (CBS) shall be capable to receive BMC messages in the Idle mode.

7 Idle mode measurements

7.1 Network control of UE measurement activities

7.1.1 Intra-frequency cell measurements

The optional parameter Q_{intra} provides means for the network to control the UE Intra-frequency measurement activities in idle mode. The parameter is included in the system information of the serving cell.

Depending on the presence of the parameter, and the quality of the serving cell, Q_s , the following 2 cases are possible:

1. Parameter Q_{intra} is available for serving cell:

$Q_s > Q_{intra}$	UE need not perform Intra-frequency measurements
$Q_s \leq Q_{intra}$	UE shall perform Intra-frequency measurements

2. Parameter Q_{intra} is not available for serving cell:
UE shall perform Intra-frequency measurements.

7.1.2 Inter-frequency cell measurements

The optional parameters Q_{inter} and $Q_{intersearchsize}$ provide means for the network to control the UE Inter-frequency measurement activities in idle mode. The parameters are included in the system information of the serving cell.

Depending on the presence of the parameters, and the quality of the serving cell, Q_s , the following 3 cases are possible

1. Parameters Q_{inter} and $Q_{intersearchsize}$ are available for serving cell:

$Q_s > Q_{inter} + Q_{intersearchsize}$	UE shall perform Inter-frequency measurements
$Q_{inter} < Q_s \leq Q_{inter} + Q_{intersearchsize}$	UE need not perform Inter-frequency measurements
$Q_s \leq Q_{inter}$	UE shall perform Inter-frequency measurements

2. Parameters Q_{inter} is available for serving cell, $Q_{intersearchadd}$ is not available for serving cell:

$Q_s > Q_{inter}$	UE need not perform Inter-frequency measurements
$Q_s \leq Q_{inter}$	UE shall perform Inter-frequency measurements

3. Parameters Q_{inter} and $Q_{intersearchsize}$ are not available for serving cell:
UE shall perform Inter-frequency measurements.

7.1.3 Inter-Radio Access Technology measurements

The parameter Q_{search} provides means for the network to control the UE Intra-Radio Access Technology measurement activities in idle mode. The parameter is included in the system information of the serving cell.

$Q_s > Q_{search}$	UE need not perform Inter-RAT measurements
$Q_s \leq Q_{search}$	UE shall perform Inter-RAT measurements

8 Discontinuous Reception

The UE may use Discontinuous Reception (DRX) in idle mode in order to reduce power consumption. When DRX is used the UE needs only to monitor one Page Indicator, PI, (see definition in [7] and [8]) in one Paging Occasion per DRX cycle.

The DRX cycle length shall be $2^k \cdot \text{PBP}$ frames, where k is an integer and PBP is the Paging Block Periodicity. PBP is only applicable for TDD. For FDD, PBP=1.

The UE may be attached to different CN domains with different DRX cycle lengths. In this case, the UE shall use the shortest of those DRX cycle lengths. The DRX cycle lengths to use for each CN domain are given in system information. An UE may also be assigned an individual DRX cycle length to use in idle mode by a CN.

The DRX cycle lengths to use for UTRAN connected mode is also given in system information. An UE may also be assigned an individual DRX cycle length to use by UTRAN.

The UE shall use the IMSI, the Cell System Frame Number (SFN), N_p (number of page indicators within a frame), Frame offset (For FDD, Frame offset = 0), PBP and the DRX cycle length to determine the Paging Occasions.

The Paging Occasions are the frames where:

$$\text{Cell SFN} = \{ \text{IMSI mod (DRX cycle length div PBP)} \} * \text{PBP} + n * \text{DRX cycle length} + \text{Frame Offset}$$

Where $n = 0, 1, 2, \dots$ as long as SFN is below its maximum value.

The actual Page Indicator within a Paging Occasion that the UE shall read is similarly determined based on IMSI.

The Page Indicator to use is calculated by using the following formula:

$$\text{PI} = \text{DRX Index mod } N_p$$

where $\text{DRX Index} = \{ \text{IMSI div (DRX cycle length div PBP)} \}$

The number of Page Indicators per frame, $N_p = (18, 36, 72, 144)$, is given in IE "Number of PI per frame", part of system information in FDD mode. In TDD mode, N_p is calculated by PICH repetition cycle and Burst Type (long or short midamble).

If the UE has no IMSI, for instance when making an emergency call without USIM, the UE shall use a default number, $\text{IMSI} = 0$, in the formulas above.

For FDD, see [7] for details about the timing between a PICH frame and when the paging message is transmitted on the PCH in the associated S-CCPCH frame. In TDD mode, the Paging Message Receiving Occasion is calculated using the following formula:

$$\text{Paging Message Receiving Occasion} = \text{Paging Occasion} + N_{\text{PICH}} + N_{\text{GAP}} + \{ (\text{DRX Index div } N_p) \text{ mod } N_{\text{PCH}} \} * 2$$

The value N_{PICH} is the number of frames for PICH transmission. The value N_{GAP} is the number of frames between the last frame carrying PICH for this Paging Occasion and the first frame carrying paging messages for this Paging Occasion. The value N_{PCH} is the number of Paging Groups.

9 Multicast services

9.1 State diagram between the multicast service and DSCH

NOTE: The use of DSCH for multicast services is FFS.

The multicast service relative to the DSCH consists of the following states:

- MT_Null State
- MT_Monitor State

- MT_Saving State
- MT_Active State

Figure 6 shows the multicast state diagram relative to the DSCH. The MT_Monitor State is a state for decoding the DSCH in order to monitor its multicast control data and the MT_Saving State is a state in which the UE savings for the supporting power saving feature.




Figure 6: Multicast State Diagram relative to the DSCH, MT=Multicast service

9.1.1 MT_Null State

a) Attributes

- Multicast service has not been activated.
- DSCH is not established.

b) Behaviour

- Waits for activation of multicast service.

9.1.2 MT_Monitor State

a) Attributes

- DSCH is monitored in order to decode the multicast control data that contains the assigned multicast identifier.

b) Behaviour

- Receives the DSCH control data on DSCH and confirms the assigned multicast identifier.

9.1.3 MT_Saving State

a) Attributes

- DSCH is not monitored for the control or the user data.

b) Behaviour

- FFS

9.1.4 MT_Active State

a) Attributes

- DSCH is not monitored for the control data.
- DSCH is monitored for the user data.

b) Behaviour

- Receives the multicast user data on the established DSCH.

10 Examples of Procedures

10.1 NAS initiated change of system information

The sequence in Figure 7 shows the change of broadcast system information initiated from the non-access stratum (NAS).




Figure 7: Example sequence, non-access stratum initiated change of broadcast system info

A non-access stratum entity in the network issues a request for change of the broadcast system information, by issuing a RRC Information Broadcast REQ primitive over the General Control (GC) SAP.

The change in system information in this example is such that it is not necessary for the UEs to be forced to receive BCCH immediately after the change. All UEs will eventually read the new system information either at e.g. cell reselection or at UE state change.

When the UE reads system information on BCCH and the RRC layer finds out that the non-access part of the information has been changed, an RRC Information Broadcast IND primitive is issued to the non-access stratum entity in the UE over the General Control (GC) SAP.

NOTE: The network may force the UEs in a paging group to read system information by sending a page request message, but this is not shown in the example above.

10.2 System Information Update to NAS




Figure 8: System Information Update to NAS

AS sends system information to NAS when a change of system information is detected in the cell currently camped on. This happens for instance when a new cell is selected due to cell reselection. The information sent can include PLMN identity, registration area and NAS information. The NAS information includes the identity of the NAS defined service area.

10.3 CN originated paging in idle mode




Figure 9: Example sequence of CN initiated paging request in idle mode

Figure 9 illustrates a CN originated paging request when the UE is in idle mode.

In the UE, a NAS entity issues the primitive RRC Paging Control REQ, which tells RRC to listen to paging and notifications addressed to a given UE paging identity and on a paging group which can be calculated using information given from NAS.

NOTE: The paging group calculation info can e.g. be the IMSI of the UE.

A NAS entity on the network side requests paging of an UE using the RRC Paging REQ primitive over the Nt-SAP. The primitive contains a UE paging identity, an area where the page request is to be broadcast, information for calculation of the paging group and NAS information to be transparently transmitted to the UE by the paging request.

The RRC layer calculates the paging group, and formats a Paging Request Type 1 message containing the UE paging identity and the NAS information. The RRC layer then requests MAC to transmit the message on the PCH on the selected paging group.

In the UE, the RRC layer continuously monitors the paging group, compares the UE paging identities in received paging request messages with its own identities. A match occurs, and in this case the UE paging identity and the NAS information is forwarded to the NAS entity of the UE.

10.4 PLMN Selection, automatic mode, normal case




Figure 10: PLMN Selection, automatic mode, normal case

At power-on, the non-access stratum (NAS) selects the PLMN with highest priority, possibly the last PLMN stored prior to previous power off. The access stratum (AS) is requested to find a cell belonging to that PLMN. When searching for the requested PLMN and in order to speed up the search, AS may use a list of cell information stored prior to previous power-off. When a cell belonging to the requested PLMN is found, that cell is selected and NAS is notified that the PLMN was found.

10.5 PLMN Reselection, automatic mode




Figure 11: PLMN Reselection, automatic mode

Triggered by, for instance, a timer, AS sends a list to NAS with all PLMNs currently available. The list includes the identities of available PLMNs and possibly information about their NAS defined service area(s). Assuming that a PLMN with higher priority is found, NAS requests AS to select a cell belonging to the PLMN with highest priority. When searching for the requested PLMN and in order to speed up the search, AS may use a list of cell information previously stored, if any. When a cell belonging to the requested PLMN is found, that cell is selected and NAS is notified that the PLMN was found.

10.6 PLMN Reselection, manual mode




Figure 12: PLMN Reselection, manual mode

NAS requests AS to report all PLMNs currently available, for instance as a response to a user request. AS sends a list to NAS with all PLMNs currently available. The list includes the identities of available PLMNs and possibly information about their NAS defined service area(s). Assuming that a PLMN with higher priority is selected by for instance the user, NAS requests AS to select a cell belonging to the PLMN with highest priority. When searching for the requested PLMN and in order to speed up the search, AS may use a list of cell information previously stored, if any. When a cell belonging to the requested PLMN is found, that cell is selected and NAS is notified that the PLMN was found.

10.7 PLMN Selection, automatic mode, selected PLMN not found




Figure 13: PLMN Selection, automatic mode, selected PLMN not found

At power-on, the non-access stratum selects the PLMN with highest priority, possibly from the list of PLMNs stored prior to previous power off. The access stratum is requested to find a cell belonging to that PLMN. When searching for the requested PLMN and in order to speed up the search, AS may use a list of cell information stored prior to previous power-off. If no cell is found belonging to the requested PLMN, a list of available PLMNs is sent to NAS, indicating which PLMN has been temporarily chosen by AS.

10.8 NAS Controlled Cell Selection

10.8.1 Execution in Access Stratum




Figure 14: NAS Controlled Cell Selection, execution in AS

NAS may influence the cell selection and reselection by sending control information to AS. This information can include, for example, lists of forbidden registration areas and a list of NAS defined service areas in priority order. The control information is used by AS in cell selection and reselection:

- Cells belonging to a forbidden registration area will only be selected if no better cell is found. At this point, the services provided the UE might be limited.
- Cells belonging to a NAS defined service area with higher priority than current service area will be considered better than the cell currently camped on. Depending on radio access mode, the most suitable cell in idle mode may not be the most suitable cell in connected mode.

10.8.2 Execution in Non-Access Stratum




Figure 15: NAS Controlled Cell Selection, execution in NAS

As an alternative to the example in Section 11.8.1, AS sends cell selection information to NAS. This information can include PLMN identity, registration area and NAS defined service area. The information contains the full set of available registration areas and NAS defined service areas. The information is typically sent when there is a change of available areas, for instance when a neighbour cell belonging to a new registration area/NAS defined service area is found. Correspondingly, a new list of available areas is sent from AS to NAS when for instance coverage is lost from the cell currently camped on and that is the only cell belonging to the current NAS defined service area.

AS performs cell selection and reselection for the selected registration area/NAS defined service area without interaction with NAS. However, before reselecting a cell in another registration area/NAS defined service area, AS must check with NAS.

Annex A (informative): Change history

Change history					
TSG-RAN#	Version	CR	Tdoc RAN	New Version	Subject/Comment
RAN_05	-	-	RP-99464	3.0.0	Approved at TSG-RAN #5 and placed under Change Control
RAN_06	3.0.0	001	RP-99632	3.1.0	Modification and editorial changes
RAN_06	3.0.0	002	RP-99633	3.1.0	Specification of Cell reselection procedures in
RAN_06	3.0.0	003	RP-99633	3.1.0	Integration of Cell Broadcast Service (CBS)
RAN_06	3.0.0	004	RP-99633	3.1.0	Measurement used as a quality estimate for cell
RAN_06	3.0.0	006	RP-99632	3.1.0	Discontinuous reception
RAN_06	3.0.0	008	RP-99633	3.1.0	Barred Cells and Access Control
RAN_06	3.0.0	009	RP-99633	3.1.0	Introduction of network control of UE measurement
RAN_06	3.0.0	011	RP-99631	3.1.0	Editorial issues

History

Document history		
V3.1.0	January 2000	Publication