

# ETSI TS 136 420 V9.0.0 (2010-02)

---

*Technical Specification*

**LTE;  
Evolved Universal Terrestrial Radio  
Access Network (E-UTRAN);  
X2 general aspects and principles  
(3GPP TS 36.420 version 9.0.0 Release 9)**

---



---

**Reference**RTS/TSGR-0336420v900

---

---

**Keywords**LTE

---

**ETSI**

650 Route des Lucioles  
F-06921 Sophia Antipolis Cedex - FRANCE

---

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C  
Association à but non lucratif enregistrée à la  
Sous-Préfecture de Grasse (06) N° 7803/88

---

**Important notice**

---

Individual copies of the present document can be downloaded from:

<http://www.etsi.org>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at

<http://portal.etsi.org/tb/status/status.asp>

If you find errors in the present document, please send your comment to one of the following services:

[http://portal.etsi.org/chaicor/ETSI\\_support.asp](http://portal.etsi.org/chaicor/ETSI_support.asp)

---

**Copyright Notification**

---

No part may be reproduced except as authorized by written permission.  
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2010.  
All rights reserved.

**DECT**<sup>TM</sup>, **PLUGTESTS**<sup>TM</sup>, **UMTS**<sup>TM</sup>, **TIPHON**<sup>TM</sup>, the TIPHON logo and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.

**3GPP**<sup>TM</sup> is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

**LTE**<sup>TM</sup> is a Trade Mark of ETSI currently being registered

for the benefit of its Members and of the 3GPP Organizational Partners.

**GSM**<sup>®</sup> and the GSM logo are Trade Marks registered and owned by the GSM Association.

---

## Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<http://webapp.etsi.org/IPR/home.asp>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

---

## Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

# Contents

Intellectual Property Rights .....	2
Foreword.....	2
Foreword.....	4
1 Scope .....	5
2 References .....	5
3 Definitions, symbols and abbreviations .....	5
3.1 Definitions .....	5
3.2 Symbols.....	5
3.3 Abbreviations .....	5
4 General aspects.....	6
4.1 Introduction .....	6
4.2 X2 interface general principles.....	6
4.3 X2 interface specification objectives.....	6
4.3.1 General.....	6
4.3.2 Addressing of eNBs over the X2 interface .....	6
4.4 X2 interface capabilities .....	6
4.4.1 Radio application related signalling.....	6
4.4.2 X2 tunnels.....	7
4.5 X2 interface characteristics .....	7
4.5.1 Uses of SCTP.....	7
4.5.1.1 General .....	7
5 Functions of the X2 interface .....	7
5.1 Function list.....	7
5.2 Function description .....	7
5.2.1 Intra LTE-Access-System mobility support for ECM-CONNECTED UE.....	7
5.2.1.1 Context transfer from source eNB to target eNB .....	8
5.2.1.2 Control of user plane transport bearers between source eNB and target eNB .....	8
5.2.1.3 Handover cancellation.....	8
5.2.1.4 UE context release in source eNB .....	8
5.2.2 Load management.....	8
5.2.3 Inter-cell interference coordination.....	8
5.2.3.1 Uplink interference load management .....	8
5.2.3.2 Downlink interference avoidance.....	8
5.2.4 General X2 management and error handling functions .....	8
5.2.4.1 Error indication .....	8
5.2.4.2 Reset.....	8
5.2.5 Trace functions .....	9
5.2.6 Application level data exchange between eNBs .....	9
6 X2 interface protocols and protocol structure .....	9
6.1 General .....	9
6.2 Radio signalling protocols.....	9
6.2.1 X2AP protocol.....	9
6.3 User plane protocol .....	9
6.3.1 Tunnelling protocol GTP-U.....	9
7 Other X2 interface specifications .....	10
7.1 E-UTRAN X2 interface: X2 layer 1 (TS 36.421).....	10
7.2 E-UTRAN X2 interface: X2 signaling transport (TS 36.422).....	10
7.3 E-UTRAN X2 interface: X2 application protocol (X2AP) (TS 36.423).....	10
7.4 E-UTRAN X2 interface: X2 data transport (TS 36.424).....	10
7.5 Summary of E-UTRAN X2 interface Technical Specifications.....	11
<b>Annex A (informative): Change history .....</b>	<b>12</b>
History .....	13

---

## Foreword

This Technical Specification has been produced by the 3<sup>rd</sup> Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

---

# 1 Scope.

The present document is an introduction to the TSG RAN TS 36.42x series of UMTS Technical Specifications that define the X2 interface. It is an interface for the interconnection of two E-UTRAN NodeB (eNB) components within the Evolved Universal Terrestrial Radio Access Network (E-UTRAN) architecture [2].

---

## 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

- [1] 3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
  - [2] 3GPP TS 36.401: "E-UTRAN architecture description".
  - [3] 3GPP TS 36.421: "X2 layer 1".
  - [4] 3GPP TS 36.422: "X2 signaling transport".
  - [5] 3GPP TS 36.423: "X2 application protocol (X2AP)".
  - [6] 3GPP TS 36.424: "X2 data transport".
- 

## 3 Definitions, symbols and abbreviations

### 3.1 Definitions

For the purposes of the present document, the terms and definitions given in TR 21.905 [1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in TR 21.905 [1].

**E-RAB:** Defined in [2].

### 3.2 Symbols

For the purposes of the present document, the following symbols apply:

### 3.3 Abbreviations

For the purposes of the present document, the abbreviations given in TR 21.905 [x] and the following apply. An abbreviation defined in the present document takes precedence over the definition of the same abbreviation, if any, in TR 21.905 [1].

ECM	EPS Connection Management
E-RAB	E-UTRAN Radio Access Bearer

X2-C

X2 Control plane

---

## 4 General aspects

### 4.1 Introduction

The interface allowing to interconnect eNBs with each other is referred to as the X2 interface.

### 4.2 X2 interface general principles

The general principles for the specification of the X2 interface are as follows:

- the X2 interface should be open;
- the X2 interface shall support the exchange of signalling information between two eNBs, in addition the interface shall support the forwarding of PDUs to the respective tunnel endpoints;
- from a logical standpoint, the X2 is a point-to-point interface between two eNBs within the E-UTRAN. A point-to-point logical interface should be feasible even in the absence of a physical direct connection between the two eNBs.

### 4.3 X2 interface specification objectives

#### 4.3.1 General

The X2 interface specifications shall facilitate the following:

- inter-connection of eNBs supplied by different manufacturers;
- support of continuation between eNBs of the E-UTRAN services offered via the S1 interface;
- separation of X2 interface Radio Network functionality and Transport Network functionality to facilitate introduction of future technology.

#### 4.3.2 Addressing of eNBs over the X2 interface

-

### 4.4 X2 interface capabilities

#### 4.4.1 Radio application related signalling

The X2 interface provides capability to support radio interface mobility between eNBs, of UEs having a connection with E-UTRAN.

## 4.4.2 X2 tunnels

# 4.5 X2 interface characteristics

## 4.5.1 Uses of SCTP

### 4.5.1.1 General

The SCTP is used to support the exchange of X2 Application Protocol (X2AP) signalling messages between two eNBs

A single SCTP association per X2-C interface instance shall be used with one pair of stream identifiers for X2-C common procedures. Only a few pairs of stream identifiers should be used for X2-C dedicated procedures. The upper limit for the number of stream identifiers for dedicated procedures is FFS.

Source-eNB communication context identifiers that are assigned by the source-eNB for X2-C dedicated procedures, and target-eNB communication context identifiers that are assigned by the target-eNB for X2-C dedicated procedures, shall be used to distinguish UE specific X2-C signalling transport bearers. The communication context identifiers are conveyed in the respective X2AP messages.

---

# 5 Functions of the X2 interface

## 5.1 Function list

The list of functions on the X2 interface is the following:

- Intra LTE-Access-System Mobility Support for ECM-CONNECTED UE:
  - Context transfer from source eNB to target eNB;
  - Control of user plane transport bearers between source eNB and target eNB;
  - Handover cancellation;
  - UE context release in source eNB.
- Load Management
- Inter-cell Interference Coordination
  - Uplink Interference Load Management;
- General X2 management and error handling functions:
  - Error indication;
  - Reset.
- Application level data exchange between eNBs
- Trace functions

## 5.2 Function description

### 5.2.1 Intra LTE-Access-System mobility support for ECM-CONNECTED UE

This function allows the eNB to handover the control of a certain UE to another eNB.



### 5.2.1.1 Context transfer from source eNB to target eNB

This function allows transferring information required to maintain the E-UTRAN services for an UE in ECM-CONNECTED from source to target eNB.

### 5.2.1.2 Control of user plane transport bearers between source eNB and target eNB

This function allows establishing and releasing transport bearers between source and target eNB to allow for data forwarding. At most one user plane transport bearer per E-RAB allocated to the UE may be established for relaying DL data received from the EPC from the source eNB to the target eNB. At most one user plane transport bearer per E-RAB allocated to the UE may be established for relaying the UL data received from the UE from the source eNB to the target eNB.

### 5.2.1.3 Handover cancellation

This function allows informing an already prepared target eNB that a prepared handover will not take place. It allows releasing the resources allocated during a preparation.

### 5.2.1.4 UE context release in source eNB

This function allows the target eNB to trigger the release of the resources allocated to the UE in the source eNB.

## 5.2.2 Load management

This function allows exchanging overload and traffic load information between eNBs, such that the eNBs can control the traffic load appropriately. This information may be spontaneously sent to selected neighbour eNBs, or reported as configured by a neighbour eNB.

## 5.2.3 Inter-cell interference coordination

This function allows keeping inter-cell interference under control. For this neighbouring eNBs exchange appropriate information allowing that eNBs make radio resource assignments such that interference is mitigated.

### 5.2.3.1 Uplink interference load management

This function allows indicating an uplink interference overload and resource blocks especially sensitive to inter-cell interference between neighbouring eNBs, such that neighbour eNBs can co-ordinate with each other such that the mutual interference caused by their uplink radio resource allocations is mitigated.

### 5.2.3.2 Downlink interference avoidance

This function allows an eNB to inform its neighbour eNBs about downlink power restrictions in its own cells, per resource block for interference aware scheduling by the neighbour eNBs.

## 5.2.4 General X2 management and error handling functions

These functions allow for managing of signalling associations between eNBs, surveying X2 interface and recovering from errors.

### 5.2.4.1 Error indication

This function allows the reporting of general error situations on application level.

### 5.2.4.2 Reset

This function allows an eNB<sub>1</sub> to inform another eNB<sub>2</sub> that it has recovered from an abnormal failure and that all the contexts (except the application level data – see section 5.2.6) related to eNB<sub>1</sub> and stored in eNB<sub>2</sub> shall be deleted, and the associated resources released.

## 5.2.5 Trace functions

Trace recoding sessions on E-UTRAN interfaces for a particular UE is initiated by the EPC. The trace initiation information is also propagated to the Target eNB during handover, attached to certain handover messages on X2.


## 5.2.6 Application level data exchange between eNBs

This function allows two eNBs to exchange application level data when an X2 connection is setup, and to update this information at any time.

# 6 X2 interface protocols and protocol structure

## 6.1 General

There shall exist a clear separation between the Radio Network Layer and the Transport Layer. Therefore, the radio network signaling and X2 data streams are separated from the data transport resource and traffic handling as shown in Figure 6.1.1.



**Figure 6.1.1: Separation of Radio Network Protocols and transport over X2**

## 6.2 Radio signalling protocols

### 6.2.1 X2AP protocol

The protocol responsible for providing signalling information across the X2 interface is called the X2 Application Protocol (X2AP). The X2AP is terminated by the two eNBs inter-connected via the X2 interface X2AP Procedure Modules.

## 6.3 User plane protocol

### 6.3.1 Tunnelling protocol GTP-U

## 6.4 X2 interface protocol structure

The X2 interface protocol architecture consists of two functional layers:

- Radio Network Layer, defines the procedures related to the interaction between eNBs. The radio network layer consists of a Radio Network Control Plane and a Radio Network User Plane.
- The transport network layer provides services for user plane and signaling transport.




Figure 6.4.1: X2 Interface protocol structure

## 7 Other X2 interface specifications

### 7.1 E-UTRAN X2 interface: X2 layer 1 (TS 36.421)

3GPP TS 36.421 specifies the range of physical layer technologies that may be used to support the X2 interface.

### 7.2 E-UTRAN X2 interface: X2 signaling transport (TS 36.422)

3GPP TS 36.422 specifies how the X2AP signaling messages are transported over X2.

### 7.3 E-UTRAN X2 interface: X2 application protocol (X2AP) (TS 36.423)


3GPP TS 36.423 specifies the radio network layer signaling procedures of the control plane between eNBs in E-UTRAN.

### 7.4 E-UTRAN X2 interface: X2 data transport (TS 36.424)

3GPP TS 36.424 specifies the standards for user data transport protocols over the E-UTRAN X2 interface.

## 7.5 Summary of E-UTRAN X2 interface Technical Specifications

The relationship between the technical specifications that define the E-UTRAN X2 interface is shown in Figure 7.5.1.



**Figure 7.5.1: X2 Interface Technical Specifications**

---

## Annex A (informative): Change history

Change history						
Date	TSG #	TSG Doc.	CR	Rev	Subject/Comment	New
2007-11	38	RP-070853			specification presented to TSG-RAN for information and approval	1.0.0
2007-12	38				specification approved at TSG-RAN and placed under change control	8.0.0
2008-12	42	RP-080845	002	2	Correction of SAE Bearer and Update of the list of X2 functions	8.1.0
2009-12	-	-	-	-	Creation of Rel-9 version based on v.8.1.0	9.0.0

---

# History

<b>Document history</b>		
V9.0.0	February 2010	Publication