

ETSI TS 138 306 V15.3.0 (2018-10)



**5G;
NR;
User Equipment (UE) radio access capabilities
(3GPP TS 38.306 version 15.3.0 Release 15)**



Reference

RTS/TSGR-0238306vf30

Keywords

5G

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the only prevailing document is the print of the Portable Document Format (PDF) version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommiteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2018.

All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members.
3GPP™ and **LTE™** are trademarks of ETSI registered for the benefit of its Members and
of the 3GPP Organizational Partners.

oneM2M logo is protected for the benefit of its Members.

GSM® and the GSM logo are trademarks registered and owned by the GSM Association.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Foreword.....	2
Modal verbs terminology.....	2
Foreword.....	4
1 Scope	5
2 References	5
3 Definitions, symbols and abbreviations	6
3.1 Definitions	6
3.2 Symbols.....	6
3.3 Abbreviations	6
4 UE radio access capability parameters.....	6
4.1 Supported max data rate	6
4.1.1 General.....	6
4.1.2 Supported max data rate	6
4.1.3 Void	7
4.1.4 Total layer 2 buffer size	7
4.2 UE Capability Parameters	8
4.2.1 Introduction.....	8
4.2.2 General parameters	9
4.2.3 SDAP Parameters	10
4.2.4 PDCP Parameters.....	10
4.2.5 RLC parameters	10
4.2.6 MAC parameters.....	11
4.2.7 Physical layer parameters	12
4.2.7.1 <i>BandCombinationList</i> parameters	12
4.2.7.2 <i>BandNR</i> parameters	12
4.2.7.3 <i>CA-ParametersEUTRA</i>	16
4.2.7.4 <i>CA-ParametersNR</i>	16
4.2.7.5 <i>FeatureSetDownlink</i> parameters	17
4.2.7.6 <i>FeatureSetDownlinkPerCC</i> parameters	20
4.2.7.7 <i>FeatureSetUplink</i> parameters	21
4.2.7.8 <i>FeatureSetUplinkPerCC</i> parameters	23
4.2.7.9 <i>MRDC-Parameters</i>	23
4.2.7.10 <i>Phy-Parameters</i>	24
4.2.7.11 Other PHY parameters	29
4.2.8 Void	29
4.2.9 <i>MeasAndMobParameters</i>	30
4.2.10 Inter-RAT parameters	32
4.2.10.1 <i>eutraFDD</i>	32
4.2.10.2 <i>eutraTDD</i>	32
4.2.11 Void	32
4.2.12 Void	32
5 Optional features without UE radio access capability parameters	32
6 Conditionally mandatory features	32
7 Capability coordination in MR-DC operation.....	32
8 UE Capability Constraints.....	32
Annex A (informative): Change history	34
History	35

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

1 Scope

The present document defines the NR UE Radio Access Capability Parameters.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

- [1] 3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
- [2] 3GPP TS 38.101-1: "NR; User Equipment (UE) radio transmission and reception Part 1: Range 1 Standalone".
- [3] 3GPP TS 38.101-2: "NR; User Equipment (UE) radio transmission and reception Part 2: Range 2 Standalone".
- [4] 3GPP TS 38.101-3: "NR; User Equipment (UE) radio transmission and reception Part 3: Range 1 and Range 2 Interworking operation with other radios".
- [5] 3GPP TS 38.133: "NR; Requirements for support of radio resource management".
- [6] 3GPP TS 38.211: "NR; Physical channels and modulation".
- [7] 3GPP TS 37.340: "Evolved Universal Terrestrial Radio Access (E-UTRA) and NR Multi-connectivity".
- [8] 3GPP TS 38.321: "NR; Medium Access Control (MAC) protocol specification".
- [9] 3GPP TS 38.331: "NR; Radio Resource Control (RRC) protocol specification".
- [10] 3GPP TS 38.212: "NR; Multiplexing and channel coding".
- [11] 3GPP TS 38.213: "NR; Physical layer procedures for control".
- [12] 3GPP TS 38.214: "NR; Physical layer procedures for data".
- [13] 3GPP TS 38.215: "NR; Physical layer measurements".
- [14] 3GPP TS 36.101: "Evolved Universal Terrestrial Radio Access (E-UTRA) radio transmission and reception".
- [15] 3GPP TS 36.306: "Evolved Universal Terrestrial Radio Access (E-UTRA) User Equipment (UE) radio access capabilities".
- [16] 3GPP TS 38.323: "NR; Packet Data Convergence Protocol (PDCP) specification".
- [17] 3GPP TS 36.331: "Evolved Universal Terrestrial Radio Access (E-UTRA) Radio Resource Control (RRC); Protocol Specification".

3 Definitions, symbols and abbreviations

3.1 Definitions

For the purposes of the present document, the terms and definitions given in 3GPP TR 21.905 [1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in 3GPP TR 21.905 [1].

Fallback band combination: A band combination that would result from another band combination by releasing at least one SCell or uplink configuration of SCell.

3.2 Symbols

For the purposes of the present document, the following symbols apply:

MaxDLDataRate:	Maximum DL data rate
MaxDLDataRate_MN:	Maximum DL data rate in the MN
MaxDLDataRate_SN:	Maximum DL data rate in the SN
MaxULDataRate:	Maximum UL data rate

3.3 Abbreviations

For the purposes of the present document, the abbreviations given in 3GPP TR 21.905 [1] and the following apply. An abbreviation defined in the present document takes precedence over the definition of the same abbreviation, if any, in 3GPP TR 21.905 [1].

BC	Band Combination
DL	Downlink
FS	Feature Set
FSPC	Feature Set Per Component-carrier
MAC	Medium Access Control
MCG	Master Cell Group
MN	Master Node
MR-DC	Multi-RAT Dual Connectivity
PDCP	Packet Data Convergence Protocol
RLC	Radio Link Control
RTT	Round Trip Time
SCG	Secondary Cell Group
SDAP	Service Data Adaptation Protocol
SN	Secondary Node
UL	Uplink

4 UE radio access capability parameters

4.1 Supported max data rate

4.1.1 General

The DL and UL max data rate supported by the UE is calculated by band or band combinations supported by the UE. A UE supporting MR-DC shall support the calculated DL and UL max data rate defined in 4.1.2.

4.1.2 Supported max data rate

For NR, the approximate data rate for a given number of aggregated carriers in a band or band combination is computed as follows.

$$\text{data rate (in Mbps)} = 10^{-6} \cdot \sum_{j=1}^J \left(v_{\text{Layers}}^{(j)} \cdot Q_m^{(j)} \cdot f^{(j)} \cdot R_{\text{max}} \cdot \frac{N_{\text{PRB}}^{BW(j),\mu} \cdot 12}{T_s^\mu} \cdot (1 - OH^{(j)}) \right)$$

wherein

J is the number of aggregated component carriers in a band or band combination

$R_{\max} = 948/1024$

For the j -th CC,

$v_{\text{Layers}}^{(j)}$ is the maximum number of layers

$Q_m^{(j)}$ is the maximum modulation order

$f^{(j)}$ is the scaling factor

The scaling factor can take the values 1, 0.8, 0.75, and 0.4.

$f^{(j)}$ is signalled per band and per band per band combination

μ is the numerology (as defined in TS 38.211 [6])

T_s^μ is the average OFDM symbol duration in a subframe for numerology μ , i.e. $T_s^\mu = \frac{10^{-3}}{14 \cdot 2^\mu}$. Note that normal cyclic prefix is assumed.

$N_{\text{PRB}}^{BW^{(j),\mu}}$ is the maximum RB allocation in bandwidth $BW^{(j)}$ with numerology μ , as defined in 5.3 TS 38.101-1 [2] and 5.3 TS 38.101-2 [3], where $BW^{(j)}$ is the UE supported maximum bandwidth in the given band or band combination.

$OH^{(j)}$ is the overhead and takes the following values

0.14, for frequency range FR1 for DL

0.18, for frequency range FR2 for DL

0.08, for frequency range FR1 for UL

0.10, for frequency range FR2 for UL

NOTE: Only one of the UL or SUL carriers (the one with the higher data rate) is counted for a cell operating SUL.

The approximate maximum data rate can be computed as the maximum of the approximate data rates computed using the above formula for each of the supported band or band combinations.

For EUTRA in case of MR-DC, the approximate data rate for a given number of aggregated carriers in a band or band combination is computed as follows.

$$\text{Data rate (in Mbps)} = 10^{-3} \cdot \sum_{j=1}^J TBS_j$$

wherein

J is the number of aggregated EUTRA component carriers in MR-DC band combination

TBS_j is the total maximum number of DL-SCH transport block bits received within a 1ms TTI for j -th CC, as derived from TS36.213 [22] based on the UE supported maximum MIMO layers for the j -th carrier, and based on the modulation order and number of PRBs based on the bandwidth of the j -th carrier.

The approximate maximum data rate can be computed as the maximum of the approximate data rates computed using the above formula for each of the supported band or band combinations.

For MR-DC, the approximate maximum data rate is computed as the sum of the approximate maximum data rates from NR and EUTRA.

4.1.3 Void

4.1.4 Total layer 2 buffer size

The total layer 2 buffer size is defined as the sum of the number of bytes that the UE is capable of storing in the RLC transmission windows and RLC reception and reordering windows and also in PDCP reordering windows for all radio bearers.

The required total layer 2 buffer size in MR-DC and NR-DC is the maximum value of the calculated values based on the following equations:

- $MaxULDataRate_{MN} * RLCRTT_{MN} + MaxULDataRate_{SN} * RLCRTT_{SN} + MaxDLDataRate_{SN} * RLCRTT_{SN} + MaxDLDataRate_{MN} * (RLCRTT_{SN} + X2/Xn\ delay + Queuing\ in\ SN)$
- $MaxULDataRate_{MN} * RLCRTT_{MN} + MaxULDataRate_{SN} * RLCRTT_{SN} + MaxDLDataRate_{MN} * RLCRTT_{MN} + MaxDLDataRate_{SN} * (RLCRTT_{MN} + X2/Xn\ delay + Queuing\ in\ MN)$

Otherwise it is calculated by $MaxDLDataRate * RLC\ RTT + MaxULDataRate * RLC\ RTT$.

NOTE: Additional L2 buffer required for preprocessing of data is not taken into account in above formula.

The required total layer 2 buffer size is determined as the maximum total layer 2 buffer size of all the calculated ones for each band combination and the applicable Feature Set combination in the supported MR-DC or NR band combinations. The RLC RTT for NR cell group corresponds to the smallest SCS numerology supported in the band combination and the applicable Feature Set combination.

wherein

$X2/Xn\ delay + Queuing\ in\ SN = 25ms$ if SCG is NR, and $55ms$ if SCG is EUTRA

$X2/Xn\ delay + Queuing\ in\ MN = 25ms$ if MCG is NR, and $55ms$ if MCG is EUTRA

RLC RTT for EUTRA cell group = $75ms$

RLC RTT for NR cell group is defined in Table 4.1.4-1

Table 4.1.4-1: RLC RTT for NR cell group per SCS

SCS (KHz)	RLC RTT (ms)
15KHz	50
30KHz	40
60KHz	30
120KHz	20

4.2 UE Capability Parameters

4.2.1 Introduction

If the UE supports both FDD and TDD, set all fields in UE-MRDC-Capability and/or UE-NR-Capability, except fdd-UE-MRDC-Capability, tdd-UE-MRDC-Capability, fdd-UE-NR-Capability, and tdd-UE-NR-Capability, to include the values applicable for both FDD and TDD (i.e. functionality supported by both modes). If (some of) the UE capability fields have a different value for FDD and TDD, the UE includes supported FDD/TDD dedicated additional functionality by the field in fdd-UE-MRDC-Capability/tdd-UE-MRDC-Capability and/or fdd-UE-NR-Capability/tdd-UE-NR-Capability. If the UE supports either FDD or TDD only, set all fields in UE-MRDC-Capability and/or UE-NR-Capability, except fdd-UE-MRDC-Capability, tdd-UE-MRDC-Capability, fdd-UE-NR-Capability and tdd-UE-NR-Capability, to include the values applicable for the FDD/TDD supported by the UE.

4.2.2 General parameters

Definitions for parameters	Per	M	FDD-TDD diff
delayBudgetReporting Indicates whether the UE supports delay budget reporting as specified in TS 38.331 [9].	UE	No	No
inactiveState Indicates whether the UE supports RRC_inactive as specified in TS 38.331 [9].	UE	Yes	No
splitSRB-WithOneUL-Path Indicates whether the UE supports UL transmission via either MCG path or SCG path for the split SRB as specified in TS 37.340 [7].	UE	No	Yes
splitDRB-withUL-Both-MCG-SCG Indicates whether the UE supports UL transmission via both MCG path and SCG path for the split DRB as specified in TS 37.340 [7].	UE	Yes	Yes
srb3 Indicates whether the UE supports direct SRB between the SN and the UE as specified in TS 37.340 [7].	UE	Yes	Yes
v2x-EUTRA Indicates whether the UE supports EUTRA V2X according to <i>UE-EUTRA-Capability</i> as defined in [x], independent of the configured EN-DC band combination.	UE	No	No
voiceOverMCGBearer Indicates whether the UE supports IMS voice over NR PDCP for MCG bearer in NR. It is mandated to the IMS voice capable UE in NR otherwise optional.	UE	No	No

4.2.3 SDAP Parameters

4.2.4 PDCP Parameters

Definitions for parameters	Per	M	FDD-TDD diff
continueROHC-Context Defines whether the UE supports ROHC context continuation operation where the UE does not reset the current ROHC context upon handover.	UE	No	No
maxNumberROHC-ContextSessions Defines the maximum number of header compression context sessions supported by the UE, excluding context sessions that leave all headers uncompressed.	UE	No	No
outOfOrderDelivery Indicates whether UE supports Out of order delivery of data to upper layers by PDCP.	UE	No	No
pdcp-DuplicationMCG-OrSCG Indicates whether the UE supports PDCP duplication over MCG or SCG DRB as specified in TS 38.323 [16].	UE	No	No
pdcp-DuplicationSplitDRB Indicates whether the UE supports PDCP duplication over split DRB as specified in TS 38.323 [16].	UE	No	No
pdcp-DuplicationSplitSRB Indicates whether the UE supports PDCP duplication over split SRB1/2 as specified in TS 38.323 [16].	UE	No	No
pdcp-DuplicationSRB3 Indicates whether the UE supports PDCP duplication over SRB3 as specified in TS 38.323 [16].	UE	No	No
shortSN Indicates whether the UE supports 12 bit length of PDCP sequence number.	UE	Yes	No
supportedROHC-Profiles Defines which ROHC profiles from the list below are supported by the UE: <ul style="list-style-type: none"> - 0x0000 ROHC No compression (RFC 5795) - 0x0001 ROHC RTP/UDP/IP (RFC 3095, RFC 4815) - 0x0002 ROHC UDP/IP (RFC 3095, RFC 4815) - 0x0003 ROHC ESP/IP (RFC 3095, RFC 4815) - 0x0004 ROHC IP (RFC 3843, RFC 4815) - 0x0006 ROHC TCP/IP (RFC 6846) - 0x0101 ROHC RTP/UDP/IP (RFC 5225) - 0x0102 ROHC UDP/IP (RFC 5225) - 0x0103 ROHC ESP/IP (RFC 5225) - 0x0104 ROHC IP (RFC 5225) A UE that supports one or more of the listed ROHC profiles shall support ROHC profile 0x0000 ROHC uncompressed (RFC 5795).	UE	No	No
uplinkOnlyROHC-Profiles Indicates which ROHC profile(s) from the list below are supported in uplink-only ROHC operation by the UE. <ul style="list-style-type: none"> - 0x0006 ROHC TCP (RFC [6846]) A UE that supports uplink-only ROHC profile(s) shall support ROHC profile 0x0000 ROHC uncompressed (RFC 5795).	UE	No	No

4.2.5 RLC parameters

Definitions for parameters	Per	M	FDD-TDD diff
am-WithShortSN Indicates whether the UE supports AM DRB with 12 bit length of RLC sequence number.	UE	Yes	No
um-WithLongSN Indicates whether the UE supports UM DRB with 12 bit length of RLC sequence number.	UE	Yes	No
um-WithShortSN Indicates whether the UE supports UM DRB with 6 bit length of RLC sequence number.	UE	Yes	No

4.2.6 MAC parameters

Definitions for parameters	Per	M	FDD-TDD diff
<i>Ich-ToSCellRestriction</i> Indicates whether the UE supports restricting data transmission from a given LCH to a configured (sub-) set of serving cells (see allowedServingCells in LogicalChannelConfig). A UE supporting pdcp-Duplication (see PDCP-Config) shall also support Ich-ToSCellRestriction.	UE	Tbd	Tbd
<i>Icp-Restriction</i> Indicates whether UE supports the selection of logical channels for each UL grant based on RRC configured restriction.	UE	No	No
<i>logicalChannelSR-DelayTimer</i> Indicates whether the UE supports the logicalChannelSR-DelayTimer as specified in TS 38.321 [8]	UE	No	Yes
<i>longDRX-Cycle</i> Indicates whether UE supports long DRX cycle as specified in TS 38.321 [8].	UE	Yes	Yes
<i>multipleConfiguredGrant</i> Indicates whether UE supports [16] configured grant configurations per cell group.	UE	No	Yes
<i>multipleSR-Configurations</i> Indicates whether the UE supports [8] SR configurations per cell group.	UE	No	Yes
<i>pucch-SpatialRelInfoMAC-CE</i> Indicates whether the UE supports indication of PUCCH-spatialrelationinfo by a MAC CE per PUCCH resource.	UE	No	No
<i>recommendedBitRate</i> Indicates whether the UE supports the bit rate recommendation message from the gNB to the UE as specified in TS 38.321 [8].	UE	No	No
<i>recommendedBitRateQuery</i> Indicates whether the UE supports the bit rate recommendation query message from the UE to the gNB as specified in TS 38.321[8]. This field is only applicable if the UE supports recommendedBitRate.	UE	No	No
<i>shortDRX-Cycle</i> Indicates whether UE supports short DRX cycle as specified in TS 38.321 [8].	UE	Yes	Yes
<i>skipUplinkTxDynamic</i> Indicates whether the UE supports skipping of UL transmission for an uplink grant indicated on PDCCH if no data is available for transmission as specified in TS 38.321 [8].	UE	No	Yes

4.2.7 Physical layer parameters

4.2.7.1 *BandCombinationList* parameters

Definitions for parameters	Per	M	FDD TDD DIFF	FR1 FR2 DIFF
<i>bandEUTRA</i> Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101.	Band	Yes	No	No
<i>bandNR</i> Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	No	No
<i>ca-BandwidthClassDL-EUTRA</i> Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101.	Band	No	No	No
<i>ca-BandwidthClassDL-NR</i> Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	No	No	No
<i>ca-BandwidthClassUL-EUTRA</i> Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101.	Band	No	No	No
<i>ca-BandwidthClassUL-NR</i> Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	No	No	No
<i>ca-ParametersEUTRA</i> Contains the EUTRA part of band combination parameters for a given EN-DC band combination.	BC	No	No	No
<i>ca-ParametersNR</i> Contains the NR band combination parameters for a given EN-DC and/or NR CA band combination.	BC	No	No	No
<i>featureSetCombination</i> Indicates the feature set that the UE supports on the NR CA and/or MR-DC band combination by FeatureSetCombinationId. It is mandatory for the UE supporting NR CA and/or MR-DC.	BC	Yes /No	No	No
<i>mrdc-Parameters</i> Contains the band combination parameters for a given EN-DC band combination.	BC	No	No	No
<i>supportedBandwidthCombinationSet</i> Defines the supported bandwidth combination for the band combination set as defined in the 38.101-1 [2], 38.101-2 [3] and 38.101-3 [4]. Field encoded as a bit map, where bit N is set to "1" if UE support Bandwidth Combination Set N for this band combination as defined in the 38.101-1 [2], 38.101-2 [3] and 38.101-3 [4]. The leading / leftmost bit (bit 0) corresponds to the Bandwidth Combination Set 0, the next bit corresponds to the Bandwidth Combination Set 1 and so on.	BC	Tbd	No	No

4.2.7.2 *BandNR* parameters

Definitions for parameters	Per	M	FDD TDD DIFF	FR1 FR2 DIFF
additionalActiveTCI-StatePDCCH Indicates whether the UE supports one additional active TCI-State for control in addition to the supported number of active TCI-States for PDSCH. The UE can include this field only if <i>maxNumberConfiguredTCIstatesPerCC</i> in <i>tcI-StatePDSCH</i> is set to 1. Otherwise, the UE does not include this field.	Band	Yes	No	No
aperiodicBeamReport Indicates whether the UE supports aperiodic 'CRI/RSRP' or 'SSBRI/RSRP' reporting on PUSCH. For FR2, it is mandatory.	Band	Yes /No	No	No
aperiodicTRS Indicates whether the UE supports DCI triggering aperiodic TRS associated with periodic TRS.	Band	No	No	No
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	No	No
beamCorrespondence Indicates whether UE supports beam correspondence as defined in <TBD RAN4 >.	Band	Tbd	No	No
beamManagementSSB-CSI-RS Defines support of SS/PBCH and CSI-RS based RSRP measurements. The capability comprises signalling of <ul style="list-style-type: none"> - Maximum total number of one port NZP CSI-RS resources and SS/PBCH blocks that are supported by the UE for 'CRI/RSRP' and 'SSBRI/RSRP' reporting within a slot and across all serving cells. Support of n8 is mandatory for at least for >6Ghz bands. - Maximum total number of two ports NZP CSI-RS resources that are supported by the UE for 'CRI/RSRP' or 'SSBRI/RSRP' reporting within a slot and across all serving cells. - Supported density of one RE per PRB for one port NZP CSI-RS resource for RSRP reporting. At least density of CSI-RS =3 is mandatory at least for FR2. 	Band	No	No	No
beamReportTiming Indicates the number of OFDM symbols between the last symbol of SSB/CSI-RS and the first symbol of the transmission channel containing beam report. The UE includes this field for each supported sub-carrier spacing.	Band	Tbd	No	No
bwp-DiffNumerology Indicates whether the UE supports BWP adaptation up to 4 BWPs with the different numerologies. For the UE capable of this feature, the bandwidth of a UE-specific RRC configured BWP includes the bandwidth of the initial DL BWP and SSB for PCell and PSCell. For SCell(s), the bandwidth of the UE-specific RRC configured BWP includes SSB, if there is SSB on SCell(s).	Band	No	No	No
bwp-SameNumerology Defines type A/B BWP adaptation (up to 2/4 BWPs) with the same numerology. For the UE capable of this feature, the bandwidth of a UE-specific RRC configured BWP includes the bandwidth of the initial DL BWP and SSB for PCell and PSCell. For SCell(s), the bandwidth of the UE-specific RRC configured BWP includes SSB, if there is SSB on SCell(s).	Band	No	No	No
bwp-WithoutRestriction Indicates support of BWP operation without bandwidth restriction. The Bandwidth restriction in terms of BWP for PCell and PSCell means that the bandwidth of a UE-specific RRC configured BWP may not include the bandwidth of initial DL BWP and SSB. For SCell(s), it means that the bandwidth of BWP may not include SSB.	Band	No	No	No
channelBWs-DL Indicates for each subcarrier spacing whether the UE supports channel bandwidths lower than the maximum channel bandwidth as defined in TS 38.101-1 [2] and TS 38.101-2 [3]. If this parameter is not included, the UE supports all channel bandwidths. For FR1, the bits starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits starting from the leading / leftmost bit indicate 50, 100 and 200MHz.	Band	Yes	No	No

channelBWs-UL Indicates for each subcarrier spacing whether the UE supports channel bandwidths lower than the maximum channel bandwidth as defined in TS 38.101-1 [2] and TS 38.101-2 [3]. If this parameter is not included, the UE supports all channel bandwidths. For FR1, the bits starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits starting from the leading / leftmost bit indicate 50, 100 and 200MHz.	Band	Yes	No	No
crossCarrierSchedulingDL-SameSCS Indicates whether the UE supports cross carrier scheduling for the same numerology in DL carrier aggregation with carrier indicator field (CIF).	Band	No	Yes	No
crossCarrierSchedulingUL-SameSCS Indicates whether the UE supports cross carrier scheduling for the same numerology in UL carrier aggregation with carrier indicator field (CIF).	Band	No	Yes	No
csi-RS-ForTracking Indicates support of CSI-RS for tracking (i.e. TRS). This capability signalling comprises the following parameters: <ul style="list-style-type: none"> - <i>burstLength</i> indicates the TRS burst length; - <i>maxSimultaneousResourceSetsPerCC</i> indicates the maximum number of TRS resource sets per CC which the UE can track simultaneously; - <i>maxConfiguredResourceSetsPerCC</i> indicates the maximum number of TRS resource sets configured to UE per CC; - <i>maxConfiguredResourceSetsAllCC</i> indicates the maximum number of TRS resource sets configured to UE across CCs. 	Band	Tbd	No	No
extendedCP Indicates whether the UE supports 60 kHz subcarrier spacing with extended CP length for reception of PDCCH, and PDSCH, and transmission of PUCCH, PUSCH, and SRS.	Band	No	No	No
groupBeamReporting Indicates whether UE supports RSRP reporting for the group of two reference signals.	Band	No	No	No
maxNumberActiveTCI-PerBWP Defines maximum number of TCI states for PDSCH reception that can be activated for the UE using MAC Control Element from the set of RRC configured TCI states as defined in TS 38.214 [12] Section 5.1.5.	Band	Tbd	No	No
maxNumberConfiguredTCIstatesPerCC Defines maximum number of TCI states that can be configured for the UE using RRC signalling. This value shall not be lower than the maximum number of TCI states supported by the UE for MAC Control Element activation.	Band	Tbd	No	No
maxNumberCSI-RS-BFR Indicates maximal number of CSI-RS resources across all CCs for UE to monitor PDCCH quality	Band	Tbd	No	No
maxNumberCSI-RS-SSB-BFR Defines maximal number of different CSI-RS [and/or SSB] resources across all CCs for new beam identifications.	Band	Tbd	No	No
maxNumberNonGroupBeamReporting Defines support of non-group based RSRP reporting using N_max RSRP values reported.	Band	Tbd	No	No
maxNumberRxBeam Defines whether UE supports receive beamforming switching using NZP CSI-RS resource. UE shall indicate a single value for the preferred number of NZP CSI-RS resource repetitions per CSI-RS resource set.	Band	Tbd	No	No
maxNumberRxTxBeamSwitchDL Defines the number of Tx and Rx beam changes UE can perform within a slot across all configured serving cells. UE shall report one value per each subcarrier spacing supported by the UE.	Band	Tbd	No	No
maxNumberSimultaneousSRS-PerCC Defines the number of SRS resources that can be transmitted by the UE in one OFDM symbol per each CC.	Band	Tbd	No	No
maxNumberSSB-BFR Defines maximal number of different SSBs across all CCs for UE to monitor PDCCH quality	Band	Tbd	No	No

maxUplinkDutyCycle Indicates the maximum percentage of uplink symbols can be scheduled within a certain evaluation period so as to ensure compliance with applicable electromagnetic energy absorption requirements provided by regulatory bodies. This field is only applicable for FR1 power class 2 UE as specified in TS38.101. If the field is absent, 50% shall be applied. Value n60 corresponds to 60%, value n70 corresponds to 70% and so on.	Band	Tbd	No	No FR1
pdsch-256QAM-FR2 Indicates whether the UE supports 256QAM for PDSCH for FR2.	Band	No	No	No FR2
periodicBeamReport Indicates whether UE supports periodic 'CRI/RSRP' or 'SSBRI/RSRP' reporting using PUCCH formats 2, 3 and 4 in one slot. For FR2, it is mandatory.	Band	Yes /No	No	No
ptrs-DensityRecommendationSetDL For each supported sub-carrier spacing, indicates preferred threshold sets for determining DL PTRS density. For each supported sub-carrier spacing, this field comprises: <ul style="list-style-type: none"> - two values of <i>frequencyDensity</i>; - three values of <i>timeDensity</i>. 	Band	Yes for FR 2	No	No
ptrs-DensityRecommendationSetUL For each supported sub-carrier spacing, indicates preferred threshold sets for determining UL PTRS density. For each supported sub-carrier spacing, this field comprises: <ul style="list-style-type: none"> - two values of <i>frequencyDensity</i>; - three values of <i>timeDensity</i>; - five values of <i>sampleDensity</i>. 	Band	No	No	No
pusch-256QAM Indicates whether the UE supports 256QAM for PUSCH.	Band	No	No	No
pusch-TransCoherence Defines support of the uplink codebook subset by the UE for UL precoding for PUSCH transmission as described in Section 6.1.1.1 of TS 38.214 [12]. UE indicated support of partial coherent codebook subset shall also support non-coherent codebook subset. UE indicated support of full coherent codebook subset shall also support partial and non-coherent codebook subset.	Band	Tbd	No	No
rateMatchingLTE-CRS Indicates whether the UE supports receiving PDSCH with resource mapping that excludes the REs determined by the higher layer configuration LTE-carrier configuring common RS, as specified in TS 38.214 [12].	Band	Yes	No	No
sp-BeamReportPUCCH Indicates support of semi-persistent 'CRI/RSRP' or 'SSBRI/RSRP' reporting using PUCCH formats 2, 3 and 4 in one slot.	Band	No	No	No
sp-BeamReportPUSCH Indicates support of semi-persistent 'CRI/RSRP' or 'SSBRI/RSRP' reporting on PUSCH.	Band	No	No	No
srs-TxSwitch Defines whether UE supports SRS antenna port switching as defined in Section 6.2.1.2 of TS 38.214 [12].	Band or FS	Tbd	No	No

<p>supportedSRS-Resources Defines support of SRS resources. The capability signalling comprising indication of:</p> <ul style="list-style-type: none"> - Supported maximum number of aperiodic SRS resources that can be configured for the UE per each BWP - Supported maximum number of aperiodic SRS resources per slot in the BWP - Supported maximum number of periodic SRS resources per BWP - Supported maximum number of periodic SRS resources per slot in the BWP - Supported maximum number of semi-persistent SRS resources that can be configured for the UE per each BWP - Supported maximum number of semi-persistent SRS resources per slot in the BWP - Supported maximum number of SRS antenna port per each SRS resource 	Band or FS	Tbd	No	No
<p>tc-StatePDSCH Defines support of TCI-States for PDSCH. The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberConfiguredTCIstatesPerCC</i> indicates the maximum number of configured TCI-states per CC for PDSCH.; - <i>maxNumberActiveTCI-PerBWP</i> indicates the maximum number of activated TCI-states per BWP per CC, including control and data. 	Band	Tbd	No	No
<p>twoPortsPTRS-DL Defines whether UE supports PT-RS with 2 antenna ports for DL reception.</p>	Band	No	No	No
<p>twoPortsPTRS-UL Defines whether UE supports PT-RS with 2 antenna ports for UL transmission.</p>	Band	No	No	No
<p>ue-PowerClass If the UE supports the different power class than the default power class (see TS 36.101 [14]), the UE shall report the supported power class in this field.</p>	Band	Yes	No	No
<p>uplinkBeamManagement Defines support of beam management for UL. The capability include indication of the</p> <ul style="list-style-type: none"> - Maximum number of SRS resources per SRS resource set supported by the UE. - Maximum number of SRS resource sets supported by the UE. 	Band	Tbd	No	No

4.2.7.3 CA-ParametersEUTRA

Definitions for parameters	Per	M	FDD TDD DIFF	FR1 FR2 DIFF
<p>additionalRx-Tx-PerformanceReq <i>additionalRx-Tx-PerformanceReq</i> defined in 4.3.5.22, 36.306 [15].</p>	BC	Tbd	No	No
<p>multipleTimingAdvance <i>multipleTimingAdvance</i> defined in 4.3.5.3, 36.306 [15].</p>	BC	Tbd	No	No
<p>simultaneousRx-Tx <i>simultaneousRx-Tx</i> defined in 4.3.5.4, 36.306 [15].</p>	BC	Tbd	No	No
<p>supportedBandwidthCombinationSetEUTRA Indicates the set of supported bandwidth combinations for the LTE part for inter-band EN-DC. The first (left-most) bit in the bitmap corresponds to the BWCS#1 and so on. If the bit is set to 1, the UE supports the corresponding BWCS.</p>	BC	Tbd	No	No
<p>supportedNAICS-2CRS-AP <i>supportedNAICS-2CRS-AP</i> defined in 4.3.5.8, 36.306 [15].</p>	BC	Tbd	No	No
<p>ue-CA-PowerClass-N <i>ue-CA-PowerClass-N</i> defined in 4.3.5.1.3, 36.306 [15].</p>	BC	Tbd	No	No

4.2.7.4 CA-ParametersNR

Definitions for parameters	Per	M	FDD TDD DIFF	FR1 FR2 DIFF
diffNumerologyAcrossPUCCH-Group Indicates whether different numerology across PUCCH groups in CA is supported by the UE.	BC	No	No	No
diffNumerologyWithinPUCCH-Group Indicates whether UE supports different numerology across carriers within a PUCCH group and a same numerology between DL and UL per carrier for data/control channel at a given time.	BC	No	No	No
multipleTimingAdvances Indicates whether multiple timing advances are supported by the UE. For NR CA band combination, if the band combination comprised of more than one band entry (i.e., inter-band or intra-band non-contiguous band combination), the field indicates that different timing advances on different band entries are supported. For EN-DC band combination, this field is not presented and it is mandatory for the UE supporting EN-DC band combination. In this release, up to two timing advances are supported for EN-DC band combination or NR CA band combination. Note: For NR CA, it is mandatory with IOT bit for inter-band NR CA, otherwise optional. For EN-DC, it is mandatory without IOT bit.	BC	Yes /No	No	No
parallelTxSRS-PUCCH-PUSCH Indicates whether the UE supports parallel transmission of SRS, PUCCH and PUSCH across CCs in an inter-band CA band combination.	BC	No	No	No
parallelTxPRACH-SRS-PUCCH-PUSCH Indicates whether the UE supports parallel transmission of PRACH, SRS, PUCCH and PUSCH across CCs in an inter-band CA band combination.	BC	No	No	No
simultaneousRxTxInterBandCA Indicates whether the UE supports simultaneous transmission and reception in TDD-TDD and TDD-FDD inter-band NR CA. It is mandatory for certain TDD-FDD and TDD-TDD band combinations defined in TS 38.101-1 [2], 38.101-2 [3] and 38.101-3 [4].	BC	Yes /No	No	No
simultaneousRxTxSUL Indicates whether the UE supports simultaneous reception and transmission for a NR band combination including SUL. Mandatory/Optional support depends on band combination and captured in TS 38.101-1 [2].	BC	Yes /No	No	No
supportedNumberTAG Defines the number of timing advance groups are supported by the UE	BC	Tbd	No	No

4.2.7.5 FeatureSetDownlink parameters

Definitions for parameters	Per	M	FDD TDD DIFF	FR1 FR2 DIFF
crossCarrierSchedulingDL-OtherSCS Indicates whether the UE supports cross carrier scheduling for the different numerologies in DL carrier aggregation with carrier indicator field (CIF).	FS	No	Yes	No
csi-RS-IM-ReceptionForFeedback Indicates support of CSI-RS and CSI-IM reception for CSI feedback. This capability signalling comprises the following parameters: <ul style="list-style-type: none"> - <i>maxNumberNzp-Csi-Rs-PerCC</i> indicates the maximum number of configured NZP-CSI-RS resources per CC; - <i>maxNumberPortsAcrossNzp-Csi-Rs-PerCC</i> indicates the maximum number of ports across all configured NZP-CSI-RS resources per CC; - <i>maxNumberCS-IM-PerCC</i> indicates the maximum number of configured CSI-IM resources per CC; - <i>maxNumberSimultaneousCSI-RS-ActBWP-AllCC</i> indicates the maximum number of simultaneous CSI-RS resources in active BWPs across all CCs; - <i>totalNumberPortsSimultaneousCSI-RS-ActBWP-AllCC</i> indicates the total number of CSI-RS ports in simultaneous CSI-RS resources in active BWPs across all CCs. 	FS	Tbd	No	No
csi-RS-MeasSCellWithoutSSB Defines whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS38.215 [13], where CSI-RS resource is configured for a cell that does not transmit SS/PBCH block. A UE that supports this feature shall also support <i>scellWithoutSSB</i> .	FS	No	No	No
featureSetListPerDownlinkCC Indicates which features the UE supports on the individual DL carriers of the feature set (and hence of a band entry that refer to the feature set) by <i>FeatureSetDownlinkPerCC-Id</i> . The UE shall hence include as many <i>FeatureSetDownlinkPerCC-Id</i> in this list as the number of carriers it supports according to the <i>ca-bandwidthClassDL</i> . The order of the elements in this list is not relevant, i.e., the network may configure any of the carriers in accordance with any of the <i>FeatureSetDownlinkPerCC-Id</i> in this list.	FS	Tbd	No	No
intraBandFreqSeparationDL Indicates DL frequency separation class the UE supports, which indicates frequency separation between lower edge of lowest CC and upper edge of highest CC in a frequency band, for intra-band non-contiguous CA. It is mandatory to report for UE to support non-continuous CA in FR2.	FS	[Yes/No]	No	No
pdcchMonitoringAnyOccasions Defines the supported PDCCH search space monitoring occasions. <i>withoutDCI-gap</i> indicates whether the UE supports PDCCH search space monitoring occasions in any symbol of the slot for Type 1-PDCCH common search space configured by dedicated RRC signaling, for a Type 3-PDCCH common search space, or for a UE-specific search space with the capability of supporting at least 44, 36, 22, and 20 blind decodes in a slot for 15 kHz, 30 kHz, 60kHz, and 120 kHz subcarrier spacing values respectively. <i>withDCI-gap</i> indicates whether the UE supports PDCCH search space monitoring occasions in any symbol of the slot with minimum time separation between two consecutive transmissions of PDCCH scrambled with C-RNTI or CS-RNTI for Type 1-PDCCH common search space configured by dedicated RRC signaling, for a Type 3-PDCCH common search space, or for a UE-specific search space, with the capability of supporting at least 44, 36, 22, and 20 blind decodes in a slot for 15 kHz, 30 kHz, 60kHz, and 120 kHz subcarrier spacing values respectively.	FS	No	No	No
pdcchMonitoringAnyOccasionsWithSpanGap Indicates whether the UE supports PDCCH search space monitoring occasions in any symbol of the slot with minimum time separation between two consecutive transmissions of PDCCH scrambled with C-RNTI or CS-RNTI for Type 1-PDCCH common search space configured by dedicated RRC signaling, for a Type 3-PDCCH common search space, or for a UE-specific search space with span up to two OFDM symbols for two OFDM symbols or span up to three OFDM symbols for four and seven OFDM symbols.	FS	No	No	No
pdsch-DifferentTB-PerSlot Defines whether the UE supports reception of up to two, four or seven PDSCHs for different transport blocks with PDSCH scrambled using C-RNTI, TC-RNTI, or CS-RNTI within the same slot.	FS	No	No	No

<p>scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.</p>	FS	Tbd	No	No
<p>sCellWithoutSSB Defines whether the UE supports configuration of SCell that does not transmit SS/PBCH block. This is conditionally mandatory with capability signalling for intra-band CA but not supported for inter-band CA.</p>	FS	Yes/No	No	No
<p>searchSpaceSharingCA-DL Defines whether the UE supports DL PDCCH search space sharing for carrier aggregation operation.</p>	FS	No	No	No
<p>srs-AssocCSI-RS Indicates whether UE supports calculation of the precoder for SRS transmission based on channel measurements using associated NZP CSI-RS resource as described in Section 6.1.1.2 of TS 38.214 [12]. UE supporting this feature shall also indicate support of non-codebook based PUSCH transmission</p>	FS	No	No	No
<p>timeDurationForQCL Defines minimum number of OFDM symbols required by the UE to perform PDCCH reception and applying spatial QCL information received in DCI for PDSCH processing as described in TS 38.214 [12] Section 5.1.5, i.e. Threshold-Sched-Offset. UE shall indicate one value of the minimum number of OFDM symbols per each subcarrier spacing of 60kHz and 120kHz.</p>	FS	Tbd	No	No FR2
<p>type1-3-CSS Defines whether the UE is able to receive PDCCH in a Type1-PDCCH common search space configured by dedicated RRC signaling, or in a Type3-PDCCH common search space or in a UE-specific search space, with an associated CORESET duration of 3 symbols in FR2.</p>	FS	Yes	No	No
<p>type1-MultiPanelCodebookList List of type I multi-panel codebooks supported by the UE. Each entry includes the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberTxPortsPerResource</i> indicates the maximum number of Tx ports in a resource across all CCs simultaneously; - <i>maxNumberResources</i> indicates the maximum number of resources across all CCs simultaneously; - <i>totalNumberTxPorts</i> indicates the total number of Tx ports across all CCs simultaneously; - <i>supportedCodebookMode</i> indicates supported codebook modes (mode 1, mode2 or both of mode 1 and mode 2); - <i>supportedNumberPanels</i> indicates supported number of panels; - <i>maxNumberCSI-RS-PerResourceSet</i> indicates the maximum number of CSI-RS resource in a resource set. 	FS	No	No	No
<p>type1-SinglePanelCodebookList List of type I single panel codebooks supported by the UE. Each entry includes the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberTxPortsPerResource</i> indicates the maximum number of Tx ports in a resource across all CCs simultaneously; - <i>maxNumberResources</i> indicates the maximum number of resources across all CCs simultaneously; - <i>totalNumberTxPorts</i> indicates the total number of Tx ports across all CCs simultaneously; - <i>supportedCodebookMode</i> indicates supported codebook modes (mode 1 or both of mode 1 and mode 2); - <i>maxNumberCSI-RS-PerResourceSet</i> indicates the maximum number of CSI-RS resource in a resource set. 	FS	Tbd	No	No

<p>typell-CodebookList List of type II codebooks supported by the UE. Each entry includes the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberTxPortsPerResource</i> indicates the maximum number of Tx ports in a resource across all CCs simultaneously; - <i>maxNumberResources</i> indicates the maximum number of resources across all CCs simultaneously; - <i>totalNumberTxPorts</i> indicates the total number of Tx ports across all CCs simultaneously; - <i>parameterLx</i> indicates the parameter "Lx" in codebook generation where x is an index of Tx ports indicated by <i>maxNumberTxPortsPerResource</i>; - <i>amplitudeScalingType</i> indicates the amplitude scaling type supported by the UE (wideband or both of wideband and sub-band); - <i>amplitudeSubsetRestriction</i> indicates whether amplitude subset restriction is supported for the UE; - <i>maxNumberCSI-RS-PerResourceSet</i> indicates the maximum number of CSI-RS resource in a resource set. 	FS	Tbd	No	No
<p>typell-CodebookPortSelectionList List of type II codebooks with port selection supported by the UE. Each entry includes the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberTxPortsPerResource</i> indicates the maximum number of Tx ports in a resource across all CCs simultaneously; - <i>maxNumberResources</i> indicates the maximum number of resources across all CCs simultaneously; - <i>totalNumberTxPorts</i> indicates the total number of Tx ports across all CCs simultaneously; - <i>parameterLx</i> indicates the parameter "Lx" in codebook generation where x is an index of Tx ports indicated by <i>maxNumberTxPortsPerResource</i>; - <i>amplitudeScalingType</i> indicates the amplitude scaling type supported by the UE (wideband or both of wideband and sub-band); - <i>maxNumberCSI-RS-PerResourceSet</i> indicates the maximum number of CSI-RS resource in a resource set. 	FS	Tbd	No	No
<p>ue-SpecificUL-DL-Assignment Indicates whether the UE supports dynamic determination of UL and DL link direction and slot format based on Layer 1 scheduling DCI and higher layer configured parameter UL-DL-configuration-dedicated as specified in TS 38.213 [11].</p>	FS	No	No	No

4.2.7.6 *FeatureSetDownlinkPerCC* parameters

Definitions for parameters	Per	M	FDD TDD DIFF	FR1 FR2 DIFF
channelBW-90mhz Indicates whether the UE supports the channel bandwidth of 90 MHz.	FSPC	No	No	No
maxNumberMIMO-LayersPDSCH Defines the maximum number of spatial multiplexing layer(s) supported by the UE for DL reception. For single CC standalone NR, it is mandatory with capability signaling to support at least 4 MIMO layers in the bands where 4Rx is specified as mandatory for the given UE and at least 2 MIMO layers in FR2. Some relaxations to this requirement may be applicable in the future (including in Rel-15). Mandatory in all cases means mandatory with capability signaling.	FSPC	Tbd	No	No
supportedBandwidthDL Indicates maximum DL channel bandwidth supported for a given SCS that UE supports within a single CC, which is defined in Table 5.3.5-1 in TS38.101-1 [2] for FR1 and Table 5.3.5-1 in TS38.101-2 [3] for FR2. For FR1, all the bandwidths listed in TS38.101-1 v15.0.0 Table 5.3.5-1 for each band shall be mandatory with a single CC. For FR2, the set of mandatory CBW is 50, 100, 200 MHz. When this field is included in a band combination with a single band entry and a single CC entry (i.e. non-CA band combination), the UE shall indicate the maximum channel bandwidth for the band according to TS 38.101-1 [2] and TS 38.101-2 [3].	FSPC	Tbd	No	Tbd
supportedModulationOrderDL Defines the supported modulation scheme for DL by the UE.	FSPC	Tbd	No	Tbd
supportedSubCarrierSpacingDL Defines the supported sub-carrier spacing for DL by the UE indicating the UE supports simultaneous reception with same or different numerologies in CA. Note the UE shall support all mandated sub-carrier spacing for FR1/FR2. Same numerology for intra-band NR CA including both continuous and non-continuous is mandatory with capability in both FR1 and FR2. Two mixed numerologies between FR1 band(s) and FR2 band(s) in DL are mandatory with capability if UE supports inter-band NR CA including both FR1 band(s) and FR2 band(s). Optional for other cases.	FSPC	Yes /No	No	No

4.2.7.7 *FeatureSetUplink* parameters

Definitions for parameters	Per	M	FDD TDD DIFF	FR1 FR2 DIFF
scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.	FS	Tbd	No	No
crossCarrierSchedulingUL-OtherSCS Indicates whether the UE supports cross carrier scheduling for the different numerologies in UL carrier aggregation with carrier indicator field (CIF).	FS	No	Yes	No
csi-ReportFramework Indicates whether the UE supports CSI report framework. This capability signalling comprises the following parameters: <ul style="list-style-type: none"> - <i>maxNumberPeriodicCSI-ReportPerBWP</i> indicates the maximum number of periodic CSI report per BWP; - <i>maxNumberAperiodicCSI-ReportPerBWP</i> indicates the maximum number of aperiodic CSI report setting per BWP; - <i>maxNumberSemiPersistentCSI-ReportPerBWP</i> indicates the maximum number of semi-persistent CSI report setting per BWP; - <i>simultaneousCSI-ReportsAllCC</i> indicates the number of CSI report(s) which the UE can simultaneously process across all CCs. The CSI report comprises periodic, semi-persistent and aperiodic CSI and any latency classes and codebook types. 	FS	Tbd	No	No
dynamicSwitchSUL Indicates whether the UE supports supplemental uplink with dynamic switch (DCI based selection of PUSCH carrier)	FS	Tbd	No	No
featureSetListPerUplinkCC Indicates which features the UE supports on the individual UL carriers of the feature set (and hence of a band entry that refer to the feature set) by FeatureSetUplinkPerCC-Id. The UE shall hence include as many FeatureSetUplinkPerCC-Id in this list as the number of carriers it supports according to the ca-bandwidthClassUL. The order of the elements in this list is not relevant, i.e., the network may configure any of the carriers in accordance with any of the FeatureSetUplinkPerCC-Id in this list.	FS	Tbd	No	No
intraBandFreqSeparationUL Indicates UL frequency separation class the UE supports, which indicates frequency separation between lower edge of lowest CC and upper edge of highest CC in a frequency band, for intra-band non-contiguous CA. It is mandatory to report for UE to support non-continuous CA in FR2.	FS	[Ye s/N o]	No	No
pusch-DifferentTB-PerSlot Indicates whether the UE supports transmission of up to two, four or seven PUSCHs for different transport blocks within the same slot.	FS	No	No	No
searchSpaceSharingCA-UL Defines whether the UE supports UL PDCCH search space sharing for carrier aggregation operation.	FS	No	No	No
srs-TxSwitch Defines whether UE supports SRS antenna port switching as defined in Section 6.2.1.2 of TS 38.214 [12].	Band or FS	Tbd	No	No

<p>supportedSRS-Resources Defines support of SRS resources. The capability signalling comprising indication of:</p> <ul style="list-style-type: none"> - Supported maximum number of aperiodic SRS resources that can be configured for the UE per each BWP - Supported maximum number of aperiodic SRS resources per slot in the BWP - Supported maximum number of periodic SRS resources per BWP - Supported maximum number of periodic SRS resources per slot in the BWP - Supported maximum number of semi-persistent SRS resources that can be configured for the UE per each BWP - Supported maximum number of semi-persistent SRS resources per slot in the BWP - Supported maximum number of SRS antenna port per each SRS resource 	Band or FS	Tbd	No	No
<p>twoPUCCH-Group Indicates whether two PUCCH group in CA with a same numerology across CCs for data and control channel [at a given time] is supported by the UE.</p>	FS	No	No	No

4.2.7.8 FeatureSetUplinkPerCC parameters

Definitions for parameters	Per	M	FDD TDD DIFF	FR1 FR2 DIFF
<p>channelBW-90mhz Indicates whether the UE supports the channel bandwidth of 90 MHz.</p>	FSPC	No	No	No
<p>maxNumberMIMO-LayersCB-PUSCH Defines supported maximum number of MIMO layers at the UE for PUSCH transmission with codebook precoding. UE indicating support of this feature shall also indicate support of PUSCH codebook coherency subset.</p>	FSPC	Tbd	No	No
<p>maxNumberMIMO-LayersNonCB-PUSCH Defines supported maximum number of MIMO layers at the UE for PUSCH transmission using non-codebook precoding.</p>	FSPC	Tbd	No	No
<p>maxNumberSRS-ResourcePerSet Defines the maximum number of SRS resources per SRS resource set configured for codebook based transmission to the UE.</p>	FSPC	Tbd	No	No
<p>simultaneousTxSUL-NonSUL Indicates whether the UE supports simultaneous transmission of SRS on an SUL/non-SUL carrier and PUSCH/PUCCH/SRS/PRACH on the other UL carrier in the same cell.</p>	FSPC	No	No	No
<p>supportedBandwidthUL Indicates maximum UL channel bandwidth supported for a given SCS that UE supports within a single CC, which is defined in Table 5.3.5-1 in TS38.101-1 [2] for FR1 and Table 5.3.5-1 in TS38.101-2 [3] for FR2. For FR1, all the bandwidths listed in TS38.101-1 v15.0.0 Table 5.3.5-1 for each band shall be mandatory with a single CC. For FR2, the set of mandatory CBW is 50, 100, 200 MHz. When this field is included in a band combination with a single band entry and a single CC entry (i.e. non-CA band combination), the UE shall indicate the maximum channel bandwidth for the band according to TS 38.101-1 [2] and TS 38.101-2 [3].</p>	FSPC	Tbd	No	Tbd
<p>supportedModulationOrderUL Defines the supported modulation scheme for UL by the UE.</p>	FSPC	Tbd	No	Tbd
<p>supportedSubCarrierSpacingUL Defines the supported sub-carrier spacing for UL by the UE, indicating the UE supports simultaneous transmission with same or different numerologies in CA, or indicating the UE supports different numerologies on NR UL and SUL within one cell. Note the UE shall support all mandated sub-carrier spacing for FR1/FR2. Same numerology for intra-band NR CA including both continuous and non-continuous is mandatory with capability in both FR1 and FR2. Two mixed numerologies between FR1 band(s) and FR2 band(s) in UL are mandatory with capability if UE supports inter-band NR CA including both FR1 band(s) and FR2 band(s). Optional for other cases.</p>	FSPC	Yes/No	No	No

4.2.7.9 MRDC-Parameters

Definitions for parameters	Per	M	FDD TDD DIFF	FR1 FR2 DIFF
asyncIntraBandENDC Indicates whether the UE supports asynchronous FDD-FDD intra-band EUTRA-NR EN-DC with MRTD and MTTD as specified in [x]. If it is not supported for FDD-FDD intra-band EUTRA-NR EN-DC, the UE supports only synchronous FDD-FDD intra-band EUTRA-NR EN-DC.	BC	No	No	No FR1
dynamicPowerSharing Indicates whether the UE supports dynamic EN-DC power sharing or not. If the UE supports this capability it will dynamically share the power between NR and LTE if $P_{LTE} + P_{NR} > P_{cmax}$.	BC	Yes	No	Tbd
simultaneousRxTxInterBandENDC Indicates whether the UE supports simultaneous transmission and reception in TDD-TDD and TDD-FDD inter-band EN-DC. It is mandatory for certain TDD-FDD and TDD-TDD band combinations defined in TS 38.101-3 [4].	BC	Yes /No	No	No
singleUL-Transmission Indicates that the UE does not support simultaneous UL transmissions as defined in TS 38.101-3 [4]. The UE may only set this bit for certain band combinations defined in TS 38.101-3 [4]. If set for a particular band combination, the bit applies to all fallback band combinations of this band combination that are defined in TS 38.101-3 [4] as being allowed to set the bit and does not apply to any other fallback band combinations defined in TS 38.101-3 [4].	BC	Tbd	No	No
t dm- Pattern Indicates whether the UE supports the <i>t dm- Pattern</i> for <i>single UL-transmission</i> associated functionality. Support is conditionally mandatory for UEs that do not support dynamic power sharing and for UEs that indicate single UL for any BC, and optional otherwise.	BC	Yes /No	Yes	Tbd
ul-SharingEUTRA-NR Indicates whether the UE supports EN-DC with EUTRA-NR coexistence in UL sharing via TDM only, FDM only, or both TDM and FDM from UE perspective.	BC	No	No	No
ul-SwitchingTimeEUTRA-NR Indicates support of switching type between LTE UL and NR UL for EN-DC with LTE-NR coexistence in UL sharing from UE perspective. Type1 indicates UE supports switching within less than 0 us and type2 indicates UE supports switching within less than 20us. It is mandatory to report switching time type 1 or type 2 if UE supports LTE and NR UL Transmission in the shared carrier via TDM only or LTE and NR UL transmission in the shared carrier via FDM or TDM.	BC	[Ye s]	No	No

4.2.7.10 *Phy-Parameters*

Definitions for parameters	Per	M	FDD TDD DIFF	FR1 FR2 DIFF
absoluteTPC-Command Indicates whether the UE supports absolute TPC command mode.	UE	No	No	Yes
almostContiguousCP-OFDM-UL Indicates whether the UE supports almost contiguous UL CP-OFDM transmissions.	UE	Tbd	No	Yes
bwp-SwitchingDelay Defines whether the UE supports BWP switching delay within type1 or type2 specified in TS 38.xxx. It is mandatory to report type 1 or type 2.	UE	[Yes]	No	No
calibrationGapPA Indicates whether the UE needs PA calibration gap to meet the UE Tx requirements.	UE	Tbd	No	No FR2
cbg-FlushIndication-DL Indicates whether the UE supports CBG-based (re)transmission for DL using CBG flushing out information (CBGFI) as specified in TS 38.214 [12].	UE	No	No	No
cbg-TransIndication-DL Indicates whether the UE supports CBG-based (re)transmission for DL using CBG transmission information (CBGTI) as specified in TS 38.214 [12].	UE	No	No	No
cbg-TransIndication-UL Indicates whether the UE supports CBG-based (re)transmission for UL using CBG transmission information (CBGTI) as specified in TS 38.214 [12].	UE	No	No	No
configuredUL-GrantType1 Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.	UE	No	No	No
configuredUL-GrantType2 Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.	UE	No	No	No
csi-ReportWithoutCQI Indicates whether UE supports CSI reporting with report quantity set to 'CRI/RI/i1' as defined in Section 5.2.1.4 of TS 38.214 [12].	UE	No	No	Yes
csi-ReportWithoutPMI Indicates whether UE supports CSI reporting with report quantity set to 'CRI/RI/CQI' as defined in Section 5.2.1.4 of TS 38.214 [12].	UE	Tbd	No	Yes
csi-RS-CFRA-ForHO Indicates whether the UE can perform handover using a contention free random access on PRACH resources that are associated with CSI-RS resources of the target cell.	UE	No	No	No
downlinkSPS Indicates whether the UE supports PDSCH reception based on semi-persistent scheduling.	UE	No	No	No
dynamicBetaOffsetInd-HARQ-ACK-CSI Indicates whether the UE supports indicating beta-offset (UCI repetition factor onto PUSCH) for HARQ-ACK and/or SR via DCI among the RRC configured beta-offsets.	UE	No	No	No
dynamicHARQ-ACK-Codebook Indicates whether the UE supports HARQ-ACK codebook dynamically constructed by DCI(s).	UE	Yes	No	No
dynamicHARQ-ACK-CodeB-CBG-Retx-DL Indicates whether the UE supports HARQ-ACK codebook size for CBG-based (re)transmission based on the DAI-based solution as specified in TS 38.213 [11].	UE	No	No	No
dynamicPRB-BundlingDL Indicates whether UE supports DCI-based indication of the PRG size for PDSCH reception.	UE	No	No	No
dynamicSFI Indicates whether the UE supports monitoring for DCI format 2_0 and determination of slot formats via DCI format 2_0.	UE	No	Yes	Yes
dynamicSwitchRA-Type0-1-PDSCH Indicates whether the UE supports dynamic switching between resource allocation Types 0 and 1 for PDSCH as specified in TS 38.212 [10].	UE	No	No	No
dynamicSwitchRA-Type0-1-PUSCH Indicates whether the UE supports dynamic switching between resource allocation Types 0 and 1 for PUSCH as specified in TS 38.212 [10].	UE	Tbd	No	No
freqHoppingPUCCH-F0-2 Indicates whether the UE supports transmission of a PUCCH format 0 or 2 without frequency hopping.	UE	Yes	No	Yes
freqHoppingPUCCH-F1-3-4 Indicates whether the UE supports transmission of a PUCCH format 1, 3 or 4 without frequency hopping.	UE	Yes	No	Yes

interleavingVRB-ToPRB-PDSCH Indicates whether the UE supports receiving PDSCH with interleaved VRB-to-PRB mapping as specified in TS 38.211 [6].	UE	Tbd	No	No
interSlotFreqHopping-PUSCH Indicates whether the UE supports inter-slot frequency hopping for PUSCH transmissions.	UE	No	No	No
intraSlotFreqHopping-PUSCH Indicates whether the UE supports intra-slot frequency hopping for PUSCH transmission, except for PUSCH scheduled by PDCCH in the Type1-PDCCH common search space before RRC connection establishment.	UE	Yes	No	Yes
multipleCORESET Indicates whether the UE supports configuration of more than one PDCCH CORESET per BWP in addition to the CORESET with CORESET-ID 0 in the BWP. It is mandatory with capability signaling for FR2 and optional for FR1.	UE	Yes /No	No	No
mux-SR-HARQ-ACK-CSI-PUCCH Indicates whether the UE supports multiplexing SR, HARQ-ACK and CSI on a PUCCH or piggybacking on a PUSCH once per slot.	UE	[No]	No	Yes
nzp-CSI-RS-IntefMgmt Indicates whether the UE supports interference measurements using NZP CSI-RS.	UE	[No]	No	No
oneFL-DMRS-ThreeAdditionalDMRS Defines whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 1 symbol front-loaded DM-RS with three additional DM-RS symbols.	UE	No	No	Yes
oneFL-DMRS-TwoAdditionalDMRS Defines support of DM-RS pattern for DL reception and/or UL transmission with 1 symbol front-loaded DM-RS with 2 additional DM-RS symbols and more than 1 antenna ports.	UE	Yes	No	Yes
onePortsPTRS Defines whether UE supports PT-RS with 1 antenna port in DL reception and/or UL transmission. It is mandatory with UE capability signalling for FR2 and optional for FR1.	UE	Yes /No	No	Yes
onePUCCH-LongAndShortFormat Indicates whether the UE supports transmission of one long PUCCH format and one short PUCCH format in TDM in the same slot.	UE	No	No	Yes
pdccchMonitoringSingleOccasion Indicates whether the UE supports receiving PDCCH scrambled with C-RNTI or CS-RNTI in a search space configured to be monitored within a single span of any three contiguous OFDM symbols in a slot with the capability of supporting at least 44 blind decodes in a slot for 15 kHz subcarrier spacing.	UE	No	No	No FR1
pdccch-BlindDetectionCA Indicates PDCCH blind decoding capabilities supported by the UE for CA with more than 4 CCs as specified in TS 38.213 [11]. The field value is from 4 to 16.	UE	Tbd	No	Yes
pdsch-256QAM-FR1 Indicates whether the UE supports 256QAM for PDSCH for FR1.	UE	Yes	No	Yes
pdsch-MappingTypeA Indicates whether the UE supports receiving PDSCH using PDSCH mapping type A with less than seven symbols.	UE	Yes	No	No
pdsch-MappingTypeB Indicates whether the UE supports receiving PDSCH using PDSCH mapping type B.	UE	Yes	No	No
pdsch-RepetitionMultiSlots Indicates whether the UE supports receiving PDSCH scheduled by DCI format 1_0 or 1_1 when configured with higher layer parameter aggregationFactorDL > 1.	UE	No	No	Tbd
pdsch-RE-MappingFR1 Indicates the maximum number of PDSCH Resource Element (RE) mapping supported for FR1, respectively. Value n6 means 6 RE mapping patterns and n10 means 10 RE mapping patterns, and so on.	UE	Tbd	No	Yes
pdsch-RE-MappingFR2 Indicates the maximum number of PDSCH Resource Element (RE) mapping supported for FR2, respectively. Value n6 means 6 RE mapping patterns and n10 means 10 RE mapping patterns, and so on.	UE	Tbd	No	Yes
precoderGranularityCORESET Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6].	UE	No	No	No
pre-EmptIndication-DL Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11].	UE	No	No	No

pucch-F2-WithFH Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot.	UE	Yes	No	Yes
pucch-F3-WithFH Indicates whether the UE supports transmission of a PUCCH format 3 (4~14 OFDM symbols in total) with frequency hopping in a slot.	UE	Yes	No	Yes
pucch-F3-4-HalfPi-BPSK Indicates whether the UE supports pi/2-BPSK for PUCCH format 3/4. It is optional for FR1 and mandatory with capability signalling for FR2.	UE	Yes /No	No	Yes
pucch-F4-WithFH Indicates whether the UE supports transmission of a PUCCH format 4 (4~14 OFDM symbols in total) with frequency hopping in a slot.	UE	Yes	No	Yes
pusch-RepetitionMultiSlots Indicates whether the UE supports transmitting PUSCH scheduled by DCI format 0_0 or 0_1 when configured with higher layer parameter aggregationFactorUL > 1.	UE	Yes	No	No
pucch-Repetition-F1-3-4 Indicates whether the UE supports transmission of a PUCCH format 1 or 3 or 4 over multiple slots with the repetition factor 2, 4 or 8.	UE	Yes	No	No
pusch-HalfPi-BPSK Indicates whether the UE supports pi/2-BPSK for PUSCH. It is optional for FR1 and mandatory with capability signalling for FR2.	UE	Yes /No	No	Yes
pusch-LBRM Indicates whether the UE supports limited buffer rate matching in UL as specified in TS 38.212 [10].	UE	No	No	Yes
ra-Type0-PUSCH Indicates whether the UE supports resource allocation Type 0 for PUSCH as specified in TS 38.214 [12].	UE	No	No	No
rateMatchingResrcSetDynamic Indicates whether the UE supports receiving PDSCH with resource mapping that excludes the REs corresponding to resource sets configured with RB-symbol level granularity based on dynamic indication in the scheduling DCI as specified in TS 38.214 [12].	UE	No	No	No
rateMatchingResrcSetSemi-Static Indicates whether the UE supports receiving PDSCH with resource mapping that excludes the REs corresponding to resource sets configured with RB-symbol level granularity following the semi-static configuration as specified in TS 38.214 [12].	UE	Yes	No	No
scs-60kHz Indicates whether the UE supports 60kHz subcarrier spacing for data channel in FR1.	UE	No	No	No FR1
semiOpenLoopCSI Indicates whether UE supports CSI reporting with report quantity set to 'CRI/RI/i1' as defined in Section 5.2.1.4 of TS 38.214 [12].	UE	No	No	Yes
semiStaticHARQ-ACK-Codebook Indicates whether the UE supports HARQ-ACK codebook constructed by semi-static configuration	UE	Yes	No	No
spatialBundlingHARQ-ACK Indicates whether the UE supports spatial bundling of HARQ-ACK bits carried on PUCCH or PUSCH per PUCCH group. With spatial bundling, two HARQ-ACK bits for a DL MIMO data is bundled into a single bit by logical "AND" operation.	UE	Yes	No	No
Sp-CSI-IM Indicates whether the UE supports semi-persistent CSI-IM.	UE	No	No	Yes
sp-CSI-ReportPUCCH Indicates whether UE supports semi-persistent CSI reporting using PUCCH formats 2, 3 and 4.	UE	No	No	No
sp-CSI-ReportPUSCH Indicates whether UE supports semi-persistent CSI reporting using PUSCH.	UE	No	No	No
Sp-CSI-RS Indicates whether the UE supports semi-persistent CSI-RS.	UE	Yes	No	Yes
supportedDMRS-TypeDL Defines supported DM-RS configuration types at the UE for DL reception. Type 1 is mandatory with capability signaling. Type 2 is optional.	UE	Yes /No	No	Yes
supportedDMRS-TypeUL Defines supported DM-RS configuration types at the UE for UL transmission. At least support of type1 is mandatory. Support both type 1 and type 2 are mandatory with capability signalling.	UE	Yes	No	Yes
tdd-MultiDL-UL-SwitchPerSlot Indicates whether the UE supports more than one switch points in a slot for actual DL/UL transmission(s).	UE	No	TDD only	Yes

<i>tpc-PUCCH-RNTI</i> Indicates whether the UE supports group DCI message based on TPC-PUCCH-RNTI for TPC commands for PUCCH.	UE	No	No	Yes
<i>tpc-PUSCH-RNTI</i> Indicates whether the UE supports group DCI message based on TPC-PUSCH-RNTI for TPC commands for PUSCH.	UE	No	No	Yes
<i>tpc-SRS-RNTI</i> Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI for TPC commands for SRS.	UE	No	No	Yes
<i>twoDifferentTPC-Loop-PUCCH</i> Indicates whether the UE supports two different TPC loops for PUCCH closed loop power control.	UE	Yes	Yes	Yes
<i>twoDifferentTPC-Loop-PUSCH</i> Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control.	UE	Yes	Yes	Yes
<i>twoFL-DMRS</i> Defines whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols.	UE	Yes	No	Yes
<i>twoFL-DMRS-TwoAdditionalDMRS</i> Defines whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS.	UE	Yes	No	Yes
<i>twoPUCCH-AnyOthersInSlot</i> Indicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by 4-22 and 4-2.	UE	No	No	Yes
<i>twoPUCCH-F0-2-ConsecSymbols</i> Indicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in consecutive symbols in a slot.	UE	No	Yes	Yes
<i>type1-PUSCH-RepetitionMultiSlots</i> Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.	UE	No	No	No
<i>type2-PUSCH-RepetitionMultiSlots</i> Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.	UE	No	No	No
<i>type2-SP-CSI-Feedback-LongPUCCH</i> Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in Section 5.2.4 of TS 38.214 [12].	UE	No	No	No
<i>uci-CodeBlockSegmentation</i> Indicates whether the UE supports segmenting UCI into multiple code blocks depending on the payload size.	UE	Yes	No	Yes

4.2.7.11 Other PHY parameters

Definitions for parameters	Per	M	FDD TDD DIFF	FR1 FR2 DIFF
<i>appliedFreqBandListFilter</i> Mirrors the <i>FreqBandList</i> that the NW provided in the capability enquiry, if any. The UE filtered the band combinations in the <i>supportedBandCombinationList</i> in accordance with this <i>appliedFreqBandListFilter</i> .	UE	No	No	No
<i>downlinkSetEUTRA</i> Indicates the features that the UE supports on the DL carriers corresponding to one EUTRA band entry in a band combination by FeatureSetEUTRA-DownlinkId. The FeatureSetEUTRA-DownlinkId = 0 means that the UE does not support a EUTRA DL carrier in this band of a band combination.	Band	Tbd	No	No
<i>downlinkSetNR</i> Indicates the features that the UE supports on the DL carriers corresponding to one NR band entry in a band combination by FeatureSetDownlinkId. The FeatureSetDownlinkId = 0 means that the UE does not support a DL carrier in this band of a band combination.	Band	Tbd	No	No
<i>featureSetCombinations</i> Pools of feature sets that the UE supports on the NR CA or MR-DC band combinations.	UE	Tbd	No	No
<i>featureSets</i> Pools of downlink and uplink features sets as well as a pool of FeatureSetCombination elements. A FeatureSetCombination refers to the IDs of the feature set(s) that the UE supports in that FeatureSetCombination. The BandCombination entries in the BandCombinationList then indicate the ID of the FeatureSetCombination that the UE supports for that band combination.	UE	Tbd	No	No
<i>naics-Capability-List</i> Indicates that UE in MR-DC supports NAICS as defined in defined in TS 36.331 [10].	UE	No	No	No
<i>supportedBandCombinationList</i> Defines the supported CA and/or MR-DC band combinations by the UE. For each band combination the UE identifies the associated feature set combination by featureSetCombinations index referring to featureSetCombination.	UE	Yes	No	No
<i>supportedBandListNR</i> Includes the supported NR bands as defined in TS 38.101-1 [2] and TS 38.101-2 [3].	UE	Yes	No	No
<i>uplinkSetEUTRA</i> Indicates the features that the UE supports on the UL carriers corresponding to one EUTRA band entry in a band combination by FeatureSetEUTRA-UplinkId. The FeatureSetUplinkId = 0 means that the UE does not support a UL carrier in this band of a band combination.	Band	Tbd	No	No
<i>uplinkSetNR</i> Indicates the features that the UE supports on the UL carriers corresponding to one NR band entry in a band combination by FeatureSetUplinkId. The FeatureSetUplinkId = 0 means that the UE does not support a UL carrier in this band of a band combination.	Band	Tbd	No	No

4.2.8 Void

4.2.9 *MeasAndMobParameters*

Definitions for parameters	Per	M	FDD-TDD diff	FR1 FR2 diff
csi-RS-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of CSI-RS as specified in TS38.213 [11] and 38.133 [5]. This parameter needs FR1 and FR2 differentiation.	UE	Yes	No	Yes
csi-RSRP-AndRSRQ-MeasWithSSB Indicates whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS38.215 [13], where CSI-RS resource is configured with an associated SS/PBCH. This parameter needs FR1 and FR2 differentiation.	UE	No	No	Yes
csi-RSRP-AndRSRQ-MeasWithoutSSB Indicates whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS38.215 [13], where CSI-RS resource is configured for a cell that transmits SS/PBCH block and without an associated SS/PBCH block. This parameter needs FR1 and FR2 differentiation.	UE	No	No	Yes
csi-SINR-Meas Indicates whether the UE can perform CSI-SINR measurements based on configured CSI-RS resources as specified in TS38.215 [13]. This parameter needs FR1 and FR2 differentiation.	UE	No	No	Yes
eutra-CGI-Reporting Defines whether the UE supports acquisition of relevant information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9].	UE	Yes	No	No
eventA-MeasAndReport Indicates whether the UE supports NR measurements and events A triggered reporting as specified in TS 38.331 [9]	UE	Yes	Yes	No
eventB-MeasAndReport Indicates whether the UE supports EUTRA measurement and event B triggered reporting as specified in TS 38.331 [9]. It is mandated if the UE supports EUTRA.	UE	Yes	No	No
handover-eLTE Indicates whether the UE supports HO to EUTRA connected to 5GC. It is mandated if the UE supports EUTRA connected to 5GC.	UE	Yes	Yes	Yes
handoverFDD-TDD Indicates whether the UE supports HO between FDD and TDD. It is mandated if the UE supports both FDD and TDD.	UE	Yes	No	No
handoverInterF Indicates whether the UE supports inter-frequency HO.	UE	Yes	Yes	Yes
handoverLTE Indicates whether the UE supports HO to EUTRA connected to EPC. It is mandated if the UE supports EUTRA connected to EPC.	UE	Yes	Yes	Yes
independentGapConfig This field indicates whether the UE supports two independent measurement gap configurations for FR1 and FR2 specified in TS 38.133 [5].	UE	No	Yes	No
intraAndInterF-MeasAndReport Indicates whether the UE supports NR intra-frequency and inter-frequency measurements and at least periodical reporting.	UE	Yes	Yes	No
nr-CGI-Reporting Defines whether the UE supports acquisition of relevant information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9].	UE	Yes	No	No
simultaneousRxDataSSB-DiffNumerology Indicates whether the UE supports concurrent intra-frequency measurement on serving cell or neighbouring cell and PDCCH or PDSCH reception from the serving cell with a different numerology.	UE	No	Yes	Yes
sftd-MeasPSCell Indicates whether the UE supports SFTD measurements between the Pcell and a configured PSCell.	UE	No	Yes	No
sftd-MeasNR-Cell Indicates whether the SFTD measurement between the Pcell and the NR cells is supported by the UE which is capable of EN-DC when EN-DC is not configured.	UE	No	Yes	No
ssb-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of SS/PBCH block as specified in TS38.213 [11] and 38.133 [5].	UE	Yes	No	No

Definitions for parameters	Per	M	FDD-TDD diff	FR1 FR2 diff
ssb-AndCSI-RS-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of SS/PBCH block and CSI-RS as specified in TS38.213 [11] and 38.133 [5].	UE	Tbd	No	No
ss-SINR-Meas Indicates whether the UE can perform SS-SINR measurement as specified in TS38.215 [13]. This parameter needs FR1 and FR2 differentiation.	UE	No	No	Yes
supportedGapPattern Indicates measurement gap pattern(s) optionally supported by the UE. The leading / leftmost bit (bit 0) corresponds to the gap pattern 2, the next bit corresponds to the gap pattern 3, as specified in TS 38.311 [9] and so on.	UE	No	No	No

4.2.10 Inter-RAT parameters

4.2.10.1 *eutraFDD*

This parameter defines whether the UE supports EUTRA FDD.

4.2.10.2 *eutraTDD*

This parameter defines whether the UE supports EUTRA TDD.

4.2.11 Void

4.2.12 Void

5 Optional features without UE radio access capability parameters

6 Conditionally mandatory features

Features	Condition
Skipping UL configured grant if no data to transmit.	Configured grant type ½ is supported.
<i>multipleTimingAdvances</i>	EN-DC is supported.
<i>tdm-pattern</i>	<i>dynamicPowerSharing</i> is not supported or single UL for any band combination is indicated.

7 Capability coordination in MR-DC operation

In MR-DC operation, only two nodes (one EUTRA eNB and one NR gNB) need to be considered in the EUTRA/NR capability coordination. For capabilities for which coordination is needed, it is up to the MN to make the decision on how to resolve the dependency between MN and SN configurations. The MN provides the resulting UE capabilities usable for SCG configuration to the SN. The SN is allowed to initiate the re-negotiation of capability. For capabilities for which no coordination is needed, the SN specific capabilities are just forwarded by the MN to the SN. For feature set combination, MN determines its own feature set combination to be used in MN side based on *supportedBandCombination* in MRDC container then determines the allowed feature set combination list in SN side and indicates them to SN via *SCG-ConfigInfo*. SN may request to MN different feature set combination to be used in SN side via *SCG-Config*.

8 UE Capability Constraints

The following table lists constraints indicating the minimum UE capabilities that the UE shall support.

Parameter	Description	Value
#DRBs	The number of DRBs that a UE shall support.	16 without duplication 8 per MAC entity with duplication
#minCellperMeasObjectNR	The minimum number of neighbour cells (excluding black list cells) that a UE shall be able to store associated with a MeasObjectNR.	32
#minBlackCellRangeSperMeasObjectNR	The minimum number of blacklist cell PCI ranges that a UE shall be able to store associated with a MeasObjectNR	8
#minCellperMeasObjectEUTRA	The minimum number of neighbour cells that a UE shall be able to store associated with a MeasObjectEUTRA.	32
#minCellTotal	The minimum number of neighbour cells (excluding black list cells) that UE shall be able to store in total from all measurement objects configured.	256 with counting CSI-RS and SSB as 2
#cell for CGI reporting	the limit regarding the cells NR can configure includes the cell for which the UE is requested to report CGI	(# minCellperMeasObjectRAT - 1), where RAT represents NR and EUTRA.

Annex A (informative): Change history

Change history							
Date	Meeting	TDoc	CR	Rev	Cat	Subject/Comment	New version
06/2017	RAN2#98	R2-1704810				First version	0.0.1
06/2017	RAN2#NR2	R2-1707386					0.0.2
08/2017	RAN2#99	R2-1708750					0.0.3
12/2017	RAN2#100	R2-1712587					0.0.4
12/2017	RAN2#100	R2-1714141					0.0.5
12/2017	RAN2#100	R2-1714271					0.1.0
12/2017	RP-78	RP-172521				Submitted to RAN#78 for approval	1.0.0
12/2017	RP-78					Upgraded to Rel-15	15.0.0
03/2018	RP-79	RP-180440	0003	3	F	Updates on UE capabilities	15.1.0
06/2018	RP-80	RP-181216	0009	2	B	Introduce ANR in NR	15.2.0
	RP-80	RP-181216	0012	1	F	Miscellaneous corrections	15.2.0
	RP-80	RP-181216	0013	-	B	Delay budget report and MAC CE adaptation for NR for TS 38.306	15.2.0
09/2018	RP-81	RP-181940	0008	4	F	Correction on total layer2 buffer size	15.3.0
	RP-81	RP-181942	0024	1	F	Introduction of UE capability constraints	15.3.0
	RP-81	RP-181942	0030	-	F	38.306 corrections and cleanup	15.3.0

History

Document history		
V15.2.0	September 2018	Publication
V15.3.0	October 2018	Publication